

PZ120E Software Manual

E-816 Windows GCS DLL

Windows Library Reference

Release: 2.0.0 Date: 2009-03-25



This document describes software for use with the following product(s):

- E-816
Computer Interface and Command Interpreter Submodule (firmware version 3.20 and newer) for Piezo Controllers



© Physik Instrumente (PI) GmbH & Co. KG
Auf der Römerstr. 1 · 76228 Karlsruhe, Germany
Tel. +49-721-4846-0 · Fax: +49-721-4846-299
info@pi.ws · www.pi.ws

Physik Instrumente (PI) GmbH & Co. KG is the owner of the following company names and trademarks:
PI®, PIC®, PICMA®, PLine®, PIFOC®, PiezoWalk®, NEXACT®, NEXLINE®, NanoCube®, NanoAutomation®

The following designations are protected company names or registered trademarks of third parties:
Microsoft, Windows, LabView

The products described in this manual are in part protected by the following patents:
US-Patent No. 6,950,050

Copyright 1999–2009 by Physik Instrumente (PI) GmbH & Co. KG, Karlsruhe, Germany.
The text, photographs and drawings in this manual enjoy copyright protection. With regard thereto, Physik Instrumente (PI) GmbH & Co. KG reserves all rights. Use of said text, photographs and drawings is permitted only in part and only upon citation of the source.

First printing 2009-03-25
Document Number PZ120E Eco, BRo, Release 2.0.0
E-816_DLL_PZ120E.doc

Subject to change without notice. This manual is superseded by any new release. The newest release is available for download at www.pi.ws (<http://www.pi.ws>).

Disclaimer

This software is provided "as is". PI does not guarantee that this software is free of errors and will not be responsible for any damage arising from the use of this software. The user agrees to use this software on his own responsibility.

Table of Contents

| | | |
|-----------|---|-----------|
| 1. | Introduction..... | 5 |
| 1.1. | Threads..... | 5 |
| 1.2. | Master Unit..... | 5 |
| 2. | Quick Start | 6 |
| 2.1. | Software Installation..... | 6 |
| 2.2. | Connect the Controller | 7 |
| 2.3. | Install USB Driver..... | 7 |
| 2.4. | Starting Up | 7 |
| 2.5. | Samples | 9 |
| 3. | DLL Handling | 10 |
| 3.1. | Using a Static Import Library..... | 10 |
| 3.2. | Using a Module Definition File | 10 |
| 3.3. | Using Windows API Functions..... | 11 |
| 4. | Function Calls | 12 |
| 4.1. | Controller ID..... | 12 |
| 4.2. | Axes Parameter | 12 |
| 4.3. | Special Axis Identifier Δ | 13 |
| 5. | Types Used in PI Software | 14 |
| 5.1. | Boolean Values..... | 14 |
| 5.2. | NULL Pointers..... | 14 |
| 5.3. | C-Strings..... | 14 |
| 6. | Functions for Communication Initialization | 15 |
| 6.1. | Overview | 15 |
| 6.2. | Function Description | 16 |
| 6.3. | Interface Settings | 18 |
| 7. | Functions for Sending and Reading Strings | 19 |
| 7.1. | Overview | 19 |
| 7.2. | Function Description | 19 |
| 8. | Functions for E-816 Commands..... | 20 |
| 8.1. | Overview | 20 |
| 8.2. | Function Description | 23 |
| 9. | Error Codes..... | 39 |

10. Index 53

1. Introduction

The E-816 DLL allows controlling one or more PI E-816 Computer Interface and Command Interpreter Submodules connected to a host PC based on the PI General Command Set (GCS). GCS is the PI standard command set and ensures the compatibility between different PI controllers.

The library is available for the following operating systems:

- **Windows** 2000, XP and Vista: E-816 DLL
See Sections 3 to 5 for more information about PI DLLs.
- **Linux** operating systems (kernel 2.6, GTK 2.0, glibc 2.4): libpi_e816.so.x.x.x and libpi_e816-x.x.x.a where x.x.x gives the version of the library

NOTES

This manual was originally written for the Windows version of the E-816 library (DLL), and so the terminology used in this document is that common with Windows DLLs. Nevertheless this manual can also be used for the Linux versions of the E-816 library because there is no difference in the functionality of the library functions between the individual operating systems.

1.1. Threads

This DLL is not "thread-safe". The function calls of the DLL are not synchronized and can be safely used by only one thread at a time.

1.2. Master Unit

Several E-816s can be connected together in a network using the I²C bus lines provided. One device of the network is connected to the host PC with an RS-232 or USB cable. This E-816 is the master and all other E-816s in the network are slaves. With the commands of the E-816 DLL you can control all networked E-816s via the single master. The network behaves like a single multi-axis controller. The DLL does not care which E-816 in the network is the master.

To change the master, you must reconnect the RS-232 or USB cable and power-cycle the E-816s. With an RS-232 connection, the master can be changed while the library is active. With a USB connection, the connection must be closed before changing the master, and re-opened afterwards.

The term "E-816 network" as used in this manual should be understood to refer to a single (non-networked) E-816 as well. See the E-816 User Manual for more information on networking.

Although the E-816 itself will not accept more than one axis identifier per command, most of the DLL functions will; they split multi-axis commands into single-axis commands before sending them over the interface. This means that when you call **one** DLL function addressing three axes, three commands will be sent and cannot be exactly synchronized.

There are some commands which may only be addressed to the master. If you want to send them to a slave unit, e.g. to change its configuration, first make it the master. The master-only commands are:

E816_qERR() (p.28)
E816_qIDN() (p.29)
E816_qI2C() (p.29)
E816_qSSN() (p. 32)
E816_qCCL() (p. Fehler! Textmarke nicht definiert.)
E816_BDR() (p.23)
E816_qBDR() (p.27)
E816_AVG() (p.23)
E816_qAVG() (p.27)
E816_qSAI() (p. 31)
E816_SCH() (p.33)
E816_qSCH() (p.31)
E816_SPA() (p.34)*
E816_qSPA() (p.31)*
E816_WPA() (p.37)
E816_RST() (p.33)
E816_DEL() (p. 24)
E816_MAC_BEG() (p. 24)
E816_MAC_DEF() (p. 24)
E816_MAC_DEL() (p. 25)
E816_MAC_END() (p. 25)
E816_MAC_NSTART() (p. 25)
E816_MAC_qDEF() (p. 25)
E816_MAC_qFREE() (p. 26)
E816_MAC_START() (p. 26)
E816_qMAC() (p. 29)
E816_IsRunningMacro() (p. 24)
E816_qHLP() (p. 28)

*With firmware revisions 2.xx, E816_SPA() and E816_qSPA() are only available for the master unit. With firmware revision 3.20 and newer they can also be used with slave units.


Some of the commands require an axis identifier for compatibility reasons; you must use an axis identifier that will be recognized as the master. The master has whatever axis identifier has been assigned to it and, in addition, always executes commands addressed to the special axis identifier "A". If you do not know which axis identifier the master has been assigned, simply use "A" (or call **E816_qSCH()** (p.31)).

2. Quick Start

2.1. Software Installation

To install the E-816 DLL on your host PC, proceed as follows:

Windows operating systems:

1. Insert the product CD in your host PC.
2. If the Setup Wizard does not open automatically, start it from the root directory of the CD with the  icon.
3. Follow the on-screen instructions and select the "typical" installation. Typical components are LabView drivers, GCS DLL, PIMikroMove™, PITerminal.

Linux operating systems:

1. Insert the product CD in the host PC.
2. Open a terminal and go to the /linux directory on the CD.
3. Log in as superuser (root).
4. Start the install script with `./INSTALL`
Keep in mind the case sensitivity of Linux when typing the command.
5. Follow the on-screen instructions. You can choose the individual components to install.

If the installation fails, make sure you have installed the kernel header files for your kernel.

See Sections for more information about PI DLLs.

2.2. Connect the Controller

Physically connect the controller (respective the master unit of an I²C-network) to the PC. The RS-232 and USB interfaces can be active simultaneously.

With USB connections, communication can not be maintained after the E-816 is power-cycled or reset. The connection must then be closed and reopened.

2.3. Install USB Driver

The first time you connect over the USB interface, be sure you are logged on the PC as a user having administrator rights. After the E-816 is powered on, a message will appear saying that new hardware has been detected. Follow the on-screen instructions and insert the E-816 CD. The required hardware driver is found in the \USB_Driver directory.

2.4. Starting Up

NOTES

The following E-816 factory defaults are valid for the first start-up, unless agreed otherwise before delivery:

- Number of readings to use for an average: 32
Can be changed using `E816_AVG()`
- Channel name (= axis identifier): A
Can be changed using `E816_SCH()`
- Data rate: 115,200 baud
Can be changed in the range of 9,600 to 115,200 baud using `E816_BDR()`

Values set with `E816_AVG()`, `E816_SCH()` and `E816_BDR()` can be saved to non-volatile memory where they become the new power-on defaults. See the `E816_WPA()` description for details.

When controlling the E-816, timing problems can occur if several functions for GCS commands are run in rapid sequence, resulting in lost commands. To prevent such communication errors, it is recommended that you include a certain wait time between the different programming steps, depending on the command to be executed. This is

especially true for command functions that need a certain execution time inside the E-816 module, like E816_MOV(), E816_MVR(), E816_SPA(), E816_SVA(), E816_SVR(), E816_RST(), E816_WPA(), E816_SWT() and E816_WTO().

Using a start-up macro, you can set up the device to start with closed-loop operation. See the E-816 User Manual for details.

The term “E-816 network” as used in this manual should be understood to refer to a single (non-networked) E-816 as well.

Preparation:

1. Set up the units in which the E-816s are installed (e.g. E-621, E-625 or E-665 controllers) as described in the “Starting Operation” or “Quick Start” section of the corresponding User Manual.

In particular, be sure the units are configured to allow computer-controlled operation (see “Control Modes” in the E-816 User Manual and the User Manual of the piezo control electronics for details). In computer-controlled operation, axis motion can then be caused by move commands (e.g. E816_MOV() or E816_SVA()); received via interface or from a running macro), wave table output (E816_WTO()) and trigger input (E816_MVT()).

2. If you are planning to run networked E-816s, prepare the system for networking:

A unique axis identifier (also referred to as “channel name”) must be assigned to each of the units. E-816s delivered together installed in the same chassis (e.g. E-621 modules) come preconfigured with unique axis identifiers, but the identifiers of E-816s installed in stand-alone devices such as E-625s or E-665 by default are all set to “A” and need to be changed.

Follow the instructions in “Setting Channel Names” in the E-816 User Manual to change the channel name of an E-816, and see “Checking Connection and Master Unit” in the E-816 User Manual for how to check the settings.

If all axis identifiers were adapted, interconnect the units which are to be networked as described in “Interlinking Multiple E-816s” in the E-816 User Manual. After interconnecting all units, power-cycle them.

Write a program that performs the following steps:

1. Open a connection between the host PC and the E-816 network, e.g. by calling E816_ConnectRS232()
2. Call E816_qSAI() to determine which axes are present in the network
3. Call E816_qSCH() to determine the axis identifier of the master unit
4. Call E816_qSVO() to check the current servo mode of the axes (open-loop or closed-loop operation). If you want to change the servo mode, use E816_SVO().
5. Make a few test moves to verify your program's operation:
In open-loop operation, use E816_SVA() or E816_SVR().
In closed-loop operation, use E816_MOV() or E816_MVR().

2.5. Samples

There are various sample programs for different programming languages to be found in the \Sample directory of the E-816 CD. The sample code below shows how to connect to an E-816 over USB.

```
char axes[10];
int ID;

// connect to the E-816 over USB
char szDevices[1000];
int nrDevices = E816_EnumerateUSB(szDevices, 999, NULL);
if (nrDevices<=0)
{
    printf("No devices connected to USB");
    goto exit;
}
char* p = strtok(szDevices, "\n");
printf("Found %d devices, connecting to first: \"%s\"\n", nrDevices, szDevices);
ID = E816_ConnectUSB(szDevices);
if (ID<0)
    return FALSE;

if (!E816_qSAI(ID, axes, 9))
    return FALSE;

printf("qSAI() returned \"%s\"", axes);
```

3. DLL Handling

To get access to and use the DLL functions, the library must be included in your software project. There are a number of techniques supported by the Windows operating system and supplied by the different development systems. The following sections describe the methods which are most commonly used. For detailed information, consult the relevant documentation of the development environment being used. (It is possible to use the `E816_DLL.DLL` in Delphi projects. Please see <http://www.drbob42.com/delphi/headconv.htm> for a detailed description of the steps necessary.)

3.1. Using a Static Import Library

The `E816_DLL.DLL` module is accompanied by the `E816_DLL.LIB` file. This is the static import library which can be used by the Microsoft Visual C++ system for 32-bit applications. In addition, other systems, like the National Instruments LabWindows CVI or Watcom C++ can handle (i.e. understand) the binary format of a VC++ static library. When the static library is used, the programmer must:

Use a header or source file in which the DLL functions are declared, as needed for the compiler. The declaration should take into account that these functions come from a "C-Language" Interface. When building a C++ program, the functions have to be declared with the attribute specifying that they are coming from a C environment. The VC++ compiler needs an `extern "C"` modifier. The declarations must also specify that these functions are to be called like standard Win-API functions. That means the VC++ compiler needs a `WINAPI` or `__stdcall` modifier in the declaration.

Add the static import library to the program project. This is needed by the linker and tells it that the functions are located in a DLL and that they are to be linked dynamically during program startup.

3.2. Using a Module Definition File

The module definition file is a standard element/resource of a 16- or 32-bit Windows application. Most IDEs (integrated development environments) support the use of module definition files. Besides specification of the module type and other parameters like stack size, function imports from DLLs can be declared. In some cases the IDE supports static import libraries. If that is the case, the IDE might not support the ability to declare DLL-imported functions in the module definition file. When a module definition file is used, the programmer must:

Use a header or source file where the DLL functions must be declared, which is needed for the compiler. The declaration should take into account that these functions come from a "C-Language" Interface. When building a C++ program, the functions have to be declared with the attribute indicating that they are coming from a C environment. The VC++ compiler needs an `extern "C"` modifier. The declarations must also specify that these functions are to be called like standard Win-API functions. Therefore, the VC++ compiler needs a `WINAPI` or `__stdcall` modifier in the declaration.

Modify the module definition file with an `IMPORTS` section. In this section, all functions used in the program must be named. Follow the syntax of the `IMPORTS` statement. Example:

```
IMPORTS
E816_DLL.E816_IsConnected
```

3.3. Using Windows API Functions

If the library is not to be loaded during program startup, it can sometimes be loaded during program execution using Windows API functions. The entry point for each desired function has to be obtained. The DLL linking/loading with API functions during program execution is always possible, independent of the development system or files which have to be added to the project. When the DLL is loaded dynamically during program execution, the programmer has to:

Use a header or source file in which local or global pointers of a type appropriate for pointing to a function entry point are defined. This type could be defined in a `typedef` expression. In the following example, the type `FP_E816_IsConnected` is defined as a pointer to a function which has an `int` as argument and returns a `BOOL` value. Afterwards a variable of that type is defined.

```
typedef BOOL (WINAPI *FP_E816_IsConnected)( int );
FP_E816_IsConnected pE816_IsConnected;
```

Call the Win32-API `LoadLibrary()` function. The DLL must be loaded into the process address space of the application before access to the library functions is possible. This is why the `LoadLibrary()` function has to be called. The instance handle obtained has to be saved for use by the `GetProcAddress()` function. Example:

```
HINSTANCE hPI_Dll = LoadLibrary("E816_DLL.DLL\0");
```

Call the Win32-API `GetProcAddress()` function for each desired DLL function. To call a library function, the entry point in the loaded module must be known. This address can be assigned to the appropriate function pointer using the `GetProcAddress()` function. Afterwards the pointer can be used to call the function. Example:

```
pE816_IsConnected =
(FP_E816_IsConnected)GetProcAddress(hPI_Dll, "E816_IsConnected\0");
if (pE816_IsConnected == NULL)
{
    // do something, for example
    return FALSE;
}
BOOL bResult = (*pE816_IsConnected)(1); // call E816_IsConnected(1)
```

4. Function Calls

Almost all functions will return a boolean value of type `BOOL` (see "Types Used in PI Software," p.14. If the function succeeds the return value is `TRUE`, otherwise it is `FALSE`. To find out what went wrong, call **E816_GetError()** (p.17) and look up the value returned in "Error Codes," p.39.

4.1. Controller ID

The first argument to most function calls is the ID of the selected controller. To allow the handling of multiple controllers, the user will be returned a non-negative "ID" when he or she opens a connection to a controller (see "Functions for Communication Initialization" p.15) This is a kind of index to an internal array storing the information for the different controllers. All other calls addressing the same controller have this ID as first parameter.

4.2. Axes Parameter

The E-816 will only accept one axis per command sent over the interface. The DLL functions will accept more than one axis, splitting one function call into several single-axis commands. So although you call only one function, the resulting actions on the E-816s are not executed simultaneously.

The parameters for the axes are stored in an array passed to the function. The parameter for the first axis is stored in `array[0]`, for the second axis in `array[1]`, and so on. So if you call **E816_qPOS**(ID, "ABC", double `pos[3]`), the position for 'A' is in `pos[0]`, for 'B' in `pos[1]` and for 'C' in `pos[2]`. If you call **E816_MOV**(ID, "AC", double `pos[2]`) the target position for 'A' is in `pos[0]` and for 'C' in `pos[1]`.

| | |
|-----------------------------------|---|
| Axes: <code>szAxes = "ABC"</code> | Positions: <code>pos = {1.0, 2.0, 3.0}</code> |
| <code>szAxes[0] = 'A'</code> | <code>pos[0] = 1.0</code> |
| <code>szAxes[1] = 'B'</code> | <code>pos[1] = 2.0</code> |
| <code>szAxes[2] = 'C'</code> | <code>pos[2] = 3.0</code> |

If you call **E816_MOV**(ID, "AC", double `pos[2]`) the target position for 'A' is in `pos[0]` and for 'C' in `pos[1]`.

Each axis identifier is sent only once. Only the **last** occurrence of an axis identifier is actually sent to the controller with its argument. Thus if you call **E816_MOV**(ID, "AAB", `pos[3]`) with `pos[3] = { 1.0, 2.0, 3.0 }`, 'A' will move to 2.0 and 'B' to 3.0. If you then call **E816_qPOS**(ID, "AAB", `pos[3]`), `pos[0]` and `pos[1]` will both contain 2.0 as the position of 'A'.

(See **E816_MOV**() (p.26) and **E816_qPOS**() (p.30))

See "Types Used in PI Software," p.14 for a description of types used for parameters.

4.3. Special Axis Identifier A

The E-816 which is directly linked to the host PC with the serial or USB cable is the master. This master has an axis identifier just like all the other controllers. In addition, the master will execute all commands addressed to the special axis identifier "A". If you do not know the name that has been assigned to the master unit, you can always use "A" to address it. Assigning a unit the axis name "A" with **E816_SCH()** (p.33) erases any previous axis name assignment it might have and makes the unit unreachable as a slave.

5. Types Used in PI Software

5.1. Boolean Values

The library uses the convention used in Microsoft's C++ for boolean values. If your compiler does not support this directly, it can be easily set up: Just add the following lines to a central header file of your project:

```
typedef int BOOL;  
#define TRUE 1  
#define FALSE 0
```

5.2. NULL Pointers

In the library and the documentation, "null pointers" (pointers pointing nowhere) have the value **NULL**. This is defined in the Windows environment. If your compiler does not know this, simply use:

```
#define NULL 0
```

5.3. C-Strings

The library uses the C convention to handle strings. Strings are stored as `char` arrays with `'\0'` as terminating delimiter. Thus, the "type" of a c-string is `char*`. Do not forget to provide enough memory for the final `'\0'`. If you declare:

```
char* szText = "HELLO";
```

it will occupy 6 bytes in memory. To remind you of the zero at the end, the names of the corresponding variables start with "sz".

6. Functions for Communication Initialization

To use the DLL and communicate with a E-816 controller the user must initialize the DLL with one of the "open" functions

E816_InterfaceSetupDlg() (p.17), **E816_ConnectRS232()** (p.16) or **E816_ConnectUSB()**. Before connecting a device using the **E816_ConnectUSB()** function, its description string should be queried by **E816_EnumerateUSB()**.

Notes

The first time you connect over the USB interface, be sure you are logged on the PC as a user having administrator rights. After the E-816 is powered on, a message will appear saying that new hardware has been detected. Follow the on-screen instructions and insert the E-816 CD. The required hardware driver is found in the \USB_Driver directory.

With USB connections, communication can not be maintained after the E-816 is power-cycled or reset. The connection must then be closed and reopened.

When controlling the E-816, timing problems can occur if several functions for GCS commands are run in rapid sequence, resulting in lost commands. To prevent such communication errors, it is recommended that you include a certain wait time between the different programming steps, depending on the command to be executed. This is especially true for command functions that need a certain execution time inside the E-816 module, like **E816_MOV()**, **E816_MVR()**, **E816_SPA()**, **E816_SVA()**, **E816_SVR()**, **E816_RST()**, **E816_WPA()**, **E816_SWT()** and **E816_WTO()**.

To allow the handling of more than one master controller (i.e. multiple, separate networks), the user will be returned a non-negative "ID" when he calls one of the "open" functions. This is a kind of index to an internal array storing the information for the different controller networks. All other calls addressing the same controller network have this ID as first parameter.

E816_CloseConnection() (p.16) will close the connection to the specified controller network and free the respective system resources.

To change the master unit of a network, you must reconnect the RS-232 or USB cable and power-cycle the E-816s. With an RS-232 connection, the master can be changed while the library is active. With a USB connection, the connection must be closed before changing the master, and re-opened afterwards.

6.1. Overview

```
void E816_CloseConnection (int ID)
int E816_ConnectRS232 (const int nPortNr, const long BaudRate)
int E816_ConnectUSB (const char* szDescription)
int E816_EnumerateUSB (char* szBuffer, int iBufferSize, const char* szFilter)
int E816_FindOnRS (int *pnStartPort, int *pnStartBaud)
int E816_GetError (int ID)
int E816_InterfaceSetupDlg (const char* szRegKeyName)
BOOL E816_IsConnected (int ID)
BOOL E816_TranslateError (int errNr, char *szBuffer, const int maxlen)
```

6.2. Function Description

void **E816_CloseConnection** (int ID)

Close connection to E-816 controller network associated with *ID*. *ID* will not be valid any longer.

Parameters:

ID ID of controller network, if *ID* is not valid nothing will happen.

int **E816_ConnectRS232** (const int *nPortNr*, const long *BaudRate*)

Open an RS-232 ("COM") interface to an E-816. All future calls to control this E-816 network need the ID returned by this call.

Parameters:

nPortNr COM port to use (e.g. 1 for "COM1")

BaudRate to use

Returns:

ID of new object, -1 if interface could not be opened or no E-816 is responding.

int **E816_ConnectUSB** (const char* *szDescription*)

Open a USB connection to a controller using one of the identification strings listed by `E816_EnumerateUSB()`. All future calls to control this controller need the ID returned by this call. Will fail if there is already a connection.

Parameters:

szDescription the description of the controller returned by `E816_EnumerateUSB()`

Returns:

ID of new object, -1 if interface could not be opened or no controller is responding, or the controller responds that it is already connected via USB.

int **E816_EnumerateUSB** (char* *szBuffer*, int *iBufferSize*, const char* *szFilter*)

Lists the identification strings of all controllers available via USB interfaces. Using the mask, you can filter the results for certain text.

Parameters:

szBuffer buffer for the USB devices description.

iBufferSize size of the buffer

szFilter only controllers whose descriptions match the filter are returned in the buffer (e.g. a filter of "E-816" will only return the E-816 controllers, and not all PI controllers).

Returns:

>= 0: the number of controllers in the list
<0: Error code

int E816_FindOnRS (int * *pnStartPort*, int * *pnStartBaud*)

Scan available RS-232 ports (up to "COM24") and search for a connected E-816. The scan will open the ports at different baudrates and check whether an E-816 responds. The baudrates used are 110, 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 38400, 57600, 115200, 128000 and 256000 baud. The search will start with the value pointed to by *pnStartPort* and go up to port 24. With the value pointed to by *pnBaudRate* you can narrow the range of baudrates to be used. Only baudrates in the above list that are greater than the value specified will be used. If the scan was successful, the values pointed to by *pnStartPort* and *pnStartBaud* contain the values used to open the connection to the E-816. This connection is still active when the function returns, and the E-816 found can be addressed with the returned ID. All future calls to control this E-816 need the ID returned by this call.

Note:

This call may take some time to finish. It will take several 100 milliseconds for each configuration. So if your E-816 is connected on COM4 with 115200 baud and you start from COM1 and search with all baudrates it will take quite long.

Parameters:

pnStartPort pointer to `int` with the start value for the scan; upon return, if successful, the current port number setting

pnStartBaud pointer to `int` with the start value for the scan; upon return, if successful, the current baud rate setting in baud.

Returns:

ID of new object or -1 if no E-816 is responding.

int E816_GetError (int ID)

Get error status of E816 library and/or the master E-816. This call will also clear the internal error. If there is no internal error the function will call **E816_qERR()** (p.28).

Returns:

error ID, see Error Codes (p.39) for the meaning of the codes.

int E816_InterfaceSetupDlg (const char* *szRegKeyName*)

Open dialog to let user select the interface and create a new E816 object. All future calls to control this E-816 network need the ID returned by this call. See Interface Settings (p. 18) for a detailed description of the dialogs shown.

Parameters:

szRegKeyName key in the window registry to store the settings, the key used is "HKEY_LOCAL_MACHINE\SOFTWARE*<your keyname>*" if *keyname* is NULL or "" the default key "HKEY_LOCAL_MACHINE\SOFTWARE\PI\E816_DLL" is used.

Note:

Use '\\' if you want to create a key and a subkey at once. To create "MyCompany\E816_DLL" you must call

```
E816_InterfaceSetupDlg( "MyCompany\\E816_DLL" )
```

Returns:

ID of new object, -1 if user pressed "CANCEL", the interface could not be opened, or no E-816 is responding.

BOOL E816_IsConnected (int *ID*)

Check whether there is an E-816 controller network with an ID of *ID*.

Returns:

TRUE if *ID* points to an existing controller network, **FALSE** otherwise.

BOOL E816_TranslateError (int *errNr*, char * *szBuffer*, const int *maxlen*)

Translate error number to error message.

Parameters:

errNr number of error, as returned from E816_GetError() (p.17).

szBuffer pointer to buffer for the message

maxlen size of the buffer

Returns:

TRUE if successful, **FALSE**, if the buffer was too small to store the message

6.3. Interface Settings

With **E816_InterfaceSetupDlg** (), p. 17, the *Connect* dialog is called. This dialog offers interface tab cards where you can configure and establish the connection (see descriptions below). Note that not all of the interfaces shown via the tab cards may be present on your controller.

RS-232

- **COM Port:** Select the desired COM port of the PC, something like "COM1" or "COM2". Only the ports available on the system are displayed.
- **Baud Rate:** The baud rate of the interface. The baud rate chosen will be set on both the host PC and the controller side of the interface.

If you move the RS-232 cable to a new master in an E-816 network, make sure it has the proper baud rate.

USB

- All controllers available via USB are listed. Click on the controller to which you want to connect, and click the "Connect" button.

7. Functions for Sending and Reading Strings

CAUTION

Do not mix up the usage of `E816_GcsCommandset`, `E816_GcsGetAnswer` and `E816_GcsGetAnswerSize` with the usage of the PI library functions for GCS commands which are described in Section “Functions for E-816 Commands” on p. 20.

7.1. Overview

BOOL E816_GcsCommandset (int ID, const char* szCommand)
BOOL E816_GcsGetAnswer (int ID, char* szAnswer, int iBufferSize)
BOOL E816_GcsGetAnswerSize (int ID, int* piAnswerSize)

7.2. Function Description

BOOL E816_GcsCommandset (int ID, const char* szCommand)

Sends a GCS command to the controller. Any GCS command can be sent, but this command is intended to allow use of commands not having a function in the current version of the library.

See the User Manual of the controller for a description of the GCS commands which are understood by the controller firmware, for a command reference and for any limitations regarding the arguments of the commands.

Parameters:

ID ID of controller
szCommand the GCS command as string

Returns:

TRUE if no error, **FALSE** otherwise

BOOL E816_GcsGetAnswer (int ID, char* szAnswer, int iBufferSize)

Gets the answer to a GCS command, provided its length does not exceed *bufsize*. The answers to a GCS command are stored inside the DLL, where as much space as necessary is obtained. Each call to this function returns and deletes the oldest answer in the DLL.

See the User Manual of the controller for a description of the GCS commands which are understood by the controller firmware, for a command reference and for any limitations regarding the arguments of the commands.

Parameters:

ID ID of controller
szAnswer the buffer to receive the answer.
iBufferSize the size of *szAnswer*.

Returns:

TRUE if no error, **FALSE** otherwise

BOOL E816_GcsGetAnswerSize (int ID, int* piAnswerSize)

Gets the size of an answer of a GCS command.

Parameters:

ID ID of controller
piAnswerSize pointer to integer to receive the size of the oldest answer waiting in the DLL.

Returns:

TRUE if no error, **FALSE** otherwise

8. Functions for E-816 Commands

These functions encapsulate the embedded commands of the E-816 and provide some shortcuts to make working with the E-816 easier. See **Function Calls** (p.12) for some general notes about the parameter syntax. **Types Used in PI Software** (p.14) will give you some general information about the syntax of most commands.

NOTE

When controlling the E-816, timing problems can occur if several functions for GCS commands are run in rapid sequence, resulting in lost commands. To prevent such communication errors, it is recommended that you include a certain wait time between the different programming steps, depending on the command to be executed. This is especially true for command functions that need a certain execution time inside the E-816 module, like E816_MOV(), E816_MVR(), E816_SPA(), E816_SVA(), E816_SVR(), E816_RST(), E816_WPA(), E816_SWT() and E816_WTO().

8.1. Overview

| Function | Short Description | Page |
|--|---|------|
| BOOL E816_AVG (int ID, int nAverage) | Set number of samples to use for averages on master unit | 23 |
| BOOL E816_BDR (int ID, int nBaudRate) | Set master unit baudrate | 23 |
| BOOL E816_DCO (int ID, char *szAxes, BOOL *pbValarray) | Set D/A converter drift compensation on or off | 23 |
| BOOL E816_DEL (int ID, double <i>dmSeconds</i>) | Delay the controller for n milliseconds, recommended for usage in macro operation | 24 |
| BOOL E816_IsRunningMacro (int ID, BOOL *pbRunningMacro) | Test if a macro is running on master unit | 24 |
| BOOL E816_MAC_BEG (int ID, const char *szName) | Calls macro function on master unit: Start recording macro | 24 |
| BOOL E816_MAC_DEF (int ID, const char *szMacroName) | Calls macro function on master unit: Set the specified macros as start-up macro | 24 |
| BOOL E816_MAC_DEL (int ID, const char *szMacroName) | Calls macro function on master unit: Delete macro | 25 |
| BOOL E816_MAC_END (int ID) | Calls macro function on master unit: End macro recording | 25 |
| BOOL E816_MAC_NSTART (int ID, const char *szName, int nrRuns) | Calls macro function on master unit: Execute macro n times, n should be in the range from 1 to 65535 | 25 |
| BOOL E816_MAC_qDEF (int ID, char *szBuffer, int iBufferSize) | Calls macro function on master unit: Ask name of start-up macro | 25 |
| BOOL E816_MAC_qFREE (int ID, int* pNumberChars) | Calls macro function on master unit: Get free memory to store additional macros | 26 |
| BOOL E816_MAC_START (int ID, const char *szName) | Calls macro function on master unit: Start macro (single run) | 26 |

| Function | Short Description | Page |
|---|--|------|
| BOOL E816_MOV (int ID, const char* szAxes, const double *pdValarray) | Move the given axis to absolute position | 26 |
| BOOL E816_MVR (int ID, const char* szAxes, const double *pdValarray) | Move the given axis relative to current position | 26 |
| BOOL E816_MVT (int ID, const char *szAxes, const BOOL *pbValarray) | Set "move triggered" mode on/off for the given axis | 27 |
| BOOL E816_qAVG (int ID, int *pnAverage) | Get number of samples being used for averages on master unit | 27 |
| BOOL E816_qBDR (int ID, int *pnBaudRate) | Get master unit baudrate | 27 |
| BOOL E816_qDCO (int ID, char *szAxes, BOOL *pbValarray) | Get D/A converter drift compensation setting | 28 |
| BOOL E816_qDIP (int ID, const char *szAxes, BOOL *pbValarray) | Ask if a digital pulse was detected since the last call of DIP? for the given axis | 28 |
| BOOL E816_qERR (int ID, int *pnError) | Get master unit error code | 28 |
| BOOL E816_qHLP (int ID, char* szBuffer, int iBufferSize) | Get online help list; currently no information is available | 28 |
| BOOL E816_qI2C (int ID, int *pnErrorCode, char *pcChannel) | Get status of I ² C bus | 29 |
| BOOL E816_qIDN (int ID, char *buffer, int maxlen) | Get master unit version information | 29 |
| BOOL E816_qMAC (int ID, char * szName, char * szBuffer, const int maxlen) | List the content of one macro or the names of all macros on the master E-816 | 29 |
| BOOL E816_qMOV (int ID, const char* szAxes, double *pdValarray) | Read the last commanded position of the given axis | 30 |
| BOOL E816_qMVT (int ID, const char *szAxes, BOOL *pbValarray) | Get current "move triggered" mode of the given axis | 30 |
| BOOL E816_qONT (int ID, const char* szAxes, BOOL *pbOnTarget) | Get on-target status of the given axis | 30 |
| BOOL E816_qOVF (int ID, const char* szAxes, BOOL *pbOverflow) | Get overflow status of the given axis | 30 |
| BOOL E816_qPOS (int ID, const char* szAxes, double *pdValarray) | Read the actual position of the given axis | 30 |
| BOOL E816_qSAI (int ID, char *axes, const int maxlen) | Get names assigned to all connected (networked) axes | 31 |
| BOOL E816_qSCH (int ID, char *pcChannelName) | Get channel name (= axis identifier) of master unit | 31 |
| BOOL E816_qSPA (int ID, const char* szAxes, int *iCmdarray, double *dValarray) | Get specified parameter of the specified axis | 31 |
| BOOL E816_qSSN (int ID, char *szAxes, int *piValarray) | Get master unit serial number | 32 |

| Function | Short Description | Page |
|--|---|------|
| BOOL E816_qSWT (int ID, char cAxis, int nIndex, double *pdValue) | Get wave table data | 32 |
| BOOL E816_qSVA (int ID, const char* szAxes, double *pdValarray) | Read the last commanded piezo voltage of the given axis | 32 |
| BOOL E816_qSVO (int ID, char *szAxes, BOOL *pbValarray) | Get servo-ON/OFF status of the given axis | 33 |
| BOOL E816_qVOL (int ID, const char* szAxes, double *pdValarray) | Read the actual piezo voltage of the given axis | 33 |
| BOOL E816_RST (int ID) | Reset the master unit | 33 |
| BOOL E816_SCH (int ID, const char cChannelName) | Set channel name (= axis identifier) of master unit | 33 |
| BOOL E816_SPA (int ID, const char* szAxes, int *iCmdarray, double *dValarray) | Set specified parameter of the specified axis | 34 |
| BOOL E816_SVA (int ID, const char* szAxes, double *pdValarray) | Set the given axis to absolute piezo voltage | 35 |
| BOOL E816_SVO (int ID, char *szAxes, BOOL *pbValarray) | Set servo-ON/OFF status of the given axis | 35 |
| BOOL E816_SVR (int ID, const char* szAxes, double *pdValarray) | Change the given axis piezo voltage relative to current value | 36 |
| BOOL E816_SWT (int ID, const char cAxis, const int nIndex, const double dValue) | Set wave table data | 36 |
| BOOL E816_WPA (int ID, const char* szPassword) | Write all master unit parameters to master unit flash ROM | 37 |
| BOOL E816_WTO (int ID, const char cAxis, const int nNumber) | Set wave table output | 37 |
| BOOL E816_WTOtimer (int ID, const char cAxis, const int nNumber, int timer) | Set wave table output | 38 |

8.2. Function Description

BOOL **E816_AVG** (int ID, int *nAverage*)

Corresponding command: `AVG`

Sets the number of samples to be used when calculating averages on the master unit. Larger values mean more stable output, but slower measurement speed. Must be one of following values: 1, 2, 4, 8, 16, 32 or 64.

This command only changes the setting in RAM; the new setting will be lost when the unit is powered down or reset (`E816_RST()`) unless the RAM settings are written to EEPROM with `E816_WPA()`.

Parameters:

ID ID of controller network

nAverage number of samples used for average

Returns:

TRUE if successful, FALSE otherwise

BOOL **E816_BDR** (int ID, int *nBaudRate*)

Corresponding command: `BDR`

Set the RS-232 communications baud rate. of the master. The baud rate can be set to 9600, 19200, 38400, 57600 or 115200 baud. This will only change the setting in the RAM. To store it in the EEPROM call `E816_WPA()` (p.37) afterwards. After the next start of the controller the new setting will be used. If you want to change it immediately, call `E816_RST()` (p.33) after `E816_WPA()` (p.37).

Parameters:

ID ID of controller network

nBaudRate number of samples used for BaudRate

Returns:

TRUE if successful, FALSE otherwise

BOOL **E816_DCO** (int ID, const char * *szAxes*, const BOOL * *pbValarray*)

Corresponding command: `DCO`

Set D/A converter drift compensation "on" or "off". If *pbValarray[index]* is **FALSE** the mode is "off", if **TRUE** it is set to "on". The ON setting eliminates drift of the D/A converter in the E-816 used to provide the target signal to the separate E-802 servo-control submodule. This setting is recommended for static operation, but should be turned OFF for dynamic operation. The drift compensation setting is ignored during wave table output. See "Drift Compensation" and the DCO command in the E-816 User Manual for more details.

This command only changes the setting in RAM; the new setting will be lost when the unit is powered down or reset (`E816_RST()`) unless the RAM settings are written to EEPROM with `E816_WPA()`.

Parameters:

ID ID of controller network

szAxes string with axes

pbValarray modes for the specified axes, **TRUE** for "on", **FALSE** for "off"

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_DEL (int *ID*, double *dmSeconds*)

Corresponding command: DEL

Delays the master unit for *dmSeconds* milliseconds, recommended for usage in macro operation (see E816_MAC functions).

Available with firmware revision 3.20 and newer.

Parameters:

ID ID of controller network

dmSeconds delay value in milliseconds

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_IsRunningMacro (int *ID*, BOOL * *pbRunningMacro*)

Corresponding command: #8 (ASCII 8)

Check if a macro is currently running on the master unit.

Available with firmware revision 3.20 and newer.

Parameters:

ID ID of controller network

pbRunningMacro pointer to boolean to receive answer: TRUE if a macro is running, FALSE otherwise

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MAC_BEG (int *ID*, const char * *szName*)

Corresponding command: MAC BEG

Put the DLL in macro recording mode (macro is recorded on the master unit). This function sets a flag in the library and effects the operation of other functions. Function will fail if already in recording mode. If successful, the commands that follow become part of the macro, so do not check error state unless FALSE is returned. End the recording with E816_MAC_END().

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szName name under which macro will be stored in the controller

Returns:

TRUE if successful, FALSE otherwise

Errors:

PI_IN_MACRO_MODE if a macro is already being recorded

BOOL E816_MAC_DEF (int *ID*, const char * *szMacroName*)

Corresponding command: MAC DEF

Set macro with name *szName* as start-up macro on the master unit. This macro will be automatically executed with the next power-on or reboot of the controller. If *szName* is omitted, the current start-up macro selection is canceled. To find out what macros are available call E816_qMAC().

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szMacroName name of the macro to be the start-up macro

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MAC_DEL (int *ID*, const char * *szMacroName*)

Corresponding command: MAC DEL

Delete macro with name *szName* on the master unit. To find out what macros are available on the master unit call E816_qMAC().

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szMacroName name of the macro to delete

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MAC_END (int *ID*)

Corresponding command: MAC END

Take the DLL out of macro recording mode (macros was recorded on the master unit). This function resets a flag in the library and effects the operation of certain other functions. Function will fail if the DLL is not in recording mode.

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

Returns:

TRUE if successful, FALSE otherwise

Errors:

PI_NOT_IN_MACRO_MODE the controller was not recording a macro

BOOL E816_MAC_NSTART (int *ID*, const char * *szName*, int *nrRuns*)

Corresponding command: MAC START

Start macro with name *szName* on the master unit. The macro is repeated *nrRuns* times. To find out what macros are available on the master unit call E816_qMAC().

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szName string with name of the macro to start

nrRuns nr of runs

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MAC_qDEF (int *ID*, char * *szBuffer*, const int *iBufferSize*)

Corresponding command: MAC DEF?

Ask for the start-up macro on the master unit.

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szBuffer buffer to receive the string read in from controller, contains the name of the start-up macro. If no start-up macro is defined, the response is an empty string with the terminating character.

iBufferSize size of *buffer*, must be given to avoid buffer overflow.

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MAC_qFREE (int *ID*, int* *pNrChars*)

Corresponding command: MAC FREE?

Ask for free space on the master unit.

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

pNrChars pointer to int for storing the number of free characters

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MAC_START (int *ID*, const char * *szMacroName*)

Corresponding command: MAC START

Start macro with name *szName* on the master unit. To find out what macros are available on the master unit call E816_qMAC().

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szMacroName string with name of the macro to start

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MOV (int *ID*, const char* *szAxes*, double * *pdValarray*)

Corresponding command: MOV

Move *szAxes* to absolute positions.

Before using this command, please make sure the E-816 is in computer-controlled mode and has servo-control mode set ON (with E816_SVO()). See "Modes of Operation" in the E-816 User Manual for more information.

Move commands like E816_MOV() are not accepted when the wave table output is running (E816_WTO()) or when triggered motion is enabled (E816_MVT()).

Parameters:

ID ID of controller network

szAxes string with axes

pdValarray target positions for the axes

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MVR (int *ID*, const char* *szAxes*, double * *pdValarray*)

Corresponding command: MVR

Move *szAxes* relative to current position.

Before using this command, please make sure the E-816 is in computer-controlled mode and has servo-control mode set ON (with E816_SVO()). See "Modes of Operation" in the E-816 User Manual for more information.

Move commands like E816_MVR() are not accepted when the wave table output is running (E816_WTO()) or when triggered motion is enabled (E816_MVT()).

Parameters:

ID ID of controller network
szAxes string with axes
pdValarray target positions for the axes

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_MVT (int ID, const char * szAxes, const BOOL * pbValarray)

Corresponding command: MVT

Sets the “move triggered” mode ON or OFF. If this mode is enabled for an axis, every trigger pulse received causes a relative step. The step size is given by parameter 11 which can be set with E816_SPA().

Available with firmware revision 3.20 and newer.

Before you enable the “move triggered” mode, make sure the E-816 is in computer-controlled mode (see “Control Modes” in the E-816 User Manual). Furthermore, the piezo control electronics must be configured to accept trigger input, and a suitable trigger signal must be available (min. trigger pulse width = 5 µs; max. trigger frequency = 400 Hz). For details, see the MVT description in the E-816 User Manual and the manual of the piezo control electronics in which the E-816 is installed.

Triggered motion can not be enabled as long as the wave table output is running. When triggered motion is enabled, move commands (e.g. E816_SVA(), E816_MOV()) are not accepted and wave table output (E816_WTO()) can not be started.

The setting made with E816_MVT() is lost upon reset or when the device is powered down. Default setting is 0.

Parameters:

ID ID of controller network
szAxes string with axes
pbValarray modes for the specified axes, TRUE for "on", FALSE for "off"

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qAVG (int ID, int * pnAverage)

Corresponding command: AVG?

Get the number of samples used for average calculations by the master E-816.

Note:

This command will only query master E-816.

Parameters:

ID ID of controller network
pnAverage pointer to int for storing the number of samples used for average

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qBDR (int ID, int * pnBaudRate)

Corresponding command: BDR?

Get current RAM baudrate setting of the master. This is the value that will be saved to ROM by E816_WPA and may differ from both the power-up and/or the current operating value. See E816_BDR() (p.23) for information on how to change the baudrate.

Parameters:

ID ID of controller network
pnBaudRate pointer to int for storing the baudrate

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qDIP (int ID, char * szAxes, BOOL * pbValarray)

Corresponding command: DIP?

Ask if a digital pulse was detected for the given axis since the last call of E816_qDIP(). After a call of this function, the E-816 resets the pulse flag.

Available with firmware revision 3.20 and newer.

For meaningful results, make sure that the piezo control electronics in which the E-816 is installed is configured properly. For details, see the DIP description in the E-816 User Manual and the manual of the piezo control electronics in which the E-816 is installed.

Parameters:

ID ID of controller network

szAxes string with axes

pbValarray array to be filled with the answer values for the specified axes, **TRUE** for "trigger detected", **FALSE** for "no trigger detected"

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qDCO (int ID, char * szAxes, BOOL * pbValarray)

Corresponding command: DCO?

Get the state of the D/A converter drift compensation for szAxes

See "Drift Compensation" and the DCO command in the E-816 User Manual for details

Parameters:

ID ID of controller network

szAxes string with axes

pbValarray array to be filled with the servo-mode values for the specified axes, **TRUE** for "on", **FALSE** for "off"

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qERR (int ID, int * pnError)

Corresponding command: ERR?

Get the error state of the master E-816. It is safer to call **E816_GetError()** (p.17) because this will also return the internal error state of the library.

Parameters:

ID ID of controller network

pnError variable for storing error code of the master controller

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qHLP (int ID, char* szBuffer, int iBufferSize)

Corresponding command: HLP?

Reports device's online help list for the master unit. This command is provided for compatibility reasons since the current E-816 firmware is not yet able to generate a help string.

Available with firmware revision 3.20 and newer.

Parameters:

ID ID of controller network

szBuffer buffer to receive the string read in from controller, lines are separated by '\n' ("line-feed")

iBufferSize size of szBuffer, must be given to avoid buffer overflow.

Returns:

TRUE if no error, **FALSE** otherwise

BOOL E816_qI2C (int ID, int * *pnErrorCode*, char * *pcChannel*)

Corresponding command: I2C?

Get the state if the I2C bus connecting networked E-816s. The status is returned as a bitmap. The bit definition viewpoint is that of the master.

- bit 0: CHK_SEN0 timeout
- bit 1: CHK_PEN0 timeout
- bit 2: CHK_RSEN0 timeout
- bit 3: CHK_RWO timeout
- bit 4: CHK_BFO timeout
- bit 5: CHK_BF1 timeout
- bit 6: CHK_ACK0 timeout
- bit 7 (LSB): SLAVE_BUSY timeout

Parameters:

ID ID of controller network

pnErrorCode pointer to *int* for storing the bitmap with errors

pcChannel pointer to *char* for storing the associated channel name

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qIDN (int ID, char * *buffer*, int *maxlen*)

Corresponding command: *IDN?

Get identification string of the master controller.

Parameters:

ID ID of controller network

buffer buffer for storing the string read in from controller

maxlen size of *buffer*, must be given to avoid a buffer overflow.

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qMAC (int ID, char * *szName*, char * *szBuffer*, const int *maxlen*)

Corresponding command: MAC?

Get macros available on the master unit, or list contents of a specific macro on the master unit. If *szName* is empty or **NULL**, all available macros are listed in *szBuffer*, separated with line-feed characters. Otherwise the content of the macro with name *szName* is listed, the single lines separated with by line-feed characters. If there are no macros stored or the requested macro is empty the answer will be "".

See "Working with E-816 Macros" and the MAC command description in the E-816 User manual for details.

Parameters:

ID ID of controller network

szName string with name of the macro to list

szBuffer buffer to receive the string read in from controller, lines are separated by line-feed characters

maxlen size of *buffer*, must be given to avoid buffer overflow.

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qMOV (int ID, const char* szAxes, double * pdValarray)

Corresponding command: MOV?

Read the commanded target positions for szAxes.

Parameters:

ID ID of controller network

szAxes string with axes

pdValarray array to be filled with target positions of the axes

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qMVT (int ID, const char * szAxes, BOOL * pbValarray)

Corresponding command: MVT?

Reports the current "move triggered" mode setting of the given axis.

Available with firmware revision 3.20 and newer.

Parameters:

ID ID of controller network

szAxes string with axes

pbValarray array to be filled with the trigger-motion values for the specified axes,

TRUE for "on", **FALSE** for "off"

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qONT (int ID, const char* szAxes, BOOL * pbOnTarget)

Corresponding command: ONT?

Check if szAxes have reached target position.

Parameters:

ID ID of controller network

szAxes string with axes

pbOnTarget array to be filled with current on-target status of the axes: **TRUE** for on target, **FALSE** otherwise

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qOVF (int ID, const char* szAxes, BOOL * pbOverflow)

Corresponding command: OVF?

Check overflow status of szAxes.

Parameters:

ID ID of controller network

szAxes string with axes

pbOverflow array to be filled with current overflow status of the axes. The overflow status is supplied to the E-816 as a voltage level from other modules/submodules in the system. See the respective manuals for details.

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qPOS (int ID, const char* szAxes, double * pdValarray)

Corresponding command: POS?

Get the current positions of szAxes.

Parameters:

ID ID of controller network
szAxes string with axes
pdValarray array to be filled with current positions of the axes

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qSAI (int *ID*, char * *axes*, const int *maxlen*)

Corresponding command: SAI?

Get connected axes. Each character in the returned string is an axis identifier for one connected axis.

Can only be sent to the master unit but provides data about the entire network. If axes turn up missing, try power-cycling the E-816s.

Parameters:

ID ID of controller network
axes buffer to store the string read in
maxlen size of *buffer*, must be given to prevent a buffer overflow.

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qSCH (int *ID*, char * *pcChannelName*)

Corresponding command: SCH?

Get channel name (= axis identifier) of the master E-816. In addition to any name reported here, the master E-816 is always addressable with the special axis identifier "A".

Parameters:

ID ID of controller network
pcChannelName pointer to `char` for storing the channel name of the master

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qSPA (int *ID*, const char* *szAxes*, int * *iCmdarray*, double * *dValarray*)

Corresponding command: SPA?

Read current parameter settings for *szAxes*. With firmware revisions 2.xx, E816_qSPA() is only available for the master unit, i.e. the values in *szAxes* must be the axis identifier of the master unit or "A". With firmware revision 3.20 and newer, E816_qSPA() can also be used with slave units.

For each parameter you wish to query, you must respecify the axis in *szAxes* and a parameter ID in the corresponding element of *iCmdarray*. The parameter ID can have following values (see the E-816 User Manual for details):

- 1 for VAD gain
- 2 for VAD offset
- 3 for PAD gain
- 4 for PAD offset
- 5 for DA gain
- 6 for DA offset
- 7 for KSen
- 8 for OSen
- 9 for Kpzt
- 10 for Opzt

- 11 for the step size used for triggered motion (see E816_MVT()), the value is interpreted as µm in closed-loop operation or as volts in open-loop operation (with firmware rev. 3.20 and newer)
- 12 for configuration of wave table operation, the value is bit-coded as follows (with firmware rev. 3.20 and newer):

| | Bit 1 "TrigOnce" | Bit 0 "En" |
|-----------------|--|---|
| Description | If set, every trigger pulse received starts one wave table output cycle, i.e. all points set by the last call of E816_WTO() are output once. | If set, the last saved status of E816_WTO() and E816_SVO() is recovered after power-on or reset |
| Default setting | 0 = Normal wave trigger mode, i.e. one point is output per trigger pulse | 0 = Status recovery disabled |

Parameters:

- ID* ID of controller network
- szAxes* axis designators (e.g. "AAAA")
- iCmdarray* IDs of parameters to query
- dValarray* array to be filled with the values of the parameters

Returns:

TRUE if successful, FALSE otherwise

Errors:

PI_INVALID_SPA_CMD_ID one of the IDs in *iCmdarray* is not valid, must be in 1-12

BOOL E816_qSSN (int ID, char * szAxes, int * piValarray)

Corresponding command: SSN?

Get serial number of the master unit.

Parameters:

- ID* ID of controller network
- szAxes* string with axis designator
- piValarray* array to be filled with the serial number of the master unit

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qSVA (int ID, const char* szAxes, double * pdValarray)

Corresponding command: SVA?

Read the commanded piezo voltages for *szAxes*. (see also E816_qVOL() (p.33))

Parameters:

- ID* ID of controller network
- szAxes* string with axes
- pdValarray* array to be filled with the voltage values for the axes

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_qSWT (int ID, const char cAxis, const int nIndex, const double *pdValue)

Corresponding command: SWT?

Get wave table data. Each E-816 has a wave table with 64 entries (256 points with firmware revision 3.20 and newer). With this command you can read a value from the table.

Parameters:

ID ID of controller network
cAxis channel name of the axis
nIndex index for table entry, must be in 0-63. (0 to 255)
pdValue pointer to value to be filled with wave table entry

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qSVO (int ID, char * szAxes, BOOL * pbValarray)

Corresponding command: SVO?

Get the servo modes for szAxes
 Reports the last sent E816_SVO() settings of the given axis. Even if the E-816 is in analog mode, E816_qSVO() does not report the hardware settings for the servo mode. See E-816 User Manual for more information.

Parameters:

ID ID of controller network
szAxes string with axes
pbValarray array to be filled with the servo-mode values for the specified axes, **TRUE** for "on", **FALSE** for "off"

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_qVOL (int ID, const char* szAxes, double * pdValarray)

Corresponding command: VOL?

Get current piezo voltages for szAxes. (see also **E816_qSVA()** (p.32))

Parameters:

ID ID of controller network
szAxes string with axes
pdValarray array to be filled with the current voltages for the axes

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_RST (int ID)

Corresponding command: RST

Restart master E-816 controller. Use this command if you want to use settings saved with **E816_WPA()** (p.37) without power-cycling the E-816. The master unit remains master after a reset, even if the communications cable is pulled before the unit is ready, so changing masters requires power-cycling.

The E-816 will need some time to restart (up to several seconds), so subsequent commands may fail with a timeout error if you do not wait.

Parameters:

ID ID of controller network

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_SCH (int ID, const char cChannelName)

Corresponding command: SCH

Set the channel name (axis identifier) of the E-816. E816_SCH() can only be used with the master unit, but the axis identifier set is to be used to address the unit irrespective of its current master / slave state.

Note that if the name is set to A with this command, the unit cannot be addressed as slave since commands with A as axis identifier will always be executed by the master unit.

This will only change the setting in the RAM. To store it in the EEPROM call **E816_WPA()** (p.37) afterwards.

Parameters:

- ID** ID of controller network
- cChannelName** the channel name of the device, can be any letter from A to Z; if "A", the unit will not be reachable as slave

Returns:

TRUE if successful, **FALSE** otherwise

```
BOOL E816_SPA (int ID, const char* szAxes, int * iCmdarray, double * dValarray)
```

Corresponding command: SPA

Set parameters for szAxes. With firmware revisions 2.xx, E816_SPA() is only available for the master unit. With firmware revision 3.20 and newer it can also be used with slave units.

You must include an axis identifier in szAxes for each parameter you wish to set. Missing or illegal axis names in szAxes will cause an error (**PI_INVALID_AXIS_IDENTIFIER**). The function uses the parameter IDs in the iCmdarray and sets the parameters to the values in the corresponding elements of dValarray. The parameter IDs can have following values (see the E-816 User Manual for details):

- 7 for KSen
- 8 for OSen
- 9 for Kpzt
- 10 for Opzt
- 11 for the step size used for triggered motion (see E816_MVT()), the value is interpreted as µm in closed-loop operation or as volts in open-loop operation (with firmware rev. 3.20 and newer)
- 12 for configuration of wave table operation, the value is bit-coded as follows (with firmware rev. 3.20 and newer):

| | Bit 1 "TrigOnce" | Bit 0 "En" |
|-----------------|--|--|
| Description | If set, every trigger pulse received starts one wave table output cycle, i.e. all points set by the last call of E816_WTO() are output once. | If set, the last saved status of E816_WTO(), E816_WTOtimer() and E816_SVO() is recovered after power-on or reset |
| Default setting | 0 = Normal wave trigger mode, i.e. one point is output per trigger pulse | 0 = Status recovery disabled |

Unlike the other functions, E816_SPA() has two arrays as arguments. The first array has the parameters which have to be modified, the second one the values. If you want to set, for example, KSen (ID=7) to 1.0 and OSen (ID=8) to 10.0 for the master axis, you must call E816_SPA(id, "AA", {7, 8}, {1.0, 10.0})

| | | |
|-----------------|--------------|----------------------|
| szAxes = "AA" | cmd = {7, 8} | values = {1.0, 10.0} |
| szAxes[0] = 'A' | cmd[0] = 7 | values[0] = 1.0 |
| szAxes[1] = 'A' | cmd[1] = 8 | values[1] = 10.0 |

If the same parameter ID appears more than once in iCmdarray, the **last** value will be set. For example E816_SPA(id, "AAA", {7, 7, 9}, {10.0, 20.0, 30.0}) will set the KSen of axis A to 20.0 and the Kpzt to 30.0.

Parameters:

- ID** ID of controller network

szAxes axes for which the parameter should be set
iCmdarray parameter IDs (see above)
dValarray array with the values for the parameters

Returns:

TRUE if successful, **FALSE** otherwise

Errors:

PI_INVALID_SPA_CMD_ID one of the IDs in *iCmdarray* is not valid, must each be one of {7,8,9,10,11,12}

BOOL E816_SVA (int ID, const char* szAxes, double * pdValarray)

Corresponding command: SVA

Set piezo voltages for szAxes to absolute values.

Before using this command, please make sure the E-816 is in computer-controlled mode and has servo-control mode set OFF (with E816_SVO()). See "Modes of Operation" in the E-816 User Manual for more information.

Move commands like E816_SVA() are not accepted when the wave table output is running (E816_WTO()) or when triggered motion is enabled (E816_MVT()).

Parameters:

ID ID of controller network
szAxes string with axes
pdValarray voltages for the axes

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_SVO (int ID, char * szAxes, BOOL * pbValarray)

Corresponding command: SVO

Set servo-control "on" or "off" (closed-loop / open-loop mode). If *pbValarray[index]* is **FALSE** the mode is "off", if **TRUE** it is set to "on".

Only takes effect when the E-816 is in computer-controlled mode. See "Modes of Operation" in the E-816 User Manual for more information. Note that in computer-controlled mode the servo mode selection made by the DIP switches or SERVO toggle switch on the piezo control electronics is ignored.

E816_WPA() saves the current E816_SVO() settings. But to make them the new power-on defaults, you must set parameter 12 with E816_SPA() to the corresponding value (see p. 34). With the default setting of parameter 12, the last saved E816_SVO() settings are not recovered on power-on or reset.

Parameters:

ID ID of controller network
szAxes string with axes
pbValarray modes for the specified axes, **TRUE** for "on", **FALSE** for "off"

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_SVR (int ID, const char* szAxes, double * pdValarray)

Corresponding command: SVR

Set piezo voltages for szAxes relatively, i.e. increase current voltages by the specified values.

Before using this command, please make sure the E-816 is in computer-controlled mode and has servo-control mode set OFF (with E816_SVO()). See "Modes of Operation" in the E-816 User Manual for more information.

Move commands like E816_SVR() are not accepted when the wave table output is running (E816_WTO()) or when triggered motion is enabled (E816_MVT()).

Parameters:

ID ID of controller network

szAxes string with axes

pdValarray values to be added to voltage of the axes

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_SWT (int ID, const char cAxis, const int nIndex, const double dValue)

Corresponding command: SWT

Set wave table data. Each E-816 has a wave table with 64 entries (256 points with firmware revision 3.20 and newer). With this command you can place a value in the table. The data is automatically stored in non-volatile memory and can be reused after next power-up.

The first time data is written to the wave table, it is recommended to define all points. Afterwards, it may be sufficient to define certain points.

Parameters:

ID ID of controller network

cAxis channel name of the axis

nIndex index for table entry, must be in 0 to 63 (0 to 255)

dValue new value for wave table entry, the value is interpreted as μm in closed-loop operation or as volts in open-loop operation

Returns:

TRUE if successful, FALSE otherwise

BOOL E816_WPA (int ID, const char* *szPassword*)

Corresponding command: WPA

E816_WPA() only affects the master unit. The current values of parameters settable by E816_SPA(), E816_AVG(), E816_BDR(), E816_DCO() and E816_SCH() are written to nonvolatile memory (EEPROM), where they become the new power-on defaults.

Furthermore, E816_WPA() saves macros, and is also required if an existing macro has been changed, was deleted or defined as start-up macro (see the E816_MAC functions).

Note that the volatile (RAM) value of E816_BDR() does not go into effect until after it is written to ROM and the system reset, so the RAM value may differ from the current operating value.

E816_WPA() also saves the current E816_WTO() and E816_SVO() settings. But to make them the new power-on defaults, you must set parameter 12 with E816_SPA() to the corresponding value (see p. 34). With the default setting of parameter 12, the last saved E816_WTO() and E816_SVO() settings are not recovered on power-on or reset.

If the current RAM values are incompatible, the system may malfunction. Be sure that you have entered the correct parameter settings before using E816_WPA().

Parameters:

ID ID of controller network

szPassword password needed to store the parameters. The password is "100".

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_WTO (int ID, const char *cAxis*, const int *nNumber*)

Corresponding command: WTO

Start or stop the wave table output. One wave-table point is output each time an external trigger signal is received.

Before starting wave table output, please make sure the E-816 is in computer-controlled mode. Furthermore, the piezo control electronics must be configured to accept trigger input, and a suitable trigger signal must be available (min. trigger pulse width = 5 µs; max. trigger frequency = 400 Hz). For details, see the E-816 User Manual and the manual of the piezo control electronics in which the E-816 is installed.

Wave table output can not be started as long as triggered motion is enabled (E816_MVT()). When wave table output is running, move commands (e.g. E816_SVA(), E816_MOV()) are not accepted and triggered motion (E816_MVT()) can not be enabled.

During wave-table output drift compensation (see E816_DCO()) is not carried out even if set to 1.

During wave-table output it is possible to change values in the wave table, with changes taking effect when the next point is output.

E816_WPA() saves the current E816_WTO() settings. But to make them the new power-on defaults, you must set parameter 12 with E816_SPA() to the corresponding value (see p. 34). With the default setting of parameter 12, the last saved E816_WTO() settings are not recovered on power-on or reset.

See "Working with the Wave Table" in the E-816 User Manual for more information.

Parameters:

ID ID of controller network

cAxis channel name of the axis

nNumber if 0, the output is stopped. With *nNumber* in 1 to 64 (1 to 256 with firmware rev. 3.20 and newer), the output is started from index 0 to (*nNumber*-1).

Returns:

TRUE if successful, **FALSE** otherwise

BOOL E816_WTOTimer (int *ID*, const char *cAxis*, const int *nNumber*, int *timer*)

Corresponding command: WTO

Start or stop the wave table output. Output of the points specified by *nNumber* will be started immediately and each point will be output for the amount of time specified by *timer* in milliseconds. Output will roll over from the point with index *nNumber*-1 to the point with index 0 and continue until stopped by E816_WTOTimer() or E816_WTO() with *nNumber* = 0.

Before starting wave table output, please make sure the E-816 is in computer-controlled mode. For details, see the E-816 User Manual.

Wave table output can not be started as long as triggered motion is enabled (E816_MVT()). When wave table output is running, move commands (e.g. E816_SVA(), E816_MOV()) are not accepted and triggered motion (E816_MVT()) can not be enabled.

During wave-table output drift compensation (see E816_DCO()) is not carried out even if set to 1.

During wave-table output it is possible to change values in the wave table, with changes taking effect when the next point is output.

E816_WPA() saves the current E816_WTOTimer() settings. But to make them the new power-on defaults, you must set parameter 12 with E816_SPA() to the corresponding value (see p. 34). With the default setting of parameter 12, the last saved E816_WTOTimer() settings are not recovered on power-on or reset.

See "Working with the Wave Table" in the E-816 User Manual for more information.

Parameters:

ID ID of controller network

cAxis channel name of the axis

nNumber if 0, the output is stopped. With *nNumber* in 1 to 64 (1 to 256 with firmware rev. 3.20 and newer), the output continues indefinitely. Stop with an

E816_WTOTimer() or **E816_WTO()** with *nNumber* = 0

timer time in milliseconds, each point will be output for that amount of time

Returns:

TRUE if successful, **FALSE** otherwise

9. Error Codes

The error codes are defined in separate header files shipped with the E-816 GCS_DLL.

The error codes listed here are those of the *PI General Command Set*. As such, some are not relevant to the E-816 and will simply never occur with the systems this manual describes.

Controller Errors

| | | |
|----|--------------------------------------|---|
| 0 | PI_CNTR_NO_ERROR | No error |
| 1 | PI_CNTR_PARAM_SYNTAX | Parameter syntax error |
| 2 | PI_CNTR_UNKNOWN_COMMAND | Unknown command |
| 3 | PI_CNTR_COMMAND_TOO_LONG | Command length out of limits or command buffer overrun |
| 4 | PI_CNTR_SCAN_ERROR | Error while scanning |
| 5 | PI_CNTR_MOVE_WITHOUT_REF_OR_NO_SERVO | Unallowable move attempted on unreferenced axis, or move attempted with servo off |
| 6 | PI_CNTR_INVALID_SGA_PARAM | Parameter for SGA not valid |
| 7 | PI_CNTR_POS_OUT_OF_LIMITS | Position out of limits |
| 8 | PI_CNTR_VEL_OUT_OF_LIMITS | Velocity out of limits |
| 9 | PI_CNTR_SET_PIVOT_NOT_POSSIBLE | Attempt to set pivot point while U,V and W not all 0 |
| 10 | PI_CNTR_STOP | Controller was stopped by command |
| 11 | PI_CNTR_SST_OR_SCAN_RANGE | Parameter for SST or for one of the embedded scan algorithms out of range |
| 12 | PI_CNTR_INVALID_SCAN_AXES | Invalid axis combination for fast scan |
| 13 | PI_CNTR_INVALID_NAV_PARAM | Parameter for NAV out of range |
| 14 | PI_CNTR_INVALID_ANALOG_INPUT | Invalid analog channel |
| 15 | PI_CNTR_INVALID_AXIS_IDENTIFIER | Invalid axis identifier |
| 16 | PI_CNTR_INVALID_STAGE_NAME | Unknown stage name |
| 17 | PI_CNTR_PARAM_OUT_OF_RANGE | Parameter out of range |
| 18 | PI_CNTR_INVALID_MACRO_NAME | Invalid macro name |
| 19 | PI_CNTR_MACRO_RECORD | Error while recording macro |
| 20 | PI_CNTR_MACRO_NOT_FOUND | Macro not found |

| | | |
|----|-------------------------------------|--|
| 21 | PI_CNTR_AXIS_HAS_NO_BRAKE | Axis has no brake |
| 22 | PI_CNTR_DOUBLE_AXIS | Axis identifier specified more than once |
| 23 | PI_CNTR_ILLEGAL_AXIS | Illegal axis |
| 24 | PI_CNTR_PARAM_NR | Incorrect number of parameters |
| 25 | PI_CNTR_INVALID_REAL_NR | Invalid floating point number |
| 26 | PI_CNTR_MISSING_PARAM | Parameter missing |
| 27 | PI_CNTR_SOFT_LIMIT_OUT_OF_RANGE | Soft limit out of range |
| 28 | PI_CNTR_NO_MANUAL_PAD | No manual pad found |
| 29 | PI_CNTR_NO_JUMP | No more step-response values |
| 30 | PI_CNTR_INVALID_JUMP | No step-response values recorded |
| 31 | PI_CNTR_AXIS_HAS_NO_REFERENCE | Axis has no reference sensor |
| 32 | PI_CNTR_STAGE_HAS_NO_LIM_SWITCH | Axis has no limit switch |
| 33 | PI_CNTR_NO_RELAY_CARD | No relay card installed |
| 34 | PI_CNTR_CMD_NOT_ALLOWED_FOR_STAGE | Command not allowed for selected stage(s) |
| 35 | PI_CNTR_NO_DIGITAL_INPUT | No digital input installed |
| 36 | PI_CNTR_NO_DIGITAL_OUTPUT | No digital output configured |
| 37 | PI_CNTR_NO_MCM | No more MCM responses |
| 38 | PI_CNTR_INVALID_MCM | No MCM values recorded |
| 39 | PI_CNTR_INVALID_CNTR_NUMBER | Controller number invalid |
| 40 | PI_CNTR_NO_JOYSTICK_CONNECTED | No joystick configured |
| 41 | PI_CNTR_INVALID_EGE_AXIS | Invalid axis for electronic gearing, axis can not be slave |
| 42 | PI_CNTR_SLAVE_POSITION_OUT_OF_RANGE | Position of slave axis is out of range |
| 43 | PI_CNTR_COMMAND_EGE_SLAVE | Slave axis cannot be commanded directly when electronic gearing is enabled |

| | | |
|----|-------------------------------------|--|
| 44 | PI_CNTR_JOYSTICK_CALIBRATION_FAILED | Calibration of joystick failed |
| 45 | PI_CNTR_REFERENCING_FAILED | Referencing failed |
| 46 | PI_CNTR_OPM_MISSING | OPM (Optical Power Meter) missing |
| 47 | PI_CNTR_OPM_NOT_INITIALIZED | OPM (Optical Power Meter) not initialized or cannot be initialized |
| 48 | PI_CNTR_OPM_COM_ERROR | OPM (Optical Power Meter) Communication Error |
| 49 | PI_CNTR_MOVE_TO_LIMIT_SWITCH_FAILED | Move to limit switch failed |
| 50 | PI_CNTR_REF_WITH_REF_DISABLED | Attempt to reference axis with referencing disabled |
| 51 | PI_CNTR_AXIS_UNDER_JOYSTICK_CONTROL | Selected axis is controlled by joystick |
| 52 | PI_CNTR_COMMUNICATION_ERROR | Controller detected communication error |
| 53 | PI_CNTR_DYNAMIC_MOVE_IN_PROCESS | MOV! motion still in progress |
| 54 | PI_CNTR_UNKNOWN_PARAMETER | Unknown parameter |
| 55 | PI_CNTR_NO_REP_RECORDED | No commands were recorded with REP |
| 56 | PI_CNTR_INVALID_PASSWORD | Password invalid |
| 57 | PI_CNTR_INVALID_RECORDER_CHAN | Data Record Table does not exist |
| 58 | PI_CNTR_INVALID_RECORDER_SRC_OPT | Source does not exist; number too low or too high |
| 59 | PI_CNTR_INVALID_RECORDER_SRC_CHAN | Source Record Table number too low or too high |
| 60 | PI_CNTR_PARAM_PROTECTION | Protected Param: current Command Level (CCL) too low |
| 61 | PI_CNTR_AUTOZERO_RUNNING | Command execution not possible while Autozero is running |
| 62 | PI_CNTR_NO_LINEAR_AXIS | Autozero requires at least one linear axis |
| 63 | PI_CNTR_INIT_RUNNING | Initialization still in progress |
| 64 | PI_CNTR_READ_ONLY_PARAMETER | Parameter is read-only |
| 65 | PI_CNTR_PAM_NOT_FOUND | Parameter not found in non-volatile memory |
| 66 | PI_CNTR_VOL_OUT_OF_LIMITS | Voltage out of limits |

| | | |
|----|--|--|
| 67 | PI_CNTR_WAVE_TOO_LARGE | Not enough memory available for requested wave curve |
| 68 | PI_CNTR_NOT_ENOUGH_DDL_MEMORY | Not enough memory available for DDL table; DDL can not be started |
| 69 | PI_CNTR_DDL_TIME_DELAY_TOO_LARGE | Time delay larger than DDL table; DDL can not be started |
| 70 | PI_CNTR_DIFFERENT_ARRAY_LENGTH | The requested arrays have different lengths; query them separately |
| 71 | PI_CNTR_GEN_SINGLE_MODE_RESTART | Attempt to restart the generator while it is running in single step mode |
| 72 | PI_CNTR_ANALOG_TARGET_ACTIVE | Motion commands and wave generator activation are not allowed when analog target is active |
| 73 | PI_CNTR_WAVE_GENERATOR_ACTIVE | Motion commands are not allowed when wave generator is active |
| 74 | PI_CNTR_AUTOZERO_DISABLED | No sensor channel or no piezo channel connected to selected axis (sensor and piezo matrix) |
| 75 | PI_CNTR_NO_WAVE_SELECTED | Generator started (WGO) without having selected a wave table (WSL). |
| 76 | PI_CNTR_IF_BUFFER_OVERRUN | Interface buffer did overrun and command couldn't be received correctly |
| 77 | PI_CNTR_NOT_ENOUGH_RECORDED_DATA | Data Record Table does not hold enough recorded data |
| 78 | PI_CNTR_TABLE_DEACTIVATED | Data Record Table is not configured for recording |
| 79 | PI_CNTR_OPENLOOP_VALUE_SET_WHEN_SERVO_ON | Open-loop commands (SVA, SVR) are not allowed when servo is on |
| 80 | PI_CNTR_RAM_ERROR | Hardware error affecting RAM |
| 81 | PI_CNTR_MACRO_UNKNOWN_COMMAND | Not macro command |
| 82 | PI_CNTR_MACRO_PC_ERROR | Macro counter out of range |
| 83 | PI_CNTR_JOYSTICK_ACTIVE | Joystick is active |
| 84 | PI_CNTR_MOTOR_IS_OFF | Motor is off |
| 85 | PI_CNTR_ONLY_IN_MACRO | Macro-only command |
| 86 | PI_CNTR_JOYSTICK_UNKNOWN_AXIS | Invalid joystick axis |
| 87 | PI_CNTR_JOYSTICK_UNKNOWN_ID | Joystick unknown |
| 88 | PI_CNTR_REF_MODE_IS_ON | Move without referenced stage |

| | | |
|-----|--|--|
| 89 | PI_CNTR_NOT_ALLOWED_IN_CURRENT_MOTION_MODE | Command not allowed in current motion mode |
| 100 | PI_LABVIEW_ERROR | PI LabVIEW driver reports error. See source control for details. |
| 200 | PI_CNTR_NO_AXIS | No stage connected to axis |
| 201 | PI_CNTR_NO_AXIS_PARAM_FILE | File with axis parameters not found |
| 202 | PI_CNTR_INVALID_AXIS_PARAM_FILE | Invalid axis parameter file |
| 203 | PI_CNTR_NO_AXIS_PARAM_BACKUP | Backup file with axis parameters not found |
| 204 | PI_CNTR_RESERVED_204 | PI internal error code 204 |
| 205 | PI_CNTR_SMO_WITH_SERVO_ON | SMO with servo on |
| 206 | PI_CNTR_UUDECODE_INCOMPLETE_HEADER | uudecode: incomplete header |
| 207 | PI_CNTR_UUDECODE_NOTHING_TO_DECODE | uudecode: nothing to decode |
| 208 | PI_CNTR_UUDECODE_ILLEGAL_FORMAT | uudecode: illegal UUE format |
| 209 | PI_CNTR_CRC32_ERROR | CRC32 error |
| 210 | PI_CNTR_ILLEGAL_FILENAME | Illegal file name (must be 8-0 format) |
| 211 | PI_CNTR_FILE_NOT_FOUND | File not found on controller |
| 212 | PI_CNTR_FILE_WRITE_ERROR | Error writing file on controller |
| 213 | PI_CNTR_DTR_HINDERS_VELOCITY_CHANGE | VEL command not allowed in DTR Command Mode |
| 214 | PI_CNTR_POSITION_UNKNOWN | Position calculations failed |
| 215 | PI_CNTR_CONN_POSSIBLY_BROKEN | The connection between controller and stage may be broken |
| 216 | PI_CNTR_ON_LIMIT_SWITCH | The connected stage has driven into a limit switch, call CLR to resume operation |
| 217 | PI_CNTR_UNEXPECTED_STRUT_STOP | Strut test command failed because of an unexpected strut stop |
| 218 | PI_CNTR_POSITION_BASED_ON_ESTIMATION | While MOV! is running position can only be estimated! |
| 219 | PI_CNTR_POSITION_BASED_ON_INTERPOLATION | Position was calculated during MOV motion |
| 230 | PI_CNTR_INVALID_HANDLE | Invalid handle |

| | | |
|-----|--|---|
| 231 | PI_CNTR_NO_BIOS_FOUND | No bios found |
| 232 | PI_CNTR_SAVE_SYS_CFG_FAILED | Save system configuration failed |
| 233 | PI_CNTR_LOAD_SYS_CFG_FAILED | Load system configuration failed |
| 301 | PI_CNTR_SEND_BUFFER_OVERFLOW | Send buffer overflow |
| 302 | PI_CNTR_VOLTAGE_OUT_OF_LIMITS | Voltage out of limits |
| 303 | PI_CNTR_OPEN_LOOP_MOTION_SET_WHEN_SERVO_ON | Open-loop motion attempted when servo ON |
| 304 | PI_CNTR_RECEIVING_BUFFER_OVERFLOW | Received command is too long |
| 305 | PI_CNTR_EEPROM_ERROR | Error while reading/writing EEPROM |
| 306 | PI_CNTR_I2C_ERROR | Error on I2C bus |
| 307 | PI_CNTR_RECEIVING_TIMEOUT | Timeout while receiving command |
| 308 | PI_CNTR_TIMEOUT | A lengthy operation has not finished in the expected time |
| 309 | PI_CNTR_MACRO_OUT_OF_SPACE | Insufficient space to store macro |
| 310 | PI_CNTR_EUI_OLDVERSION_CFGDATA | Configuration data has old version number |
| 311 | PI_CNTR_EUI_INVALID_CFGDATA | Invalid configuration data |
| 333 | PI_CNTR_HARDWARE_ERROR | Internal hardware error |
| 400 | PI_CNTR_WAV_INDEX_ERROR | Wave generator index error |
| 401 | PI_CNTR_WAV_NOT_DEFINED | Wave table not defined |
| 402 | PI_CNTR_WAV_TYPE_NOT_SUPPORTED | Wave type not supported |
| 403 | PI_CNTR_WAV_LENGTH_EXCEEDS_LIMIT | Wave length exceeds limit |
| 404 | PI_CNTR_WAV_PARAMETER_NR | Wave parameter number error |
| 405 | PI_CNTR_WAV_PARAMETER_OUT_OF_LIMIT | Wave parameter out of range |
| 406 | PI_CNTR_WGO_BIT_NOT_SUPPORTED | WGO command bit not supported |
| 555 | PI_CNTR_UNKNOWN_ERROR | BasMac: unknown controller error |

| | | |
|------|-----------------------------------|---|
| 601 | PI_CNTR_NOT_ENOUGH_MEMORY | not enough memory |
| 602 | PI_CNTR_HW_VOLTAGE_ERROR | hardware voltage error |
| 603 | PI_CNTR_HW_TEMPERATURE_ERROR | hardware temperature out of range |
| 1000 | PI_CNTR_TOO_MANY_NESTED_MACROS | Too many nested macros |
| 1001 | PI_CNTR_MACRO_ALREADY_DEFINED | Macro already defined |
| 1002 | PI_CNTR_NO_MACRO_RECORDING | Macro recording not activated |
| 1003 | PI_CNTR_INVALID_MAC_PARAM | Invalid parameter for MAC |
| 1004 | PI_CNTR_RESERVED_1004 | PI internal error code 1004 |
| 1005 | PI_CNTR_CONTROLLER_BUSY | Controller is busy with some lengthy operation (e.g. reference move, fast scan algorithm) |
| 2000 | PI_CNTR_ALREADY_HAS_SERIAL_NUMBER | Controller already has a serial number |
| 4000 | PI_CNTR_SECTOR_ERASE_FAILED | Sector erase failed |
| 4001 | PI_CNTR_FLASH_PROGRAM_FAILED | Flash program failed |
| 4002 | PI_CNTR_FLASH_READ_FAILED | Flash read failed |
| 4003 | PI_CNTR_HW_MATCHCODE_ERROR | HW match code missing/invalid |
| 4004 | PI_CNTR_FW_MATCHCODE_ERROR | FW match code missing/invalid |
| 4005 | PI_CNTR_HW_VERSION_ERROR | HW version missing/invalid |
| 4006 | PI_CNTR_FW_VERSION_ERROR | FW version missing/invalid |
| 4007 | PI_CNTR_FW_UPDATE_ERROR | FW update failed |

Interface Errors

| | | |
|----|--------------|---|
| 0 | COM_NO_ERROR | No error occurred during function call |
| -1 | COM_ERROR | Error during com operation (could not be specified) |
| -2 | SEND_ERROR | Error while sending data |

| | | |
|-----|------------------------|--|
| -3 | REC_ERROR | Error while receiving data |
| -4 | NOT_CONNECTED_ERROR | Not connected (no port with given ID open) |
| -5 | COM_BUFFER_OVERFLOW | Buffer overflow |
| -6 | CONNECTION_FAILED | Error while opening port |
| -7 | COM_TIMEOUT | Timeout error |
| -8 | COM_MULTILINE_RESPONSE | There are more lines waiting in buffer |
| -9 | COM_INVALID_ID | There is no interface or DLL handle with the given ID |
| -10 | COM_NOTIFY_EVENT_ERROR | Event/message for notification could not be opened |
| -11 | COM_NOT_IMPLEMENTED | Function not supported by this interface type |
| -12 | COM_ECHO_ERROR | Error while sending "echoed" data |
| -13 | COM_GPIB_EDVR | IEEE488: System error |
| -14 | COM_GPIB_ECIC | IEEE488: Function requires GPIB board to be CIC |
| -15 | COM_GPIB_ENOL | IEEE488: Write function detected no listeners |
| -16 | COM_GPIB_EADR | IEEE488: Interface board not addressed correctly |
| -17 | COM_GPIB_EARG | IEEE488: Invalid argument to function call |
| -18 | COM_GPIB_ESAC | IEEE488: Function requires GPIB board to be SAC |
| -19 | COM_GPIB_EABO | IEEE488: I/O operation aborted |
| -20 | COM_GPIB_ENEB | IEEE488: Interface board not found |
| -21 | COM_GPIB_EDMA | IEEE488: Error performing DMA |
| -22 | COM_GPIB_EOIP | IEEE488: I/O operation started before previous operation completed |
| -23 | COM_GPIB_ECAP | IEEE488: No capability for intended operation |
| -24 | COM_GPIB_EFSO | IEEE488: File system operation error |
| -25 | COM_GPIB_EBUS | IEEE488: Command error during device call |

| | | |
|-----|---|---|
| -26 | COM_GPIB_ESTB | IEEE488: Serial poll-status byte lost |
| -27 | COM_GPIB_ESRQ | IEEE488: SRQ remains asserted |
| -28 | COM_GPIB_ETAB | IEEE488: Return buffer full |
| -29 | COM_GPIB_ELCK | IEEE488: Address or board locked |
| -30 | COM_RS_INVALID_DATA_BITS | RS-232: 5 data bits with 2 stop bits is an invalid combination, as is 6, 7, or 8 data bits with 1.5 stop bits |
| -31 | COM_ERROR_RS_SETTINGS | RS-232: Error configuring the COM port |
| -32 | COM_INTERNAL_RESOURCES_ERROR | Error dealing with internal system resources (events, threads, ...) |
| -33 | COM_DLL_FUNC_ERROR | A DLL or one of the required functions could not be loaded |
| -34 | COM_FTDIUSB_INVALID_HANDLE | FTDIUSB: invalid handle |
| -35 | COM_FTDIUSB_DEVICE_NOT_FOUND | FTDIUSB: device not found |
| -36 | COM_FTDIUSB_DEVICE_NOT_OPENED | FTDIUSB: device not opened |
| -37 | COM_FTDIUSB_IO_ERROR | FTDIUSB: IO error |
| -38 | COM_FTDIUSB_INSUFFICIENT_RESOURCES | FTDIUSB: insufficient resources |
| -39 | COM_FTDIUSB_INVALID_PARAMETER | FTDIUSB: invalid parameter |
| -40 | COM_FTDIUSB_INVALID_BAUD_RATE | FTDIUSB: invalid baud rate |
| -41 | COM_FTDIUSB_DEVICE_NOT_OPENED_FOR_ERASE | FTDIUSB: device not opened for erase |
| -42 | COM_FTDIUSB_DEVICE_NOT_OPENED_FOR_WRITE | FTDIUSB: device not opened for write |
| -43 | COM_FTDIUSB_FAILED_TO_WRITE_DEVICE | FTDIUSB: failed to write device |
| -44 | COM_FTDIUSB_EEPROM_READ_FAILED | FTDIUSB: EEPROM read failed |
| -45 | COM_FTDIUSB_EEPROM_WRITE_FAILED | FTDIUSB: EEPROM write failed |
| -46 | COM_FTDIUSB_EEPROM_ERASE_FAILED | FTDIUSB: EEPROM erase failed |
| -47 | COM_FTDIUSB_EEPROM_NOT_PRESENT | FTDIUSB: EEPROM not present |
| -48 | COM_FTDIUSB_EEPROM_NOT_PROGRAMMED | FTDIUSB: EEPROM not programmed |

| | | |
|-----|---------------------------|---|
| -49 | COM_FTDIUSB_INVALID_ARGS | FTDIUSB: invalid arguments |
| -50 | COM_FTDIUSB_NOT_SUPPORTED | FTDIUSB: not supported |
| -51 | COM_FTDIUSB_OTHER_ERROR | FTDIUSB: other error |
| -52 | COM_PORT_ALREADY_OPEN | Error while opening the COM port: was already open |
| -53 | COM_PORT_CHECKSUM_ERROR | Checksum error in received data from COM port |
| -54 | COM_SOCKET_NOT_READY | Socket not ready, you should call the function again |
| -55 | COM_SOCKET_PORT_IN_USE | Port is used by another socket |
| -56 | COM_SOCKET_NOT_CONNECTED | Socket not connected (or not valid) |
| -57 | COM_SOCKET_TERMINATED | Connection terminated (by peer) |
| -58 | COM_SOCKET_NO_RESPONSE | Can't connect to peer |
| -59 | COM_SOCKET_INTERRUPTED | Operation was interrupted by a nonblocked signal |
| -60 | COM_PCI_INVALID_ID | No device with this ID is present |
| -61 | COM_PCI_ACCESS_DENIED | Driver could not be opened (on Vista: run as administrator!) |

DLL Errors

| | | |
|-------|----------------------------|---|
| -1001 | PI_UNKNOWN_AXIS_IDENTIFIER | Unknown axis identifier |
| -1002 | PI_NR_NAV_OUT_OF_RANGE | Number for NAV out of range--must be in [1,10000] |
| -1003 | PI_INVALID_SGA | Invalid value for SGA--must be one of 1, 10, 100, 1000 |
| -1004 | PI_UNEXPECTED_RESPONSE | Controller sent unexpected response |
| -1005 | PI_NO_MANUAL_PAD | No manual control pad installed, calls to SMA and related commands are not allowed |
| -1006 | PI_INVALID_MANUAL_PAD_KNOB | Invalid number for manual control pad knob |
| -1007 | PI_INVALID_MANUAL_PAD_AXIS | Axis not currently controlled by a manual control pad |
| -1008 | PI_CONTROLLER_BUSY | Controller is busy with some lengthy operation (e.g. reference move, fast scan algorithm) |

| | | |
|-------|-------------------------------|--|
| -1009 | PI_THREAD_ERROR | Internal error--could not start thread |
| -1010 | PI_IN_MACRO_MODE | Controller is (already) in macro mode-- command not valid in macro mode |
| -1011 | PI_NOT_IN_MACRO_MODE | Controller not in macro mode-- command not valid unless macro mode active |
| -1012 | PI_MACRO_FILE_ERROR | Could not open file to write or read macro |
| -1013 | PI_NO_MACRO_OR_EMPTY | No macro with given name on controller, or macro is empty |
| -1014 | PI_MACRO_EDITOR_ERROR | Internal error in macro editor |
| -1015 | PI_INVALID_ARGUMENT | One or more arguments given to function is invalid (empty string, index out of range, ...) |
| -1016 | PI_AXIS_ALREADY_EXISTS | Axis identifier is already in use by a connected stage |
| -1017 | PI_INVALID_AXIS_IDENTIFIER | Invalid axis identifier |
| -1018 | PI_COM_ARRAY_ERROR | Could not access array data in COM server |
| -1019 | PI_COM_ARRAY_RANGE_ERROR | Range of array does not fit the number of parameters |
| -1020 | PI_INVALID_SPA_CMD_ID | Invalid parameter ID given to SPA or SPA? |
| -1021 | PI_NR_AVG_OUT_OF_RANGE | Number for AVG out of range--must be >0 |
| -1022 | PI_WAV_SAMPLES_OUT_OF_RANGE | Incorrect number of samples given to WAV |
| -1023 | PI_WAV_FAILED | Generation of wave failed |
| -1024 | PI_MOTION_ERROR | Motion error while axis in motion, call CLR to resume operation |
| -1025 | PI_RUNNING_MACRO | Controller is (already) running a macro |
| -1026 | PI_PZT_CONFIG_FAILED | Configuration of PZT stage or amplifier failed |
| -1027 | PI_PZT_CONFIG_INVALID_PARAMS | Current settings are not valid for desired configuration |
| -1028 | PI_UNKNOWN_CHANNEL_IDENTIFIER | Unknown channel identifier |
| -1029 | PI_WAVE_PARAM_FILE_ERROR | Error while reading/writing wave generator parameter file |
| -1030 | PI_UNKNOWN_WAVE_SET | Could not find description of wave form. Maybe WG.INI is missing? |

| | | |
|-------|---|---|
| -1031 | PI_WAVE_EDITOR_FUNC_NOT_LOADED | The WGWaveEditor DLL function was not found at startup |
| -1032 | PI_USER_CANCELLED | The user cancelled a dialog |
| -1033 | PI_C844_ERROR | Error from C-844 Controller |
| -1034 | PI_DLL_NOT_LOADED | DLL necessary to call function not loaded, or function not found in DLL |
| -1035 | PI_PARAMETER_FILE_PROTECTED | The open parameter file is protected and cannot be edited |
| -1036 | PI_NO_PARAMETER_FILE_OPENED | There is no parameter file open |
| -1037 | PI_STAGE_DOES_NOT_EXIST | Selected stage does not exist |
| -1038 | PI_PARAMETER_FILE_ALREADY_OPENED | There is already a parameter file open. Close it before opening a new file |
| -1039 | PI_PARAMETER_FILE_OPEN_ERROR | Could not open parameter file |
| -1040 | PI_INVALID_CONTROLLER_VERSION | The version of the connected controller is invalid |
| -1041 | PI_PARAM_SET_ERROR | Parameter could not be set with SPA- -parameter not defined for this controller! |
| -1042 | PI_NUMBER_OF_POSSIBLE_WAVES_EXCEEDED | The maximum number of wave definitions has been exceeded |
| -1043 | PI_NUMBER_OF_POSSIBLE_GENERATORS_EXCEEDED | The maximum number of wave generators has been exceeded |
| -1044 | PI_NO_WAVE_FOR_AXIS_DEFINED | No wave defined for specified axis |
| -1045 | PI_CANT_STOP_OR_START_WAV | Wave output to axis already stopped/started |
| -1046 | PI_REFERENCE_ERROR | Not all axes could be referenced |
| -1047 | PI_REQUIRED_WAVE_NOT_FOUND | Could not find parameter set required by frequency relation |
| -1048 | PI_INVALID_SPP_CMD_ID | Command ID given to SPP or SPP? is not valid |
| -1049 | PI_STAGE_NAME_ISNT_UNIQUE | A stage name given to CST is not unique |
| -1050 | PI_FILE_TRANSFER_BEGIN_MISSING | A uuencoded file transferred did not start with "begin" followed by the proper filename |
| -1051 | PI_FILE_TRANSFER_ERROR_TEMP_FILE | Could not create/read file on host PC |
| -1052 | PI_FILE_TRANSFER_CRC_ERROR | Checksum error when transferring a file to/from the controller |

| | | |
|-------|--|---|
| -1053 | PI_COULDNT_FIND_PISTAGES_DAT | The PiStages.dat database could not be found. This file is required to connect a stage with the CST command |
| -1054 | PI_NO_WAVE_RUNNING | No wave being output to specified axis |
| -1055 | PI_INVALID_PASSWORD | Invalid password |
| -1056 | PI_OPM_COM_ERROR | Error during communication with OPM (Optical Power Meter), maybe no OPM connected |
| -1057 | PI_WAVE_EDITOR_WRONG_PARAMNUM | WaveEditor: Error during wave creation, incorrect number of parameters |
| -1058 | PI_WAVE_EDITOR_FREQUENCY_OUT_OF_RANGE | WaveEditor: Frequency out of range |
| -1059 | PI_WAVE_EDITOR_WRONG_IP_VALUE | WaveEditor: Error during wave creation, incorrect index for integer parameter |
| -1060 | PI_WAVE_EDITOR_WRONG_DP_VALUE | WaveEditor: Error during wave creation, incorrect index for floating point parameter |
| -1061 | PI_WAVE_EDITOR_WRONG_ITEM_VALUE | WaveEditor: Error during wave creation, could not calculate value |
| -1062 | PI_WAVE_EDITOR_MISSING_GRAPH_COMPONENT | WaveEditor: Graph display component not installed |
| -1063 | PI_EXT_PROFILE_UNALLOWED_CMD | User Profile Mode: Command is not allowed, check for required preparatory commands |
| -1064 | PI_EXT_PROFILE_EXPECTING_MOTION_ERROR | User Profile Mode: First target position in User Profile is too far from current position |
| -1065 | PI_EXT_PROFILE_ACTIVE | Controller is (already) in User Profile Mode |
| -1066 | PI_EXT_PROFILE_INDEX_OUT_OF_RANGE | User Profile Mode: Block or Data Set index out of allowed range |
| -1067 | PI_PROFILE_GENERATOR_NO_PROFILE | ProfileGenerator: No profile has been created yet |
| -1068 | PI_PROFILE_GENERATOR_OUT_OF_LIMITS | ProfileGenerator: Generated profile exceeds limits of one or both axes |
| -1069 | PI_PROFILE_GENERATOR_UNKNOWN_PARAMETER | ProfileGenerator: Unknown parameter ID in Set/Get Parameter command |
| -1070 | PI_PROFILE_GENERATOR_PAR_OUT_OF_RANGE | ProfileGenerator: Parameter out of allowed range |
| -1071 | PI_EXT_PROFILE_OUT_OF_MEMORY | User Profile Mode: Out of memory |
| -1072 | PI_EXT_PROFILE_WRONG_CLUSTER | User Profile Mode: Cluster is not assigned to this axis |

| | | |
|-------|----------------------------------|---|
| -1073 | PI_UNKNOWN_CLUSTER_IDENTIFIER | Unknown cluster identifier |
| -1074 | PI_INVALID_DEVICE_DRIVER_VERSION | The installed device driver doesn't match the required version. Please see the documentation to determine the required device driver version. |
| -1075 | PI_INVALID_LIBRARY_VERSION | The library used doesn't match the required version. Please see the documentation to determine the required library version. |
| -1076 | PI_INTERFACE_LOCKED | The interface is currently locked by another function. Please try again later. |

10. Index

- *IDN? 30
- AVG 24
- AVG? 28
- axes parameter 12
- BDR 24
- BDR? 29
- BOOL 14
- boolean values 14
- c strings 14
- Communication Initialization 15
- DCO 24
- DCO? 29
- DEL 25
- DIP? 29
- dynamic loading of a DLL 11
- E-516 Commands 21
- E816_EnumerateUSB 16
- E816_AVG 24
- E816_BDR 24
- E816_CloseConnection 16
- E816_ConnectRS232 16
- E816_ConnectUSB 16
- E816_DCO 24
- E816_DEL 25
- E816_END 26
- E816_FindOnRS 17
- E816_GcsCommandset 19
- E816_GcsGetAnswer 19
- E816_GcsGetAnswerSize 20
- E816_GetError 17
- E816_InterfaceSetupDlg 17
- E816_IsConnected 18
- E816_IsRunningMacro 25
- E816_MAC_BEG 25
- E816_MAC_DEF 25
- E816_MAC_DEL 26
- E816_MAC_NSTART 26
- E816_MAC_qDEF 27
- E816_MAC_qFREE 27
- E816_MAC_START 27
- E816_MOV 27
- E816_MVR 28
- E816_MVT 28
- E816_qAVG 28
- E816_qBDR 29
- E816_qDCO 29
- E816_qDIP 29
- E816_qERR 30
- E816_qHLP 30
- E816_qI2C 30
- E816_qIDN 30
- E816_qMAC 31
- E816_qMOV 31
- E816_qMVT 31
- E816_qONT 32
- E816_qOVF 32
- E816_qPOS 32
- E816_qSAI 32
- E816_qSCH 33
- E816_qSPA 33
- E816_qSSN 34
- E816_qSVA 34
- E816_qSVO 34
- E816_qSWT 34
- E816_qVOL 35
- E816_RST 35
- E816_SCH 35
- E816_SetErrorCheck 18
- E816_SPA 36
- E816_SVA 37
- E816_SVO 37
- E816_SVR 37
- E816_SWT 38
- E816_TranslateError 18
- E816_WPA 38
- E816_WTO 38
- E816_WTOTimer 39
- ERR? 30
- Error codes 40
- FALSE 14
- GetProcAddress - Win32 API function 11
- HLP? 30
- I2C? 30
- interface settings 18
- LIB - static import library 10
- linking a DLL 10
- LoadLibrary - Win32 API function 11
- MAC BEG 25
- MAC DEF 25
- MAC DEF? 27
- MAC DEL 26
- MAC END 26
- MAC FREE? 27
- MAC START 26, 27
- MAC? 31
- module definition file 10
- MOV 27
- MOV? 31
- MVR 28
- MVT 28
- MVT? 31
- NULL 14
- ONT? 32
- OVF? 32
- POS? 32
- RS-232 settings 18
- RST 35
- SAI? 32
- SCH 35
- SCH? 33
- settings for RS-232 18

SPA 36
SPA? 33
SSN? 34
static import library 10
SVA 37
SVA? 34
SVO 37
SVO? 34

SVR 37
SWT 38
SWT? 34
TRUE 14
VOL? 35
WPA 38
WTO 38, 39

