


## PZ121E Software Manual



## E-816 LabView Driver Library

Release: 5.3.0      Date: 2007-06-28



This document describes software for use with the following product(s):

- E-816 Computer Interface and Command Interpreter Submodule (firmware version 2.11 or newer) for PZT Controllers



© Physik Instrumente (PI) GmbH & Co. KG  
 Auf der Römerstr. 1 · 76228 Karlsruhe, Germany  
 Tel. +49 721 4846-0 · Fax: +49 721 4846-299  
 info@pi.ws · www.pi.ws

# Table of Contents

- 0. DISCLAIMER .....2**
- 1. INTRODUCTION .....2**
  - 1.1. PI GENERAL COMMAND SET (GCS).....2
  - 1.2. SCOPE OF THIS MANUAL.....3
  - 1.3. VI STRUCTURE .....3
  - 1.4. WORKING WITH TWO PI PRODUCTS WHICH UNDERSTAND PI'S GENERAL COMMAND SET (GCS) IN LABVIEW .....6
  - 1.5. FIRST STEPS FOR GCS-COMPATIBLE PI CONTROLLERS .....7
- 2. LOW LEVEL VIS .....27**
  - 2.1. COMMUNICATION VIs (“COMMUNICATION.LLB”):.....27
  - 2.2. GENERAL COMMAND VIs (“GENERAL COMMAND.LLB”):.....33
  - 2.3. PZT SPECIFIC VIs (“PZT VOLTAGE.LLB”).....46
  - 2.4. SPECIAL COMMANDS (“SPECIAL COMMAND.LLB”).....50
  - 2.5. OLD COMMANDS AND COMMANDS WITH ALTERNATE IMPLEMENTATIONS (“OLD COMMANDS.LLB”) .....58
  - 2.6. FILE HANDLING VIs (“FILE HANDLING.LLB”) .....59
  - 2.7. LIMIT- AND REFERENCE-SPECIFIC COMMANDS (“LIMITS.LLB”).....61
  - 2.8. COMMANDS FOR OPTICAL OR ANALOG SIGNALS (“OPTICAL OR ANALOG INPUT.LLB”) .....62
  - 2.9. SUPPORT VIs FOR SCANNING ALGORITHMS (“SCAN SUPPORT.LLB”).....63
  - 2.10. WAVE-GENERATOR-SPECIFIC COMMANDS (“WAVEGENERATOR.LLB”).....63
  - 2.11. ANALOG CONTROLLER VIs (“ANALOG CONTROL.LLB”) .....64
  - 2.12. SUPPORT VIs (“SUPPORT.LLB”) .....66
- 3. HIGH LEVEL VIS .....76**
  - 3.1. PI TERMINAL.VI.....76
  - 3.2. E816\_SIMPLE\_TEST.VI .....80
  - 3.3. E816\_CONFIGURATION\_SETUP.VI.....81
  - 3.4. E816\_SAMPLE\_APPLICATION\_1.VI.....83
  - 3.5. E816\_SAMPLE\_APPLICATION\_1A.VI.....84
  - 3.6. SHOW\_SAVE\_LOAD\_XY\_DATA.VI .....85
- 4. PI SYSTEMS CURRENTLY SUPPORTED BY THIS DRIVER SET.....86**
- 5. APPENDIX A .....88**
- 6. INDEX.....96**

© Copyright 2007 by Physik Instrumente (PI) GmbH & Co. KG

Physik Instrumente (PI) GmbH & Co. KG is the owner of the following company names and trademarks: PI®, PLine®, NEXLINE®, Hyperbit™, Mercury™, Mercury™ Step

Devices or processes mentioned in this manual are covered by the following patents: U.S. Patent 6,950,050, US-patent No. 6,765,335, US-patent No. 6,800,984, German patent No. 10148267, German patent No. 19945042

The following designations are protected company names or registered trademarks of third parties: Windows®, LabVIEW™

Release: 5.3.0

File:E816\_GCSTLabVIEW\_PZ121E\_530.doc, 5072896 Bytes

## 0. Disclaimer


This software is provided “as is”. Physik Instrumente (PI) does not guarantee that this software is free of errors and will not be responsible for any damage arising from the use of this software. The user agrees to use this software on his own responsibility.

## 1. Introduction

The LabVIEW software consists of a collection of virtual instrument (VI) drivers. All functionality involves invoking one or more VIs with the appropriate parameter and global variable settings.

These VIs are provided to ease the task of programming your application. They, and the accompanying documentation, assume a prior knowledge of proper LabVIEW programming techniques. The provided “Simple Test” and “Configuration Setup” VIs help to solve the essential initialization steps, but are not intended to provide an out-of-the-box, universal solution to a particular application.

To minimize the need for consulting the manual during programming, each VI comes with a detailed VI description that appears in the *Context Help* window when you move the cursor over the VI icon. Use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window.



LabVIEW 7.1 or higher and NI-VISA 3.6 or higher must be installed prior to using this driver set. To control an analog system, DAQmx 8.3 or higher must also be installed.

### 1.1. PI General Command Set (GCS)

This VI driver set supports the *PI General Command Set*, which is based on ASCII communication with well-defined commands and replies. This makes it possible to control different PI systems, such as the *E-516 Display Module* or the *C-880 Multi-Axis Controller*, with only one driver set simply by “wiring” the correct command parameters to the associated VIs.

#### Translation Libraries

To control PI systems with a native command set that is not compatible with the *PI General Command Set*, e.g. the *E-710 Digital Piezo Controller* or the *C-843 Motion Control Board*, controller-specific libraries are used. Each such library translates *PI General Command Set* commands to the controller’s native language. **There is also a universal library which adds this functionality: GCSTranslator.dll; it must be installed on the computer in the GCS\_LabVIEW\Low Level folder, no matter whether the system being controlled is *PI General Command Set* compatible or not.**

For these and certain other systems (such as PC add-on cards), the required system-specific DLLs and data files (e.g. PIStages.dat) must be properly installed. If you install this driver set from within the setup program of the PI software CD ROM, this installation is done automatically. If you want to install this driver set manually, please run "GCSLibrarySetup.exe" from the CD-ROM that came with your system. This setup tool makes sure that all necessary libraries and their data files are correctly registered in the Windows™ environment and can be found by the GCS drivers (if LabVIEW still cannot find PIStages.dat, it may be because it is marked read-only. To see, open Microsoft Explorer, right-click the file PIStages.dat and select *Properties*. Make sure that the *read-only* attribute is not checked.)

To control a system using an analog interface DAQmx 8.3 and a DAQmx-compatible National Instruments DAC card must be installed.

Once the libraries and data files for the system to control are installed, this LabVIEW driver set can be used to control a non-GCS-compatible system just like any GCS-compatible system, and PCI/ISA-based controller boards by selecting "DLL" as communication interface (see Section "First Steps for GCS-Compatible PI Controllers" on p. 7 and the "XXXX\_Configuration\_Setup.vi" (with XXXX being the PI product number of your system) in section 3).

### Units and GCS

The GCS system uses physical units of measure. Most controllers and GCS software have default conversion factors chosen to convert hardware-dependent units (e.g. encoder counts) into mm or degrees, as appropriate. These defaults are generally taken from a database of stages that can be connected. The direction of motion associated with positive and negative relative moves can also be controlled by parameter settings. In some cases an additional scale factor can be applied, making a second physical unit available without overwriting the conversion factor for the first. It is also sometimes possible to enter a conversion factor as numerator and denominator of a fraction, reducing the number of digits and outside calculations needed for high-precision entry of gearhead system values. See the DFF.vi and SPA.vi command descriptions (if supported by your PI controller), taking special note of the sections referring specifically to your controller.

## 1.2. Scope of This Manual

This manual covers only VIs which can be used with the product with which it came.

## 1.3. VI Structure

The folder structure of the LabVIEW drivers consists of the main folder "GCS\_LabVIEW" with the sub-folder "Low Level".

The main folder "GCS\_LabVIEW" contains a terminal VI (for command based systems), a configuration VI (XXXX\_Configuration\_Setup.vi with XXXX being the PI product number of your system), a simple test VI, and, if available, several sample programs.

The sub-folder "Low Level" contains VIs for the following functions:

- Establishing communication with different PI systems which support the PI General Command Set via RS-232, GPIB or TCP/IP interfaces, or with analog systems
- Defining the parameter IDs of the connected axes

- Sending and receiving ASCII characters to/from the specified system or setting and reading voltages for an analog system
- Sending system-specific commands (system-specific commands are separated into function-specific LLBs).

Additionally, the sub-folder “Low Level” contains GCSTranslator.dll.

Following the data flow concept of LabVIEW, all VIs have their wiring inputs on the left side and their wiring outputs on the right side of each connector pane. For quick integration, this **connector pane** in most cases has the following pattern:

1					15
2	7	9	11	13	16
3					17
4					18
5	8	10	12	14	19
6					20

The terminals are assigned as follows (if the mentioned, control/indicator is present in one of the supplied libraries):

- 1 System number
- 2 Optical board, Interface, or other main input control
- 3 Axes to query, Affected axes, Number of systems, or other main input control
- 4 All axes?, Invert order?, or other main input control
- 5 Axis identifier?, No. of digits, or other main input control
- 6 Error in
- 7 Parameter number, Without axis ID?, or other input control
- 8 Step size, or other input control
- 9 AA step size, or other input control
- 10 Input control
- 11 Input control or output indicator
- 12 Input control or output indicator
- 13 Input control or output indicator
- 14 Input control or output indicator
- 15 Hidden error, Connected axes, String read, or other main output indicator
- 16 Axes to query out, Bytes read, or other main output indicator
- 17 No. of rows, or other main output indicator
- 18 Output indicator
- 19 Output indicator
- 20 Error out

Also note that this driver set does not use the standard LabVIEW error numbers recommended by National Instruments, but rather those used by PI controllers. As a result, the error texts displayed by LabVIEW will not describe the error accurately. Use “GCSTranslateError.vi” to get the description of a PI GCS error

number. Some VIs use an additional indicator Controller error to indicate that the selected system has been queried for a controller error with „ERR?“ and reported an error number  $\neq$  zero.

See also chapter 5 on p. 88 for a summary of error numbers produced by this driver set.

In LabVIEW, uncheck *Enable automatic error handling dialogs* in *Tools*→*Options*→*New and Changed in 7.x* to prevent that LabVIEW suspends execution and displays an error dialog box for any error that occurs during the execution of the VIs.

### **Important:**

Before running any VIs to control a connected system, **“XXXX\_Configuration\_Setup.vi”** (located in the main folder, with XXXX being the PI product number of your system) must be run. This initialization VI performs all necessary steps automatically:

1. It opens the communications port,
2. It defines the IDs for the connected axes,
3. It references the connected stages (if appropriate), depending on if the controller requires a referencing before axes can be moved and on your custom settings,
4. It defines the controller name.

After these steps all parameters are saved into global variables, so that other VIs invoked during the same LabView session can access this data at runtime.

As the initialization is a complex procedure which uses a large number of sub-VIs, **XXXX\_Configuration\_Setup.vi** is password-protected, meaning that you cannot see or modify the diagram. In this way, the full initialization is packed into one single and fully tested procedure which you simply insert into your own application program. For security reasons as well as your convenience, we recommend that you not modify this VI.

For testing a PI system using a command-based interface, the easiest method is to call “PI Terminal.vi”, which is located in the “GCS\_LabVIEW” main folder. This is a “stand-alone” routine that calls “PI Ask for Communication Parameters.vi” first and then opens the specified communications ports. It does not, however, define the connected axes of the (motion) systems.

A more system-specific sample VI is “XXXX\_Simple\_Test.vi” (with XXXX being the PI product number of your system), also located in the “GCS\_LabVIEW” main folder. It is available both for command-based and analog systems.

#### 1.4. Working with two PI products which understand PI's General Command Set (GCS) in LabVIEW

When installing the LabVIEW programming support for two different PI products, there are two "Low Level" folders installed, one in each product-specific LabVIEW driver set. This is because every product comes with only the VIs which are used with the product. Another product may have different libraries or different library contents due to the product supporting more or fewer functions. When working with two product-specific LabVIEW driver set installations on one computer, it is important to make sure that LabVIEW always uses the right libraries.

- a) When working separately with two products, the "Low Level" folder of each product must be located in the same folder as the product-specific main VI which calls sub-VIs from the product-specific driver set. Otherwise LabVIEW will start searching for sub VIs wherever it finds them, which may result in version conflicts and "broken Run" arrows. Please make sure that no VIs are saved under LabVIEW's own "user.lib" sub-folder. If they are LabVIEW will always find them there first, which will cause errors in many cases.
- b) When working with two products in parallel, the libraries should be combined. Under LabVIEW 7.1 (but also under older LabVIEW versions), this is quite easy using LabVIEW's "Library manager", which can be found on the "Tools" menu. First, make a backup copy of the older library you want to combine with the newer one. In Library manager, open the newer library (e.g. "Special.lib" from the C-865 release) in the left window, and the older library (e.g. "Special.lib" from the older C-843 release) in the right window. Then choose "Show dates", "Disable files with identical dates", and "Sort alphabetically". This will show you only the VIs which have different file dates or which are only present in one of these libraries, but will not show any identical VIs. Now select all VIs which are still shown on the left window and copy them to the right window. In this way, you get a library with all VIs used by both product driver sets, and the newest version of each. Do this for all libraries in the low level folder. Make sure to work thereafter with the combined libraries instead of the product-specific libraries.

## 1.5. First Steps for GCS-Compatible PI Controllers

### 1.5.1. Analog systems

*Step 1:* To control an analog system, DAQmx 8.3 and a DAQmx compatible National Instruments DAC card must be installed. To use the patented HyperBit technology (U.S. Patent 6,950,050; international patents pending), which makes it possible to control an analog system with a physical resolution higher than the nominal output resolution of the DAC board, a password must be obtained from PI. Please contact your local sales representative for details about PIs HyperBit technology.

*Step 2:* Before powering up the controller/amplifier, make sure that any internal jumpers and switches are properly set. In particular, the control input voltage range must be set properly. See the respective User Manuals for details.

*Step 3:* With the controller still powered down, connect each positioner to the controller axis for which it was calibrated (usually marked on a label on the controller).

*Step 4:* With the controller still powered down, connect Analog IN (or Control IN) and Sensor Monitor lines from the controller axes to be under analog control to the DAC card in the host PC. If the controller does not have a Sensor Monitor Output, connect the Analog Out line of the DAC card to the corresponding Analog In line of the card.

*Step 5:* If the controller also has a command interface, and if commands are necessary to activate analog-input control, then those commands must be sent from any PC (could be the PC with the DAC card) using any software that supports the command interface (usually including LabVIEW). Most controllers are or can be configured with analog control as the power-up or factory default. See the controller User Manual and associated software manuals for details.

*Step 6:* Make sure all manual settings on the controller are correct. In particular, the servo state must be set as desired and the DC-Offset potentiometer, if present and not deactivated, should be set to 0.

*Step 7:* Power up the controller.

*Step 8 (advanced users can skip this step):* To check communication between the analog system and the host PC, run "Analog\_Simple\_Test.vi". This VI will return the axis ID of one connected axis, its movement range and its current position value expressed in volts on a relative scale corresponding to the control input range. See Section 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 9:*

#### **WARNING: Analog\_Configuration\_Setup.vi May Cause Move**

When you start "Analog\_Configuration\_Setup.vi" with All axes? = TRUE and Move to middle? = TRUE or Offset/Gain correction = TRUE, the VI will output voltages on the selected AO channels. It is therefore important to make sure that items connected to or mounted on stages connected to the corresponding analog channels of the controller cannot be damaged by such a move.

If an axis under analog control has a DC-offset knob on the controller or amplifier, make sure that it is in the zero-offset position (usually full counter-clockwise).



To begin controlling one or more analog channels with this driver set, run “Analog\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment:

- Definition of axis IDs,
- Definition of DAQmx input and output tasks,
- Determination of optimum AO voltage range and AO range offset for maximum physical bit resolution in given voltage range,
- Offset and gain correction (if appropriate) and
- Definition of the controller name.

During your testing phase (when you simply run the VIs without wiring them together into a program) do not close “Analog\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. The VI will stay idle when all tasks are finished and you can run all command VIs separately afterwards. Do not forget to press the **STOP** button when you have finished working manually with this driver set.

When programming your application, you should include “Analog\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “Analog\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

When working with more than one axis and commanding a subset of them, the DAQmx task will always command all connected axes. The axes to command will be commanded to their given target positions and all other axes to their current positions, which may result in a small motion of the axes which were not commanded, due to drift. This occurs because a DAQmx task can only command all physical channels (i.e. axes) at once and not single channels (axes) separately. Voltages commanded or read with VOL.vi and VOL?.vi are the control voltages, not the resultant amplified and servo-controlled voltages seen by the piezos.

If you generate too many HyperBits by setting the PWM rate too high, the rate capacity of the card or the load capacity of the computer's bus can be exceeded. This may result in a runtime error, or sluggish operation during HyperBit analog output. Solutions: set your VIs to request a lower PWM rate; check your NIMax configuration settings to ensure DMA is being used; or use a faster card. Keep in mind that DAC granularity is only one of many possible limiters to system resolution. Ambient noise and vibration and electronic/amplifier noise, for example, also limit what your system can achieve. There is no point generating HyperBits below the fundamental noise floor.

If your controller has a digital display, values displayed on the display may differ slightly from values reported by LabVIEW because of the different measurement system, data conversion and software-internal offset- and gain corrections.

GCS syntax version: 2.0

**1.5.2. C-702**

*Step 1:* The C-702 controller is delivered pre-configured. Before you start, please check that the current configuration matches your stage connections. See the C-702 User Manual for a detailed description of this step.

*Step 2 (advanced users can skip this step):* To check communication between the C-702 controller and the host PC, run "C702\_Simple\_Test.vi". This VI will return the ID string of the C-702 controller, the axis IDs of the connected axes, and their current positions. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions. Please make sure that you have all reported axes connected. If you want to work with only some of these axes, remember the IDs of those axes so that you can enter them in the Axes to move control in "C702\_Configuration\_Setup.vi"; thereafter the other axes will not be moved when executing "C702\_Configuration\_Setup.vi".

*Step 3:*

**WARNING: C702\_Configuration\_Setup.vi May Cause Move**

When you start "C702\_Configuration\_Setup.vi" with All axes? = TRUE, the VI will automatically determine which axes have a reference switch and which have limit switches and, if the referencing mode of these axes is ON, will move these stages to these sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stages or not) can be switched off (see chapter 3). See description of RON for details and warnings.

To control one or more C-702 controllers with this driver set, run "C702\_Configuration\_Setup.vi". This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "C702\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "C702\_Configuration\_Setup.vi" as an initialization VI in your software. See chapter 3 for a detailed description of "C702\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel.

GCS syntax version: 1.0

**1.5.3. C-843**

To control one or more C-843 boards with this driver set, "C843\_GCS\_DLL.dll", "MC.dll", "PiStages.dat" and the C-843 device driver must be installed on your computer. See chapter 1.1 for information about methods for proper installation of the first three items. A description of how to install the C-843 device driver is given in the C-843 User Manual. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the C-843 board in the host PC, run "C843\_Simple\_Test.vi". This VI will return the ID string of the C-843 board and the axis IDs of the connected axes. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: C843\_Configuration\_Setup.vi May Cause Move**

When you start "C843\_Configuration\_Setup.vi" with All axes? = TRUE, the VI will automatically determine which axes have a reference switch and which have limit switches and, if the referencing mode of these axes is ON, will move these stages to these sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stages or not) can be switched off. See description of RON for details and warnings.

Open "C843\_Configuration\_Setup.vi". Select your C-843 board (2- or 4-axis version, board number) and leave "Use dialog to define connected stages" = TRUE. Run the VI. In the following screen, specify which stages you have connected to which axes and press OK. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "C843\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "C843\_Configuration\_Setup.vi" as an initialization VI in your software. See chapter 3 for a detailed description of "C843\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

If you do not find your stage in the drop-down list, press CANCEL. You can then either define a User Stage with the Stage Editor, or you can contact PI to see about getting a new stage list: the "PiStages.dat" file contains all relevant stage parameters.

Default axis names are 1 to 4, but can be changed using "SAI.vi".

GCS syntax version: 1.0

**1.5.4. C-843.PM**

With this driver set, "C843\_PM\_GCS\_DLL.dll", "MC.dll", "PiStages.dat" and the C-843 device driver must be installed on your computer if you wish to control axes on PIs linear piezo motor stages. It can be used with axes on other motorized stages connected to the same or other C-843 boards in the same machine. See chapter 1.1 for information about methods for proper installation of the first three items. A description of how to install the C-843 device driver is given in the C-843 User Manual. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the C-843 board in the host PC, run "C843\_PM\_Simple\_Test.vi". This VI will return the ID string of the C-843 board and the axis IDs of the connected axes. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: C843\_PM\_Configuration\_Setup.vi May Cause Move**

When you start "C843\_PM\_Configuration\_Setup.vi" with All axes? = TRUE, the VI will automatically determine which axes have a reference switch and which have limit switches and, if the referencing mode of these axes is ON, will move these stages to these sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stages or not) can be switched off. See description of RON for details and warnings.

Open "C843\_PM\_Configuration\_Setup.vi". Select your C-843 board (2- or 4-axis version, board number) and leave "Use dialog to define connected stages" = TRUE. Run the VI. In the following screen, specify which stages you have connected to which axes and press OK. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "C843\_PM\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "C843\_PM\_Configuration\_Setup.vi" as an initialization VI in your software. See chapter 3 for a detailed description of "C843\_PM\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

If you do not find your stage in the drop-down list, press CANCEL. You can then either define a User Stage with the Stage Editor, or you can contact PI to see about getting a new stage list: the "PIStages.dat" file contains all relevant stage parameters.

Default axis names are 1 to 4, but can be changed using "SAI.vi".

GCS syntax version: 1.0

**1.5.5. C-848**

*Step 1:* The C-848 controller is delivered pre-configured. Before you start, please check that the current configuration matches your stage connections. See the C-848 User Manual for a detailed description of this step.

*Step 2 (advanced users can skip this step):* To check communication between the C-848 controller and the host PC, run “C848\_Simple\_Test.vi”. This VI will return the ID string of the C-848 controller, the axis IDs of the connected axes, and their current positions. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions. Please make sure that you have all reported axes connected. If you want to work with only some of these axes, remember the IDs of those axes so that you can enter them in the Axes to move control in “C848\_Configuration\_Setup.vi”; thereafter the other axes will not be moved when executing “C848\_Configuration\_Setup.vi”.

*Step 3:*

**WARNING: C848\_Configuration\_Setup.vi May Cause Move**

When you start “C848\_Configuration\_Setup.vi” with All axes? = TRUE, the VI will automatically determine which axes have a reference switch and which have limit switches and, if the referencing mode of these axes is ON, will move these stages to these sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stages or not) can be switched off (see chapter 3). See description of RON for details and warnings.

To control one or more C-848 controllers with this driver set, run “C848\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “C848\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement “C848\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “C848\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

If you have an older C-848 with a joystick connection, before using a directly connected joystick, calibrate it by running “PI Terminal.vi”. Type “JEN CALIB” and follow the instructions on the screen.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel.

GCS syntax version: 1.0

**1.5.6. C-865**

To control one or more C-865s with this driver set, “C865\_GCS\_DLL.dll”, “MC\_C865.dll”, and “PiStages.dat” must be installed on your computer. See Section 1.1 for information about methods for proper installation of the first three items. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the C-865 controller, run “C865\_Simple\_Test.vi”. This VI will return the ID string of the C-865 controller. See Section 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: C865\_Configuration\_Setup.vi May Cause Move**

When you start “C865\_Configuration\_Setup.vi” with Is axis connected and can be moved? = TRUE, the VI will automatically determine if the connected axis has a reference switch or limit switch and, if the referencing mode of this axis is ON, will move the stage to one of the switches. It is therefore important to make sure that items connected to or mounted on the connected stage will not be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stage or not) can be switched off. See description of RON for details and warnings.

Open “C865\_Configuration\_Setup.vi”. Select the RS-232 settings (port number and appropriate baudrate) and leave Use dialog to define connected stage = TRUE. Run the VI. In the following screen, specify which stage you have connected and press OK. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of the axis ID, the initialization of the connected stage, including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “C865\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement “C865\_Configuration\_Setup.vi” as an initialization VI in your software. See Section 3 for a detailed description of “C865\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

If you do not find your stage in the drop-down list, press CANCEL. You can then either define a User Stage with the Stage Editor, or you can contact PI to see about getting a new stage list: the “PiStages.dat” file contains all relevant stage parameters.

Default axis name is “1”, but can be changed using “SAI.vi”.

If the controller does not respond, please reset it using the reset button (unlabeled) on the rear panel of the C-865 controller.

See also “C865\_Sample\_Application\_1.vi” and “C865\_Sample\_Application\_1a.vi” as sample VIs showing how to implement “C865\_Configuration\_Setup.vi” as the initialization VI for the C-865 in your application.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel.

GCS syntax version: 1.0

**1.5.7. C-866**

To control one or more C-866s with this driver set, "C866\_GCS\_DLL.dll", "MC\_C866.dll" and "PiStages.dat" must be installed on your computer. See Section 1.1 for information about methods for proper installation of the first three items. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the C-866 controller, run "C866\_Simple\_Test.vi". This VI will return the ID string of the C-866 controller. See Section 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: C866\_Configuration\_Setup.vi May Cause Move**

When you start "C866\_Configuration\_Setup.vi" with Is axis connected and can be moved? = TRUE, the VI will automatically determine if the connected axis has a reference switch or limit switch and, if the referencing mode of this axis is ON, will move the stage to one of the switches. It is therefore important to make sure that items connected to or mounted on the connected stage will not be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stage or not) can be switched off. See description of RON for details and warnings.

Open "C866\_Configuration\_Setup.vi". Select the correct interface settings and leave Use dialog to define connected stage = TRUE. Run the VI. In the following screen, specify which stage you have connected and press OK. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of the axis ID, the initialization of the connected stage, including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "C866\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "C866\_Configuration\_Setup.vi" as an initialization VI in your software. See Section 3 for a detailed description of "C866\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

If you do not find your stage in the drop-down list, press CANCEL. You can then either define a User Stage with the Stage Editor, or you can download a newer version of the stage list file "PiStages.dat" (which contains all relevant stage parameters) from our homepage [www.pi.ws](http://www.pi.ws) (see C-866 User Manual for a download instruction).

Default axis name is "1", but can be changed using "SAI.vi".

If the controller does not respond, please reset it using the recessed Reset button on the front panel.

See also "C866\_Sample\_Application\_1.vi", "C866\_Sample\_Application\_1a.vi" and "C866\_Sample\_Application\_2.vi" as sample VIs showing how to implement "C866\_Configuration\_Setup.vi" as the initialization VI for the C-866 in your application.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel. GCS syntax version: 1.0

**1.5.8. C-880**

*Step 1:* The C-880 controller is delivered pre-configured. Before you start, please check that the current configuration matches your stage connections. See the C-880 User Manual for a detailed description of this step.

*Step 2 (advanced users can skip this step):* To check communication between the C-880 controller and the host PC, run "C880\_Simple\_Test.vi". This VI will return the ID string of the C-880 controller, the axis IDs of the connected axes, and their current positions. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions. Please make sure that you have all reported axes connected. If you want to work with only some of these axes, remember the IDs of those axes so that you can enter them in the Axes to move control in "C880\_Configuration\_Setup.vi"; thereafter the other axes will not be moved when executing "C880\_Configuration\_Setup.vi".

*Step 3:*

**WARNING: C880\_Configuration\_Setup.vi May Cause Move**

When you start "C880\_Configuration\_Setup.vi" with All axes? = TRUE, the VI will automatically determine which axes have a reference switch and which have limit switches and, if the referencing mode of these axes is ON, will move these stages to these sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stages or not) can be switched off (see chapter 3). See description of RON for details and warnings.

To control one or more C-880 controllers with this driver set, run "C880\_Configuration\_Setup.vi". This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "C880\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "C880\_Configuration\_Setup.vi" as an initialization VI in your software. See chapter 3 for a detailed description of "C880\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Before using a joystick connected to the C-880 controller, calibrate the joystick by running "PI Terminal.vi". Type "JEN CALIB" and follow the instructions on the screen.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel.

GCS syntax version: 1.0



**1.5.9. C-880K005**

To control a C-880K005 controller with this driver set, you must perform the following steps:

1. Run "PI Open Interface.vi"
2. Run "Multix axis assignment.vi".
3. Reference all connected stages using "PI\_Multix.vi" with Command = REF and All axes? = TRUE. If no referencing is desired, referencing mode can be switched off using Command = RON. With referencing mode off, only relative moves can be commanded (using Command = MVR), unless the actual position is set with Command = POS.vi. Thereafter both relative and absolute moves can be commanded.

OR

1. Run C880K005\_Simple\_Test.vi
2. Proceed as in step 3 above.

After these steps, a number of selected commands can be used by calling "PI\_Multix.vi".

The control concept of the C-880K005 is based on the assumption that several C-880 multi-axis motion controllers are connected to the C-880K005, which is commanded over a single interface from the host PC. In this way, the number of axes to command is not limited by the number of connectors available on a single C-880. To ease handling so many axes, the user does not have to worry about the individual C-880 controllers, but only the C-880K005 controller with axes 1 to N, N being the sum of all axes connected to all interconnected C-880s.

The C-880K005 is called the "controller" and handles the communication to all connected C-880 controllers, which are called VControllers (virtual controllers). "PI\_Multix.vi" must be used to send commands. For ease of operation, when running "Multix axis assignment.vi", all connected axes of all connected C-880 controllers are queried and the axis IDs 1 to N are assigned to these axes automatically.

A C-880 connected to the C-880K005 can be directly commanded by setting it active ("ACT.vi"). The C-880K005 communications controller then passes subsequent commands to the active C-880, except for commands which, by their nature, must be directly handled by the C-880K005 (e.g. WAA).

**Example:** Three C-880 controllers are connected to the C-880K005, and each C-880 controller has 12 axes designated A to L on each of the C-880's. These ID's are taken as VAxis IDs and the axis IDs 1 to 36 are assigned for the C-880K005 controller. To command axis A of C-880 1 (VController 1) and axis B of C-880 3 (VController 3), the user commands axes 1 and 26 in "PI\_Multix.vi"; the axis and value parsing is done internally.

See "C880K005\_Simple\_Test.vi" and "C880K005\_Configuration\_Setup.vi" for sample programs for the driver configuration of the C-880K005.

**1.5.10. E-516**

*Step 1 (advanced users can skip this step):* To check communication with the E-516 controller, run “E516\_Simple\_Test.vi”. This VI will return the ID string and the help string of the E-516 controller, the available axis IDs and positions of all axes. See Section 3 for a description of this VI and use the *Help→Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: E516\_Configuration\_Setup.vi May Cause Move**

When you start “E516\_Configuration\_Setup.vi” with Move all axes to middle? = TRUE, or Move all axes to middle? = FALSE and Axes to move = TRUE for some axes, the VI will move all axes or the selected axes to their middle positions. It is therefore important to make sure that items connected to or mounted on the connected stages will not be damaged by such a move.

Open “E516\_Configuration\_Setup.vi”. First select the interface settings (Interface = “RS232” or “GPIB”, RS232 settings = Portnumber and appropriate Baudrate, or GPIB settings = Bus and Address). Select whether a wave generator output is to be stopped (if you are not sure if there is any wave generator output running, leave this control TRUE) and whether the axes are to be moved to the midpoints of their travel ranges.

Then run the VI. It performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: definition of the axis IDs, the online setting of the controller, the servo setting of the axes and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “E516\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can include “E516\_Configuration\_Setup.vi” as an initialization VI in your software. See Section 3 for a detailed description of “E516\_Configuration\_Setup.vi” and use the *Help→Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Default position unit is  $\mu\text{m}$ , default velocity unit is  $\mu\text{m}/\text{ms}$ .

To use wave-generator-specific VI's, whose names start with “WGWaveEditor\_\*.vi”, “WGWaveEditor.dll” must be installed on your computer. During the installation of “WGWaveEditor.dll” “NTGraph.ocx” will be installed also. If “NTGraph.ocx” is not registered correctly in the Windows environment, the editor of “WGWaveEditor.dll” will not function.

See “E516\_WaveGenerator\_Sample\_Program.vi” for a sample program using these VIs.

GCS syntax version: 1.0

**1.5.11. E-710**

To control one or more E-710s with this driver set, "E7XX\_GCS\_DLL.dll" must be installed on your computer. See Section 1.1 for information about methods for a proper installation. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the E-710 controller, run "E710\_Simple\_Test.vi". This VI will return the ID string of the E-710 controller and the available axis IDs. See Section 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display a *Context Help* window with the control/indicator descriptions.

*Step 2:*

**WARNING: E710\_Configuration\_Setup.vi May Cause Move**

When you start "E710\_Configuration\_Setup.vi" with Perform autozero? = TRUE and/or Move to middle? = TRUE, the VI will perform an automated zero-point calibration of the connected linear axes and/or move these axes to their middle positions. It is therefore important to make sure that items connected to or mounted on the connected stages will not be damaged by such a move.

Open "E710\_Configuration\_Setup.vi". First select the interface settings (Interface = "RS232" or "GPIB", RS232 settings = Portnumber and appropriate Baudrate, or GPIB settings = Bus and Address), and specify if stages are connected. Select whether the automated zero-point calibration is to be performed (linear axes only), whether the Low voltage parameter is to be defined automatically or manually, and whether the axes are to be moved to the midpoints of their travel ranges.

**WARNING:**

The repeat write times of the internal non-volatile memory of the E-710 controller are limited. Do not use commands which write to the EEPROM (e.g. WPA, SEP) except when necessary. See User Manual for details.

Then run the VI. It performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of the axis IDs, the initialization of the axes (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "E710\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "E710\_Configuration\_Setup.vi" as an initialization VI in your software. See Section 3 for a detailed description of "E710\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Default axis IDs are "1", "2", "3", "4".

Default position unit is  $\mu\text{m}$ , default velocity unit is  $\mu\text{m}/\text{ms}$ .

Due to the emulation of the native E-710 command set, the execution of "MOV.vi" and "MVR.vi" is noticeably slower than that of the native firmware commands. Therefore this driver set provides the special non-GCS motion functions "NMOV.vi" and "NMVR.vi" for the case that your application requires quickest possible response to motion commands. See the VI reference of these two VIs for details.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows Control Panel.

GCS syntax version: 1.0

**1.5.12. E-753**

*Step 1:* The E-753 controller is delivered pre-configured. Before you start, please check that the current configuration matches your stage connections.

*Step 2 (advanced users can skip this step):* To check communication between the E-753 controller and the host PC, run “E753\_Simple\_Test.vi”. This VI will return the ID string of the E-753 controller, the axis ID and stage name of the connected axis, and its current position. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 3:*

**WARNING: E753\_Configuration\_Setup.vi May Cause Move**

When you start “E753\_Configuration\_Setup.vi” with Connected? = TRUE and Perform Autozero? = TRUE or Move to Middle? = TRUE, the VI will move the stage. It is therefore important to make sure that items connected to or mounted on the connected stage cannot be damaged by such a move. If a move is not desired, Connected? can be switched off (see chapter 3).

To control one or more E-753 controllers with this driver set, run “E753\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of the axis ID, the automated zero-point calibration (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “E753\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work.

When programming your application, you can implement “E753\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “E753\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions. See also “E753\_Sample\_Application\_1.vi” and “E753\_Sample\_Application\_2a.vi” as sample VIs showing how to implement your application using “E753\_Configuration\_Setup.vi”.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel.

Default position unit is  $\mu\text{m}$ , default velocity unit is  $\mu\text{m/s}$ .

Default axis ID is “1”.

GCS syntax version: 2.0

**1.5.13. E-755**

*Step 1:* The E-755 controller is delivered pre-configured. Before you start, please check that the current configuration matches your stage connections.

*Step 2 (advanced users can skip this step):* To check communication between the E-755 controller and the host PC, run “E755\_Simple\_Test.vi”. This VI will return the ID string of the E-755 controller, the axis ID of the connected axis, and its current position/voltage (depending on closed-loop or open-loop controller). See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 3:*

**WARNING: E755\_Configuration\_Setup.vi May Cause Move**

When you start “E755\_Configuration\_Setup.vi” with Connected? = TRUE, the VI will automatically determine if the axis can be referenced and, if it can, will move the stage to the positive or negative hard stop. It is therefore important to make sure that items connected to or mounted on the connected stage cannot be damaged by such a move. If referencing is not possible (because the controller is an open-loop device, or the hard stop of the connected stage cannot be used for referencing) or not desired, Connected? can be switched off (see chapter 3).

To control one or more E-755 controllers with this driver set, run “E755\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis ID, the initialization of the connected stage including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “E755\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work.

**Do not forget to run “Close connection if open.vi” with Close DaisyChain = TRUE before re-connecting this or any other controller connected to the same interface (except if you want to connect another device to the same DaisyChain).**

When programming your application, you can implement “E755\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “E755\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows control panel.

Default position unit is  $\mu\text{m}$ , default velocity unit is  $\mu\text{m/s}$ .

GCS syntax version: 2.0

**1.5.14. E-761**

To control one or more E-761 boards with this driver set, "E7XX\_GCS\_DLL.dll" must be installed on your computer. See Section 1.1 for information about methods for a proper installation. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the E-761 controller, run "E761\_Simple\_Test.vi". This VI will return the ID string of the E-761 controller and the available axis IDs. See Section 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: E761\_Configuration\_Setup.vi May Cause Move**

When you start "E761\_Configuration\_Setup.vi" with Perform autozero? = TRUE and/or Move to middle? = TRUE, the VI will perform an automated zero-point calibration of the connected linear axes and/or move these axes to their middle positions. It is therefore important to make sure that items connected to or mounted on the connected stages will not be damaged by such a move.

Open "E761\_Configuration\_Setup.vi". First select the Board number and specify if stages are connected. Select whether the automated zero-point calibration is to be performed (linear axes only), whether the Low voltage parameter is to be defined automatically or manually, whether the servo status is to be changed to ON, whether a wave generator output is to be stopped (if you are not sure if there is any wave generator output running, leave this control TRUE because AutoZero cannot be performed while a wave generator is running) and whether the axes are to be moved to the midpoints of their travel ranges.

Then run the VI. It performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of the axis IDs, the initialization of the axes (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close "E761\_Configuration\_Setup.vi"; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement "E761\_Configuration\_Setup.vi" as an initialization VI in your software. See Section 3 for a detailed description of "E761\_Configuration\_Setup.vi" and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Default axis IDs are "1","2","3". Default piezo channel IDs are "1", "2", "3", "4". Defaults sensor IDs are "1", "2", "3". Default analog input board no. is "4".

Default position unit is  $\mu\text{m}$ , default velocity unit is  $\mu\text{m}/\text{ms}$ .

Before using a joystick connected to the host PC, install joystick driver and calibrate joystick in the Windows Control Panel.

GCS syntax version: 1.0

**1.5.15. E-816****NOTE: Installation and hardware settings**

The setup on the E-816 CD offers the choice between a "digital" and an "analog" LabVIEW driver set. The digital driver set is required if you operate the E-816 over a "standard" PC interface (e.g. RS-232), while the analog driver set is needed if the E-816 is to be commanded by an analog control input signal which is generated by a DAC card in the PC. For mixed operation both driver sets must be installed. See below for how to install the driver sets manually and for the required hardware settings on the controller in which the E-816 is integrated.

See "Analog systems" on p. 7 for more information regarding the analog driver set.

**Operation with analog control input only ("analog operation"):**

To install the analog LabVIEW driver set manually, copy the \E-816\_GCS\_LabVIEW\_analog directory into the \Programme\PIE-816\ directory.

For analog operation, the servo must be on, and the controller hardware must be configured properly:

E-621: The DIP switches on the front panel of the module must be set as follows (switch 1 is at the top, and the ON position is on the left): sw. 1 ON, sw. 2 OFF, sw. 3 ON, sw. 4 OFF.

E-625: The DIP switches on the front panel must be set as follows (switch 1 is on the left, and the ON position is down): sw. 1 ON, sw. 2 OFF, sw. 3 ON, sw. 4 OFF.

E-665: The toggle switches on the front panel must be set to "Analog" and "Servo ON".

See the User Manual of your controller hardware for more information.

**Operation via standard PC interface only ("digital operation", via RS-232):**

To install the digital LabVIEW driver set manually, copy the \E-816\_GCS\_LabVIEW\_digital directory into the \Programme\PIE-816\ directory.

Controller hardware settings:

E-621: The DIP switches on the front panel of the module must be set as follows (switch 1 is at the top, and the ON position is on the left): sw. 1 OFF, sw. 2 ON, sw. 3 OFF, sw. 4 ON.

E-625: The DIP switches on the front panel must be set as follows (switch 1 is on the left, and the ON position is down): sw. 1 OFF, sw. 2 ON, sw. 3 OFF, sw. 4 ON.

E-665: The toggle switches on the front panel must be set to "Digital" (required) and "Servo OFF" (not required but recommended).

See the User Manual of your controller hardware for more information.

**Mixed operation:**

To install both LabVIEW driver sets manually:

First copy the \E-816\_GCS\_LabVIEW\_digital directory into the \Programme\PIE-816\ directory. Then copy all VIs with the "Analog" suffix from the \E-816\_GCS\_LabVIEW\_analog directory on the CD to the \Programme\PIE-816\ E-816\_GCS\_LabVIEW\_digital directory on the PC. At last, copy the Analog control.llb LLB from the \E-816\_GCS\_LabVIEW\_analog\Low Level directory on the CD to the \Programme\PIE-816\ E-816\_GCS\_LabVIEW\_digital\Low Level directory on the PC (overwrite the existing LLB). In doing so, the analog "dummy" VIs in the "digital" directory are replaced by the proper VIs. Switching between analog and digital operation requires also changing the hardware settings (see above).

*Step 1:* The E-816 controller is delivered pre-configured. Before you start, please check that the current configuration matches your stage connections.

*Step 2 (advanced users can skip this step):* To check communication between the E-816 controller and the host PC, run “E816\_Simple\_Test.vi”. This VI will return the ID string of the E-816 controller, the axis IDs and positions of all axes. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 3:*

**WARNING: E816\_Configuration\_Setup.vi May Cause Move**

When you start “E816\_Configuration\_Setup.vi” with Connected? = TRUE and Switch servo on? = TRUE, the VI may move the stages. It is therefore important to make sure that items connected to or mounted on the connected stages cannot be damaged by such a move. If a move is not desired, Connected? can be switched off (see chapter 3).

To control one or more E-816 controllers with this driver set, run “E816\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment, e.g. the definition of the axis IDs and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “E816\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work.

When programming your application, you can implement “E816\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “E816\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions. See also “E816\_Sample\_Application\_1.vi” and “E816\_Sample\_Application\_1a.vi” as sample VIs showing how to implement your application using “E816\_Configuration\_Setup.vi”.

When controlling the E-816, timing problems can occur if several command VIs are run in rapid sequence, resulting in lost commands. To prevent such communication errors, it is recommended that you include a certain wait time between the different programming steps, depending on the command to be executed. This is especially true for commands that need a certain execution time inside the E-816 module, like MOV, MVR, SPA, SVA, SVR, RST, WPA, SWT and WTO.

Only one axis per command can be controlled. “Split multiple axes command.vi” (“located in Support.lib”) can be used for commanding multiple axes at a time with DCO, DCO?, MOV, MOV?, MVR, ONT?, OVF?, POS?, RST, SVA, SVA?, SVO, SVO?, SVR and VOL?.

Default position unit is  $\mu\text{m}$ , default velocity unit is  $\mu\text{m/s}$ .

Default axis ID for the master unit is “A”. See E-816 User Manual about a detailed description how to set up an E-816 network and assign axis IDs for slaves.

GCS syntax version: 1.0



**1.5.16. F-206**

This driver set (PI General LabVIEW Driver Set) and the F-206 LabVIEW driver set that also comes with the F-206 system are fully compatible and can be used in parallel. The F-206 can be fully controlled with the PI General LabVIEW Driver Set. The axis identifiers of the F-206 (X,Y,Z,U,V,W), NanoCube (K,L,M, if present) and additional axes (A,B, if any) cannot be changed.

*Step 1 (advanced users can skip this step):* To check communication between the F-206 controller and the host PC, run “F206\_Simple\_Test.vi”. This VI will return the ID and help strings of the F-206 controller and the axis IDs and stage names of the connected axes (according to your selection of Is a NanoCube present? and How many additional axes are present?). If you have ordered the AC8 option, you can drive up to two additional separate, motor-driven axes (PWM-compatible motors with position control) with the F-206 controller (see also the F-206 User Manual). If you have ordered the NCU option, you can drive a 3-axis piezo stage (“NanoCube”) with the F-206 controller. Before you proceed with step 2, please check that the current configuration matches your stage connections. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: F206\_Configuration\_Setup.vi May Cause Move**

When you start “F206\_Configuration\_Setup.vi” with Initialize hexapod? = TRUE and/or Initialize additional axes? = TRUE, the VI will automatically move the Hexapod (and NanoCube, if present) and/or the additional axes to their sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move.

To control one or more F-206 controllers with this driver set, run “F206\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “F206\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement “F206\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “F206\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

GCS syntax version: 1.0

**1.5.17. M-840 / M-850**

This driver set (PI General LabVIEW Driver Set) and the M-840 / M-850 LabVIEW driver set that comes with the M-840 / M-850 system are fully compatible and can be used in parallel. The M-840 / M-850 can be fully controlled with the PI General LabVIEW Driver Set and is called “M-8X0” from here on. The axis identifiers of the M-840 / M-850 and additional axes (if any) cannot be changed.

*Step 1 (advanced users can skip this step):* To check communication between the M-8X0 controller and the host PC, run “M8X0\_Simple\_Test.vi”. This VI will return the ID and help strings of the M-8X0 controller and the axis IDs and stage names of the connected axes (according to your selection of How many additional axes? are connected to the M-8X0 controller). If you have ordered the AC8 option, you can drive up to two additional separate, motor-driven axes (PWM-compatible motors with position control) with the M-8X0 controller (see also the M-8X0 User Manual). Before you proceed with step 2, please check that the current configuration matches your stage connections. See chapter 3 for a description of this VI and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: M8X0\_Configuration\_Setup.vi May Cause Move**

When you start “M\_8X0\_Configuration\_Setup.vi” with Initialize hexapod? = TRUE and/or Initialize additional axes? = TRUE, the VI will automatically move the Hexapod and/or the additional axes to their sensor switches. It is therefore important to make sure that items connected to or mounted on connected stages cannot be damaged by such a move.

To control one or more M-8X0 controllers with this driver set, run “M8X0\_Configuration\_Setup.vi”. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of axis IDs, the initialization of the connected stages including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “M8X0\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement “M8X0\_Configuration\_Setup.vi” as an initialization VI in your software. See chapter 3 for a detailed description of “M8X0\_Configuration\_Setup.vi” and use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

GCS syntax version: 1.0

**1.5.18. Mercury™**

To control one or more Mercury™ controller with this driver set, “Mercury\_GCS\_DLL.dll” and “PiStages.dat” must be installed on your computer. See Section 1.1 for information about methods for proper installation of these items. The following steps must then be performed:

*Step 1 (advanced users can skip this step):* To check communication with the Mercury™ controller, run “Mercury\_Simple\_Test.vi”. This VI will return the ID string of the Mercury™ controller. See Section 3 for a description of this VI and use the *Help→Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

*Step 2:*

**WARNING: Mercury\_Configuration\_Setup.vi May Cause Move**

When you start “Mercury\_Configuration\_Setup.vi” with Are all axes connected and can be moved? = TRUE, the VI will automatically determine if the connected axes have a reference switch or limit switch and, if the referencing mode of these axes is ON, will move the stages to one of the switches. It is therefore important to make sure that items connected to or mounted on the connected stages will not be damaged by such a move. If referencing is not possible (because the connected stage has no reference or limit switch) or not desired, referencing mode (the mode which tells the controller to reference the stage or not) can be switched off. See description of RON for details and warnings.

Open “Mercury\_Configuration\_Setup.vi”. Select the RS-232 settings (port number and appropriate baudrate) and leave Use dialog to define connected stages = TRUE. Run the VI. In the following screen, specify which stages you have connected and press OK. This VI performs all steps necessary for a full configuration of the driver VIs in the LabVIEW environment: the definition of the axis ID, the initialization of the connected stages, including referencing (if appropriate) and the definition of the controller name. During your testing phase (when you simply run the VIs without wiring them together into a program), do not close “Mercury\_Configuration\_Setup.vi”; otherwise all global settings will be lost and the driver VIs will not work. When programming your application, you can implement “Mercury\_Configuration\_Setup.vi” as an initialization VI in your software. See Section 3 for a detailed description of “Mercury\_Configuration\_Setup.vi” and use the *Help→Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

If you do not find your stage in the drop-down list, press CANCEL. You can then either define a User Stage with the Stage Editor, or you can contact PI to see about getting a new stage list: the “PiStages.dat” file contains all relevant stage parameters.

The default axis names are determined by the device address (see Mercury™ User Manual), typically “A” – “P”, and can be changed using “SAI.vi”.

See also “Mercury\_Sample\_Application\_1.vi” and “Mercury\_Sample\_Application\_1a.vi” as sample VIs showing how to implement “Mercury\_Configuration\_Setup.vi” as the initialization VI for the Mercury in your application.

GCS syntax version: 1.0

## 2. Low Level VIs

The following low-level VIs can be found in the “Low Level” folder:

### 2.1. Communication VIs (“Communication.llb”):

#### 2.1.1. Available DLL interfaces.ctf

Valid for	C-843, C-843.PM, C-865, C-866, E-710, E-755, E-761, Mercury™ (but must be present for all other systems also)
Input	None
Output	None
Remarks	Type definition for hardware interfaces available when communicating with a system through a PI GCS DLL.

#### 2.1.2. Available DLLs.ctf

Valid for	C-843, C-843.PM, C-865, C-866, E-710, E-755, E-761, Mercury™ (but must be present for all other systems also)
Input	None
Output	None
Remarks	Type definition for available GCS DLLs for communicating with a system.

#### 2.1.3. Available interfaces.ctf

Valid for	All systems
Input	None
Output	None
Remarks	Type definition for available interfaces for communicating with a system.

#### 2.1.4. BDR.vi

Valid for	E-755, E-816
Input	System number (1), No. of digits (1), Baudrate (57.6), Error in (no error) E-755: No. of digits must be 0. Baudrate is given in baud. E-816: No. of digits must be 1. Baudrate is given in kbaud.
Output	Error out
Remarks	Set baudrate for RS-232 communication. Valid baudrates are 9.6, 19.2, 38.4, 57.6 and 115.2 (GCS I) and 9600, 19200, 38400, 57600, 115200 (GCS II). <u>No. of digits</u> is the number of digits after the decimal point in the baud rate specification that will be sent. VI waits 3 sec after sending BDR. E-755: Baud rate changes with BDR.vi are done in RAM only. After the baud rate was changed with BDR.vi, "Close connection if open.vi" with "Close Daisychain?" = TRUE must be called and communications must be re-established with the new baud rate (see instruction in E-755 User Manual). Incorrect entries may have unpredictable results and may not set an error status. Use WPA.vi to write the current baud rate setting to non-

volatile memory where it becomes the power-on default. Check RAM setting with BDR?.vi before running WPA.vi.

E-816: Baudrate changes must be written to non-volatile memory with WPA.vi and do not take effect before the next power on or RST. Incorrect entries (such as 56) have unpredictable results and may not set an error status. Check RAM setting with BDR?.vi after setting the baudrate before running WPA.vi. This command cannot be issued to a slave E-816.

**2.1.5. BDR?.vi**

Valid for	E-755, E-816
Input	System number (1), Error in (no error)
Output	Baudrate, Error out
Remarks	Returns current RAM baudrate setting for RS-232 communication. E-755: The value returned reflects the value that is currently in effect. This value will be saved to non-volatile memory if parameters are saved with WPA.vi. Returned baud rate value is baud. E-816: The value returned reflects the value that will be saved to non-volatile memory if parameters are saved with WPA.vi. This may differ from the value currently in effect. Returned Baudrate value is kbaud.

**2.1.6. Close connection if open.vi**

Valid for	All systems
Input	System number (1), Error in (no error)
Output	Was connected? (T/F), Error out
Remarks	This VI checks if the connection to the selected system is already open and, if it is, it closes this connection.

**2.1.7. Find baudrate.vi**

Valid for	C848, C-702, C-880, C-880K005, E-516, E-755, E-816, F-206, M-8X0
Input	System number (1), RS-232 Port number (0: COM1), Timeout (2000), Valid baudrates (array of 5 values), Flow control (All FALSE, x13, x11, x0), Termination character (LF), Interface clear (XXX\n), String to Send (*idn?), Error in (no error) C-702: Input and output HW handshake must be TRUE. All other controls=default. C-848: Input and output HW handshake must be TRUE. All other controls=default. C-880: Input and output HW handshake must be TRUE. All other controls=default. C-880K005: All controls=default. E-516: Input and output HW handshake must be TRUE. All other controls=default. E-753: Input and output HW handshake must be TRUE. Not available for Interface = TCP/IP. All other controls=default. E-755: Input and output HW handshake must be TRUE. Not available for Interface = DLL and DLL Interface = RS232DC (DaisyChain). Interface clear = \18 (Use "\Codes Display" to enter), String to Send = err?. All other controls=default. E-816: Input and output HW handshake must be TRUE. All other controls=default. F-206: All controls=default.

	M-8X0: All controls=default.
Output	Baudrate out, String read, Error out
Remarks	Opens COM port of given system with valid baudrates until status of <u>Error out</u> is false.

**2.1.8. GCSTranslator DLL Functions.vi**

Valid for	C-843, C-843.PM, C-844, C-865, C-866, E-710, E-755, E-761, Mercury™ (but must be present in Communication.llb for all other systems also)
Input	System number (1), Function (C844_IsDLLAvailable), String buffer (empty string), String input (empty string), Error in (no error)
Output	DLL I32 Return value, Numerical output, Boolean output (T/F), String output, Error out
Remarks	This VI calls a given function from GCSTranslator.dll. GCSTranslator.dll must be installed. To call a system-specific function, the system-specific GCS DLL must be installed also.  <b>Warning:</b> For <u>XXX_GcsGetANswer</u> , <u>String buffer</u> must be large enough, otherwise the application may crash. Call <u>XXX_GcsGetANswerSize</u> first to determine necessary string length.

**2.1.9. Get subnet.vi**

Valid for	C-702, E-753 (but must be present for all other systems except Analog systems, too)
Input	None
Output	Subnet
Remarks	Calls IPCONFIG and returns subnet broadcast addresses of all installed network cards.

**2.1.10. Global DaisyChain.vi**

Valid for	All systems
Input	None
Output	None
Remarks	A global variable which contains setup information for DaisyChain systems.

**2.1.11. Global1.vi**

Valid for	All systems
Input	None
Output	None
Remarks	A global variable which contains communication setup information.

**2.1.12. Initialize Global1.vi**

Valid for	All systems
Input	System number (1), Error in (no error)
Output	Error out
Remarks	This VI initializes Global1 according to the given system no.

**2.1.13. Initialize Global DaisyChain.vi**


Valid for E-755 (but must be present for all other systems except Analog systems, too)  
 Input System number (1), Error in (no error)  
 Output Error out  
 Remarks This VI initializes Global DaisyChain according to the given system no.

**2.1.14. Is DaisyChain open.vi**

Valid for E-755 (but must be present for all other systems except Analog systems, too)  
 Input System number (1), Error in (no error)  
 Output Port ID, DC open?, Error out  
 Remarks This VI checks if a DaisyChain connection is already open for the communication port defined for the given system no. It does also return the Port ID of the DaisyChain connection if any exists.

**2.1.15. PI Ask for Communication Parameters.vi**

Valid for All except analog systems  
 Input None  
 Output Number of systems, Cancel (T/F), Interface configuration, DLL interface configuration, Flow control



Remarks A user-interface VI for setting up communications parameters (RS-232 or GPIB, number of systems, baudrate, timeout etc.) for up to 4 systems. Press F1 for displaying a help window with the appropriate interface configuration of each PI controller.

**2.1.16. PI Open Interface of one system.vi**

Valid for All except analog systems

Input System Number (1), Interface configuration (RS232, 5000, COM1, 57600), DLL Interface configuration (C-843, Board, 1), TCP/IP configuration (localhost, 3000, 0), Flow control (All FALSE, x13, x11, x0), Bitt settings and parity (8, 1bit, no parity), Termination character (LF), Syntax (GCS 1.0), String to send (\*idn?), Interface clear (XXX\n), Register DC (FALSE: If not open)

Output String read, Error out

**Remarks** Establishes communication with one connected system. **This VI is called automatically by “XXXX\_Configuration\_Setup.vi” (with XXXX being the PI product number of your system) and must be completed successfully before any other VI can use the interface.** The interface and error status of the chosen system are cleared by this VI, which sends XXX (no command), \*IDN? and ERR?.

C-702: Interface = RS232 or TCP/IP, RS232: Input and output HW handshake must be TRUE, Syntax: GCS 1.0; Term char = LF.

C-843: Interface = DLL, DLL for Device = C-843, DLL Interface = Board, Parameter = Board number (1 for first C-843 board), Syntax: GCS 1.0; Term char = LF.

C-843.PM: Interface = DLL, DLL for Device = C-843.PM, DLL Interface = Board, Parameter = Board number (1 for first C-843 board) , Syntax: GCS 1.0; Term char = LF.

C-844: Interface = DLL, DLL for Device = C-844, DLL Interface = RS232 or GPIB, Parameter = empty string, RS232 baud rate = 9600

C-865: Interface = DLL, DLL for Device = C-865, DLL Interface = RS232, Parameter = empty string, RS232 baud rate = set as appropriate, Syntax: GCS 1.0; Term char = LF.

C-866: Interface = DLL, DLL for Device = C-866, DLL Interface = RS232 or USB, RS232: Parameter = empty string, RS232 baud rate = set as appropriate, USB: Parameter = Serial no. of system to connect to, Syntax: GCS 1.0; Term char = LF.

C-880: Interface = RS232 or GPIB, RS232: Input and output HW handshake must be TRUE, Syntax: GCS 1.0; Term char = LF.

C-848: Interface = RS232 or GPIB, RS232: Input and output HW handshake must be TRUE, Syntax: GCS 1.0; Term char = LF.

C-880K005: Interface = RS232, Input and output HW handshake must be FALSE, Syntax: GCS 1.0; Term char = LF.

E-516: Interface = RS232 or GPIB, RS232: Input and output HW handshake must be TRUE, Syntax: GCS 1.0; Term char = LF.

E-710: Interface = DLL, DLL for Device = E-710, DLL Interface = RS232 or GPIB, Parameter = empty string, Syntax: GCS 1.0; Term char = LF.

E-753: Interface = RS232 or TCP/IP, RS232: Input and output HW handshake must be TRUE, Syntax: GCS 2.0; Term char = LF.

E-755: Single Device: Interface = RS232, Input and output HW handshake must



be TRUE.  
 DaisyChain: Interface = DLL, DLL for Device = E-755, DLL Interface = RS232\_DC, Parameter = Number of device in chain (first device: 1), Register DC: FALSE.  
Syntax: GCS 2.0; Term char = LF.

E-761: Interface = DLL, DLL for Device = E-761, DLL Interface = Board, Parameter = Board number (1 for first E-761 board), Syntax: GCS 1.0; Term char = LF.

E-816: Interface = RS232 (supports only RS-232 communication), Input and output HW handshake must be TRUE, Syntax: GCS 1.0; Term char = LF.

F-206: Interface = RS232 or GPIB, The error status will not be cleared by this VI. The first ERR? query will report a hidden error with error code 1, which will be cleared during system initialization (INI). RS232: Input and output handshake settings must be FALSE, Syntax: GCS 1.0; Term char = LF.

M-8X0: Interface = RS232 or GPIB. RS232: Input and output handshake settings must be FALSE, Syntax: GCS 1.0; Term char = LF.

Mercury™: Interface = DLL, DLL for Device = Mercury, DLL Interface = RS232, Parameter = empty string, RS232 baud rate = set as appropriate, Syntax: GCS 1.0; Term char = LF.

**2.1.17. PI Open Interface.vi**

Valid for	All except analog systems
Input	Number of systems (1), Interface configuration (RS232, 5000, COM1, 57600), DLL Interface configuration (C-843, Board, 1), TCP/IP configuration (localhost, 3000, 0), Flow control (All FALSE, x13, x11, x0), Bitt settings and parity (8, 1bit, no parity), Termination character (LF), Syntax (GCS 1.0), String to send (*idn?)
Output	Error out
<b>Remarks</b>	Establishes communication with up to four connected systems. The interface and error statuses of all connected systems are cleared by this VI, which sends XXX (no command), *IDN? and ERR?.  See "PI Open Interface of one system.vi" for control settings.

**2.1.18. PI Receive String.vi**

Valid for	All systems
Input	System number (1), Strip spaces? (F), Error in (no error)
Output	String read, Bytes read, Error out
Remarks	Read string from selected system.

**2.1.19. PI Send String.vi**

Valid for	All systems
Input	System number (1), String to send (empty string), Attach termination char.? (T), Error in (no error)
Output	Error out
Remarks	Sends command with or without trailing termination character to selected system.

**2.1.20. PI VISA Receive Characters.vi**

Valid for	C-702, C-848, C-880, C-880K005, E-516, E-753, E-816, F-206, M-8X0 (but must be present in Communication.llb for all other systems also)
Input	System number (1), Bytes to read (1), Error in (no error)
Output	String read, Bytes read, Error out
Remarks	This vi reads n bytes (characters) via the chosen VISA interface. Sub-vi for "PI Receive String.vi".

**2.1.21. Syntax.ctl**

Valid for	All systems
Input	None
Output	None
Remarks	Type definition for GCS version.

**2.1.22. Termination character.ctl**

Valid for	All systems
Input	None
Output	None
Remarks	Type definition for termination character.

**2.2. General Command VIs ("General command.llb"):**

**2.2.1. \*IDN?.vi**

Valid for	All systems
Input	System number (1), Error in (no error)
Output	Identification, Error out
Remarks	Returns system identification string.

**2.2.2. Controller names.ctl**

Valid for	All systems
Input	None
Output	None
Remarks	Type definition for control <u>Controller names</u> .

**2.2.3. Define connected axes.vi**

Valid for	All systems
Input	System number (1), Read from controller?(F), Invert order?(F), Conn. axes (empty string array), Error in (no error)

Analog: Only supported when called by Analog\_Configuration\_Setup.vi  
 C-702: Read from controller = TRUE, Invert order = TRUE  
 C-843: Read from controller = TRUE, Invert order = FALSE  
 C-843.PM: Read from controller = TRUE, Invert order = FALSE  
 C-844: Read from controller = TRUE, Invert order = FALSE  
 C-848: Read from controller = TRUE, Invert order = TRUE  
 C-865: Read from controller = TRUE, Invert order = FALSE  
 C-866: Read from controller = TRUE, Invert order = FALSE  
 C-880: Read from controller = TRUE, Invert order = TRUE  
 E-516: Read from controller = TRUE, Invert order = FALSE  
 E-710: Read from controller = TRUE, Invert order = FALSE  
 E-753: Read from controller = TRUE, Invert order = FALSE  
 E-755: Read from controller = TRUE, Invert order = FALSE  
 E-761: Read from controller = TRUE, Invert order = FALSE  
 E-816: Read from controller = TRUE, Invert order = FALSE  
 F-206: Read from controller = FALSE, Invert order = FALSE, Connected axes = X,Y,Z,U,V,W, (A,B,K,L,M optional)  
 M-8X0: Read from controller = FALSE, Invert order = FALSE, Connected axes = X,Y,Z,U,V,W, (A,B optional)  
 Mercury™: Read from controller = TRUE, Invert order = FALSE

Output Connected axes out, Error out

**Remarks** Writes connected axes into Global2 (Array).vi. **This VI is called automatically by “XXXX\_Configuration\_Setup.vi” (with XXXX being the PI product number of your system) and must be completed successfully before any other axis-specific command VI is called.** Requires “SAI?.vi” to be present.

**2.2.4. Define connected systems (Array).vi**

Valid for All systems  
 Input Controller names (array of Enum controls, none), Change only one system? (F), System number (1), Error in (no error)  
 Analog system: Only supported when called by Analog\_Configuration\_Setup.vi

Output Controller names out, Error out

**Remarks** Defines connected systems and writes controller names into Global2 (Array).vi. **This VI is called automatically by “XXXX\_Configuration\_Setup.vi” (with XXXX being the PI product number of your system) and must be completed successfully before “General wait for movement to stop.vi” is called.** If Change only one system? is FALSE, all entries from Controller names are written into “Global2 (Array).vi”. If Change only one system? is TRUE, only the entry for the given system number is overwritten in “Global2 (Array).vi”.

**2.2.5. ERR?.vi**

Valid for All systems.  
 Input System number (1), Error in (no error)

Output	Controller error (T/F), Error out Analog: VI does not report any errors.
Remarks	Returns error information. <u>Controller error</u> is TRUE if selected system reports error code ≠ 0. See appendix A of this manual for a list of PI error codes and use “GCSTranslateError.vi” to translate error codes into error descriptions programmatically.

**2.2.6. Global2 (Array).vi**

Valid for	All systems
Input	System (array of Conn. axes (empty string array), Controller name (Enum control, none))
Output	None
Remarks	A global variable which contains identifiers for all connected axes of all connected systems and the names of all connected systems.

**2.2.7. HLP?.vi**

Valid for	Analog systems, C-702, C-843, C-843.PM, C-848, C-865, C-866, C-880, E-516, E-710, E-753, E-755, E-761, Mercury™. To support analog interfacing, VI must be present for E-816 also.
Input	System number (1), Error in (no error)
Output	Help string, Error out
Remarks	Returns help string.

**2.2.8. Initialize Global2.vi**

Valid for	All systems
Input	System number (1), Error in (no error)
Output	Error out
Remarks	This VI initializes Global2 (Array) according to the given system no.

**2.2.9. MOV.vi**

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, F-206, M-8X0, Mercury™
Input	System number (1), Axes to move (empty string array), Position values (empty num. array, 0), No. of digits (4), Error in (no error) C-880K005: VI only supported when called through PI_Multix.vi E-753: Motion commands are not allowed when the wave generator is active or the analog input is used for target generation. E-755: Command not available for E-755.101. E-816: Only one axis per command allowed. It is necessary to wait a certain time before sending the next command to prevent it from being lost. F-206: No mix between F-206 axes X,Y,Z,U,V,W and separate axes A,B allowed
Output	Error out
Remarks	Moves specified axes to specified absolute positions. <u>No. of digits</u> is the number of digits after the decimal point in the position value(s) that will be

sent.

E-710: See also "NMOV.vi" in "Old commands.llb".

**2.2.10. MOV?.vi**

Valid for	C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)  C-702: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-843: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-843.PM: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-844: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-848: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-865: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-866: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-880: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-710: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. E-755: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. Command not available for E-755.101.  E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE E-816: <u>All axes?</u> = FALSE, only one axis per command allowed. F-206: Command has different implementation, please use MOV?_old.vi M-8X0: Command has different implementation, please use MOV?_old.vi Mercury™: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
Output	Target position, Error out
Remarks	Returns commanded target position.

**2.2.11. MVR.vi**

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™
Input	System number (1), Axes to move (empty string array), Position values (empty num. array, 0), No. of digits (4), Error in (no error)  C-880K005: VI only supported when called through PI_Multix.vi E-755: Command not available for E-755.101. E-816: Only one axis per command allowed. It is necessary to wait a certain time before sending the next command to prevent it from being lost.
Output	Error out
Remarks	Moves specified axes <b>relative</b> to current position. <u>No. of digits</u> is the number of digits after the decimal point in the position value(s) that will be sent.  E-710: See also "NMVR.vi" in "Old commands.llb".  E-753: Motion commands are not allowed when the wave generator is active or the

analog input is used for target generation.

**2.2.12. ONT?.vi**

Valid for	C-702, C-843, C-843.PM, C-848, C-865, C-866, C-880, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™ (but must be present for all other systems also)
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)  C-702: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-843: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-843.PM: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-848: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-865: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-866: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-880: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. E-710: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. E-755: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. Command not available for E-755.101 E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. E-816: <u>All axes?</u> = FALSE, only one axis per command allowed. Mercury™: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE.
Output	Axis on target? (T/F), Error out
Remarks	Indicates whether or not queried axis is at target position.

**2.2.13. POS?.vi**

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, F-206, M-8X0, Mercury™
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)  Analog: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. C-702: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-843: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-843.PM: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-844: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-848: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-865: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-866: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-880: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE C-880K005: VI only supported when called through PI_Multix.vi E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE

	E-710: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	E-755: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. Command not available for E-755.101.
	E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	E-816: <u>All axes?</u> = FALSE, only one axis per command allowed.
	F-206: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	M-8X0: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	Mercury™: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
Output	Position, Error out
Remarks	Returns position information (actual or target position, depending on system).
	F-206: Returned position value is the commanded target position for the axis.
	M-8X0: Returned position value is the commanded target position for the axis.

**2.2.14. SAI?.vi**

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™ (but must be present in “General command.lib” for all other systems also)
Input	System number (1), Invert order? (F), SAI? ALL (F), Error in (no error) Analog: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> must be FALSE C-702: <u>Invert order</u> should be TRUE, <u>SAI? ALL</u> must be FALSE C-843: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported C-843.PM: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> must be FALSE C-844: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> must be FALSE C-848: <u>Invert order</u> should be TRUE, <u>SAI? ALL</u> must be FALSE C-865: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported C-866: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported C-880: <u>Invert order</u> should be TRUE, <u>SAI? ALL</u> must be FALSE to read all configured axis IDs and must be TRUE to get all physically defined axis IDs C-880K005: VI only supported when called through PI_Multix.vi, <u>SAI? ALL</u> must be FALSE E-516: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> must be FALSE E-710: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported E-753: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported E-755: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported E-761: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported E-816: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> must be FALSE Mercury™: <u>Invert order</u> should be FALSE, <u>SAI? ALL</u> is supported
Output	Connected axes, Error out
Remarks	Returns axis identifiers of all configured axes and writes them into Global2 (Array).vi. If SAI? ALL is TRUE, all physically available axes are returned, no matter if configured or not. Required by “Define connected axes.vi”

## 2.2.15. SPA.vi

Valid for	C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™
Input	System number (1), Axis to set (empty string array), Parameter number (empty num. array, 0), Parameter number (hex) (empty hex. array, 0), Parameter value (empty num. array, 0), No. of digits (4), Parameter string (empty string array), Parameter no. format (Decimal: FALSE) (F), Parameter format (Num.: FALSE) (F), Error in (no error)

C-702: Parameter no. format is FALSE (decimal).

**WARNING**

This command is for setting hardware-specific parameters. Wrong values may lead to improper operation or damage of your hardware! Change settings only after consultation with PI.

C-843: Parameter no. format is FALSE (decimal).

**WARNING**

This command is primarily for setting hardware-specific parameters of non-PI stages connected to the controller. Please refer to the stage manual for valid parameter settings. If you have a PI stage connected, please do not change any parameters except P (1), I (2), D (3), I-limit (4) and VFF (5).

C-843.PM: Parameter no. format is FALSE (decimal). See C-843 for warnings.

C-848: Parameter no. format is FALSE (decimal). See C-880 for warnings.

C-865: Parameter no. format is FALSE (decimal). See C-843 for warnings.

C-866: Parameter no. format is FALSE (decimal). See C-843 for warnings.

C-880: Parameter no. format is FALSE (decimal).

**WARNING**

This command is for setting hardware-specific parameters of non-PI stages connected to the controller. Please refer to the stage manual for valid parameter settings. If you have a PI stage connected, please do not change any parameters except P (1), I (2), D (3), I-limit (4) and VFF (5). The most important parameter numbers are:

- 1: P-term (0 to 32767)
- 2: I-term (0 to 32767)
- 3: D-term (0 to 32767)
- 4: I-Limit (integration limit) (0 to 32767)
- 5: VFF (velocity feed forward) (0 to 32767)
- 7: motor bias (-32767 to 32767)
- 8: maximum position error (0 to 32767)
- 9: maximum value for the motor output (0 to 32767)
- 10: maximum velocity (allowed range depends on stage)
- 11: maximum allowed acceleration (allowed range depends on stage)
- 13: maximum allowed Jerk (allowed range depends on stage)
- 14, 15: reserved

C-880K005: VI only supported when called through PI\_Multix.vi. See C-880 for



warnings and description of parameter numbers.

E-516: Parameter no. format is FALSE (decimal).

**WARNING**

This command is for setting hardware-specific calibration parameters, except parameter number 268500993. Incorrect values may lead to improper operation.

The following parameter numbers are valid:

- 7: Ksen (Coefficient of Sensor K<sub>s</sub>). When sensor output change is 1V, the position change of stage is K<sub>s</sub> (μm). (- 3.402823466e+38F to 3.402823466e+38F)
- 8: Osen (Offset of Sensor Os). When sensor output is 0V, the actual position of stage is Os (μm). (- 3.402823466e+38F to 3.402823466e+38F)
- 9: Kpzt (Coefficient of PZT voltage amplifier Kpzt). When DAC output change is 1V, the PZT Voltage change is Kpzt (V) (- 3.402823466e+38F to 3.402823466e+38F)
- 10: Opzt (Offset of PZT voltage amplifier Opzt ) When DAC output is 0V, the PZT Voltage is Opzt (V) (- 3.402823466e+38F to 3.402823466e+38F)
- 117442816: Tolerance for ONT software emulation (μm) (0 < value < 1000)

E-710: Parameter no. format is TRUE (hex.) Use “HPA?.vi” to get valid parameter numbers or see the E7XX\_GCS\_DLL Manual.

**WARNING**

This command is for setting hardware-specific parameters. Wrong values may lead to improper operation or damage of your hardware!

E-753: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers or see the E-753 User Manual. See E-710 for warnings.

E-755: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers or see the E-755 User Manual. See E-710 for warnings.

E-761: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers or see the E7XX\_GCS\_DLL Manual. See E-710 for warnings.

E-816: Parameter no. format is FALSE (decimal). See E-516 for warnings and a description of parameter numbers. Each command limited to setting one parameter for only one axis.

Mercury™: Parameter no. format is FALSE (decimal). See C-843 for warning.

Output

Controller error (T/F), Error out

Remarks

Sets parameters, waits 100 ms and queries ERR?. For axis-related parameters, Axis to set is the axis name; for piezo- or sensor-related parameters, the channel number; otherwise a parameter-related code. If parameter number is in decimal format, use Parameter number input, for hexadecimal parameter numbers use Parameter number (hex.) input and switch Parameter no. format to TRUE. For numeric parameter values use Parameter value input, for parameter strings use Parameter string input and switch Parameter format to TRUE. Do not mix decimal and hex. parameter numbers or numeric and string parameter values in one call. Parameter numbers which can be set depend on current CCL level. See GCS DLL manual for available parameter numbers and values. No. of digits is the number of digits after the decimal point in the numeric parameter value(s) that will be sent. Controller error is TRUE if selected system reports error code ≠ 0.

- C-843: For precision and convenience with gearbox systems, the counts per physical unit factor can be entered as numerator and denominator of a fraction (parameters 14 and 15).
- E-516: The SPA command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the E-516 is powered off.
- E-816: This command cannot be issued to a slave.
- E-710: The SPA command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the E-710 is powered off.
- E-753: The SPA command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the E-753 is powered off.
- E-755: The SPA command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the E-755 is powered off.
- E-761: The SPA command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the PC is powered off or the E-761 is rebooted.
- Mercury™: The SPA command saves the parameters in RAM only. Use PIStageEditor.exe to change parameters or add new stages to the data base permanently.

#### 2.2.16. SPA?.vi

Valid for	C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™
Input	<p>System number (1), Axes to query (empty string array), Parameter no. format (Decimal: FALSE) (F), Without axes? (F), Parameter no. (empty num. array, 0), Parameter no. (hex) (empty hex. array, 0), Error in (no error)</p> <p>C-702: <u>Parameter no. format</u> is FALSE (decimal).</p> <p>C-843: <u>Parameter no. format</u> is FALSE (decimal).</p> <p>C-843.PM: <u>Parameter no. format</u> is FALSE (decimal).</p> <p>C-848: <u>Parameter no. format</u> is FALSE (decimal).</p> <p>C-865: <u>Parameter no. format</u> is FALSE (decimal). Parameter number 25 is read-only.</p> <p>C-866: <u>Parameter no. format</u> is FALSE (decimal). Parameter number 25 is read-only.</p> <p>C-880: <u>Parameter no. format</u> is FALSE (decimal). Additional read-only parameter numbers are:</p> <ul style="list-style-type: none"> <li>• 14: Numerator of the counts per physical unit factor (1 to 2147483647) (factor = num./denom.)</li> <li>• 15: Denominator of the counts per physical unit factor (1 to 2147483647) (factor = num./denom.)</li> <li>• 16: Drive mode: 0=Analog 1=PWM</li> </ul>

- 19: Axis type: 0=Linear 1=Rotary
- 20: Reference switch: 0=no present, 1=present
- 28: Reference status: 0=axis not referenced; 1=axis is referenced

C-880K005: VI only supported when called through PI\_Multix.vi

E-516: Parameter no. format is FALSE (decimal).

E-710: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers.

E-753: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers.

E-755: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers.

E-761: Parameter no. format is TRUE (hex.). Use “HPA?.vi” to get valid parameter numbers.

E-816: Parameter no. format is FALSE (decimal).

Only one parameter value for only one axis per command allowed.

Mercury™: Parameter no. format is FALSE (decimal).

Output Parameter value, Parameter string, Error out

Remarks Returns parameter values for queried items and parameter numbers. For axis-related parameters, Axis to query is the axis name; for piezo- or sensor-related parameters, the channel number; otherwise a parameter-related code. If parameter number is in decimal format, use “Parameter no.” input, for hexadecimal parameter numbers use “Parameter no. (hex)” input and switch “Parameter no. format” to TRUE. If Without axes? is TRUE, all available parameter for all axes/designators are returned. For parameter numbers which output a string use Parameter string output. See GCS DLL Manual for available parameter numbers.

E-816: This command cannot be issued to a slave

C-843: The following parameter number outputs a string:  
60: stage name (maximum 14 characters)

C-843.PM: The following parameter number outputs a string:  
60: stage name (maximum 14 characters)

C-866: The following parameter number outputs a string:  
60: stage name (maximum 14 characters)

C-865: The following parameter number outputs a string:  
60: stage name (maximum 14 characters)

Mercury™: The following parameter number outputs a string:  
60: stage name (maximum 14 characters)

**2.2.17. STP.vi**

Valid for Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-516, E-753, E755, E-761, Mercury™ (but must be present for E-710 also). To support analog interfacing, VI must be present for E-816 also.

Input System number (1), Affected axes? (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)

Analog: All axes? = TRUE, Axis identifier = FALSE. STP does not set any error code.

C-702: All axes? = TRUE, Axis identifier? = FALSE

	C-843: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	C-843.PM: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	C-844: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	C-848: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	C-865: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	C-866: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	C-880: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
	E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	E-755: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	Mercury™: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE
Output	Error out
Remarks	Stops motion of specified axes. To stop a referencing routine (REF, MNL, MPL) or fast scan routine (FSC, FSA etc.), or AutoZero procedure (ATZ), or wave generator run (WGO), use "#24.vi". STP sets error code 10, call "ERR?.vi" to reset error after STP has been called.

**2.2.18. SVO.vi**

Valid for	C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-516, E-710, E-753, E-755, E-761, E-816, F-206, M-8X0, Mercury™
Input	System number (1), Without axis ID?(F), Axes to command (empty string array), Servo mode (empty bool. array, F), Error in (no error)
	C702: <u>Without axis ID</u> = FALSE
	C-843: <u>Without axis ID</u> = FALSE
	C-843.PM: <u>Without axis ID</u> = FALSE
	C-844: <u>Without axis ID</u> = FALSE
	C-848: <u>Without axis ID</u> = FALSE
	C-865: <u>Without axis ID</u> = FALSE
	C-866: <u>Without axis ID</u> = FALSE
	C-880: <u>Without axis ID</u> = FALSE
	E-516: <u>Without axis ID</u> = FALSE
	E-710: <u>Without axis ID</u> = FALSE
	E-753: <u>Without axis ID</u> = FALSE
	E-755: <u>Without axis ID</u> = FALSE. When the servo mode is switched off, RNP is automatically performed for the corresponding Nexline channel, which could take a few seconds. Command not available for E-755.101.
	E-761: <u>Without axis ID</u> = FALSE
	E-816: <u>Without axis ID</u> = FALSE. Only one axis per command allowed.
	F-206: <u>Without axis ID</u> = TRUE, only first field of <u>Servo mode</u> array is valid
	M-8X0: <u>Without axis ID</u> = TRUE, only first field of <u>Servo mode</u> array is valid
	Mercury™: <u>Without axis ID</u> = FALSE
Output	Error out

Remarks Sets servo-control mode for given axes. If Without axis ID is TRUE, then Axes to command is ignored and first field of Servo mode array is used.

**2.2.19. SVO?.vi**

Valid for C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-516, E-710, E-753, E-755, E-761, E-816, F-206, M-8X0, Mercury™

Input System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)

C-702: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-843: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-843.PM: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-844: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-848: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-865: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-866: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-880: If All axes? = TRUE, then Axis identifier? can be FALSE  
 E-516: If All axes? = TRUE, then Axis identifier? must be TRUE  
 E-710: If All axes? = TRUE, then Axis identifier? must be TRUE  
 E-753: If All axes? = TRUE, then Axis identifier? can be FALSE  
 E-755: If All axes? = TRUE, then Axis identifier? can be FALSE  
 E-761: If All axes? = TRUE, then Axis identifier? can be FALSE  
 E-816: All axes? = FALSE, only one axis per command allowed.  
 F-206: All axes? = TRUE, Axis identifier? = FALSE  
 M-8X0: All axes? = TRUE, Axis identifier? = FALSE  
 Mercury™: If All axes? = TRUE, then Axis identifier? can be FALSE

Output Servo status (T/F), Error out

F-206: Only first field of servo status array is valid  
 M-8X0: Only first field of servo status array is valid

Remarks Returns servo status of queried axes.

**2.2.20. VEL.vi**

Valid for Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, F-206, M-8X0, Mercury™. To support analog interfacing, VI must be present for E-816 also.

Input System number (1), Without axis ID? (F), No. of digits (4), Axes to set (empty string array), Velocity values (empty num. array, 0), Error in (no error)

Analog: Without axis ID? = FALSE; Velocity unit is µm/sec  
 C-702: Without axis ID? = FALSE  
 C-843: Without axis ID? = FALSE  
 C-843.PM: Without axis ID? = FALSE  
 C-844: Without axis ID? = FALSE

	C-848: <u>Without axis ID?</u> = FALSE
	C-865: <u>Without axis ID?</u> = FALSE
	C-866: <u>Without axis ID?</u> = FALSE
	C-880: <u>Without axis ID?</u> = FALSE, for NanoCube axes command is not valid
	C-880K005: VI only supported when called through PI_Multix.vi
	E-516: <u>Without axis ID?</u> = FALSE
	E-710: <u>Without axis ID?</u> = FALSE. Velocity unit is $\mu\text{m}/\text{ms}$ .
	E-753: <u>Without axis ID?</u> = FALSE. Velocity unit is $\mu\text{m}/\text{s}$ .
	E-755: <u>Without axis ID?</u> = FALSE. Velocity unit is $\mu\text{m}/\text{s}$ . Command not available for E-755.101.
	E-761: <u>Without axis ID?</u> = FALSE. Velocity unit is $\mu\text{m}/\text{ms}$ .
	F-206: F-206 platform velocity: <u>Without axis ID?</u> = TRUE; velocity of axes A and/or B: <u>Without axis ID?</u> = False; axes K,L,M: command not valid
	M-8X0: M-8X0 platform velocity: <u>Without axis ID?</u> = TRUE; velocity of axes A and/or B: <u>Without axis ID?</u> = False
	Mercury™: <u>Without axis ID?</u> = FALSE
Output	Error out, Controller error
Remarks	Sets velocity and checks for error. If <u>Without axis ID?</u> is TRUE, then <u>Axes to set</u> is ignored and first field of <u>Velocity values</u> array is used for velocity command. The velocity should not be set to 0. <u>Number of digits</u> is the number of digits after the decimal point in the velocity value(s) that will be sent. <u>Controller error</u> is TRUE if selected system reports error code $\neq 0$ .
	E-516: The VEL command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the E-516 is powered off.
	E-753: Velocity settings made with VEL are present in RAM only and will be reset to default ("Servo Loop Slew Rate" value) when the controller is powered down or rebooted.
	E-755: Velocity settings made with VEL are present in RAM only and will be reset to default ("Servo Loop Slew Rate" value) when the controller is powered down or rebooted.
	E-761: The VEL command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi with "Affected axes" as an empty array. Parameter changes not saved with WPA will be lost when the PC is powered off or the E-761 is rebooted.

### 2.2.21. VEL?.vi

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, F-206, M-8X0, Mercury™. To support analog interfacing, VI must be present for E-816 also.
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)
	Analog: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE; Velocity unit is $\mu\text{m}/\text{sec}$
	C-702: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE

	C-843: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	C-843.PM: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	C-844: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	C-848: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	C-865: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	C-866: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	C-880: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
	C-880K005: VI only supported when called through PI_Multix.vi
	E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE
	E-710: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE. Velocity unit is $\mu\text{m}/\text{ms}$ .
	E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. Velocity unit is $\mu\text{m}/\text{s}$ .
	E-755: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. Velocity unit is $\mu\text{m}/\text{s}$ . Command not available for E-755.101.
	E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. Velocity unit is $\mu\text{m}/\text{ms}$ .
	F-206: Velocity of F-206: <u>All axes?</u> = TRUE AND <u>Axis identifier?</u> = FALSE; velocity of axes A,B: <u>All axes?</u> must be FALSE; axes K,L,M: command not valid
	M-8X0: Velocity of M-8X0: <u>All axes?</u> = TRUE AND <u>Axis identifier?</u> = FALSE; velocity of axes A,B: <u>All axes?</u> must be FALSE
	Mercury™: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE.
Output	Velocity, Error out
	C-880: NanoCube axes will report velocity = 0
	F-206: F-206 velocity: only first field of <u>velocity</u> array is valid
	M-8X0: M-8X0 velocity: only first field of <u>velocity</u> array is valid
Remarks	Returns velocity setting for specified axes.

## 2.3. PZT specific VIs (“PZT voltage.llb”)

### 2.3.1. DCO.vi

Valid for	E-516, E-816
Input	System number (1), Axes to command (empty string array), Drift comp. mode (empty bool. array, F), Error in (no error)
Output	Error out
Remarks	Sets drift compensation mode for given axes. E-516: When activating/deactivating drift compensation with DCO, this setting is automatically saved to flash ROM together with the current settings for the parameters listed below, and they become the new power-on defaults: communication interface, enabled channels and display format, averaging (AVG), velocity control mode (VCO) and velocity (VEL), offset and gain for position and output voltage display, mode and tolerance for on-target reading (SPA), position limits (PLM, NLM), voltage limits (VMA, VMI), macros and default macro setting.

If current parameter values are incorrect, the system may malfunction. Be sure that you have the correct parameter settings before using DCO.

E-816: Only one axis per command allowed. It is necessary to wait a certain time before sending the next command to prevent it from being lost. See system manual for valid drift compensation modes.

**2.3.2. DCO?.vi**

Valid for	E-516, E-816
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error) E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-816: <u>All axes?</u> = FALSE, only one axis per command allowed.
Output	Drift comp. mode (T/F), Error out
Remarks	Returns drift compensation mode status of queried axes.

**2.3.3. OVF?.vi**

Valid for	E-516, E-753, E-761, E-816
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error) E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE E-816: <u>All axes?</u> = FALSE, only one axis per command allowed.
Output	Axis overflow? (T/F), Error out
Remarks	Returns overflow information for queried axes.

**2.3.4. SVA.vi**

Valid for	E-516, E-710, E-753, E-755, E-761, E-816
Input	System number (1), Axes to move (empty string array), PZT voltage (empty num. array, 0), No. of digits (4), Error in (no error) E-816: Only one axis per command allowed. It is necessary to wait a certain time before sending the next command to prevent it from being lost.
Output	Error out
Remarks	Sets absolute PZT voltage for specified axes. Servo must be switched off (using "SVO.vi") when using this command. <u>No. of digits</u> is the number of digits after the decimal point in the voltage value(s) that will be sent. E-753: <u>PZT voltage</u> is a dimensionless value whose range corresponds approximately to the mechanics travel range in $\mu\text{m}$ . Motion commands are not allowed when the wave generator is active or the analog input is used for target generation.

**2.3.5. SVA?.vi**

Valid for	E-516, E-710, E-753, E-755, E-761, E-816
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)



E-516: If All axes= TRUE, then Axis identifier? must be TRUE  
 E-710: If All axes= TRUE, then Axis identifier? must be TRUE  
 E-753: If All axes= TRUE, then Axis identifier? can be FALSE  
 E-755: If All axes= TRUE, then Axis identifier? can be FALSE  
 E-761: If All axes= TRUE, then Axis identifier? can be FALSE  
 E-816: All axes? = FALSE, only one axis per command allowed.

Output Commanded PZT voltage, Error out

Remarks Returns commanded PZT voltage for queried axes.

E-753: The response is a dimensionless value whose range corresponds approximately to the mechanics travel range in  $\mu\text{m}$ .

### 2.3.6. SVR.vi

Valid for E-516, E-710, E-753, E-755, E-761, E-816

Input System number (1), Axes to move (empty string array), PZT voltage (empty num. array, 0), No. of digits (4), Error in (no error)

E-816: Only one axis per command allowed. It is necessary to wait a certain time before sending the next command to prevent it from being lost.

Output Error out

Remarks Sets relative PZT voltage for specified axes. Servo must be switched off (using "SVO.vi") when using this command. No. of digits is the number of digits after the decimal point in the voltage value(s) that will be sent.

E-753: PZT voltage is a dimensionless value whose range corresponds approximately to the mechanics travel range in  $\mu\text{m}$ .  
 Motion commands are not allowed when the wave generator is active or the analog input is used for target generation.

### 2.3.7. VCO.vi

Valid for Analog systems, E-516, E-761. To support analog interfacing, VI must be present for E-816 also.

Input System number (1), Axes to command (empty string array), Vel. control mode (empty bool. array, F), Error in (no error)

Output Error out

Remarks Sets velocity-control mode for specified axes.

Analog: Velocity control mode can only be set for all axes equally. Therefore only first field of Vel. control mode is valid.

E-516: The VCO command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi. Parameter changes not saved with WPA will be lost when the E-516 is powered off.

E-761: The VCO command saves the parameters in RAM only. To save the currently valid parameters to flash ROM, where they become the power-on defaults, you must run WPA.vi with "Affected axes" as an empty array. Parameter changes not saved with WPA will be lost when the PC is powered off or the E-761 is rebooted.

### 2.3.8. VCO?.vi

Valid for Analog systems, E-516, E-761. To support analog interfacing, VI must be

	present for E-816 also.
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error) Analog: <u>All axes?</u> = TRUE; <u>Axis identifier?</u> = FALSE E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE
Output	Vel. control mode? (T/F), Error out Analog: Only first field of Vel. control mode? is valid.
Remarks	Returns velocity-control mode status for queried axes.

**2.3.9. VOL.vi**

Valid for	Analog systems, E-761. To support analog interfacing, VI must be present for E-816 also.
Input	System number (1), PZT channel (empty string array), PZT voltage (empty num. array, 0), No. of digits (4), Error in (no error) Analog: VI sets control voltage. E-761: <u>PZT channel</u> can be 1 to 4.
Output	Error out
Remarks	Sets absolute PZT voltage for specified PZT channel. <u>No. of digits</u> is the number of digits after the decimal point in the voltage value(s) that will be sent. If the commanded voltage exceeds the voltage limits of the piezo channel, then the command is not executed.

**2.3.10. VOL?.vi**

Valid for	Analog systems, E-516, E-710, E-753, E-755, E-761, E-816
Input	System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error) Analog: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. VI reads control voltage. E-516: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-710: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE. <u>Axes to query</u> are piezo channel numbers. E-753: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. <u>Axes to query</u> are piezo channel numbers. E-755: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. <u>Axes to query</u> are piezo channel numbers. E-761: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> can be FALSE. <u>Axes to query</u> are piezo channel numbers, which can be 1 to 4. E-816: <u>All axes?</u> = FALSE, only one axis per command allowed.
Output	Current PZT voltage, Error out
Remarks	Returns current PZT voltage for queried axes.

2.4. Special commands (“Special command.lib”)

2.4.1. #24.vi

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-753, E-755, E-761, F-206, M-8X0, Mercury™ (but must be present for E-710 also). To support analog interfacing, VI must be present for E-816 also.
Input	System number (1), Error in (no error) Analog systems: #24 does not set any error code. C-880K005: VI only supported when called through PI_Multix.vi
Output	Error out
Remarks	Stops all motion (by sending the single ASCII character 24). #24 sets error code 10, call “ERR?.vi” to reset error after #24 has been called.

2.4.2. #5.vi

Valid for	Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-753, E-755, E-761, Mercury™ (but must be present for all other systems also)
Input	System number (1), Error in (no error)
Output	Axis moving? (T/F), Error out
Remarks	<p>Polls the motion status of the connected axes by sending the single ASCII character 5. Connected axes are read from Global2.vi and displayed on the front panel for assignment. Required by “General wait for movement to stop.vi” and “Wait for axes to stop.vi”.</p> <p>Analog: Motion status can only be determined for all connected axes, not for single axes.</p> <p>F-206: Different coding in answer, please use #5_old.vi</p> <p>M-8X0: Different coding in answer, please use #5_old.vi</p>

2.4.3. AVG.vi

Valid for	E-516, E-761, E-816
Input	System number (1), Averaging time (1), Error in (no error) E-761: <u>Averaging</u> (oversampling) <u>time</u> (factor), can be 4, 8, or 16 E-816: <u>Averaging time</u> (factor) can be 1, 2, 4, 8, 16, 32 or 64
Output	Error out, Hidden error
Remarks	<p>Sets averaging time to use for measurements. <u>Hidden error</u> is TRUE if selected system reports error code ≠ 0.</p> <p>E-516: When making settings with AVG, they are automatically saved to flash ROM together with the current settings for the parameters listed below, and they become the new power-on defaults: communication interface, enabled channels and display format, drift compensation mode (DCO), velocity control mode (VCO) and velocity (VEL), offset and gain for position and output voltage display, mode and tolerance for on-target reading (SPA), position limits (PLM, NLM), voltage limits (VMA, VMI), macros and default macro setting. If current parameter values are incorrect, the system may malfunction. Be sure that you have the correct parameter settings before using AVG.</p>

E-761: The "Sensor sampling time" (ID 0x0e000100) and "Servo update time" (ID 0x0e000200) parameters are influenced by AVG. Use WPA.vi to save the values.

E-816: This command cannot be issued to a slave.

**2.4.4. AVG?.vi**

Valid for E-516, E-816

Input System number (1), Error in (no error)

Output Averaging time, Error out

Remarks Returns current measurement-averaging-time setting.

E-816: This command cannot be issued to a slave

E-761: This command returns the averaging (oversampling) factor which influences the "Sensor sampling time" (ID 0x0e000100) and "Servo update time" (ID 0x0e000200) parameters.

**2.4.5. DRR?.vi**

Valid for Analog systems, C-702, C-866, E-710, E-753, E-755, E-761. To support analog interfacing, VI must be present for E-816 also.

Input System number (1), Rec. table IDs (Empty num. array, 0), xo (0), N (100), Nmax (1024), Without parameter? (FALSE), Error in (no error)

Analog: Rec. table IDs, xo, N and Nmax are not valid. Without parameter? must be TRUE.

C-702: Nmax = 262144.

C-866: Nmax = 32,256. If N = -1 all points of the last record are returned.

E-710: Nmax = 32256.

E-753: Nmax = 65,536.

E-755: Nmax = 4096.

E-761: Nmax = 8192.

Output Data, Names, Sample time, Error out

Remarks Returns N recorded data points. N must be less than or equal to Nmax. For large N values, communication timeout must be set long enough, otherwise a communication error may occur.

E-761: Recording takes place for all recorder tables as long as the wave generator is running for an arbitrary axis. The assignment of axis and data sources to the recorder tables is as follows:

- table 1: axis 1 actual position
- table 2: axis 2 actual position
- table 3: axis 3 actual position
- table 4: analog input voltage (same value as read with TAV?, i.e. contains gain and offset for the analog input, see E-761 User Manual)

E-753: The 65,536 points are in equal shares assigned to the available data recorder tables. By default, the number of tables is 8. It can be reduced by setting the appropriate parameter value, see E-753 User Manual for details.

**2.4.6. DRR? and display data.vi**

Valid for	Analog systems, C-702, C-866, E-710, E-753, E-755, E-761. To support analog interfacing, VI must be present for E-816 also.
Input	System number (1), Rec. table IDs (Empty num. array, 0), xo (0), N (100), Nmax (1024), Without parameter? (FALSE), Error in (no error) Analog: <u>Rec. table IDs</u> , <u>xo</u> , <u>N</u> and <u>Nmax</u> are not valid. <u>Without parameter?</u> must be TRUE. C-702: <u>Nmax</u> = 262144 C-866: <u>Nmax</u> = 32,256. If N = -1 all points of the last record are returned. E-710: <u>Nmax</u> = 32256. E-753: <u>Nmax</u> = 65,536. E-755: <u>Nmax</u> = 4096 E-761: <u>Nmax</u> = 8192
Output	Data, Names, Sample time, Error out
Remarks	Returns <u>N</u> recorded data points and displays them in a 2D graph by calling "Show_Save_Load_XY_Data.vi. N must be less than or equal to <u>Nmax</u> . For large <u>N</u> values, communication timeout must be set long enough, otherwise a communication error may occur. E-761: Recording takes place for all recorder tables as long as the wave generator is running for an arbitrary axis. The assignment of axis and data sources to the recorder tables is as follows: table 1: axis 1 actual position table 2: axis 2 actual position table 3: axis 3 actual position table 4: analog input voltage (same value as read with TAV?, i.e. contains gain and offset for the analog input, see E-761 User Manual) E-753: The 65,536 points are in equal shares assigned to the available data recorder tables. By default, the number of tables is 8. It can be reduced by setting the appropriate parameter value, see E-753 User Manual for details.

**2.4.7. I2C?.vi**

Valid for	E-816
Input	System number (1), Error in (no error)
Output	I <sup>2</sup> C status message, Error out
Remarks	Returns the status message of the I <sup>2</sup> C bus. E-816: Status message consists of status bit and channel ID.

**2.4.8. RST.vi**

Valid for	C-702, C-848, C-880, E-816
Input	System number (1), Axes to be restored (empty string array), All axes? (F), Axis identifier? (T), Error in (no error) C-702: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-848: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE C-880: If <u>All axes?</u> = TRUE, then <u>Axis identifier?</u> must be TRUE E-816: <u>All axes?</u> = TRUE, <u>Axis identifier?</u> = FALSE; this command affects the

	master unit only.
Output	Error out
Remarks	Restores parameters or resets E-816 master unit. C-702: Restores last saved stage configuration in volatile memory (RAM) for any of the specified axes: Loads back the stage configuration (can be modified with CST) and the motion parameters (can be modified with SPA) which were last saved with SAVC-848: Restores parameters of any of the specified axes which have been modified using "SPA" command to values from last "SAV". C-880: Restores parameters of any of the specified axes which have been modified using "SPA" command to values from last "SAV". E-816: Resets the master unit.

**2.4.9. SCH.vi**

Valid for	E-816
Input	System number (1), Axis name (empty string), Error in (no error)
Output	Error out
Remarks	Set axis (channel) name. See User Manual for further description. Run "Define connected axes.vi" after renaming axes. E-816: This command cannot be issued to a slave E-816. Changes must be written to non-volatile memory with WPA.vi. and do not take effect before the next power on or RST.

**2.4.10. SCH?.vi**

Valid for	E-816
Input	System number (1), Error in (no error)
Output	Axis name, Error out
Remarks	Returns the axis (channel) name of the master unit.

**2.4.11. SSN?.vi**

Valid for	C-702, C-848, C-866, C-880, E-755, E-761, E-816
Input	System number (1), With channel ID (F), Channel name (empty string), Error in (no error) C-702: <u>With channel ID</u> = FALSE C-848: <u>With channel ID</u> = FALSE C-866: <u>With channel ID</u> = FALSE C-880: <u>With channel ID</u> = FALSE E-755: <u>With channel ID</u> = FALSE E-761: <u>With channel ID</u> = FALSE E-816: <u>With channel ID</u> = TRUE
Output	Serial number, Error out
Remarks	Returns controller serial number.

**2.4.12. STA?.vi**

Valid for C-702, C-848, C-880, C-880K005 (but must be present in Special command.llb for all other systems also)

Input System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)

C-702: If All axes? = TRUE, then Axis identifier? can be FALSE

C-848: If All axes? = TRUE, then Axis identifier? can be FALSE

C-880: If All axes? = TRUE, then Axis identifier? can be FALSE

C-880K005: VI only supported when called through PI\_Multix.vi

Output Axis status, Error out

C-702: See GCS DLL manual or User manual for supported status bits.

C-848, C-880:

The status word for each axis is a 16-bit register containing the following information (bit encoding is 0 = LSB, 15 = MSB):

Bit #	Description
0	Motion complete flag. This bit is set (1) when the axis trajectory has completed. This flag is only valid for the S-curve, trapezoidal, and velocity contouring profile modes.
1	Wrap-around condition flag. This bit is set (1) when the axis has reached one end of its travel range and has wrapped to the other end of the travel range. Specifically, when traveling in a positive direction past the position +1,073,741,823, the axis will wrap to position -1,073,741,824, and vice-versa. The bit can be reset with the CLR command.
2	Breakpoint reached flag. This bit is set (1) when one of the breakpoint conditions has occurred.
3	Index pulse received flag. This bit is set (1) when an index pulse has been received.
4	Motion error flag. This bit is set (1) when the maximum position error is exceeded. This bit can only be reset when the axis is no longer in a motion error condition
5	Positive limit switch flag. This bit is set (1) when the positive limit switch goes active.
6	Negative limit switch flag. This bit is set (1) when the negative limit switch goes active.
7	Command error flag. This bit is set (1) when an erroneous command has been received by the motion control chip.
8*	Servo-control on/off status (1 indicates on, 0 indicates off).
9*	Axis on/off status (1 indicates on, 0 indicates off). The C-848 always has the axis ON.
10*	In-motion flag. This bit is continuously updated and indicates whether or not the axis is in motion: 1 indicates axis is in motion, 0 not in motion.
11*	Reserved (may contain 0 or 1)
12*,13*	Current axis # (13 bit = high bit, 12 bit = low bit). Axis encoding is as follows:

Bit 13	Bit12	MC Axis	C-848 Axis
0	0	1	A
0	1	2	B

1	0	3	C
1	1	4	D

14,15 Reserved (may contain 0 or 1)

C-880K005:

The status word for each axis is a 16-bit register containing the following information (bit encoding is 0 = LSB, 15 = MSB):

Bit # Description

0	Motion complete flag. Set to 1 when motion is completed. SetMotionCompleteMode determines if this bit is based on the trajectory generator position or the encoder position.
1	Wrap-around condition flag. This bit is set (1) when the actual (encoder) position wraps from maximum allowed position to minimum or vice versa.
2	Breakpoint 1 reached flag. This bit is set (1) when breakpoint 1 is triggered.
3	Capture received flag. This bit is set (1) when a position capture occurs.
4	Motion error flag. This bit is set (1) when a motion error occurs
5	Positive limit switch flag. This bit is set (1) when the positive limit switch goes active.
6	Negative limit switch flag. This bit is set (1) when the negative limit switch goes active.
7	Instruction error flag. This bit is set (1) when an instruction error occurs.
8-10	Reserved, may be 0 or 1.
11	Commutation error flag. This bit is set (1) when a commutation error occurs.
12-13	Reserved, may be 0 or 1.
14	Breakpoint 2 reached flag. This bit is set (1) when breakpoint 2 is triggered.
15	Reserved, may be 0 or 1.

Remarks Returns axis status (integer). Required by "General wait for movement to stop.vi" and "Wait for axes to stop.vi".

**2.4.13. STE.vi**

Valid for	Analog systems, C-843, C-843.PM, C-848, C-865, C-866, C-880, E-710, E-753, E-755, E-761. To support analog interfacing, VI must be present for E-816 also.
Input	System number (1), Axis to command (empty string), Step size (0), Delay (0), No. of digits (4), Error in (no error) All systems: <u>Delay</u> = 0.
Output	Error out
Remarks	Performs a step-move from, and back to, the current position with specified <u>step size</u> (amplitude). If supported, <u>Delay</u> sets the number of servo loops between position recording (GCS II: <u>Delay</u> must be 0).. <u>No. of digits</u> is the number of digits after the decimal point in the <u>step size</u> (amplitude) values that will be sent. Controller saves a definite number of position values which can be read out with STE?.vi (GCS I) or DRR?.vi (GCS II). Use "General wait for movement to stop.vi" before calling "STE?.vi" or "DRR?.vi" to make sure that motion has finished before reading back the saved



- values. For an impulse-move, see “IMP.vi”.
- Analog: Use DRR?.vi or DRR? and display data.vi to read position values back.
- C-843: Controller saves up to 32,640 position values for all 4 channels in sum. Use STE?.vi to read position values back.
- C-843.PM: Controller saves up to 32,640 position values for all 4 channels in sum. Use STE?.vi to read position values back.
- C-848: Controller saves 1024 position values. Use STE?.vi to read position values back.
- C-865: Controller saves up to 32,640 position values. Use STE?.vi to read position values back.
- C-866: Controller saves up to 32,256 position values. STE will overwrite DRC settings of Rec. table 1 to record actual position values. Use DRC to define additional record options for Rec. table no. 2 to 4. Record table rate is reset to 1 by STE. Use STE?.vi to read position values back or DRR? to read all Rec. tables back. You can also use MVR in combination with DRC to record values of a step motion. Use DRR? to read values back then.
- C-880: Controller saves 1024 position values. Use STE?.vi to read position values back.
- E-710: Controller saves 8192 position values. “Table Rate” parameter, set with SPA, is used as sampling interval instead of Delay. Caution: Table Rate parameter influences Wave Generator, not only STE. Use STE?.vi to read position values back.
- E-753: Controller saves up to 65,536 position values. Use DRR?.vi or DRR? and display data.vi to read recorded values back. The number of servo cycles used for data recording depends on the setting made with RTR. Motion commands are not allowed when the wave generator is active or the analog input is used for target generation.
- E-755: Controller saves 4,096 position values. Use DRR?.vi or DRR? and display data.vi to read recorded values back.
- E-761: Controller saves 8192 position values. The number of servo cycles used for data recording depends on the setting made with RTR. Use STE?.vi to read position values back.

**2.4.14. TPC?.vi**

Valid for	E-710, E-753, E-755, E-761 (but must be present for Analog systems, E-516 and E-816 also)
Input	System number (1), Error in (no error)
Output	Number of piezo channels, Error out
Remarks	Returns the number of available piezo channels.

**2.4.15. WPA.vi**

Valid for	E-516, E-710, E-753, E-755, E-761, E-816
Input	System number (1), Password (100), Affected axes (empty string array), Parameter no. format (Decimal: FALSE) (F), Parameter to save (empty num. array), Parameter to save (hex.) (empty hex. array), Parameter, Error in (no error)
	E-516: <u>Affected axes</u> and <u>Parameter to save</u> = empty array
	E-710: If <u>Affected axes</u> = empty array, all parameters for all axes are saved. Parameter no. format is TRUE (hex).

	E-753: If <u>Affected axes</u> = empty array, all parameters for all axes are saved. Parameter no. format is TRUE (hex).
	E-755: If <u>Affected axes</u> = empty array, all parameters for all axes are saved. Parameter no. format is TRUE (hex).
	E-761: If <u>Affected axes</u> = empty array, all parameters for all axes are saved. Parameter no. format is TRUE (hex).
	E-816: <u>Affected axes</u> and <u>Parameter to save</u> = empty array
Output	Error out, Hidden error
Remarks	<p>If password is correct, this vi writes current settings of the given parameter numbers for <u>Affected axes</u> to non-volatile memory of the controller, waits 3000 ms and queries ERR?. For axis-related parameters, <u>Affected axes</u> is the axis name; for piezo- or sensor-related parameters, the channel number; otherwise a parameter-related code. If parameter number is in decimal format, use <u>Parameter to save</u> input, for hexadecimal parameter numbers use <u>Parameter to save (hex)</u> input and switch <u>Parameter no. format</u> to TRUE. Do not mix decimal and hex. parameter numbers in one call. See GCS DLL Manual for available parameter numbers. If "Affected axes" is an empty array, WPA is sent without axis and parameter specification. <u>Hidden error</u> is TRUE if selected system reports error code <math>\neq</math> 0.</p> <p>E-516: The WPA command saves the currently valid parameters listed below to flash ROM, where they become the power-on defaults. Parameter changes not saved with WPA will be lost when the E-516 is powered off. If current parameter values are incorrect, the system may malfunction. Be sure that you have the correct parameter settings before using the WPA command. Communication interface, enabled channels and display format, averaging (AVG), drift compensation mode (DCO), velocity control mode (VCO) and velocity (VEL), offset and gain for position and output voltage display, mode and tolerance for on-target reading (SPA), position limits (NLM, PLM), voltage limits (VMA, VMI), macros and default macro setting.</p> <p>E-710: Command is available in command level 1 only (see "CCL.vi", "CCL?.vi").</p> <p>E-753: The WPA command saves the currently valid parameter values to non-volatile memory, where they become the power-on defaults. Settings not saved with WPA will be lost when the E-753 is powered off or rebooted. Parameters can be changed in volatile memory with SPA. If current parameter values are incorrect, the system may malfunction. Be sure that you have the correct parameter settings before using the WPA command.</p> <p>E-755: The WPA command saves the currently valid parameter values to non-volatile memory, where they become the power-on defaults. Settings not saved with WPA will be lost when the E-755 is powered off or rebooted. Parameters can be changed in volatile memory with SPA, APG, BDR and SSA. If current parameter values are incorrect, the system may malfunction. Be sure that you have the correct parameter settings before using the WPA command.</p> <p>E-761: The WPA command saves the currently valid parameter values and the additional settings listed below to non-volatile memory, where they become the power-on defaults. Settings not saved with WPA will be lost when the PC is powered off or the E-761 is rebooted. If current parameter values are incorrect, the system may malfunction. Be sure that you have the correct parameter settings before using the WPA command. Additional settings saved with WPA: Velocity control mode (VCO) and velocity (VEL), position limits (NLM, PLM).</p>

**2.5. Old commands and commands with alternate implementations (“Old commands.llb”)**

**2.5.1. #5\_old.vi**

Valid for	F-206, M-8X0 (but must be present for all other systems also)
Input	System number (1), Error in (no error)
Output	Overall system moving? (T/F), Sep. Axis 1 moving? (T/F), Sep. Axis 2 moving? (T/F), Error out
Remarks	Polls the motion status of the F-206/M-8X0 and/or up to 2 additional connected axes by sending the single ASCII character 5. Required by “General wait for movement to stop.vi”.

**2.5.2. Define connected systems.vi**

Valid for	C-843, C-843.PM, C-844, C-848, C-865, C-880, C-880K005, E-516, E-710, E-761, E-816, F-206, M-8X0, Mercury™
Input	Controller names (cluster of 4 Enum controls, none), Change only one system? (F), System number (1), Error in (no error)
Output	Controller names out, Error out
<b>Remarks</b>	<p>Defines connected systems and writes controller names into Global2.vi. <b>This VI is called automatically by “XXXX_Configuration_Setup.vi” (with XXXX being the PI product number of your system) and must be completed successfully before “General wait for movement to stop.vi” is called.</b> If <u>Change only one system?</u> is FALSE, all four entries from <u>Controller names</u> are written into “Global2.vi”. If <u>Change only one system?</u> is TRUE, only the entry for the given system number is overwritten in “Global2.vi”.</p> <p>Old VI – only for compatibility reasons available. Limited to 4 systems. Use Define connected systems (Array).vi instead.</p>

**2.5.3. Global2.vi**

Valid for	C-843, C-843.PM, C-844, C-848, C-865, C-880, C-880K005, E-516, E-710, E-761, E-816, F-206, M-8X0, Mercury™
Input	Connected axes (empty string array), Connected systems (Cluster of 4 enum controls, none)
Output	None
Remarks	<p>A global variable which contains identifiers for all connected axes of all connected systems and the names of all connected systems.</p> <p>Old VI – only for compatibility reasons available. Limited to 4 systems. Use Global2 (Array).vi instead.</p>

**2.5.4. Split num query command.vi**

Valid for	E-816
Input	System number (1), Query command (0: POS?), Axes to query (empty string array), Error in (no error)
Output	Values, Error out

Remarks Splits numerical query command with more than one axis specification into the corresponding one-axis commands and returns answers for all given axes. Supported commands are POS?, MOV?, VOL?, SVA? (more commands can be added).  
Old command. Use Split multiple axes command.vi instead.

**2.5.5. Wait for hexapod system axes to stop.vi**

Valid for F-206, M-8X0 (but must be present for all other systems also)

Input System number (1), All axes? (T), Axes to wait for (empty string array), Stop refnum (F), Local stop (F), Error in (no error)

To wait for the hexapod to stop, only one hexapod axis (X, Y, Z, U, V or W) needs to be commanded, because the VI cannot distinguish between the different hexapod axes.

F-206: Axes to wait for can be any of X, Y, Z, U, V, W, A, B, K, L, M  
M-8X0: Axes to wait for can be any of X, Y, Z, U, V, W, A, B

Output Error out

Remarks This vi waits for the specified axes of a PI hexapod system (hexapod axes X, Y, Z, U, V, W and separate axes A, B) to stop using #5 polling. If a NanoCube axis (K, L or M) is commanded, the VI will return immediately. If one of the hexapod axes (X, Y, Z, U, V or W) is commanded, it will wait for all six hexapod axes to stop. It returns immediately if a communications error occurred, or if Local stop or Stop refnum is TRUE. When using as a sub-VI, use Refnum stop to stop VI from caller. Required by "General wait for movement to stop.vi".

**2.6. File handling VIs ("File handling.llb")**

**2.6.1. Array File.vi**

Valid for Analog systems, C-880, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.

Input Path (empty path), Read (F)/Delete (F), ArrayName (empty string), Error in (no error)

Output Array names, Error out

Remarks This vi checks the names of all arrays in a data file or deletes a given array from a data file.

**2.6.2. File handler.vi**

Valid for Analog systems, C-702, C-866, C-880, E-710, E-753, E-755, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.

Input Path in (empty path), Read (F) or write (T)? (F), With dialog? (F), Write new file? (F), Default file name (empty string), Extension (txt)

Output Path out, Cancelled? (T/F), Data added? (T/F)

Remarks This vi handles file name selections with or without a user interface. Files can be read or written. Path in is the path to the file to read or write.

Extension is the file extension for the file to write (e.g. txt, jpg). If Read (F) or write (T) is TRUE, Extension must be given and entry must not have a dot. If With dialog? is TRUE, in every case a dialog box will pop up where the file to read or write can be selected. Default file name is used for naming suggestions if a dialog pops up. If Read (F) or write (T)? is TRUE and Write new file? is TRUE, a dialog box will pop up if the selected file name already exists. If Write new file? is FALSE and the selected file name already exists, a dialog box will pop up to ask if data should be added. Data added? indicates if data was added to an existing file. Cancelled? indicates if the user has cancelled the operation. Path out is NotAPath if operation was cancelled or not successful and contains the selected path for the file which was read or written if the operation was successful.

### 2.6.3. GetDataFormat.vi

Valid for	Analog systems, C-702, C-866, C-880, E-710, E-753, E-755, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.
Input	IOSource (Read (F)/Write (F), Path (empty path), ArrayName (empty string), Datastream (empty string)), Error in (no error)
Output	Header out (Separator, NDim, Remarks), DataOK, Found Header, Data Type, NData, Names out, Sample time, Error out
Remarks	This vi checks the format of a data file. See separate manual "GCSDData_User_SM146E.pdf" and control descriptions in the diagram for more information.

### 2.6.4. MatrixIO.vi

Valid for	Analog systems, C-866, C-880, E-753, E-755, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.
Input	IOSource (Read (F)/Write (F), Path (empty path), ArrayName (empty string), Datastream (empty string)), Header in (Separator (\t), NDim (0), Remarks (empty string)), Data names (XName (empty string), YName (empty string), ZName (empty string)), XArray in (empty num. array), YArray in (empty num. array), ZMatrix in (empty 2D num. array), Sample time in (0), (Error in (no error))
Output	Datastream out, Header out (Separator, NDim, Remarks), Data names out (XName, YName, ZName), XArray out, YArray out, ZMatrix out, Sample time out, Error out
Remarks	This vi reads or writes data files in matrix format. See separate manual "GCSDData_User_SM146E.pdf" and control descriptions in the diagram for more information.

### 2.6.5. TableIO.vi

Valid for	Analog systems, C-702, C-866, C-880, E-710, E-753, E-755, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.
Input	IOSource (Read (F)/Write (F), Path (empty path), ArrayName (empty string), Datastream (empty string)), Header in (Separator (\t), NDim (0), Remarks (empty string)), Names in (empty string array), Table in (empty 2D num. array), Sample time in (0), (Error in (no error))
Output	Datastream out, Header out (Separator, NDim, Remarks), Names out, Table out, Sample time out, Error out

Remarks This vi reads or writes data files in table format. See separate manual “GCSDData\_User\_SM146E.pdf” and control descriptions in the diagram for more information. Sub-VI for “DRR?.vi”.

## 2.7. Limit- and reference-specific commands (“Limits.IIb”)

### 2.7.1. TMN?.vi

Valid for Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-710, E-753, E-755, E-761, Mercury™. To support analog interfacing, VI must be present for E-816 also.

Input System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)

Analog: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-702: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-843: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-843.PM: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-844: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-848: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-865: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-866: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-880: If All axes? = TRUE, then Axis identifier? can be FALSE  
 E-710: If All axes? = TRUE, then Axis identifier? must be TRUE  
 E-753: If All axes? = TRUE, then Axis identifier? can be FALSE.  
 E-755: If All axes? = TRUE, then Axis identifier? can be FALSE. Command not available for E-755.101.  
 E-761: If All axes? = TRUE, then Axis identifier? can be FALSE  
 Mercury™: If All axes? = TRUE, then Axis identifier? can be FALSE

Output Minimum travel limit, Error out

Remarks Returns minimum (low-end) travel limit (if present, position of negative limit switch, or value of negative soft limit, if set, whichever is higher).

E-761: Get the minimum accessible position value, i.e. the value of the "Range min limit" parameter (ID 0x07000000). Note: The minimum position which can be commanded depends either on the "Range min limit" parameter or—if it is greater than the "Range min limit" parameter value— on the value of the negative soft limit set with NLM.

### 2.7.2. TMX?.vi

Valid for Analog systems, C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, E-710, E-753, E-755, E-761, Mercury™. To support analog interfacing, VI must be present for E-816 also.

Input System number (1), Axes to query (empty string array), All axes? (F), Axis identifier? (T), Error in (no error)

C-702: If All axes? = TRUE, then Axis identifier? can be FALSE

C-702: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-843: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-843.PM: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-844: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-848: If All axes? = TRUE, then Axis identifier? can be FALSE  
 C-865: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-866: If All axes? = TRUE, then Axis identifier? must be TRUE  
 C-880: If All axes? = TRUE, then Axis identifier? can be FALSE  
 E-710: If All axes? = TRUE, then Axis identifier? must be TRUE  
 E-753: If All axes? = TRUE, then Axis identifier? can be FALSE.  
 E-755: If All axes? = TRUE, then Axis identifier? can be FALSE. Command not available for E-755.101.  
 E-761: If All axes? = TRUE, then Axis identifier? can be FALSE  
 Mercury™: If All axes? = TRUE, then Axis identifier? can be FALSE

Output Maximum travel limit, Error out  
 Remarks Returns maximum (high-end) travel limit (if present, position of positive limit switch or value of positive soft limit, if set, whichever is lower).  
 E-761: Get the maximum accessible position value, i.e. the value of the "Range max limit" parameter (ID 0x07000001). Note: The maximum position which can be commanded depends either on the "Range max limit" parameter or—if it is smaller than the "Range max limit" parameter value— on the value of the positive soft limit set with PLM.

## 2.8. Commands for Optical or Analog Signals (“Optical or Analog Input.IIb”)

### 2.8.1. TSC?.vi

Valid for E-710, E-753, E-755, E-761 (but must be present for Analog systems, E-516 and E-816 also)  
 Input System number (1), Error in (no error)  
 Output Number of sensor channels, Error out  
 Remarks Returns the number of available sensor channels.  
 E-753: The response comprises all ADC channels of the device: the "genuine" sensor (capacitive sensor integrated in the mechanics) and the "general purpose" analog input.

**2.9. Support VIs for scanning algorithms (“Scan support.Ilb”)**

**2.9.1. Axis names.vi**

Valid for	Analog systems, C702, C-866, C-880, E-710, E-753, E-755, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.
Input	Names (empty string array)
Output	X axis name, Y axis name, Z axis name
Remarks	Checks if "Names" contains three strings for axis names. If this is not the case, it assigns "X Values", "Y Values" and/or "Z Values" as the missing axis name.

**2.10. Wave-Generator-Specific Commands (“WaveGenerator.Ilb”)**

**2.10.1. SWT.vi**

Valid for	E-816
Input	System number (1), Axis (empty string), No. of digits (3), Max. n values (64), A <sub>0</sub> ,...,A <sub>n-1</sub> (0.001, 0.002, ..., 0.01), Error in (no error) E-816: <u>Max. n values</u> = 64
Output	Successful? (T/F), Error out
Remarks	This vi defines a waveform for one axis. Data points are transferred point by point. <u>Max. n values</u> is the maximum number of points that can be transferred. <u>No. of digits</u> is the number of digits after the decimal point in the data point value(s) that will be sent. Please refer to the User Manual for units and restrictions.

**2.10.2. SWT?.vi**

Valid for	E-816
Input	System number (1), Axis (empty string), Index (1), Error in (no error)
Output	Value, Error out
Remarks	Returns wave table point with given index for given axis.

**2.10.3. WTO.vi**

Valid for	E-816
Input	System number (1), Axis to command (empty string), No. of output points (0), With Internal Trigger Timer? (F), Timer (ms) (1000), Error in (no error)
Output	Error out
Remarks	Sets the wave table output. If <u>No. of output points</u> = 0, wave table output is disabled, otherwise <u>No. of output points</u> will be sent to the given axis. <u>No. of output points</u> must be less than or equal to 64. If <u>With Internal Trigger Timer?</u> is TRUE and <u>Timer (ms)</u> is greater than zero, the internal trigger is used in addition to the external trigger line (if any), but the external trigger resets the internal trigger timer.



**2.11. Analog controller VIs (“Analog control.lib”)**

**2.11.1. Analog FGlobal.vi**

Valid for	Analog systems (but must be present for all other systems also)
Input	System no. (1), Read(F)/Write (TRUE), VI ref in
Output	VI ref out
Remarks	This VI works as a functional global variable for VI references

**2.11.2. Analog functions (dyn).vi**

Valid for	Analog systems
Input	System number (1), Command (INITIALIZE), String (empty string), AI Task, AO Task, W_Wave settings, Continuously? (TRUE), Error in (no error)
Output	String output, Boolean output, Error out
Remarks	Executes DAQmx functions and other tasks, depending on <u>String to send</u> . VI is called dynamically from “Analog Functions.vi”.

**2.11.3. Analog functions.vi**

Valid for	Analog systems (but must be present as a Dummy VI for all other systems also)
Input	System number (1), String to send (empty string), type specifier VI Refnum, AI Task, AO Task, Waveform to write, Continuously? (TRUE), Error in (no error)
Output	Command, String output, Boolean output, Error out
Remarks	Calls Analog Functions (dyn).vi functions dynamically during runtime, depending on <u>String to send</u> .

**2.11.4. Analog functions.vi**

Valid for	Analog systems (but must be present for all other systems also) --- Dummy VI
Input	System number (1), String to send (empty string), type specifier VI Refnum, AI Task, AO Task, Waveform to write, Continuously? (TRUE), Error in (no error)
Output	Command, String output, Boolean output, Error out
Remarks	Dummy VI

**2.11.5. Analog Receive String.vi**

Valid for	Analog systems (but must be present for all other systems also)
Input	System number (1), Read/Write (T) (FALSE), Ini (False), Error in (no error)
Output	String out, Strings out, Error out
Remarks	Works as an old style global variable for String out.

**2.11.6. Available Analog Commands.ctl**

Valid for	Analog systems (but must be present for all other systems also)
Input	None

Output           None  
Remarks        Type definition for available analog commands.

**2.11.7. Global Analog.vi**

Valid for        Analog systems (but must be present for all other systems also)  
Input            None  
Output           None  
Remarks        A global variable which contains setup information for analog systems.

## 2.12. Support VIs (“Support.llb”)

Support VIs are sub-VIs for command VIs which make certain programming tasks more convenient. They can also be used for building main programs.

**Caution:** Please do not change these VIs, as that might cause the command VIs that use them to fail.

### 2.12.1. Analyse input string for terminal.vi

Valid for	All except analog systems
Input	String new (empty string), Last string sent (empty string)
Output	String out, Out not equal to in? (T/F), Attach term. char.? (T/F)
Remarks	This VI is a sub-VI for “PI Terminal.vi”. It analyses <u>String new</u> and returns it in <u>String out</u> if it is not empty and does not contain a “#” at the beginning. In case of an empty new string, <u>Last string sent</u> is returned. If <u>String new</u> contains a “#” character, the corresponding ASCII character is returned.

### 2.12.2. Assign booleans from string to axes.vi

Valid for	All Systems
Input	System number (1), Queried axes (empty string array), All axes queried? (F), Input string (empty string), Error in (no error)
Output	Booleans(T/F), Error out
Remarks	This VI assigns numerical values from input string to boolean values for queried axes. If <u>All axes?</u> is TRUE, connected axes are read from Global2.vi and displayed on the front panel for assignment.  Example: An input string like “A=0SpaceLinefeedB=1Linefeed” or “0SpaceLinefeed1Linefeed” will be converted to an output array consisting of two values “FALSE; TRUE”.
Remarks	This VI assigns numerical values / strings from input string to queried axes and parameter numbers. Sub-VI for “DRT?.vi”.

### 2.12.3. Assign NaN for chosen axes.vi

Valid for	Analog systems, C-702, C-843, C-843.PM, C-848, C-865, C-866, C-880, E-753, E-755, F-206, M-8X0, Mercury™. To support analog interfacing, VI must be present for E-816 also.
Input	Queried axes (empty string array), Values (empty num. array), Axes subset (empty string array), Value to set (NaN)
Output	New values
Remarks	This VI returns “NaN” or any given <u>Value to set</u> for the given axes subset.

### 2.12.4. Assign SPA values from string to axes.vi

Valid for	C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™
Input	Input string (empty string), Parameter no. format (Decimal: FALSE, F), Syntax (GCS 1.0), Queried axes (empty string array), Parameter no. (empty num. array, 0), Parameter no. (hex) (empty hex. array, 0), Error in (no error)

Output	Parameter values, Parameter strings, Queried axes out, Parameter no. out, Parameter no. (hex) out, Error out
Remarks	This VI assigns numerical values / strings from input string to queried axes and parameter numbers. Sub-VI for "SPA?.vi" and "SEP?.vi".

**2.12.5. Assign values from string to axes.vi**

Valid for	All systems
Input	System number (1), Queried axes (empty string array), All axes queried? (F), Axes related? (T), Input string (empty string), Error in (no error)
Output	Values, Strings, Error out
Remarks	This VI assigns numerical values and/or single lines from input string to queried axes. If <u>All axes?</u> is TRUE, connected axes are read from Global2.vi and displayed on the front panel for assignment. If <u>All axes?</u> is TRUE and <u>Axes related?</u> is FALSE, item names from <u>Input string</u> are displayed instead of connected axes.

**2.12.6. Boolean array calculations.vi**

Valid for	All systems
Input	Array1 (empty bool. array), Array2 (empty bool. array), Array3 (empty bool. array), Operator (AND)
Output	Array out
Remarks	This vi performs a boolean operation of up to three boolean input arrays. The difference to LabVIEW's own boolean operators is that the input arrays can have different sizes. The missing elements are considered to be FALSE elements and the resulting array contains the maximum number of elements.

**2.12.7. Build channel query command substring.vi**

Valid for	Analog systems, E-516, E-710, E-753, E755, E-761, E-816
Input	System number (1), Channels to query in (empty string array), Query all channels? (F), With space? (F), Channel identifier? (T), Channel type (piezo), Error in (no error)
Output	Command substring, Channels to query out, Number of rows, Error out
Remarks	This VI builds a query command substring for channel query commands. If <u>All channels?</u> is TRUE, channels to command are determined in a controller specific way and returned in <u>Channels to query out</u> , otherwise <u>Channels to query out</u> is identical with <u>Channels to query in</u> . <u>Number of rows</u> is size of the <u>Channels to query out</u> array. If <u>Channel identifier?</u> is FALSE, command substring is an empty string (e.c. for systems which accept commands like VMA? without channel IDs). If <u>With space?</u> is TRUE, a space character is added between the channel identifiers.

**2.12.8. Build command substring.vi**

Valid for	All systems
Input	Affected axes (empty string array), No. of digits (4), Parameters (empty num. array, 0), Parameters (hex.) (empty hex. array), Parameter no. format (Decimal: FALSE) (F), With space? (F)

Output Command substring

Remarks This VI builds a command substring by combining axis identifier and parameter. If parameter number is in decimal format, use Parameters input, for hexadecimal parameter numbers use Parameters (hex.) input and switch Parameter no. format to TRUE. Do not mix decimal and hex. parameter numbers in one call. No. of digits is the number of digits after the decimal point in the parameter value(s) that will be sent.

Example: For Affected axes = A; B, Parameters = 1.2342; 2.3 and No. of digits = 3 the resulting string is "SpaceA1.234SpaceB2.300".

**2.12.9. Build num command substring.vi**

Valid for All systems

Input No. of digits (4), Num 1 (empty num. array, 0), Num 2 (empty num. array, 0)

Output Command substring

Remarks This VI builds a command substring by combining Num1, Space and Num2. No. of digits is the number of digits after the decimal point in the Num 1/2 value(s) that will be sent.

Example: For Num 1 = 1.24; 3.25456, Num 2 = 5.0; 7.4321 and No. of digits = 3 the resulting string is "Space1.240Space5.000Space3.255Space7.432"

**2.12.10. Build query command substring.vi**

Valid for All systems

Input System number (1), Axes to query in (empty string array), Query all axes? (F), With space? (F), Axis identifier? (T),

Output Command substring, Axes to query out, Number of rows

Remarks This VI builds a query command substring. If All axes? is TRUE, connected axes are read from "Global2.vi" and returned in Axes to query out, otherwise Axes to query out is identical with Axes to query in. Number of rows is size of the Axes to query out array. If Axis identifier? is FALSE, command substring is an empty string (e.c. for systems which accept commands like POS? without axis IDs). If With space? is TRUE or system supports GCS II, a space character is added between the axes identifiers.

Example: If axes A;B;C;D are connected to the system to command, Axes to query in is A;B;D, Query all axes? is TRUE and Use Axis identifier? is TRUE, resulting Command substring is "ABCD", Number of rows is 4 and Axes to query out is A;B;C;D. If With space? is TRUE, the resulting Command substring is "A B C D".

**2.12.11. Build SPA command substring.vi**

Valid for C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-753, E-816, Mercury™ (but must be present for E-710, E-755 and E-761 also)

Input Axes to set (empty string array), No. of digits (4), Parameter no. format (Decimal: FALSE, F), Parameter format (Num.: FALSE, F), Parameter number (empty num. array, 0), Parameter number (hex) (empty hex. array, 0), Parameter values (empty num. array, 0), Parameter strings (empty string array), With space? (F)

Output SPA command substring  
 Remarks This VI builds a command substring for the SPA command. No. of digits is the number of digits after the decimal point in the parameter value(s) that will be sent. Sub-VI for “SPA.vi”, “CTO.vi”, “WTR.vi”.

**2.12.12. Build SPA query command substring.vi**

Valid for C-702, C-843, C-843.PM, C-844, C-848, C-865, C-866, C-880, C-880K005, E-516, E-710, E-753, E-755, E-761, E-816, Mercury™  
 Input Axes to query (empty string array), Parameter no. format (Decimal: FALSE, F), Syntax (GCS 1.0), Parameter number (empty num. array, 0), Parameter number (hex) (empty hex. array, 0)  
 Output Command substring, Number of rows  
 Remarks This VI builds an SPA? Command substring. Axes and parameters are combined into a substring, depending on Parameter no. format. Number of rows is size of Axes to query array. Sub-VI for “SPA?.vi” and “SEP?.vi” .

**2.12.13. Build stringplusnum substring.vi**

Valid for All systems  
 Input Sequence (String1String2String3Value1Value2), String1 (empty string array), String2 (empty string array), String3 (empty string array), Value1 (empty num. array, 0), Value2 (empty num. array, 0), No. of digits Value1 (6), No. of digits Value2 (6), Input selection (T,T,T,T,F), Error in (no error)  
 Output Substring, Error out  
 Remarks This vi builds a command substring by combining up to three strings and two values in the given order.

**2.12.14. Commanded axes connected?.vi**

Valid for All systems  
 Input System number (1), Commanded axes (empty string array), Error in (no error)  
 Output Controller error (T/F), Error out  
 Remarks This VI checks if Commanded axes are a subset of all connected axes (read from “Global2 (Array).vi”) and returns Controller error TRUE if this is not the case. Connected axes are defined by “Define connected axes.vi”, which is called by “XXX\_Configuration\_Setup.vi” automatically. White space strings in Commanded axes are ignored.

**2.12.15. Convert num array to string.vi**

Valid for All systems  
 Input Number of digits (4), Num. values (empty num. array)  
 Output Output string  
 Remarks This vi converts an array of numerical values to a space separated output string. The difference to LabVIEW's native Array to Spreadsheet String function is that no carriage return or newline is added.

**2.12.16. Convert num value to syntax selection.vi**

Valid for	All systems
Input	GCS syntax version (1,00)
Output	Syntax
Remarks	This VI converts a numerical value to the corresponding GCS syntax version.

**2.12.17. Count occurrences in string.vi**

Valid for	All systems
Input	Input string (empty string), Expression (empty string)
Output	Occurrences
Remarks	This VI counts, how often an expression occurs in a string.

**2.12.18. Cut out additional spaces.vi**

Valid for	All systems
Input	Mode (All Spaces), String (empty string)
Output	String out
Remarks	Searches for spaces in <u>String</u> and cuts them out, depending on <u>Mode</u> .

**2.12.19. Define axes to command from boolean array.vi**

Valid for	All systems
Input	Axes to query (empty string array), Command axis? (empty bool. array, F)
Output	Axes to command, Remaining axes
Remarks	This VI returns only those axis IDs from the <u>Axes to query</u> array in the <u>Axes to command array</u> which have a boolean value TRUE in the <u>Command axis?</u> array, and all remaining axes in the <u>Remaining axes</u> array.

**2.12.20. GCSTranslateError.vi**

Valid for	All systems
Input	Error in (no error)
Output	Error out, GCS Error?, Error description
Remarks	Returns if <u>error in</u> contains a GCS error code and if this is the case, it displays the corresponding error message and appends it to <u>source in error out</u> .

**2.12.21. General wait for movement to stop.vi**

Valid for	All systems
Input	System no. (1), Axes to wait for (empty string array), All axes? (T), Polling cycle time, ms (1), Additional wait time, ms (0), Error in (no error) E-816: <u>All axes?</u> = FALSE, only one axis per command allowed F-206: VI will not wait for INI procedure to complete. M-8X0: VI will not wait for INI procedure to complete.
Output	Error out

Remarks This VI waits for the specified axes to stop. An additional wait time can be specified. The wait method depends on the system to command. "XXX\_Configuration\_Setup.vi" (with XXX being the product name of your system) must be run before running this vi. Requires "Wait for axes to stop.vi", "#5.vi", "STA?.vi", "#5\_old.vi", "ONT?.vi" and "Wait for hexapod system axes to stop.vi" to be present.

**2.12.22. Get all axes.vi**

Valid for All systems  
 Input System no. (1)  
 Output Conn. Axes  
 Remarks This VI reads all connected axes for given system from "Global2 (Array).vi". Connected axes are defined by "Define connected axes.vi", which is called by "XXX\_Configuration\_Setup.vi" automatically.

**2.12.23. Get arrays without blanks.vi**

Valid for All systems  
 Input String array in (empty string array), Values in (empty num. array), Booleans in (empty bool. array, F), Array size in (0)  
 Output String array out, Values out, Booleans out, Array size out  
 Remarks Returns the string array and related values and boolean arrays without white space string fields.

**2.12.24. Get lines and values from string.vi**

Valid for All systems  
 Input Array size (0), Input string (empty string)  
 Output Numerical values, Strings  
 Remarks This VI returns numerical values and single lines from input string without any axis assignment. If number of lines/values (Array size) is known, algorithm is faster, otherwise Array size = 0 should be used. Sub-VI for "VST?.vi" and "STE?.vi".

**2.12.25. Get lines from string.vi**

Valid for All systems  
 Input Array size (0), Input string (empty string)  
 Output Strings  
 Remarks This VI returns single lines from input string. If number of lines (Array size) is known, algorithm is faster, otherwise Array size = 0 should be used. Sub-VI for "VST?.vi".

**2.12.26. Get string array size without blanks.vi**

Valid for All systems  
 Input String array (empty string array)  
 Output Corrected array size  
 Remarks This VI returns the size of a string array without counting white space



strings.

**2.12.27. How often does string contain regular expression.vi**

Valid for	All systems
Input	Regular expression (empty string), String (empty string)
Output	Number
Remarks	This VI returns a count of the occurrences of a regular expression in a string.

**2.12.28. Increase array size.vi**

Valid for	All systems
Input	Size (0), Array in (empty num. array, NaN), Only if Array is not empty?
Output	Array out
Remarks	If size of <u>Array in</u> is smaller than <u>Size</u> , this VI increases the size of <u>Array in</u> to <u>Size</u> . If <u>Array in</u> is an empty array and <u>Only if Array is not empty?</u> is FALSE, VI builds an array of zeros with the size of <u>Size</u> .

**2.12.29. Manual VMO.vi**

Valid for	C-844, C-848, C-848.PM, C-865, C-880, E-516, E-710, E-761, E-816, F-206, M-8X0
Input	System number (1), Axes to command (empty string array), Minimum pos. (empty num. array), Maximum pos. (empty num. array), Position values (empty num. array, 0), Error in (no error)
Output	Move possible (T/F), Error out
Remarks	Virtual movement. Indicates whether a move to the specified position is possible or not by checking if the commanded position value is within the given position range. Axes will NOT be moved.

**2.12.30. Return single characters from string.vi**

Valid for	All systems
Input	Input string (empty string), Invert order (F), Error in (no error)
Output	Character array (empty string array), Error out
Remarks	Get single characters from input string.

**2.12.31. Return space.vi**

Valid for	All systems
Input	System no. (1), With space? (F)
Output	String out, Space returned?
Remarks	This VI returns a space character in <u>String out</u> if <u>With space?</u> is TRUE or GCS syntax version is higher than 1.0.


**2.12.32. Round with options.vi**

Valid for	All systems
Input	No. of digits to round to (2), Round mode selection (Round to nearest),

Output Numeric in (0), Num array in (empty num. array)  
 Output Numeric out, Num array out  
 Remarks Rounds Numeric in and Num array in according to No. of digits to round to and Round mode selection.

**2.12.33. Select axis.vi**

Valid for All systems  
 Input System number (1)  
 Output Selected axis, Index of axis in Global2  
 Remarks This VI reads all connected axes from Global2 and writes them into a menu ring control for selection. The selected axis and it's index in Global2 are returned.



**2.12.34. Select values for chosen axes.vi**

Valid for All systems  
 Input Queried axes (empty string array), Values (empty num. array), Axes subset (empty string array)  
 Output Values subset  
 Remarks This VI returns only values for the given axes subset.

**2.12.35. Select with boolean array input.vi**

Valid for All systems  
 Input Size (0), T string (empty string), F string (empty string), T/F (empty boolean array)  
 Output String array out  
 Remarks This vi returns a string array of a given size with T string and F string, depending on the boolean value at the corresponding index of T/F.

**2.12.36. Selection to string array.vi**

Valid for All systems  
 Input Selection array (empty Menu Ring array, 0), String input (empty string array)  
 Output String array

Remarks This vi returns a string array which contains strings according to the selected value of String input.  
 Example: For Selection array = (2,0,1) and String input = (A,B,C) the resulting String array is (C,A,B).

**2.12.37. Split multiple axes command.vi**

Valid for E-816  
 Input System number (1), Command (POS?), Wait time (10), Axes to command (empty string array), Num. values in (empty num. array), Bool. values in (empty bool. array), Stop refnum, Error in (no error)  
 Output Num. values out, Bool. values out, Error out  
 Remarks Splits command with more than one axis specification into the corresponding one-axis commands and returns answers for all given axes (if any). Wait time (ms) defines the time to wait between single commands. When using as a sub-VI, connect Stop refnum terminal to stop VI from caller. Supported commands are DCO, DCO?, MOV, MOV?, MVR, ONT?, OVF?, POS?, SVA, SVA?, SVO, SVO?, SVR, VOL? and General Wait for movement to stop (GWait).

**2.12.38. Subtract axes array subset from axes array.vi**

Valid for All systems  
 Input Axes to query (empty string array), Axes subset (empty string array)  
 Output Axes to command, All present?  
 Remarks This VI returns only these axes IDs from the Axes to query array which are **not** present in the Axes subset array. If no axes IDs are returned, All present? is TRUE. Needed by "Define axes to command from boolean array.vi".

**2.12.39. Unbundle/bundle interface clusters for PI Terminal.vi**

Valid for All except analog systems  
 Input System number (1), Interface configuration (RS232, 1000, COM1, 57600), DLL interface configuration (C-843, Board, 1), Flow control (All FALSE, x13, x11, x0), TCP/IP Configuration (localhost, 3000, 0), Termination character (LF)  
 Output Interface, RS232 configuration system, GPIB configuration system, DLL for device, DLL interface, TCP/IP config. system, Term. char  
 Remarks This VI is a sub-VI for "PI Terminal.vi". It unbundles Interface configuration and DLL interface configuration and returns the cluster contents in a different composition which is used by "PI Terminal.vi".

**2.12.40. Wait for axes to stop.vi**

Valid for C-702, C-843, C-843.PM, C-844, C-848, C-865, C-880, E-753, E-755, Mercury™ (but must be present in Support.Ilb for all other systems also)  
 Input System number (1), Axes to wait for (empty string array), With status bit polling? (F), Polling cycle time, ms (400), Stop refnum (F), Local stop (F), Error in (no error)  
 C-702: With status bit polling? = FALSE

C-843: With status bit polling? = FALSE

C-843.PM: With status bit polling? = FALSE

C-844: With status bit polling? = FALSE

C-880: With status bit polling? = TRUE

E-753: With status bit polling? = FALSE

E-755: With status bit polling? = FALSE

Mercury™: With status bit polling? = FALSE

Output

Error out

Remarks

This VI waits for the specified axes to stop using #5 polling. It also stops if a communication error occurred, Stop refnum or Local stop is TRUE.


Requires "STA?.vi" to be present. Required by "General wait for movement to stop.vi". When using as a sub-VI, use Stop refnum to stop VI from caller.

### 3. High Level VIs

#### 3.1. PI Terminal.vi

The terminal VI is a stand-alone application. It first asks the user to specify the full configuration (number of controlled systems, RS-232, GPIB, TCP/IP or DLL communication, communications parameters), then it establishes a connection with a selected system. This will work for all PI devices which support the PI General Command Set, or at least follow the same syntax rules and support the \*IDN? and ERR? commands.

After starting the VI, the interface parameters of the systems with which to communicate must be selected. For this reason, "PI Terminal.vi" calls "PI Ask for Communication Parameters.vi". Select here the number of connected PI systems that you want to communicate with. For each system, select the appropriate interface parameters.



- C-702: Interface = RS232 or TCP/IP, RS232: Input and output HW handshake must be TRUE. Syntax: GCS 1.0; Term char = LF.
- C-843: Interface = DLL, DLL for Device = C-843, DLL Interface = Board, Parameter = Board number (1 for first C-843 board). Syntax: GCS 1.0; Term char = LF.
- C-843.PM: Interface = DLL, DLL for Device = C-843.PM, DLL Interface = Board, Parameter = Board number (1 for first C-843 board). Syntax: GCS 1.0; Term char = LF.
- C-844: Interface = DLL, DLL for Device = C-844, DLL Interface = RS232 or GPIB, Parameter = empty string, RS232 baud rate = 9600. Syntax: GCS 1.0; Term char = LF.
- C-865: Interface = DLL, DLL for Device = C-865, DLL Interface = RS232, Parameter = empty string, RS232 baud rate = set as appropriate. Syntax: GCS 1.0; Term char = LF.
- C-866: Interface = DLL, DLL for Device = C-866, DLL Interface = RS232 or USB, RS232: Parameter = empty string, RS232 baud rate = set as appropriate, USB: Parameter = Serial no. of system to connect to, Syntax: GCS 1.0; Term char = LF.
- C-880, C-848: Interface = RS232 or GPIB, RS232: Input and output HW handshake must be TRUE. Syntax: GCS 1.0; Term char = LF.
- C-880K005: Interface = RS232, Input and output HW handshake must be FALSE. Syntax: GCS 1.0; Term char = LF.
- E-516: Interface = RS232 or GPIB, RS232: Input and output HW handshake must be TRUE. Syntax: GCS 1.0; Term char = LF.
- E-710: Interface = DLL, DLL for Device = E-710, DLL Interface = RS232 or GPIB, Parameter = empty string. Syntax: GCS 1.0; Term char = LF.
- E-753: Interface = RS232 or TCP/IP, RS232: Input and output HW handshake must be TRUE. Syntax: GCS 2.0; Term char = LF.
- E-755: Single Device: Interface = RS232, Input and output HW handshake must be TRUE. DaisyChain: Interface = DLL, DLL for Device = E-755, DLL Interface = RS232\_DC, Parameter = Number of device in chain (first device: 1). Syntax: GCS 2.0; Term char = LF.
- E-761: Interface = DLL, DLL for Device = E-761, DLL Interface = Board, Parameter = Board number (1 for first E-761 board). Syntax: GCS 1.0; Term char = LF.
- E-816: Interface = RS232 (supports only RS-232 communication), Input and output HW handshake must be TRUE. Syntax: GCS 1.0; Term char = LF.
- F-206: Interface = RS232 or GPIB, The error status will not be cleared by this VI. The first ERR? query will report a hidden error with error code 1, which will be cleared during system initialization (INI). RS232: Input and output handshake settings must be FALSE. Syntax: GCS 1.0; Term char = LF.
- M-8X0: Interface = RS232 or GPIB. RS232: Input and output handshake settings must be FALSE. Syntax: GCS 1.0; Term char = LF.
- Mercury™: Interface = DLL, DLL for Device = Mercury™, DLL Interface = RS232, Parameter = empty string, RS232 baud rate = set as appropriate. Syntax: GCS 1.0; Term char = LF.

If the chosen timeout value is greater than 300 ms, it will automatically be set to 300 ms for a fluid program operation.

In the upper window ("Send") the user can enter commands which will be transmitted to the chosen device one line at a time when the ENTER key is pressed.


All controller responses are displayed in the Receive response window, which can be cleared by pressing the Clear Receive Window button or F2.

The view style of the Receive window can be changed to Show all characters or Hex View using the menu ring above the Receive window.

Exit or F10 will terminate the terminal application.

To send the last command again, just press the ENTER key again. The next line will then show the following entry: "(Send: cmd)" with *cmd* being the command from the line before, which was resent.

When the terminal application has just been started, pressing ENTER without entering a command will send "\*IDN?" to the chosen system.



New commands can only be inserted into the last line of the Send window. The user can scroll through the history of the Send window using the scroll bar or the cursor up/down keys, but cannot change the history or resend commands by pressing ENTER unless in the last line. Pressing ENTER will always resend the last command, no matter where the cursor is positioned. Selecting text and using copy and paste (Ctrl+C, Ctrl+V) works for single lines, if only the contents of one single line (the command text) is selected and copied, not the full line (including the LineFeed) or multiple lines.

Many of PI's General Command Set compatible devices support single-byte commands. For example, the user can stop a fast scan of a C-880 or F-206 by sending an ASCII 24 (decimal). To enter this command into the Send window simply type a "#" followed by the decimal value of the byte to be sent, e.g. enter "#24" and presses ENTER to stop a fast scan. An entry "(Send: \*)" will be added to the original command with \* being the corresponding ASCII character of the single byte sent.

Pressing F1 or the Help button will pop up a help window. To return to the terminal application, press Esc. If Send ERR? on Exit? is TRUE, an "ERR?" query is sent to the device when Exit is pressed to prevent the controller from keeping an error condition produced during the use of the terminal application.




### 3.2. E816\_Simple\_Test.vi

This simple test VI is a stand-alone sample application. Use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

Specify first:

- System no. (= 1 in a one-system configuration),
- Timeout value (in milliseconds)
- Portnumber
- Baudrate. If you don't know the baudrate settings of the connected E-816, leave Try different baudrates? TRUE. The VI will then try to find the correct baudrate automatically by calling "Find baudrate.vi".

Then start the VI. The VI will open a connection to the E-816 and query the controller for the available axis IDs, position values of these axes, and the master E-816 identification string. The diagram shows how to combine the driver and support VIs for these tasks.




### 3.3. E816\_Configuration\_Setup.vi

This VI performs a fully automatic initialization of the selected system (global settings and servo status) in the LabVIEW environment. Use the *Help*→*Show Context Help* menu sequence in the LabVIEW environment to display the *Context Help* window with the VI and control/indicator descriptions.

After the successful running of this VI, all command VIs are ready to use. Specify the correct parameters first:

- System No.: 1 in a one-system-only configuration
- Timeout value (in milliseconds)
- RS232 settings (Portnumber and Baudrate)
- Whether the servo status of all axes is to change to TRUE. If FALSE is selected here, the servo status will not be changed.



Then start the VI.

“E816\_Configuration\_Setup.vi” performs the following initialization tasks:

1. Initializes all global variables.
2. Runs “PI Open Interface of one system.vi” to open a connection to the controller.
3. Runs “\*IDN?.vi” to query for the controller identification string.
4. Defines the selected system to be "E-816"

5. Runs "Define connected axes.vi" with Read from controller = TRUE and Invert Order? = FALSE.
6. Runs "SVO.vi" to switch servo ON for all connected axes if Change servo status to ON is TRUE.
7. Runs "SVO?.vi" to query for the servo status of all connected axes.
8. Runs "POS?.vi" to query for the position of all axes.
9. Runs "ERR?.vi" to query the controller for its error status.
10. Runs "GCSTranslateError.vi" to append the error message which corresponds with a GCS error number returned by "ERR?.vi" to Source from Error out.

Use this VI as the initialization VI for the E-816 in your application.

When using as a sub-VI, connect Stop refnum terminal to stop VI from caller.


As the initialization is a complex procedure which uses a large number of sub-VIs, E816\_Configuration\_Setup.vi is password-protected, meaning that you cannot see or modify the diagram. In this way, the full initialization is packed into one single and fully tested procedure which you simply insert into your own application program. For security reasons as well as your convenience, we recommend that you not modify this VI.

### 3.4. E816\_Sample\_Application\_1.vi

This VI demonstrates how to initialize an E-816 system, how to move an axis and how to query for the position value of this axis. In this example the E-816 is connected through COM port 1 with baudrate 57600. The VI runs E816\_Configuration\_Setup.vi with these specified settings, moves the first axis relative to its current position, waits for the motion to finish and reads the position of the axis and the error status of the controller. The diagram shows how to combine the driver VIs for these tasks.

For an example of how to command multiple axes see E816\_Sample\_Application\_1a.vi

**Warning:** Before running this VI, modify the "RS232 settings" on the block diagram to reflect your configuration. The predefined settings provided with the VI probably do not match your system.




### 3.5. E816\_Sample\_Application\_1a.vi

This VI demonstrates how to initialize an E-816 system with more than one axis, how to move all connected axes and how to query for the position value. In this example the E-816 is connected through COM port 1 with baudrate 57600. The VI runs E816\_Configuration\_Setup.vi with specified settings, moves the connected axes relative to their current position, waits for the motion to finish and reads the position of the axes and the error status of the controller. Instead of calling the corresponding command VIs, it uses "Split multiple axes command.vi" which sends the chosen commands for the given axes one after another and returns the answer array (if any). The diagram shows how to combine the driver VIs for these tasks.


For an example of how to command a single axis E-816 system see E816\_Sample\_Application\_1.vi

**Warning:** Before running this VI, modify the "RS232 settings" on the block diagram to reflect your configuration. The predefined settings provided with the VI probably do not match your system.



### 3.6. Show\_Save\_Load\_XY\_Data.vi

This VI displays XY data in an XY Graph. If 1D Array X is an empty array, N X values are calculated with  $N = \text{Size of } \text{1D Array Y}$  and  $\Delta X = 1$ . No. of digits determines the resolution of Table and XY Graph. Data can be saved or loaded and a screen copy can be saved as JPG.



If data (1D Array X, 1D Array Y) are sent to the VI via the corresponding connectors, the VI will display the corresponding graphics after being called. To load data at runtime, press the Load data button. A dialog will pop up where a data file to open can be selected. The VI can read data in GCSArray, GCSTable and simple ASCII column format. Autoscale can be switched on or off. If Autoscale is off, the Y axis of the graph is scaled from 0-10.

Filter can be used to apply a filter to the current graph. For Filter = TRUE, a Lowpass, Highpass, Bandpass or Bandstop filter with appropriate settings can be selected.

Press Save data to save data (file header and numerical data). Data will be saved in GCS Array format. The file header will contain information given in X axis name, Y axis name and Remarks. With Save panel a screen copy of this VI can be saved as a JPG file. XY Graph will show the Y values over the corresponding X values. Table contains the numerical values for X and Y. Press Exit to stop execution of this VI.

Valid for	Analog systems, C-866, C-880, E-753, E-755, E-761, F-206, M-8X0. To support analog interfacing, VI must be present for E-816 also.
Input	1D Array X (empty num. array), 1D Array Y (empty num. array), 2D Array Z (empty 2D num. array), No. of digits X (, No. of digits Y, No. of digits Z, Autoscale, Error in (no error)
Output	Error out
Remarks	

**4. PI Systems Currently Supported by This Driver Set**

Product	works with LabVIEW driver version (or higher)	if product firmware/ drivers version is equal to or newer than
Analog	5.2.2	-
C-702	4.0.0	1.4.0
C-843	2.01 – 2.02 2.05 – 2.06 3.1.2., 3.1.2a 3.4.3 3.6.1	MC-DLL 1.0.2.2 MC-DLL 1.0.2.3 MC-DLL 1.0.2.3 MC-DLL 1.0.2.8 MC-DLL 1.0.2.8 GCS_DLL 1.3.1
C-843.PM	3.1.0 3.4.3a 3.6.2	MC-DLL 1.0.2.5 MC-DLL 1.0.2.5 MC-DLL 1.0.2.5 GCS_DLL 1.3.0
C-848	3.0.2	1.0
C-865	3.3.0	MC_C865.dll 1.0
C-866	5.2.1	MC_C866.dll 1.0
C-880	1.1 1.2 2.04 2.05 – 2.06 3.2.0	2.00 2.10 2.20 2.21 2.40
C-880K005	2.06	1.0
C-880K006	2.06	1.0
C-880K007	2.06	1.0
E-516	1.0 – 2.02 2.05 – 2.06 3.4.2	DSP V3.01, MCU V5 DSP V3.11, MCU V5 DSP V3.30, MCU V5
E-710 3- & 4-channel versions	3.4.0 3.4.4 (a, b)	5.027 5.0.33, 6.0.33
E-710 6-channel	3.4.4 (a, b)	2.13
E-753	5.2.0	1.0.0
E-755	5.1.0	2.0.4.1 E7XX_GCS2_DLL.dll V1.1.0
E-761	3.5.0	1.0.0
E-816	2.01 – 2.06 5.3.0	2.02 2.1.1

F-206	1.1 – 2.06	Fhx0035
M-840	2.03 – 2.06 2.2.0 3.0.1 3.1.1	Hex0037 Hex0045 Hex0050 Hex0051
M-850	2.03 – 2.06 3.0.1 3.1.1	Hex0040 Hex0050 Hex0051
Mercury™	3.6.0	1.0.6 PI_MERCURY_GCS_DLL.dll V 1.0.0.17



## 5. Appendix A

Error codes are not unambiguous, but can result from a PI error message or LabVIEW internal error code. In addition to the list below see National Instruments error codes.

100	PI LabVIEW driver reports error. See <a href="#">source</a> control for details.
0	No error
1	Parameter syntax error
2	Unknown command
3	Command length out of limits or command buffer overrun
4	Error while scanning
5	Unallowable move attempted on unreferenced axis, or move attempted with servo off
6	Parameter for SGA not valid
7	Position out of limits
8	Velocity out of limits
9	Attempt to set pivot point while U,V and W not all 0
10	Controller was stopped by command
11	Parameter for SST or for one of the embedded scan algorithms out of range
12	Invalid axis combination for fast scan
13	Parameter for NAV out of range
14	Invalid analog channel
15	Invalid axis identifier
16	Unknown stage name
17	Parameter out of range
18	Invalid macro name
19	Error while recording macro
20	Macro not found
21	Axis has no brake
22	Axis identifier specified more than once
23	Illegal axis
24	Incorrect number of parameters
25	Invalid floating point number
26	Parameter missing
27	Soft limit out of range
28	No manual pad found

29	No more step-response values
30	No step-response values recorded
31	Axis has no reference sensor
32	Axis has no limit switch
33	No relay card installed
34	Command not allowed for selected stage(s)
35	No digital input installed
36	No digital output configured
37	No more MCM responses
38	No MCM values recorded
39	Controller number invalid
40	No joystick configured
41	Invalid axis for electronic gearing, axis can not be slave
42	Position of slave axis is out of range
43	Slave axis cannot be commanded directly when electronic gearing is enabled
44	Calibration of joystick failed
45	Referencing failed
46	OPM (Optical Power Meter) missing
47	OPM (Optical Power Meter) not initialized or cannot be initialized
48	OPM (Optical Power Meter) Communication Error
49	Move to limit switch failed
50	Attempt to reference axis with referencing disabled
51	Selected axis is controlled by joystick
52	Controller detected communication error
53	MOV! motion still in progress
54	Unknown parameter
55	No commands were recorded with REP
56	Password invalid
57	Data Record Table does not exist
58	Source does not exist; number too low or too high
59	Source Record Table number too low or too high
60	Protected Param: current Command Level (CCL) too low
61	Command execution not possible while Autozero is running
62	Autozero requires at least one linear axis
63	Initialization still in progress
64	Parameter is read-only
65	Parameter not found in non-volatile memory
66	Voltage out of limits

67	Not enough memory available for requested wave curve
68	Not enough memory available for DDL table; DDL can not be started
69	Time delay larger than DDL table; DDL can not be started
70	The requested arrays have different lengths; query them separately
71	Attempt to restart the generator while it is running in single step mode
72	Motion commands and wave generator activation are not allowed when analog target is active
73	Motion commands are not allowed when wave generator output is active; use WGO to disable generator output
74	No sensor channel or no piezo channel connected to selected axis (sensor and piezo matrix)
75	Generator started (WGO) without having selected a wave table (WSL).
76	Interface buffer did overrun and command couldn't be received correctly
77	Data Record Table does not hold enough recorded data
78	Data Record Table is not configured for recording
79	Open-loop commands (SVA, SVR) are not allowed when servo is on
100	PI LabVIEW driver reports error. See source control for details.
200	No stage connected to axis
201	File with axis parameters not found
202	Invalid axis parameter file
203	Backup file with axis parameters not found
204	PI internal error code 204
205	SMO with servo on
206	uudecode: incomplete header
207	uudecode: nothing to decode
208	uudecode: illegal UUE format
209	CRC32 error
210	Illegal file name (must be 8-0 format)
211	File not found on controller
212	Error writing file on controller
213	VEL command not allowed in DTR Command Mode
214	Position calculations failed
215	The connection between controller and stage may be broken
216	The connected stage has driven into a limit switch, call CLR to resume operation
217	Strut test command failed because of an unexpected strut stop
218	While MOV! is running position can only be estimated!
219	Position was calculated during MOV motion
301	Send buffer overflow

302	Voltage out of limits
303	Attempt to set voltage when servo on
304	Received command is too long
305	Error while reading/writing EEPROM
306	Error on I2C bus
307	Timeout while receiving command
308	A lengthy operation has not finished in the expected time
309	Insufficient space to store macro
310	Configuration data has old version number
311	Invalid configuration data
333	Internal hardware error
555	BasMac: unknown controller error
601	Not enough memory
602	Hardware voltage error
603	Hardware temperature out of range
1000	Too many nested macros
1001	Macro already defined
1002	Macro recording not activated
1003	Invalid parameter for MAC
1004	Deleting macro failed
2000	Controller already has a serial number
4000	Sector erase failed
4001	Flash program failed
4002	Flash read failed
4003	HW match code missing/invalid
4004	FW match code missing/invalid
4005	HW version missing/invalid
4006	FW version missing/invalid
4007	FW update failed
0	No error occurred during function call
-1	Error during com operation (could not be specified)
-2	Error while sending data
-3	Error while receiving data
-4	Not connected (no port with given ID open)
-5	Buffer overflow
-6	Error while opening port
-7	Timeout error
-8	There are more lines waiting in buffer

-9	There is no interface or DLL handle with the given ID
-10	Event/message for notification could not be opened
-11	Function not supported by this interface type
-12	Error while sending "echoed" data
-13	IEEE488: System error
-14	IEEE488: Function requires GPIB board to be CIC
-15	IEEE488: Write function detected no listeners
-16	IEEE488: Interface board not addressed correctly
-17	IEEE488: Invalid argument to function call
-18	IEEE488: Function requires GPIB board to be SAC
-19	IEEE488: I/O operation aborted
-20	IEEE488: Interface board not found
-21	IEEE488: Error performing DMA
-22	IEEE488: I/O operation started before previous operation completed
-23	IEEE488: No capability for intended operation
-24	IEEE488: File system operation error
-25	IEEE488: Command error during device call
-26	IEEE488: Serial poll-status byte lost
-27	IEEE488: SRQ remains asserted
-28	IEEE488: Return buffer full
-29	IEEE488: Address or board locked
-30	RS-232: 5 data bits with 2 stop bits is an invalid combination, as is 6, 7, or 8 data bits with 1.5 stop bits
-31	RS-232: Error configuring the COM port
-32	Error dealing with internal system resources (events, threads, ...)
-33	A DLL or one of the required functions could not be loaded
-34	FTDIUSB: invalid handle
-35	FTDIUSB: device not found
-36	FTDIUSB: device not opened
-37	FTDIUSB: IO error
-38	FTDIUSB: insufficient resources
-39	FTDIUSB: invalid parameter
-40	FTDIUSB: invalid baud rate
-41	FTDIUSB: device not opened for erase
-42	FTDIUSB: device not opened for write
-43	FTDIUSB: failed to write device
-44	FTDIUSB: EEPROM read failed
-45	FTDIUSB: EEPROM write failed

-46	FTDIUSB: EEPROM erase failed
-47	FTDIUSB: EEPROM not present
-48	FTDIUSB: EEPROM not programmed
-49	FTDIUSB: invalid arguments
-50	FTDIUSB: not supported
-51	FTDIUSB: other error
-52	Error while opening the COM port: was already open
-53	Checksum error in received data from COM port
-54	Socket not ready, you should call the function again
-55	Port is used by another socket
-56	Socket not connected (or not valid)
-57	Connection terminated (by peer)
-58	Can't connect to peer
-59	Operation was interrupted by a nonblocked signal
-1001	Unknown axis identifier
-1002	Number for NAV out of range--must be in [1,10000]
-1003	Invalid value for SGA--must be one of 1, 10, 100, 1000
-1004	Controller sent unexpected response
-1005	No manual control pad installed, calls to SMA and related commands are not allowed
-1006	Invalid number for manual control pad knob
-1007	Axis not currently controlled by a manual control pad
-1008	Controller is busy with some lengthy operation (e.g. reference move, fast scan algorithm)
-1009	Internal error--could not start thread
-1010	Controller is (already) in macro mode--command not valid in macro mode
-1011	Controller not in macro mode--command not valid unless macro mode active
-1012	Could not open file to write or read macro
-1013	No macro with given name on controller, or macro is empty
-1014	Internal error in macro editor
-1015	One or more arguments given to function is invalid (empty string, index out of range, ...)
-1016	Axis identifier is already in use by a connected stage
-1017	Invalid axis identifier
-1018	Could not access array data in COM server
-1019	Range of array does not fit the number of parameters
-1020	Invalid parameter ID given to SPA or SPA?
-1021	Number for AVG out of range--must be >0
-1022	Incorrect number of samples given to WAV

-1023	Generation of wave failed
-1024	Motion error while axis in motion, call CLR to resume operation
-1025	Controller is (already) running a macro
-1026	Configuration of PZT stage or amplifier failed
-1027	Current settings are not valid for desired configuration
-1028	Unknown channel identifier
-1029	Error while reading/writing wave generator parameter file
-1030	Could not find description of wave form. Maybe WG.INI is missing?
-1031	The WGWaveEditor DLL function was not found at startup
-1032	The user cancelled a dialog
-1033	Error from C-844 Controller
-1034	DLL necessary to call function not loaded, or function not found in DLL
-1035	The open parameter file is protected and cannot be edited
-1036	There is no parameter file open
-1037	Selected stage does not exist
-1038	There is already a parameter file open. Close it before opening a new file
-1039	Could not open parameter file
-1040	The version of the connected controller is invalid
-1041	Parameter could not be set with SPA--parameter not defined for this controller!
-1042	The maximum number of wave definitions has been exceeded
-1043	The maximum number of wave generators has been exceeded
-1044	No wave defined for specified axis
-1045	Wave output to axis already stopped/started
-1046	Not all axes could be referenced
-1047	Could not find parameter set required by frequency relation
-1048	Command ID given to SPP or SPP? is not valid
-1049	A stage name given to CST is not unique
-1050	A uuencoded file transfered did not start with "begin" followed by the proper filename
-1051	Could not create/read file on host PC
-1052	Checksum error when transferring a file to/from the controller
-1053	The PiStages.dat database could not be found. This file is required to connect a stage with the CST command
-1054	No wave being output to specified axis
-1055	Invalid password
-1056	Error during communication with OPM (Optical Power Meter), maybe no OPM connected
-1057	WaveEditor: Error during wave creation, incorrect number of parameters
-1058	WaveEditor: Frequency out of range

-1059	WaveEditor: Error during wave creation, incorrect index for integer parameter
-1060	WaveEditor: Error during wave creation, incorrect index for floating point parameter
-1061	WaveEditor: Error during wave creation, could not calculate value
-1062	WaveEditor: Graph display component not installed
-1063	User Profile Mode: Command is not allowed, check for required preparatory commands
-1064	User Profile Mode: First target position in User Profile is too far from current position
-1065	Controller is (already) in User Profile Mode
-1066	User Profile Mode: Block or Data Set index out of allowed range
-1067	ProfileGenerator: No profile has been created yet
-1068	ProfileGenerator: Generated profile exceeds limits of one or both axes
-1069	ProfileGenerator: Unknown parameter ID in Set/Get Parameter command
-1070	ProfileGenerator: Parameter out of allowed range
-1071	User Profile Mode: Out of memory
-1072	User Profile Mode: Cluster is not assigned to this axis
-1073	Unknown cluster identifier
-1074	The installed device driver doesn't match the required version. Please see the documentation to determine the required device driver version.
-1075	The library used doesn't match the required version. Please see the documentation to determine the required library version.
-1076	The interface is currently locked by another function. Please try again later.



## 6. Index

<b>#</b>		Commanded stage name available?.vi	69
#24.vi	50	Controller names.ctl	33
#5.vi	50	Convert num array to string.vi	69
#5_old.vi	58	Convert num value to syntax selection.vi	70
<b>*</b>		Count occurrences in string.vi	70
*IDN?.vi	33	Cut out additional spaces.vi	70
<b>A</b>		<b>D</b>	
Analog FGlobal.vi	64	DCO.vi	46
Analog functions (dyn).vi	64	DCO?.vi	47
Analog functions.vi	64	Define axes to command from boolean array.vi	70
Analog Receive String.vi	64	Define connected axes.vi	33
Analog systems First Steps	7	Define connected systems (Array).vi	34
Analyse input string for terminal.vi	66	Define connected systems.vi	58
Array File.vi	59	DRR? and display data.vi	52
Assign booleans from string to axes.vi	66	DRR?.vi	51
Assign NaN for chosen axes.vi	66	<b>E</b>	
Assign SPA values from string to axes.vi	66	E-516 First Steps	17
Assign values from string to axes.vi	67	E-710 First Steps	18
Available Analog Commands.vi	64	E-753 First Steps	19
Available DLL interfaces.ctl	27	E-755 First Steps	20
Available DLLs.ctl	27	E-761 First Steps	21
Available interfaces.ctl	27	E-816 First Steps	22
AVG.vi	50	E816_Configuration_Setup.vi	81
AVG?.vi	51	E816_Sample_Application_1.vi	84
Axis names.vi	63	E816_Sample_Application_1a.vi	83
<b>B</b>		E816_Simple_Test.vi	80
BDR.vi	27	ERR?.vi	34
BDR?.vi	28	<b>F</b>	
Boolean array calculations.vi	67	F-206 First Steps	24
Build channel query command substring.vi	67	File handler.vi	59
Build command substring.vi	67	Find baudrate.vi	28
Build num command substring.vi	68	<b>G</b>	
Build query command substring.vi	68	GCSTranslateError.vi	70
Build SPA command substring.vi	68	GCSTranslator DLL Functions.vi	29
Build SPA query command substring.v	69	General wait for movement to stop.vi	70
Build stringplusnum substring.vi	69	Get all axes.vi	71
<b>C</b>		Get arrays without blanks.vi	71
C-702 First Steps	9	Get lines and values from string.vi	71
C-843 First Steps	10	Get lines from string.vi	71
C-843.PM First Steps	11	Get string array size without blanks.vi	71
C-848 First Steps	12	Get subnet.vi	29
C-865 First Steps	13	GetDataFormat.vi	60
C-866 First Steps	14	Global Analog.vi	65
C-880 First Steps	15	Global DaisyChain.vi	29
C-880K005 First Steps	16	Global1.vi	29
Close connection if open.vi	28	Global2 (Array).vi	35
		Global2.vi	58

<b>H</b>		Select values for chosen axes.vi	73
HLP?.vi	35	Select with boolean array input.vi	73
How often does string contain regular expression.vi	72	Selection to string array.vi	73
<b>I</b>		Show_Save_Load_XY_Data.vi	85
I2C?.vi	52	SPA.vi	39
Initialize Global DaisyChain.vi	30	SPA?.vi	41
Initialize Global1.vi	29	Split multiple axes command.vi	74
Initialize Global2.vi	35	Split num query command.vi	58
Is DaisyChain open.vi	30	SSN?.vi	53
<b>M</b>		STA?.vi	54
M-840 / M-850 First Steps	25	STE.vi	55
Manual VMO.vi	72	STP.vi	42
MatrixIO.vi	60	Substract axes array subset from axes array.vi	74
Mercury™ First Steps	26	SVA.vi	47
MOV.vi	35	SVA?.vi	47
MOV?.vi	36	SVO.vi	43
MVR.vi	36	SVO?.vi	44
<b>O</b>		SVR.vi	48
ONT?.vi	37	SWT.vi	63
OVF?.vi	47	SWT?.vi	63
<b>P</b>		Syntax.ctl	33
PI Ask for Communication Parameters.vi	30	<b>T</b>	
PI Open Interface of one system.vi	31	TableIO.vi	60
PI Open Interface.vi	32	Termination character.ctl	33
PI Receive String.vi	32	TMN?.vi	61
PI Send String.vi	32	TMX?.vi	61
PI Terminal.vi	76	TPC?.vi	56
PI VISA Receive Characters.vi	33	TSC?.vi	62
POS?.vi	37	<b>U</b>	
<b>R</b>		Unbundle/bundle interface clusters for PI Terminal.vi	74
Return single characters from string.vi	72	<b>V</b>	
Return space.vi	72	VCO.vi	48
Round with options.vi	72	VCO?.vi	48
RST.vi	52	VEL.vi	44
<b>S</b>		VEL?.vi	45
SAI?.vi	38	VOL.vi	49
SCH.vi	53	VOL?.vi	49
SCH?.vi	53	<b>W</b>	
Select axis.vi	73	Wait for axes to stop.vi	74
		Wait for hexapod system axes to stop.vi	59
		WPA.vi	56
		WTO.vi	63



End of document