

# Handbook

## Venus-1 Command language

# for **Corvus**

*high resolution positioning controller*

SMC Corvus  
SMC Corvus eco  
SMC PCI





---

## **About this documentation**

This handbook provides detailed information on the Venus-1 command language for the positioning controllers Corvus TT, Corvus eco, Corvus PCI


The commands are separated in functional groups to improve the overview.

The last chapter lists each command and gives a brief description of the command's function.

---

## Symbols in this documentation

To clarify the content following symbols are used.

| Symbol  | Description   |
|---|---|
|    | Warning.<br>This information must be observed strictly.                                     |
|    | Important information   |
|    | Indicates that this function can be enabled with a release code.                            |
|    | This function must be installed from the factory personal or experts.                       |
|   | Venus-1 commands are indicated with this formatting style.                                  |
|  | This configuration can not be stored into the flash memory. It is lost after power off.     |
|  | This configuration can be stored with command <b>save</b> into the controller flash memory. |

---

# Contents

|   |           |
|---|-----------|
| About this documentation .....                  | 3         |
| <b>Introduction in Venus-1 .....</b>            | <b>13</b> |
| Venus-1 is an interpreter language .....        | 14        |
| Venus-1 history.....                            | 14        |
| Command syntax for parametrisation .....        | 15        |
| Command syntax for positioning commands .....   | 17        |
| Command execution .....                         | 19        |
| Generate an automatic status reply message..... | 24        |
| Corvus communication concept .....              | 25        |
| <br><b>Basic settings</b>                       |           |
| setpitch.....                                   | 29        |
| getpitch.....                                   | 31        |
| setunit.....                                    | 33        |
| getunit.....                                    | 35        |
| setumotmin.....                                 | 37        |
| getumotmin.....                                 | 38        |
| setumotgrad .....                               | 39        |
| getumotgrad .....                               | 40        |
| setpolepairs .....                              | 41        |
| getpolepairs.....                               | 42        |
| setaxis .....                                   | 43        |
| getaxis .....                                   | 45        |
| setpowerup.....                                 | 47        |
| getpowerup.....                                 | 49        |
| setphaseareas.....                              | 51        |
| <b>Valid from firmware version 3.6.3</b>        |           |
| getphaseareas.....                              | 52        |
| setmotiondir.....                               | 53        |
| <b>Valid from firmware version 4.4.0</b>        |           |
| getmotiondir.....                               | 55        |
| <b>Valid from firmware version 4.4.0</b>        |           |

---

## **Communication**

|                |    |
|----------------|----|
| mode .....     | 59 |
| setipadr.....  | 61 |
| getipadr ..... | 62 |

## **Velocity and acceleration**

|                    |    |
|--------------------|----|
| setvel (sv).....   | 65 |
| getvel (sv).....   | 67 |
| setaccel (sa)..... | 69 |
| getaccel (ga)..... | 70 |
| setaccelfunc ..... | 71 |
| getaccelfunc ..... | 72 |
| setmanaccel .....  | 73 |
| getmanaccel .....  | 74 |
| setcalvel .....    | 75 |
| getcalvel .....    | 76 |
| setncalvel .....   | 77 |

### **Valid with firmware version 4.0**

|  |    |
|--|----|
| getncalvel .....                       | 78 |
| setrmvel.....                          | 79 |
| getrmvel.....                          | 80 |
| setnrmvel.....                         | 81 |
| <b>Valid from firmware version 4.0</b> |    |
| getnrmvel.....                         | 82 |
| setrefvel.....                         | 83 |
| getrefvel.....                         | 84 |

## **Positioning commands**

|                |    |
|----------------|----|
| move (m) ..... | 87 |
| rmove (r)..... | 89 |
| speed.....     | 91 |
| stopspeed..... | 93 |
| test.....      | 95 |
| randmove ..... | 97 |

## **Limit Switch functions**

---

---

|  |     |
|--|-----|
| calibrate (cal).....                     | 101 |
| rangemeasure (rm).....                   | 103 |
| getcaldone.....                          | 105 |
| <b>Valid from firmware version 4.42</b>  |     |
| setsw .....                              | 107 |
| getsw.....                               | 108 |
| getswst.....                             | 109 |
| setcalswdist.....                        | 111 |
| getcalswdist.....                        | 112 |
| setlimit .....                           | 113 |
| getlimit.....                            | 115 |
| ncal.....                                | 117 |
| <b>Valid from firmware version 4.0</b>   |     |
| nrm .....                                | 119 |
| <b>Valid from firmware version 4.0</b>   |     |
| getnlimit.....                           | 121 |
| <b>Valid from firmware version 4.5.0</b> |     |
| org .....                                | 123 |
| <b>Valid from firmware version 4.1.0</b> |     |
| setorg .....                             | 125 |
| <b>Valid from firmware version 4.1.0</b> |     |
| getorg .....                             | 126 |
| setorgsw.....                            | 127 |
| <b>Valid from firmware version 4.1.0</b> |     |
| getorgsw.....                            | 128 |
| getorgswst.....                          | 129 |
| <b>Valid from firmware version 4.1.0</b> |     |

## Safety functions

|                |     |
|----------------|-----|
| Ctrl-C .....   | 133 |
| Ctrl-B .....   | 135 |
| abort .....    | 137 |
| setinfunc..... | 139 |
| getinfunc..... | 141 |
| setmp.....     | 143 |
| getmp .....    | 144 |

## position / origin / coordinate system

---

---

|                  |     |
|------------------|-----|
| pos (p) .....    | 147 |
| setdisplay ..... | 149 |
| getdisplay ..... | 150 |
| setpos .....     | 151 |
| align .....      | 153 |
| ico .....        | 155 |
| getico .....     | 157 |

## **Status requests**

|                       |     |
|-----------------------|-----|
| status (st) .....     | 161 |
| geterror (ge) .....   | 165 |
| getmerror (gme) ..... | 167 |
| gsp .....             | 169 |
| getticks (gt) .....   | 171 |

## **Input / Output functions**

|               |     |
|---------------|-----|
| setout .....  | 175 |
| getout .....  | 176 |
| setaout ..... | 177 |
| getaout ..... | 178 |
| getin .....   | 179 |

## **Closed Loop commands**

|                         |     |
|-------------------------|-----|
| setnselpos .....        | 183 |
| getnselpos .....        | 185 |
| setclpara .....         | 187 |
| getclpara .....         | 190 |
| setsps .....            | 191 |
| getsp .....             | 194 |
| setscaleinterface ..... | 195 |
| getscaleinterface ..... | 196 |
| setscaletype .....      | 197 |
| getscaletype .....      | 198 |
| setclfactor .....       | 199 |
| getclfactor .....       | 200 |
| setclperiod .....       | 201 |

---

|                   |     |
|-------------------|-----|
| getclperiod ..... | 203 |
| setclwindow ..... | 205 |
| getclwindow ..... | 206 |
| setref .....      | 207 |
| getref .....      | 208 |
| refmove .....     | 209 |
| getrefst .....    | 211 |

## Trigger Output functions

|  |     |
|--|-----|
| setcloop .....                           | 215 |
| getcloop .....                           | 217 |
| outtrig (ot) .....                       | 219 |
| waitposot (wpot) .....                   | 221 |
| waitpos (wp) .....                       | 223 |
| waittime (wt) .....                      | 225 |
| waitintrag (witot) .....                 | 227 |
| waittimeot (wtot) .....                  | 229 |
| setrptdata .....                         | 231 |
| <b>Valid from firmware version 4.5.0</b> |     |
| getrptdata .....                         | 233 |
| startrpt .....                           | 235 |
| <b>Valid from firmware version 4.5.0</b> |     |

## Trigger-Input functions

|  |     |
|--|-----|
| setotmode .....                          | 239 |
| <b>Valid from firmware version 4.5.0</b> |     |
| getotmode .....                          | 240 |
| setpcin .....                            | 241 |
| getpcin .....                            | 242 |
| <b>Valid from firmware version 4.2.0</b> |     |
| setpc .....                              | 243 |
| <b>Valid from firmware version 4.2.0</b> |     |
| getpc .....                              | 244 |
| waitintrag (wit) .....                   | 245 |
| getpcdata (gpd) .....                    | 247 |
| clearpcdata (cpd) .....                  | 249 |
| setintragtimeout .....                   | 251 |

---

Valid from firmware version 4.5.0.

|                      |     |
|----------------------|-----|
| getintrigtimout..... | 252 |
|----------------------|-----|

## Joystick / Handwheel

|                       |     |
|-----------------------|-----|
| setjoysticktype ..... | 255 |
|-----------------------|-----|

|                       |     |
|-----------------------|-----|
| getjoysticktype ..... | 256 |
|-----------------------|-----|

|                    |     |
|--------------------|-----|
| joystick (j) ..... | 257 |
|--------------------|-----|

|                        |     |
|------------------------|-----|
| getjoystick (gj) ..... | 258 |
|------------------------|-----|

Valid from firmware version 4.50

|                        |     |
|------------------------|-----|
| setjoyspeed (js) ..... | 259 |
|------------------------|-----|

|                        |     |
|------------------------|-----|
| getjoyspeed (js) ..... | 260 |
|------------------------|-----|

|                          |     |
|--------------------------|-----|
| setnjoyspeed (njs) ..... | 261 |
|--------------------------|-----|

|                          |     |
|--------------------------|-----|
| getnjoyspeed (njs) ..... | 262 |
|--------------------------|-----|

|                    |     |
|--------------------|-----|
| setjoybspeed ..... | 263 |
|--------------------|-----|

|                    |     |
|--------------------|-----|
| getjoybspeed ..... | 264 |
|--------------------|-----|

|                    |     |
|--------------------|-----|
| setjoyassign ..... | 265 |
|--------------------|-----|

Valid from firmware version 4.40

|                    |     |
|--------------------|-----|
| getjoyassign ..... | 267 |
|--------------------|-----|

|                  |     |
|------------------|-----|
| setjoydiag ..... | 269 |
|------------------|-----|

Valid from firmware version 4.41

|                  |     |
|------------------|-----|
| getjoydiag ..... | 270 |
|------------------|-----|

|                |     |
|----------------|-----|
| setwheel ..... | 271 |
|----------------|-----|

|                |     |
|----------------|-----|
| getwheel ..... | 272 |
|----------------|-----|

|                   |     |
|-------------------|-----|
| setwheelres ..... | 273 |
|-------------------|-----|

|                   |     |
|-------------------|-----|
| getwheelres ..... | 274 |
|-------------------|-----|

|                     |     |
|---------------------|-----|
| setwheelratio ..... | 275 |
|---------------------|-----|

|                     |     |
|---------------------|-----|
| getwheelratio ..... | 276 |
|---------------------|-----|

|                     |     |
|---------------------|-----|
| setwheelratio ..... | 277 |
|---------------------|-----|

|                     |     |
|---------------------|-----|
| getwheelratio ..... | 278 |
|---------------------|-----|

## System commands

|            |     |
|------------|-----|
| save ..... | 281 |
|------------|-----|

|               |     |
|---------------|-----|
| restore ..... | 283 |
|---------------|-----|

|                |     |
|----------------|-----|
| getfpara ..... | 285 |
|----------------|-----|

|             |     |
|-------------|-----|
| clear ..... | 287 |
|-------------|-----|

|             |     |
|-------------|-----|
| reset ..... | 289 |
|-------------|-----|

|            |     |
|------------|-----|
| beep ..... | 291 |
|------------|-----|

---

|  |     |
|--|-----|
| version.....   | 293 |
| getmacadr .....                                      | 295 |
| identify .....                                       | 297 |
| getoptions.....                                      | 299 |
| getserialno.....                                     | 301 |
| <br><b>Position error correction</b>                 |     |
| setpcor.....   | 305 |
| getpcor .....  | 306 |
| setpdat.....   | 307 |
| getpdat .....  | 310 |
| setblc.....  | 311 |
| Valid from firmware version 3.66                     |     |
| getblc.....  | 313 |
| setblcd .....  | 315 |
| Valid from firmware version 3.66                     |     |
| getblcd.....   | 316 |
| <br><b>Corvus Macros .....</b> <b>317</b>            |     |
| Corvus Makro FAQ.....                                | 319 |
| Makro commands overview.....                         | 323 |
| <br><b>Macro functions</b>                           |     |
| beginmakro / endmakro.....                           | 327 |
| startmakro .....                                     | 329 |
| listmakro .....                                      | 331 |
| Ctrl-D .....   | 333 |
| <br><b>Venus-1 command overview .....</b> <b>335</b> |     |



---

# **Introduction in Venus-1**

---

---

## **Venus-1 is an interpreter language**

Venus-2 commands consist of ASCII-signs which are interpreted in the controller and immediately executed.

A software development surrounding to produce the control programs is not needed.

The commands can be produced by any Host and whatever programming language you are using, on condition that there is an access to the RS-232 or Ethernet interface.

In the simplest way the commands are directly transmitted to the controller via an ASCII terminal.

## **Venus-1 history**

Venus-1 for Corvus has been developed on the basis of the interpreter language Venus-1 for the controllers mc-compact, smc-compact, MC-2000 and MC-3000.

The fundamental command construction is identical.


All basic functions are compatible to the former version.

---

## Command syntax for parametrisation

The parameterisation commands are assembled following this scheme:

[parameter] \_ [axis index] \_ [command] \_



### Parameter

The parameter transmits a value without any unit.

If several parameters are prescribed for one command, they have to be divided by a blank (SP).

The following numbers and characters are permitted for parameters:

|            |             |
|------------|-------------|
| Letters    | not allowed |
| Numbers    | 0-9         |
| Characters | + -.        |

### -1 Parameter

Most of the get-commands allow the combination -1 to read out the settings of all axes.

For example:

With the command **2 getpitch** the spindle pitch of Axis-2 is asked.

The command **-1 getpitch** returns the pitch setting of all axes.

---

## Axis index

With the axes index the target axis is addressed. The number of the index is equal with the labeling at the motor connector.

| Axis label | Axis index |
|------------|------------|
| Axis-1     | 1          |
| Axis-2     | 2          |
| Axis-3     | 3          |

## Commands

For the parametrization the commands are named with get or set. It consists of several ASCII characters, capitalization is distinguished.

The following letters are allowed for commands:


|                   |             |
|-------------------|-------------|
| ASCII-Charac-ters | a-z A-Z     |
| Umlauts           | not allowed |
| Numbers           | not allowed |

---

## Command syntax for positioning commands

The positioning commands are assembled following this scheme:

[Axis-1] \_ [Axis-2] \_ [Axis-3] \_ [command] \_



### Axis-1, Axis-2, Axis-3

For the positioning, absolute or relative coordinates are transferred to the controller.

The values must be separated by a blank (SP).

The number of position values to be transferred depends on the setting of **setdim**.

| setdim          | Axis values that must be transferred |
|-----------------|--------------------------------------|
| <b>1 setdim</b> | Axis-1                               |
| <b>2 setdim</b> | Axis-1_Axis-2                        |
| <b>3 setdim</b> | Axis-1_Axis-2_Axis-3                 |

If insufficient coordinates are transferred, the move command will not be executed.

Useless coordinates will remain on the stack

The following letters are allowed for position coordinates:

|            |       |
|------------|-------|
| Letters    | no    |
| Numbers    | 0 - 9 |
| Characters | + - . |

---

## Command ending character for transmitting

In the **host mode** data which are transmitted have to be completed with a blank  
[parameter] \_ [axis index] \_ [command] \_

In the **terminal mode** the command ending is executed by [CR] (carriage returns).  
[parameter] \_ [axis index] \_ [command] [CR]

## Command ending character for receiving

[1st parameter] \_ [2nd parameter] \_ [n-parameter] [CR][LF]

Data which are transmitted from the controller are always completed with ASCII [CR] and [LF]. Some data requests return parameters in several lines. In these cases each line is also completed with [CR] and [LF].

How many lines a request returns is mentioned in the command description.

## Table of important ASCII signs for programming

| ASCII Code | Sign   | Dez | HEX  |
|------------|--------|-----|------|
| CR         | Ctrl-M | 13  | 0xD  |
| LF         | Ctrl-J | 10  | 0xA  |
| SP         |        | 32  | 0x20 |
| ETX        | Ctrl-C | 3   | 0x3  |

---

## Command execution

For the correct programming it is important to know the internal courses during the execution of the interpreter commands.

The ASCII data transmitted by a host run through the following areas of the controller:

- command input FIFO
- scanner and stack
- interpreter

### Command input FIFO



The ASCII commands are transferred from the communication interface (Host) to the data input memory and remain there until they are processed. The memory possesses a FIFO structure. This FIFO is able to accept up to 256 ASCII signs.

There is no data flow control during the transmission of the data, i.e., an overflow of the FIFO would not be recognized. For that reason not too much data should be transmitted to the controller.

With the controller switched off, the FIFO is cleared.


---

## Scanner - Interpreter - Stack

The content of the command FIFO will be read by the scanner and divided in parameters and commands.

The parameters are transmitted to a stack which can accept up to 99 values.

The Commands are directly passed to the interpreter, as soon as it is free.



---

## Blocking and non blocking commands



During the interpreter executes a move it is able to execute several other commands parallel to it. These commands are called non blocking commands.

On the other side there are commands that will be only executed until the move is finished.


If such a command is stored in the FIFO all other commands behind it will be blocked until the blocking command is executed and removed from the FIFO.

These commands are called blocking command.

### Examples of blocking and non blocking commands


The interpreter is able to execute several commands at the same time.

Below mentioned, the interpreter executes the instruction **p** and is also free to process 3x **st**.



The interpreter has been blocked with the command **ge**.

The interpreter is executes the command **move**. The FIFO contains the command **ge**, this blocks the interpreter for the execution of further commands until **move** is completed. After **ge** is executed the commands **st** are processed.



---

## Examples of non blocking commands

The commands below do not block the interpreter. These commands are also executed if the interpreter processes a **move** command.

| Command       | Description  |
|---------------|--|
| <b>st</b>     | Status   |
| <b>p</b>      | Current position   |
| <b>getin</b>  | Read digital Input   |
| <b>setout</b> | Write digital Output   |
| <b>abort</b>  | Aborts the current command<br><br>Attention:<br>This command has to pass through the FIFO it's execution could be delayed with a blocking command. |
| <b>Ctrl-C</b> | Aborts the current command<br>This command has <b>not</b> to pass the FIFO and could not be delayed with a blocking command.                       |

---


## Unlock interpreter

A lasting blockade of the interpreter is not possible, because all commands are finally processed this will unlock the interpreter.

To accelerate Interpreter unlocking, command **Ctrl-C** can be used to abort the commands.

## Terminate command execution

**Ctrl-C** has a direct access to the interpreter and will abort the current command in the interpreter.  
It is not possible to erase the FIFO totally.



---

## Generate an automatic status reply message

With the following sequence of instructions the blocking effect of the interpreter can be used to generate an automatic status reply.

```
10 10 2 move  
0 0 0 r  
st  
ge
```

### Effect:



An automatic status reply is generated, after the instruction **10 10 2 move** is executed.

### Description:

The instruction **0 0 0 r** has only the function to block the interpreter and prevent the execution of **st**.

After **move** is executed, **0 0 0 r** is processed with no effect, because it is a relative positioning with 0mm.

Afterwards the command **st** produces the desired status feedback.




---

## Corvus communication concept

### Ethernet and RS-232

RS-232 is the standard communication interface of Corvus.  
Optionally the Ethernet interface can be released.  
Both interfaces are always ready to receive data.  
The data feedback is automatically send to the interface from where the data inquiry comes.  
Terminal and host mode are supported from both interfaces.





---

# **Basic settings**

---



# **setpitch**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setpitch** adapts the controller to the transmission ratio of the drive train.

$$\text{pitch} = \frac{\text{resulting move distance}}{\text{number of motor revolutions}}$$

## Syntax:

[pitch] [axis] **setpitch**

|         | Range          | Unit |
|---------|----------------|------|
| [pitch] | 0.0001 to 4095 | mm   |
| [axis]  | 1, 2, 3        |      |

## Related command:

**getpitch**

## Example:

**4.0009 1 setpitch**

Examples in the following page

---

## Examples:

### Drive mechanism with ball screw at Axis-1:

Lead screw with pitch = 2mm

Each motor revolution produces a move distance of 2mm

Pitch = 2mm / 1 rev. = 2

Setting : *2 1 setpitch*

### Drive mechanism with lead screw and gear box

Lead screw pitch = 4mm

Gear = 120:1

120 motor revolutions produce a move distance of 4mm

Pitch = 4mm / 120 rev. = 0.0333

Setting : *0.0333 [axis] setpitch*

### Rotation table (axis unit is normalized to degrees)

Each motor revolution produce a rotation angle of 360°

Pitch = 360° / 1 rev. = 360

Setting : *360 [Axis] setpitch*

### Rotation table with gear 120:1 (axis unit is normalized to degrees)

120 motor revolutions produce a rotation angle of 360°

Pitch = 360° / 120 rev. = 3

Setting : *3 [Axis] setpitch*

# **getpitch**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getpitch** returns the pitch setting of the axis.

## Syntax:

[axis] **getpitch**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[drive train transmission ratio]

|                                  | Unit |
|----------------------------------|------|
| [drive train transmission ratio] | mm   |

## Example:

**2 getpitch**

Reply:

4.000900

**-1 getpitch**

Reply:

4.000900

2.000000

2.000000



# **setunit**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setunit** the physical units of the Axis-specific parameters are defined.



The units of velocity and acceleration are determined from the unit setting of Axis-0.

The unit of the commands **setcalvel**, **setncalvel**, **setrmvel**, **setnrmvel** and **setrefvel** are fixed to rev./s (r/s).

For the reason of compatibility with older controllers, the unit microstep is emulated from Corvus.

In this case the positioning resolution is reduced.

1 Microstep = 1 motor revolution / 40000 steps

## Syntax:

[index] [axis] **setunit**

|         | <b>Range</b>        |
|---------|---------------------|
| [index] | 0, 1, 2, 3, 4, 5, 6 |
| [axis]  | 0, 1, 2, 3          |

| [index] | <b>Unit</b>        |
|---------|--------------------|
| 0       | microstep          |
| 1       | µm                 |
| 2       | mm                 |
| 3       | cm                 |
| 4       | m                  |
| 5       | inch               |
| 6       | mil (1/ 1000 inch) |

## Related command:

**getunit**

## Example:


### 2 0 setunit

The unit of the virtual 0-Axis is set to **mm**.

As a result the settings of velocity (*sv*) and acceleration (*sa*) are referenced to mm/s resp. mm/s<sup>2</sup>.

### 1 1 setunit

The physical unit of axis-1 is set to **µm**.



# **getunit**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getunit** returns the settings the physical units.

## Syntax:

[axis] **getunit**

|        | Range          |
|--------|----------------|
| [axis] | -1, 0, 1, 2, 3 |

## Reply:

[index]

|         | Range               |
|---------|---------------------|
| [index] | 0, 1, 2, 3, 4, 5, 6 |

## Example:

**1 getunit**

**-1 getunit**

Reply:

1

Reply:

2 1 1 1



# **setumotmin**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setumotmin** determines the motor phase voltage at stand still and lower speeds.



A greater index value, will increase the motor voltage. This implies an increased motor phase current and will produce more holding torque at stand still.

Attention: It will also increase the power consumption at the motor and motor driver.

## Syntax:

[index] [axis] **setumotmin**

|         | Index range | Unit |
|---------|-------------|------|
| [index] | 0 - 3000    | mV   |
| [axis]  | 1, 2, 3     |      |

## Related command:

*getumotmin, setumotgrad*

## Example:

**2000 1 setumotmin**

# **getumotmin**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getumotmin** returns the setting of *umotmin*.

## Syntax:

[axis] **getumotmin**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[index]

|         | Range    |
|---------|----------|
| [index] | 0 - 3000 |

## Example:

**1 getumotmin**

Reply

2000

**-1 getumotmin**

2000

1000

750

# **setumotgrad**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setumotgrad** determines the motor voltage in the middle and upper speed range.



**A greater index value, will increase the motor voltage and implies an increased motor phase current and torque during the move.**

**Attention:** This will produce more power consumption at the motor and motor driver.

## Syntax:

[index] [axis] **setumotgrad**

|         | Range   |
|---------|---------|
| [index] | 0 - 300 |
| [axis]  | 1, 2, 3 |

## Related commands:

**getumotgrad, setumotmin**

## Example:

**70 1 setumotgrad**

# **getumotgrad**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getumotgrad** returns the setting of umotgrad.

## Syntax:

[axis] **getumotgrad**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[index]

|         | Range   |
|---------|---------|
| [index] | 0 - 300 |

## Example:

**1 getumotgrad**

Reply:  
50

**-1 getumotgrad**

Reply:  
50  
40  
100

# **setpolepairs**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setpolepairs** adapts the controller to the number of the stepper motor pole-pairs.

The relationship between motor type and pole-pairs is shown in the following table.

|  | <b>pole pairs</b> |
|--|-------------------|
| Hybrid Stepper Motor with full step size=1.8°  | 50                |
| Hybrid Stepper Motor with full step size= 0.9° | 100               |

## Syntax:

[pole-pairs] [axis] **setpolepairs**

|              | <b>Range</b>                |
|--------------|-----------------------------|
| [pole pairs] | 50, 100<br>other on request |
| [axis]       | 1, 2, 3                     |

## Related command:

**getpolepairs**

## Example:

**50 1 setpolepairs**

Controller Axis-1 is configured to a Stepper Motor with 100 poles or 50 pole-pairs (full step size 1.8°).

# **getpolepairs**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getpolepairs** returns the configured number of pole-pairs.

## Syntax:

[axis] **getpolepairs**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[value]

|         | Range   |
|---------|---------|
| [value] | 50, 100 |

## Example:

**1 getpolepairs**

Reply:  
50

**-1 getpolepairs**

Reply:  
50 100 50

## Description:



Command **setaxis** enables or disables the specified axis for positioning tasks.

**setaxis** also has an effect on the commands **pos**, **setpos** **cal**, **rm** and the hardware limits

The settings are significant for the programmable and manual move.

## Syntax:

[index] [axis] **setaxis**

|         | Range         |
|---------|---------------|
| [index] | 0, 1, 2, 3, 4 |
| [axis]  | 1, 2, 3       |

### [index] = 0:

The axis is disabled for all moves.

The commands **cal**, **rm** and **0 0 0 setpos** will clear the actual position, but will not change the hardware limits of the axis.

### [index] = 1:

The axis is enabled for all moves.

The commands **cal**, **rm** and **0 0 0 setpos** will clear the actual position to zero and reset the hardware limits of the axis.

### [index] = 2:

The axis is restricted enabled because the limit switch moves cal / rm will not be executed.

The commands **cal**, **rm** and **0 0 0 setpos** clear the actual position to zero but will not change the hardware limits of the axis.

---

#### [index] = 3:

The axis is disabled for all moves.

The commands **cal**, **rm** and **0 0 0 setpos** will **not** clear the actual position and **not** change the hardware limits of the axis.

#### [index] = 4:

The axis is restricted enabled because the limit switch move procedure cal / rm will not be executed.

The commands **cal**, **rm** and **0 0 0 setpos** will **not** clear the actual position and **not** change the hardware limits of the axis.

#### Related command:

**getaxis**

#### Example:

**1 3 setaxis**

# **getaxis**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getaxis** returns the setting of **setaxis**.

## Syntax:

[axis] **getaxis**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[index]

|         | Range         |
|---------|---------------|
| [index] | 0, 1, 2, 3, 4 |

## Example:

**2 getaxis**

Reply:

2

**-1 getaxis**

Reply:

1 2 2



# setpowerup

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setpowerup** it is possible to execute fixed commands automatically after power up.

Each single power up command is assigned to a binary state (D0-D4). To combine several power up commands to a command sequence, their binary states must be added.

## Syntax:

[Parameter] **setpowerup**

|             | Meaningful combinations        |
|-------------|--------------------------------|
| [Parameter] | 0, 1, 2, 3, 4, 5, 6, 7, 15, 16 |



| bin (dec) | Command   | Description  |
|-----------|---|--|
| D0 (1)    | <i>1j</i>   | Joystick On/Off<br>With power up = 0 always the before stored Joystick setting is valid.   |
| D1 (2)    | <i>cal</i>  | The axes are moving to the cal limit switches  |
| D2 (4)    | <i>rm</i>   | The axis are moving to the rm limit switches   |
| D3 (8)    | <i>randmove</i>   | random move of all enabled axes within the limits<br>The cal- and rm-limits must be determined first to prevent a hard limit crash |
| D4 (16)   | <i>cal/rm/0 0 * move</i><br><small>*depends on setdim</small> | The axes first move to the limits (cal/rm) and than to the origin.   |

---

### Example:

#### **1 setpowerup**

Joystick is enabled after power up.

#### **15 setpowerup**

After power up, the controller determines the limits of all active axes, than the axes are moved to randomized coordinates.

# **getpowerup**

Corvus TT

Corvus eco

Corvus PCI

## **Description:**

Command **getpowerup** returns the Power up command settings of the controller.

## **Syntax:**

**getpowerup**

## **Reply:**

[Parameter]

| Parameter | 0, 1, 2, 3, 4, 5, 6, 7, 15, 16 |
|-----------|--------------------------------|
|           |                                |

## **Example:**

**getpowerup**

Reply: 15



# **setphaseares**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 3.6.3

## Description:



With command **setphaseares** it is possible to reduce the resolution of the motor drivers in incremental steps. In the lowest resolution (2 Bit), the motor drivers are working in the stepper macro step mode. The resolution depends also on the settings of **setpolepairs**.

## Syntax:

[resolution (Bit)] [axis] **setphaseares**

|                | Range   |
|----------------|---------|
| [resolution] * | 2....16 |
| [axis]         | 1, 2, 3 |

\* factory setting = 16

### Polepairs = 50

| Bit | Resolution (steps/rev.) |
|-----|-------------------------|
| 2   | 200                     |
| 16  | >600.000                |

### Polepairs = 100

| Bit | Resolution (steps/rev.) |
|-----|-------------------------|
| 2   | 400                     |
| 16  | >1.200.000              |

\*\* see command **setpolepairs**

## Example:

**2 1 setphaseares**

Makro step resolution setting for Axis-1.

# **getphaseares**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 3.6.3

## Description:

Command **getphaseares** returns the motor resolution value of the selected axis.

## Syntax:

[Axis] **getphaseares**

## Reply:

[Resolution (Bit) ]

|              | Range    |
|--------------|----------|
| [Resolution] | 2.....16 |

### Polepairs = 50

| Bit | Resolution (steps/rev.) |
|-----|-------------------------|
| 2   | 200                     |
| 16  | >600.000                |

### Polepairs = 100

| Bit | Resolution (steps/rev.) |
|-----|-------------------------|
| 2   | 400                     |
| 16  | >1.200.000              |

\*\* see command **setpolepairs**

## Example:

2 **getphaseares**

# **setmotiondir**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.4.0

## Description:




With command **setmotiondir** the factory assigned relationship between the direction of motor rotation and the motion direction can be reversed.




In the case of a reversed assignment between motor direction and motion direction, the function of the limit switch inputs are changed.

This means, during the calibration move cal, the controller expects the limit switch activity at the rm input and during the rm move at the cal input.

Motor direction if a move to positive coordinates is executed.



Factory setting



Motor direction is changed with **setmotiondir**

## Syntax:

[Function] [axis] **setmotiondir**

| [Function] | Description   |
|------------|---|
| 0          | factory assigned motor direction and motion direction                 |
| 1          | Relationship between motor direction and motion direction is changed. |

## Example:

**1 1 setmotiondir**



# **getmotionondir**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.4.0

## Description:

Command **getmotionondir** indicates, if the relationship between motor direction and motion direction differs from the factory settings.

## Syntax:

[Axis] **getmotionondir**

|        | Range   |
|--------|---------|
| [Axis] | 1, 2, 3 |

## Reply:

[0,1]

|     | Description  |
|-----|--|
| [0] | Factory settings   |
| [1] | Motor direction and the function of the limit switch inputs are changed. |

## Example:

**1 getmotionondir**



---

# Communication

---



# mode

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **mode** enables Terminal or Host Mode.



In **Terminal Mode** a terminal mask is transmitted from the controller to the Host or Terminal.

The mask provides a Venus command input line and displays the actual position.

In **Host Mode** the controller returns data only after a command request.

Alternatively it is possible to enable the mode with DIP-Switch 6 directly at the controller, see Corvus Manual.

## Syntax:

[index] **mode**

| [index] | Description   |
|---------|---------------|
| 0       | Host Mode     |
| 1       | Terminal Mode |

## Example:

**1 mode**

Corvus is switched to Terminal Mode

```
VENUS-1 (Corvus) Interpreter Version: 4.55 Copyright 2008 by ITK Dr.Kassen
> X: 0.00000
> Y: 0.00000
```

Command( 0):



# ***setipadr***

Corvus TT

## **Description:**



With the command ***setipadr*** the controller Ethernet IP-Address can be defined.

The following Ethernet settings are fixed:

Subnet mask: 255.255.255.0

Port: 23

Socket: TCP/IP (Winsocket)

## **Syntax:**

***[AAA][BBB][CCC][DDD]\_setipadr***

The address elements have to be divided by a blank.

## **Related command:**

***getipadr***

## **Example:**

***192\_168\_128\_0\_setipadr***

# **getipadr**

Corvus TT

## Description:

The command **getipadr** returns the controller IP-Address.

## Syntax:

**getipadr**

## Reply:

[AAA].[BBB].[CCC].[DDD]

## Related command:

**getmacadr**

## Example:

**getipadr**

Reply:

192.168.128.0

The replied address elements are separated with a dot.

---

# **Velocity and acceleration**

---



# setvel (sv)

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setvel** configures the programmed move velocity  $v_a$ .

In consideration to the given move distances of all active axes, the controller calculates an individual velocity profile for each axis.


The setting of **setvel** relate to the axis, that moves the longest distance, see diagram.

The maximum velocity  $V_b$  or  $V_c$  depends on the distance ratio to the axis with the longest travel.

The motor rotation speed is determined from the **setvel** value and the **setpitch** value.

$$v_b = \frac{s_b}{s_a} \cdot v_a$$

$$v_c = \frac{s_c}{s_a} \cdot v_a$$



In the programmed move, all axes are starting and ending the move simultaneously.

---

### Syntax:

[velocity] **setvel**

|                  | <b>Range</b>  |
|------------------|---|
| minimum velocity | 15,26 nm/s  |
| maximum velocity | 45 rev./s, pitch =4 mm -> 180mm/s<br>60 rev./s (option) |

|            | <b>Unit</b>                |
|------------|----------------------------|
| [velocity] | Unit of the virtual 0-Axis |

### Example:

**100 sv**

# **getvel (sv)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getvel (gv)** returns the setting of **setvel**.

## Syntax:

**getvel**

## Reply:

[velocity]

|            | <b>Unit</b>   |
|------------|---------------|
| [velocity] | selected unit |

## Example:

**gv**

Reply:  
180.000000



# **setaccel (sa)**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setaccel (sa)** defines the acceleration ramp with which the controller executes the programmed move.

The axes are linear interpolated, this means the controller starts and stops all axes simultaneously.

The value of **setaccel** relates to the axis which must travel the longest distance.

The maximum acceleration of the other axes depends on the ratio to the axis with the longest travel.



Acceleration and deceleration ramp are identical.

## Syntax:

[Acceleration] **setaccel**

|                | Range  | Unit                |
|----------------|--|---------------------|
| [Acceleration] | 0 - $\frac{100000}{s^2}$ * pitch [unit]<br>polepairs * | unit/s <sup>2</sup> |

\* polepairs see command **polepairs**

## Related commands:

**getaccel / setmanaccel**

## Example:

**500 sa**

# **getaccel (ga)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getaccel (ga)** returns the setting of **setaccel**.

## Syntax:

**getaccel**

## Reply:

[Acceleration]

|                | Range  | unit               |
|----------------|--|--------------------|
| [Acceleration] | 0 - $\frac{100000}{\text{s}^2}$ * pitch [unit]<br>pole pairs | unit/ $\text{s}^2$ |

Pole pairs: 50 or 100 (see command **setpolepairs**)

## Example:

**ga**

Reply:

2400000.000000 (unit =  $\mu\text{m}$ )

# **setaccelfunc**

Corvus TT

Corvus eco


Corvus PCI

## Description:




The command **setaccelfunc** defines the acceleration function with which the positioning task is executed.

- Following functions are possible:
- Linear acceleration (trapezoidal)
  - $\sin^2$  acceleration (S-curve)



Linear acceleration



$\sin^2$  acceleration

## Syntax:

[index] **setaccelfunc**

| [index] | Description           |
|---------|-----------------------|
| 0       | Linear acceleration   |
| 1       | $\sin^2$ acceleration |

## Related command:

**getaccelfunc**

## Example:

**1 setaccelfunc**

# **getaccelfunc**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getaccelfunc** returns the adjusted acceleration function.

## Syntax:

**getaccelfunc**

## Reply:

[index]

|         | Range |
|---------|-------|
| [index] | 0, 1  |

| [index] | Description                 |
|---------|-----------------------------|
| 0       | Linear acceleration         |
| 1       | $\text{Sin}^2$ acceleration |

## Example:

**getaccelfunc**

# **setmanaccel**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setmanaccel** defines the acceleration ramp for the manual operation with Joystick or Handwheel.

## Syntax:

[Acceleration] **setmanaccel**

|                | Range | Unit                        |
|----------------|-------|-----------------------------|
| [Acceleration] |       | unit 0-Axis /s <sup>2</sup> |

## Related commands

**getmanaccel / setaccel**

## Example:

**100 setmanaccel**

# **getmanaccel**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getmanaccel** returns the setting of **setmanaccel**.

## Syntax:

**getmanaccel**

## Reply:

[Value]

|         | Range | Unit                        |
|---------|-------|-----------------------------|
| [Value] |       | unit 0-Axis /s <sup>2</sup> |

## Example:

**getmanaccel**

Reply:  
2400.000000

# setcalvel

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setcalvel** defines two velocities for the cal limit-switch move. The setting is significant for all axes.

1. velocity to move in a negative direction to the switch
2. velocity to move in a positive direction out of the switch



For the reason of compatibility with the older controllers, the unit of this velocity is defined in revolutions/s.

The resulting velocity in mm/s depends on the pitch value of the virtual 0-Axis (see command **setpitch**).

## Syntax:

[velocity] [index] **setcalvel**

| [index] | Description                      |
|---------|----------------------------------|
| 1       | Velocity to the limit-switch     |
| 2       | Velocity out of the limit-switch |

|            | Range  | Unit         |
|------------|--------|--------------|
| [Velocity] | 0 - 45 | revolution/s |
| [index]    | 1, 2   | -            |

## Related commands:

**getcalvel**, **setrmvel**

## Example:

**2 0 setpitch** (virtual 0-Axis)

**2 1 setcalvel**

**1 2 setcalvel**

The pitch of 0-Axis is adjusted to 2mm.

The controller is moving to the cal limit-switch with 2 rev./s (4 mm/s) and with 1 rev./s (2 mm/s) out of the switch.

# **getcalvel**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getcalvel** returns the adjusted velocities for cal limit-switch move.

## Syntax:

**getcalvel**

## Reply:

[velocity-1] cr  
[velocity-2] cr

|              | Range  | Unit    |
|--------------|--------|---------|
| [velocity-1] | 0 - 45 | rev. /s |
| [velocity-2] | 0 - 45 | rev. /s |

## Example:

**getcalvel**

Reply:

2.000000  
0.250000

# **setncalvel**

Corvus TT

Corvus eco

Corvus PCI

Valid with firmware version 4.0

## Description:



Command **setncalvel** defines the two velocities for the ncal limit-switch move.

1. Velocity to move in negative direction into the switch
2. Velocity to move in positive direction out of the switch



For the reason of compatibility with the older controllers, the unit of this velocity is defined in revolutions/s.

The resulting velocity in mm/s depends on the pitch value of the virtual 0-Axis (see command **setpitch**).

## Syntax:

[Velocity] [index] [axis] **setncalvel**

|            | Range    | Unit         |
|------------|----------|--------------|
| [Velocity] | 0 - 45   | revolution/s |
| [index]    | 1, 2     | -            |
| [axis]     | 1, 2, 3, | -            |

| [index] | Description                      |
|---------|----------------------------------|
| 1       | Velocity to the limit-switch     |
| 2       | Velocity out of the limit-switch |

## Related commands:

**getncalvel**, **setnrmvel**

## Example:

```
2 1 2 setncalvel  
0.1 2 2 setncalvel
```

With command 2 ncal, the controller is moving Axis-2 with 2 rev./s. to the cal limit-switch and with 0.1 rev./s out of the switch.

# **getncalvel**

Corvus TT

Corvus eco

Corvus PCI

Valid with firmware version 4.0

## Description:

The command **getncalvel** returns the *ncal* limit-switch move velocities.

## Syntax:

**[axis] getncalvel**

## Reply:

[velocity-1] cr  
[velocity-2] cr

|              | Range  | Unit    |
|--------------|--------|---------|
| [velocity-1] | 0 - 45 | rev. /s |
| [velocity-2] | 0 - 45 | rev. /s |

## Example:

**2 getncalvel**

Reply:

2.000000  
0.250000

# **setrmvel**

Corvus TT

Corvus eco

Corvus PCI

## Description:



The command **setrmvel** defines the two velocities for the rm limit-switch move. The setting is significant for all axes.

1. Velocity: move in positive direction into the limit-switch
2. Velocity: move in negative direction out of the limit-switch



For the reason of compatibility with the older controllers, the unit of this velocity is defined in revolutions/s.

The resulting velocity (mm/s) depends on the pitch value of the virtual 0-Axis (see command **setpitch**).

## Syntax:

[velocity] [index] **setcalvel**

| [index] | Description                      |
|---------|----------------------------------|
| 1       | Velocity to the limit-switch     |
| 2       | Velocity out of the limit-switch |

|              | Range  | Unit   |
|--------------|--------|--------|
| [velocity-1] | 0 - 45 | rev./s |
| [velocity-2] | 0 - 45 | rev./s |

## Example:

**2 0 setpitch** (virtual 0-Axis)

**2 1 setrmvel**

**1 2 setrmvel**

The pitch of the 0-Axis is adjusted to 2mm

The controller is moving with 2 rev./s (4 mm/s) to the rm limit-switch and with 1 rev./s (2 mm/s) out of the rm limit-switch.

# **getrmvel**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getrmvel** returns the two adjusted **rm** move velocities.

## Syntax:

**getrmvel**

## Reply:

[velocity-1]  
[velocity-2]

|              | Range  | Unit     |
|--------------|--------|----------|
| [velocity-1] | 0 - 45 | rev. /s. |
| [velocity-2] | 0 - 45 | rev. /s. |

## Example:

**getrmvel**

Reply:

2.000000  
0.250000

# **setnrmvel**

Valid from firmware version 4.0

## Description:



Command **setnrmvel** configures the two velocities for the **nrm** limit switch move.

1. velocity: move in positive direction into the limit-switch
2. velocity: move in positive direction out of the limit-switch

For the reason of compatibility with the older controllers, the unit of this velocity is defined in revolutions/s.

The resulting velocity in mm/s depends on the pitch value of the virtual 0-Axis (see command **setpitch**).

## Syntax:

[velocity] [index] [axis] **setnrmvel**

|            | Range    | Unit         |
|------------|----------|--------------|
| [Velocity] | 0 - 45   | revolution/s |
| [index]    | 1, 2     | -            |
| [axis]     | 1, 2, 3, | -            |

| [index] | Description                      |
|---------|----------------------------------|
| 1       | Velocity to the limit-switch     |
| 2       | Velocity out of the limit-switch |

## Example:

```
2 1 1 setnrmvel  
1 2 1 setnrmvel
```

The pitch of 0-Axis is adjusted to 2mm.

The controller is moving Axis-1 with 2 rev./s to the rm limit-switch and with 1 rev./s out of the switch.

# ***getnrmvel***

Valid from firmware version 4.0

## **Description:**

Command ***getnrmvel*** returns the two adjusted ***nrm*** movement velocities.

## **Syntax:**

**[axis] getnrmvel**

## **Reply:**

[velocity-1]  
[velocity-2]

|              | <b>Range</b> | <b>Unit</b> |
|--------------|--------------|-------------|
| [velocity-1] | 0 - 45       | rev. /s.    |
| [velocity-2] | 0 - 45       | rev. /s.    |

## **Example:**

**2 getnrmvel**

Reply:

2.000000  
0.250000

# **setrefvel**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setrefvel** defines the velocity with which the move to a reference mark is executed.  
See command **refmove**.



To find the reference mark with a adequate accuracy, it is recommended to choose a slow refmove velocity.

## Syntax:

[velocity] [index] **setrefvel**

|            | Range  | Unit      |
|------------|--------|-----------|
| [velocity] | 0 - 45 | mm/s      |
| [index]    | 1      | fix value |

## Related commands:

**getrefvel / setvel / refmove / setref**

## Example:

**0.5 1 setrefvel**

The refmove velocity is adjusted to 0.5mm/s.

# **getrefvel**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getrefvel** returns the setting of **setrefvel**.

To be compatible to the older controllers the command **getrefvel** returns two parameters. The second parameter is irrelevant.

## Syntax:

**getrefvel**

## Reply:

[velocity]

[NF]

|            | Range      | Unit |
|------------|------------|------|
| [velocity] | 0 - 45     | mm/s |
| [NF]       | irrelevant |      |

## Example:

**getrefvel**

Reply:

0.500000  
0.010000

---

# Positioning commands

---



# **move (m)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **move** executes point to point positioning tasks to absolute coordinates based on the point of origin. The move profile is calculated in respect to the velocity/acceleration setup and the given hard or software limits.

The axes are linear interpolated, this causes the controller to start and stop all active axes simultaneously

Command **status** returns the actual state of the move procedure.



**Ctrl-C** or **abort** interrupts the actual move.

## Syntax:

[Axis-1] [Axis-2] [Axis-3] **move**

| Absolute coordinates | Range       | Unit      |
|----------------------|-------------|-----------|
| [Axis -1]            | +/- 16383mm | axis unit |
| [Axis -2]            | +/- 16383mm | axis unit |
| [Axis -3]            | +/- 16383mm | axis unit |

---

The number of expected coordinates depends on the setting of ***setdim***.

| <b><i>setdim</i></b>   | <b>Expected number of coordinates</b> |
|------------------------|---------------------------------------|
| <b><i>1 setdim</i></b> | Axis-1                                |
| <b><i>2 setdim</i></b> | Axis-1_Axis-2                         |
| <b><i>3 setdim</i></b> | Axis-1_Axis-2_Axis-3                  |

#### Related commands:

*rmove, speed*

#### Examples:

Dimension = 3

***12.5 20.0 0.0001 m***

Dimension = 1

***12.5 m***

Dimension = 2

***12.5 20 m***

# rmove (r)

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **rmove** executes point to point positioning tasks relative to the current position.

The move profile is calculated in respect to the velocity/acceleration setup and the given hard or software limits.

The axes are linear interpolated, this causes the controller to start and stop all active axes simultaneously

The command **status** returns the actual state of the move procedure.



**Ctrl-C** or **abort** interrupt the current executed move.

## Syntax:

[Axis-1] [Axis-2] [Axis-3] **rmove**

| Relative coordinates | Range       | Unit      |
|----------------------|-------------|-----------|
| [Axis-1]             | +/- 16383mm | axis unit |
| [Axis-2]             | +/- 16383mm | axis unit |
| [Axis-3]             | +/- 16383mm | axis unit |

---

The number of expected coordinates depends on the setting of command ***setdim***.

| <b><i>setdim</i></b>   | <b>Expected number of relative axis coordinates</b> |
|------------------------|---|
| <b>1 <i>setdim</i></b> | Axis-1  |
| <b>2 <i>setdim</i></b> | Axis-1_Axis-2                                       |
| <b>3 <i>setdim</i></b> | Axis-1_Axis-2_Axis-3                                |

#### Related commands:

*move, speed*

#### Examples:

Dimension = 3

**0.5 20 0.0001 r**

Dimension = 1

**12.5 rmove**

Dimension = 2

**12.5 20 r**

# speed

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **speed** starts a constant velocity move.

The move profile is calculated in respect to the velocity/acceleration setup and the given hard or software limits.

**Speed and direction can be changed on the fly.**

With command **stopspeed** or **Ctrl-C** the move of all axes is stopped.

The speed mode is indicated in the status reply, see command **status**.

## Syntax:

[direction] [velocity] [axis] **speed**

|             | Range   | Unit    |
|-------------|---------|---------|
| [direction] | + / -   |         |
| [velocity]  | 0-60 *  | rev./s. |
| [axis]      | 1, 2, 3 |         |

\* depends on the model and the released speed grade.

## Example:

**10 1 speed**

Axis-1 is continuos moved with 10 rev./s in positive direction.

**-0.1 2 speed**

Axis-2 is continuos moved with 0.1rev./s in negative direction.

**-0.5 2 speed**

The speed of Axis-2 is changed on the fly to 0.5 rev./s.



# ***stopspeed***

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command ***stopspeed*** interrupts the constant velocity move of all axes with the adjusted acceleration.

See command ***sa***.

## Syntax:

***stopspeed***

## Example:

***stopspeed***



# test

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **test** performs a positioning test procedure. This procedure starts at the origin and moves stepwise to the maximum range, then stepwise back to the origin.

The procedure is aborted if the communication interface receives any ASCII character.



The command is only functional, if the limits of all axes are defined.

## Syntax:

[Step size] [Axis] **test**

|           | Range   | Unit       |
|-----------|---------|------------|
| Step size | any     | axis units |
| Axis      | 1, 2, 3 |            |

## Example:

```
cal  
rm  
10 1 test
```

unit = mm / The limits are determined!

Axis-1 moves in 10mm steps to the upper limit.  
If the limit border is reached, the axis moves in 10mm steps backwards to the origin.  
This procedure is executed until a ASCII sign is received.



# **randmove**

Corvus TT

Corvus eco

Corvus PCI

## Description

Command **randmove** moves all active axes to randomized coordinates with a randomized velocity/acceleration setup.

The randmove procedure is terminated if the controller receives any ASCII character.



The command is only functional if the limits of all axes are defined.

## Syntax:

**randmove**

## Example:

```
cal  
rm  
randmove
```

The limits are defined with *cal* and *rm*.

All active axes are moving to randomized positions within the limits.



---

# **Limit Switch functions**

---



# calibrate (cal)

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **cal** executes the limit-switch move to the cal limit-switches. All active axes are simultaneously moved in negative direction, until the cal-switches are in ON state.

After that, the controller moves each axis in positive direction, as long as the limit-switches switch in OFF state.

At the OFF state coordinate, the position of the axes are set to zero (depends on the setup *setaxis*). Further on it is not possible to move the axes to coordinates less than zero.



With **Ctrl-C** the cal limit-switch move is immediately aborted and the origin and lower limit is set at this coordinate.

The origin and the lower limits are not permanently stored. After power OFF these values are lost.

During the **cal** procedure the command interpreter is blocked and no other commands can be executed.

The received commands are temporary stored in the communication FIFO and executed after the cal procedure is finished.

The proceedings to generate an automatic status reply after the completion of the limit-switch move, is described in the Venus-1 introduction.

## Syntax:

**calibrate** or **cal**

## Example:

**cal**



# rangemeasure (rm)

Corvus T, Corvus eco,  
Corvus PCI

## Description:

The command **rm** executes the limit-switch move to the rm limit-switches. All active axes are simultaneously moved in positive direction, until the rm-switches are in ON state.

After that, the controller moves each axis in negative direction, as long as the limit-switches switch in OFF state.

At the OFF state coordinate, the position of the axes are set to zero (depends on the setup *setaxis*).

Further on it is not possible to move the axes behind these coordinates



With **Ctrl-C** the rm limit-switch move is immediately aborted and the origin and upper limit is set at this coordinate.

The origin and the upper limits are not permanently stored.  
After power OFF these values are lost.

During the **rm** procedure the command interpreter is blocked and no other commands can be executed. Nevertheless the received commands are temporary stored in the communication FIFO and executed after the cal procedure is finished.

The proceedings to generate an automatic status reply after completion of the limit switch movement, is described in the Venus-1 introduction.

## Syntax:

**rangemeasure** or **rm**

## Example:

**rm**



# getcaldone

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.42

## Description:

With command **getcaldone** it can be determined if the calibration moves to the limit-switch *cal* and *rm* are executed or not.



The status of the *rm*-limit switch move is cleared if an *cal*-limit switch move is executed.

## Syntax:

**[axis] getcaldone**

## Reply:

[decimal value]

|         | Range |
|---------|-------|
| [value] | 0 - 3 |

| [value] | <i>cal</i> done | <i>rm</i> done |
|---------|-----------------|----------------|
| 0       | no              | no             |
| 1       | yes             | no             |
| 2       | no              | yes            |
| 3       | yes             | yes            |

## Example:

**1 getcaldone**

Reply:

1



# setsw

Corvus TT

Corvus eco

Corvus PCI

## Description:



The command **setsw** adapts the specified limit-switch input to the connected switch type of the cal/rm-switch.

Following settings are possible:

- normally open (no)
- normally closed (nc)
- limit-switch disabled



**If a limit-switch input is disabled, it can not accomplish a safety function.**

## Syntax:

[function] [limit-switch] [axis] **setsw**

| [function] | NPN Type *  | PNP Type ** |
|------------|-------------|-------------|
| 0          | closer (nc) | opener (no) |
| 1          | opener (no) | closer (nc) |
| 2          | disabled    | disabled    |

\* NPN-Switch is switched to GND

\*\* PNP-Switch is switched to VCC

| [limit-switch] | description |
|----------------|-------------|
| 0              | cal-input   |
| 1              | rm-input    |

## Examples:

**0 0 1 setsw**

cal limit-switch input of Axis-1 is prepared for a NPN-closed or PNP-open switch.

**2 1 2 setsw**

rm limit-switch input of Axis-2 is disabled.

# getsw

## Description:

The command **getsw** returns the setting of the limit-switch inputs.

## Syntax:

[axis] **getsw**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[cal-input] [rm-input]

| [Input] | NPN-Switch * | PNP-Switch ** |
|---------|--------------|---------------|
| 0       | closer (nc)  | opener (no)   |
| 1       | opener (no)  | closer (nc)   |
| 2       | disabled     | disabled      |

## Example:

**3 getsw**

**-1 getsw**

Reply:

0 0

0 0 1 0 2 2



# **getswst**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getswst** returns the current activity of the limit-switch inputs.

## Syntax:

[axis] **getswst**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[cal-input] ] [rm-input]

| [cal-input] | Description                      |
|-------------|----------------------------------|
| 0           | cal limit-switch is in OFF state |
| 1           | cal limit-switch is in ON state  |

| [rm-input] | Description                     |
|------------|---------------------------------|
| 0          | rm limit-switch is in OFF state |
| 1          | rm limit-switch is in ON state  |

## Example:

**3 getswst**

Reply: 0 0

The cal and rm limit-switches of Axis-3 are in OFF state.

**-1 getswst**

Reply: 00 10 00

The cal limit-switch of Axis-2 is in ON state, others are OFF.



# **setcalswdist**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setcalswdist** an additional distance out of the limit-switches can be defined.

This setting reduces the working area on each side of an axis.

With this setting, the limit-switch move procedure works as follows:

1. Move to the limit-switch until it is On state
2. Move out of the limit-switch until it is released (Off state)
3. Move out a additional distance defined with **setcalswdist**



For the reason of compatibility with older controllers, the unit of **setcalswdist** is defined in motor revolutions.

The resulting distance in mm depends on the spindle pitch setting of the 0-Axis.

## Syntax:

[revolution] [axis] **setcalswdist**

|              | Range     | Unit              |
|--------------|-----------|-------------------|
| [revolution] | 0 - >1000 | Motor revolutions |
| [axis]       | 1, 2, 3   |                   |

## Related command:

**getcalswdist**

## Example:

**5 1 setcalswdist**

An additional distance of 5 motor revolutions out of the cal and rm limit-switches is performed for the limit-switch procedure of Axis-1.

# **getcalswdist**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getcalswdist** returns the settings of *setcalswdist*.

## Syntax:

[axis] **getcalswdist**

|        | <b>Range</b> |
|--------|--------------|
| [axis] | -1, 1, 2, 3  |

## Reply:

[value]

|         | <b>Unit</b> |
|---------|-------------|
| [value] | rev.        |

## Example:

**1 getcalswdist**

Reply:

5.00000

**-1 getcalswdist**

Reply:

5.00000

0.00000

0.00000

# setlimit

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setlimit** the software limits are defined for the axes.

If the limits are determined, the controller is not able to move beyond it. All moves are ramped down and stopped at the limit border.

This scenario will produce error Code 1004 (see command **ge**)

With command **setnlimit**, software limits can be defined for each axis separately.

In manual mode the limits are determined with pressing the limit-switches.

## Requirements to define software limits:

- If the hard limits are specified with the **cal/rm** limit switch moves, the software limits must be located between these limits.
- The value of the lower limit has to be less than the value of the upper limit.
- The current position has to be within these limits, otherwise the command is not executed.
- If an axis is disabled, no limit inputs are accepted.
- The limit-switch move **cal** and **rm** overwrites the software limits.
- With command **reset**, all limits are lost and switched to their maximum value +/-16383 mm

## Syntax:

**`[-A1] [-A2] [-A3] [A1+] [A2+] [A3+] setlimit`**

The number of axis parameters depends on the setting of *setdim*.

|                    | Description        |
|--------------------|--------------------|
| <code>[-A1]</code> | lower limit Axis-1 |
| <code>[-A2]</code> | lower limit Axis-2 |
| <code>[-A3]</code> | lower limit Axis-3 |

|                    | Description        |
|--------------------|--------------------|
| <code>[A1+]</code> | upper limit Axis-1 |
| <code>[A2+]</code> | upper limit Axis-2 |
| <code>[A3+]</code> | upper limit Axis-3 |

|                                | Range    | Unit      |
|--------------------------------|----------|-----------|
| <code>[-A1] [-A2] [-A3]</code> | -16383mm | user unit |
| <code>[A1+] [A2+] [A3+]</code> | +16383mm | user unit |

## Related command:

**`setnlimit, getlimit, getnlimit`**

## Example:

**`getdim = 3`**

**`0 0 0 12 25 30 setlimit`**

The axis limits are defined as follows:

Axis-1: 0 until 12

Axis-2: 0 until 25

Axis-3: 0 until 30

# **getlimit**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getlimit** returns the limit coordinates of all axes.  
Dependent on the setting of *setdim* the controller returns  
the limit coordinates of 1, 2 or 3 axes.

With command **setnlimit** the limit of a single axis can be  
replied.

If no limit is specified the maximum limit value (16383mm) is  
returned:

|

## Syntax:

**getlimit**

## Reply:

|               |               | <b>Unit</b> | <b>Axis</b> |
|---------------|---------------|-------------|-------------|
| [lower limit] | [upper limit] | unit        | 1           |
| [lower limit] | [upper limit] | unit        | 2           |
| [lower limit] | [upper limit] | unit        | 3           |

\* depends on the setting of *setdim*

## Example:

```
getdim = 3
getlimit
```

```
0.000000 7.723750 [cr]
0.000000 7.723750 [cr]
-16383.000000 16383.000000 [cr]
```



# ***nca!***

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.0

## Description:

The command ***nca!*** executes a single axis limit-switch move to the cal limit-switch. This procedure determines the origin and lower limit of the selected axis. The move procedure is similar to the function ***ca!***.



**Contrary to the ca! limit switch movement the Venus-1 command interpreter is not blocked with nca!.**

**As a result the controller can execute all command requests during the nca! procedure.**

The velocity of ***nca!*** movement is adjusted with the command ***nca!vel***

With ***Ctrl-C*** the nca! limit-switch move is immediately aborted and the origin and lower limit is set at this coordinate.

## Syntax:

**[axis] nca!**

## Example:

**1 nca!**

Axis-1 is moved to cal limit-switch.



# ***nrm***

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.0

## Description:

The command ***nrm*** executes a single axis limit-switch movement to the rm limit-switch. This procedure determines the upper limit of the selected axis.



**Contrary to the rm limit switch movement the Venus-1 command interpreter is not blocked with *nrm*. As a result the controller can execute all command requests during the *nrm* procedure.**

The other limit-switch movement functionality remain the same. See the *rm* command description.

The velocity of ***nrm*** movement is adjusted with the command *nrmvel*

With ***Ctrl-C*** the nrm limit-switch move is immediately aborted and the origin and lower limit is set at this coordinate.

## Syntax:

**[axis] *nrm***

## Example:

**1 *nrm***

Axis-1 is moved to rm limit-switch.



# ***getnlimit***

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.5.0

## **Description:**

The command ***getnlimit*** returns the current limits of a specified axes.

If no limits are specified, the following values are returned:  
-16383.000000 16383.000000

With command ***getlimit*** the limits of all axes are replied.

## **Syntax:**

[axis] ***getnlimit***

unit= user defined units

## **Reply:**

[lower limit] [upper limit]

## **Related commands**

***getlimit***

## **Example:**

***1 getnlimit***

0.000000 12.000000



# org

Corvus TT

-

-

Valid from firmware version 4.1.0

## Description:

Command **org** a moves the specified axis a relative stroke until the org-switch is in ON state.

Similar to the cal/rm limit switch procedure the controller than moves in the reverse direction, as long as the org-switch is switched to the OFF state.

The function must be enabled with command **setorg**.

The speed values for the org moves are fixed with command **setcalvel**.

If the switch is not in ON state within the specified stroke, the move is stopped and error code 1011 is generated.

With command **Ctrl-C** the org procedure is aborted.



If the org switch is already in ON state when the command **org** is executed, the controller moves the axis immediately in the reverse direction, until the org switch is in OFF state.  
In this case also error code 1011 is generated.

## Syntax:

[direction] [relative stroke] [axis] **org**

|                   | range   | unit |
|-------------------|---------|------|
| [direction]       | + / -   |      |
| [relative stroke] |         | unit |
| [axis]            | 1, 2, 3 |      |

## Example:

### **-10 1 org**

Axis-1 is moved 10 [units] in negative direction until the org-switch is in ON state. After this, the axis is moved in positive direction until the org-switch is in OFF state.



# **setorg**

Corvus TT

-

-

Valid from firmware version 4.1.0

## Description:



The command **setorg** enables or disables the org-switch input.

## Syntax:

[on/off] [axis] **setorg**

|          | Range   |
|----------|---------|
| [on/off] | 0,1     |
| [axis]   | 1, 2, 3 |

| [on/off] | Function           |
|----------|--------------------|
| 0        | org-input disabled |
| 1        | org-input enabled  |

## Example:

**1 1 setorg**

Enables org-input for Axis-1.

# **getorg**

Corvus TT

-

-

## Description:

Command **getorg** returns the org-input settings of the specified axis.

## Syntax:

[axis] **getorg**

|        | Range   |
|--------|---------|
| [axis] | 1, 2, 3 |

## Reply:

[index]

| [index] | Function           |
|---------|--------------------|
| 0       | org-input disabled |
| 1       | org-input enabled  |

## Example:

**1 getorg**

# **setorgsw**

Corvus TT

-

-

Valid from firmware version 4.1.0

## Description:



The command **setorgsw** adapts the specified org-switch input to the connected switch type.

Following settings are possible:

- normally open (no)
- normally closed (nc)

The input can be disabled with command **setorg**.

## Syntax:

[function] [axis] **setorgsw**

| [function] | NPN-Switch * | PNP-Switch ** |
|------------|--------------|---------------|
| 0          | closed (nc)  | open (no)     |
| 1          | open (no)    | closed (nc)   |

\* NPN-switch is switched to GND

\*\* PNP-switch is switched to VCC

## Examples:

**0 1 setorgsw**

org limit-switch input of Axis-1 is prepared for a NPN-closed or PNP-open switch.

# getorgsw

Corvus TT

-

-

## Description:

The command **getorgsw** returns the setting of the org-switch inputs.

## Syntax:

[axis] **getorgsw**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[function]

| [function] | NPN-Switch * | PNP-Switch ** |
|------------|--------------|---------------|
| 0          | closed (nc)  | open (no)     |
| 1          | open (no)    | closed (nc)   |

## Example:

**3 getsw**

**3 getsw**

**-1 getsw**

Reply:

0 0

Reply:

0 0 0 1 2 2

[Axis-1] [Axis-2] [Axis-3]

# getorgswst

Corvus TT

-

-

Valid from firmware version 4.1.0

## Description:

The command **getorgswst** returns the current activity of the org limit-switch input.

## Syntax:

[axis] **getorgswst**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[switch state]

| [switch state] | Description                |
|----------------|----------------------------|
| 0              | org-switch is in OFF state |
| 1              | org-switch is in ON state  |

## Example:

**1 getorgswst**

Reply: 0

The org-switch of Axis-1 is in OFF state.

**-1 getorgswst**

Reply: 0 1 0

The org-switch of Axis-2 is in ON state, others are OFF.



---

# Safety functions

---



# **Ctrl-C**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **Ctrl-C** interrupts the current executed command. Moves will be stopped immediately with the acceleration setup, defined with command **sa**.

Subsequently the already transferred commands in the RS-232 input buffer will be executed

If a *cal* or *rm* limit-switch move is interrupted with **Ctrl-C** the current axes positions are taken over as the controller lower limits or maximum range limit.



**Due to the Ctrl-C command has not to pass the command FIFO, it can not be delayed with a blocking command.**



**It is not permissible to use Ctrl-C in a quick succession.**

## Syntax:

| ASCII sign | Decimal value | Hex value |
|------------|---------------|-----------|
| Ctrl-C     | 3             | 0x3       |

## Related command:

*abort, Ctrl-B, Ctrl-D*

## Example:

**Ctrl-C**



# **Ctrl-B**

Corvus TT

Corvus eco

Corvus PCI

## Description:

With command **Ctrl+B** the motor current of all axes is turned off.

The communication with the controller is further on possible. To continue the normal motor driver operation, the controller has to be restarted with power ON/OFF or with the command **reset**.

## Syntax:

**Ctrl-B** equal to decimal 4

## Related commands:

**abort**, **Ctrl-C**, **Ctrl-D**, **setmp**

## Example:

**Ctrl-B**

The motor drivers are disabled.



# abort

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **abort** interrupts the current executed command. All moves will be stopped immediately with the acceleration setup, defined with command **sa**.

The commands in the command FIFO are not cleared.



Due to **abort** has to pass the data input FIFO, it can be delayed with a blocking command.

For example: **abort** is blocked with the command **ge**

1. **100 0 0 move (current executed)**
2. **ge**
3. **abort**

## Syntax:

**abort**

## Related command:

**Ctrl-C, Ctrl-B, Ctrl-D**

## Example:

**abort**



## Description:



Command **setfunc** a safety function via the Digital Input/Output interface can be established.

This function can interrupt the current move or/and limiting the move direction of an axis.

The function is valid for programmed and manual move.

The following move limitations can be configured:

- move is limited for all directions
- move is limited for the negative direction
- move is limited for the positive direction

## Option



To support the function **setfunc**, the controller must be equipped with the feature Digital Input/Output.

Details, see in the hardware manual

## setfunc procedure description

If a disable signal gets active at one of the configured inputs, while a move is executed, the move of all axes is stopped with the acceleration setup **sa**.

After that, each axis follows the individual setting with command **setfunc**.

Axes which are not configured with a **setfunc** function, can further on normally moved.

The **setfunc** status is reflected in the status Bit D6, additionally the assigned Axis-LED in the Corvus diagnostic display is flashing.

If the disable signal is removed, all **setfunc** limitations are canceled and the axes are free.

## Syntax:

[action] [input] [axis] **setinfunc**

|          | Range      |
|----------|------------|
| [action] | 0, 1, 2, 3 |
| [input]  | 1, 2, 3    |
| [axis]   | 1, 2, 3    |

|          | Description            |
|----------|------------------------|
| [input]  | digital inputs 1, 2, 3 |
| [action] | setinfunc limitation   |

| [action] | Function                                      |
|----------|---|
| 0        | no limitation                                 |
| 1        | moving is limited for the positive direction  |
| 2        | moving is limited for the negative direction. |
| 3        | moving is limited for all directions          |

## Related command:

**getinfunc**

## Example:

**1 1 3 setinfunc**

The following safety function is configured to Axis-3:

If Din-1 is active, all axes are stopped, Axis-3 is limited in negative direction but can be moved in positive direction.

**2 2 3 setinfunc**

If Din-2 is active, all axes are stopped, Axis-3 is limited in positive direction but can be moved in negative direction. After the axes are stopped the Axis-1 and Axis-2 can be moved normally.

# **getinfunc**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getinfunc** returns the setting of **setinfunc**.

## Syntax:

[input] [axis] **getinfunc**

|         | <b>Range</b> |
|---------|--------------|
| [input] | 1, 2, 3      |
| [axis]  | 1, 2, 3      |

## Reply:

[action]

|          | <b>Range</b> |
|----------|--------------|
| [action] | 0, 1, 2, 3   |

| [action] | <b>Function</b>                             |
|----------|---|
| 0        | no limitation                               |
| 1        | move is limited for the positive direction  |
| 2        | move is limited for the negative direction. |
| 3        | move is limited for all directions          |

## Example:

**1 3 getinfunc**



# **setmp**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setmp** the motor current from a specified axis can be switched off completely. All other functions remain active.



Depending on the rotor position, the motor will jerk if the motor current is switched on or off.

## Syntax:

[switch] [axis] **setmp**

|          | Range   |
|----------|---------|
| [switch] | 0, 1    |
| [axis]   | 1, 2, 3 |

| [switch] | Function                           |
|----------|------------------------------------|
| 0        | Motor driver is current less       |
| 1        | Motor driver in standard condition |

## Example:

**0 1 setmp**

The motor current of Axis-1 is switched off.

# **getmp**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getmp** returns the setting of *setmp*.

## Syntax:

[axis] **getmp**

| parameter | Range       |
|-----------|-------------|
| [axis]    | -1, 1, 2, 3 |

## Reply:

[switch status]

|                 | Range |
|-----------------|-------|
| [switch status] | 0, 1  |

## Example:

**1 setmp**

Reply:

0

**-1 getmp**

Reply:

0 1 1

---

---

# **position / origin / coordinate system**

---



# **pos (p)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **pos** return the current coordinate of all active axes.

The position value relates to the origin which is defined with command **cal** or **setpos**. The number of replied coordinates depends on the setting of **setdim**.

## Syntax:

**pos** or **p**

## Reply:

[Pos Axis-1] [Pos Axis-2] [Pos Axis-3]

|              | Description        | Unit |
|--------------|--------------------|------|
| [Pos Axis-1] | Position of Axis-1 | unit |
| [Pos Axis-2] | Position of Axis-2 | unit |
| [Pos Axis-3] | Position of Axis-3 | unit |

## Example:

**getdim = 2**

**pos**

Reply:

1.00000 19.00000



# **setpdisplay**

## **Description:**



Command **setpdisplay** the display format of the replied position value can be defined.

The positioning resolution is not affected by this setting.

## **Syntax:**

[VK] [NK] [Axis] **setpdisplay**

|        | <b>Function</b>                 | <b>Range</b> |
|--------|---------------------------------|--------------|
| [VK]   | digits before the decimal point |              |
| [NK]   | digits after the decimal point  |              |
| [Axis] |                                 | 1, 2, 3      |

## **Related command:**

**getpdisplay**

## **Example:**

```
1 3 1 setpdisplay  
2 10 2 setpdisplay
```

X:0.050

Y:50.0000000000

---

# **getpdisplay**

## **Description:**

Command **getpdisplay** returns the setting of **setpdisplay**.

## **Syntax:**

[Axis] **getpdisplay**

|        | <b>Range</b> |
|--------|--------------|
| [Axis] | -1, 1, 2, 3  |

## **Reply:**

Host mode:

[VK] [NK]

Terminal mode:

Axis: 1 field width: 1 precision width 3  
Axis: 2 field width: 2 precision width 10

## **Example:**

**1 getpdisplay**

# setpos

Corvus TT

Corvus eco

Corvus PCI

## Description:

With command **setpos** the point of origin of all axes can be defined. The coordinates of the limits will be recalculated if the point origin changes.

The axes must be enabled.

For special cases the zero point can be defined with a relative offset.

## Syntax:

[Axis-1] [Axis-2] [Axis-3] **setpos**

|          | Range      | unit |
|----------|------------|------|
| [Axis-1] | +/-16383mm | unit |
| [Axis-2] | +/-16383mm | unit |
| [Axis-2] | +/-16383mm | unit |

## Example:

**0 0 0 setpos**

The current coordinate is defined as the point of origin.

**10 10 10 setpos** / unit = mm

The current coordinate is defined as the point origin with an relative offset 10 mm each axis.

The command **pos** will reply the position value -10 -10 -10 if the previous coordinate was 0 0 0.



# align

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **align** rotates the orthogonal coordinate system of Axis-1 and Axis-2 (X/Y) around its origin. Axis-3 is not affected by the rotation.

After rotation, the positioning commands *move* and *rmove* are using the new coordinate system.

The limits are further checked. It is not possible to move to coordinates out of the limits.

Command *getlimit* or *getnlimit* returns the limit values.  
With command *ico* the coordinate system is restored.



To execute the function properly the controller dimension setting *setdim* must be set to 2.

## Syntax:

[0] [0] [OrgX] [OrgY] [X/Y] **align**

With [0] [0] [OrgX] [OrgY] the location of the related axis is defined.

[X/Y] defines if the related axis is X or Y.

|        | Description                            |
|--------|--|
| [OrgX] | X-coordinate of related axis           |
| [OrgY] | Y-coordinate of related axis           |
| [X/Y]  | Related axis<br>1 = X-axis, 2 = Y-axis |

|        | Range       | Unit      |
|--------|-------------|-----------|
| [OrgX] | +/- 16383mm | user unit |
| [OrgY] | +/- 16383mm | user unit |
| [X/Y]  | 1, 2        |           |

## Reply:

Command **getico** returns value=0 if the original coordinate system is rotated.

## Example:

**0 0 10 10 1 align**

The X-axis is aligned to the coordinate 0 / 0 |10 / 10  
The Y-coordinate follows automatically.

The sketch below shows a sample found on a microscope scanning stage. The sample is misaligned to the stage. With command align it is possible to adapt the controller coordinate system to the coordinates of the sample.


Border A of the object is defined with the coordinates 0 / 0 | 4.1 / 7.9

With command **0\_0\_4.1\_7.9\_2 align** this border is aligned to the new Y-Axis. Therefore the coordinate system of the controller is rotated anti clockwise around its origin.

The coordinate system of the controller is than aligned to the coordinates of the object.

Alternatively the align procedure can be related to the coordinates of border B.

This will give the same results a the previous method.



# **ico**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **ico** restores the original coordinate system of the controller.

## Syntax:

*ico*

## Related command:

*getico, align*

## Example:

*ico*



# **getico**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getico** verifies if the coordinate system is rotated with command **align**.

## Syntax:

**getico**

## Reply:

[Index]

| [Index] | Function                         |
|---------|----------------------------------|
| 0       | coordinate system is rotated     |
| 1       | coordinate system is not rotated |

|         | Range |
|---------|-------|
| [Index] | 0, 1  |

## Example:

**getico**



---

# **Status requests**

---



# **status (st)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **status** returns the current state of the controller.

Each state is assigned to a binary digit from D0 to D8.  
If more states are active, the decimal values of the digits are added.

To decode the replied status, it is necessary to convert the decimal value into a binary pattern and mask the bits.

| Binary | Decimal | Function                           |
|--------|---------|------------------------------------|
| D0     | 1       | Status current command execution   |
| D1     | 2       | Status Joystick or Handwheel       |
| D2     | 4       | Status Button A                    |
| D3     | 8       | Machine error                      |
| D4     | 16      | Status speed mode                  |
| D5     | 32      | Status In-Window                   |
| D6     | 64      | Status setinfunc                   |
| D7     | 128     | Status motor enable, safety device |
| D8     | 256     | Joystick button                    |

### D0: Current command execution or motion state

|   |                  |
|---|------------------|
| 0 | move finished    |
| 1 | move in progress |

### D1: Joystick state

|   |                        |
|---|------------------------|
| 0 | Manual mode not active |
| 1 | Manual mode is active  |

### D2: Switch A state (only Corvus TT)

|   |                      |
|---|----------------------|
| 0 | Button A not pressed |
| 1 | Button A pressed     |

---

**D3: Machine error state**

|   |                        |
|---|------------------------|
| 0 | No machine error       |
| 1 | Machine error occurred |

**D4: Speed mode state**

|   |                       |
|---|-----------------------|
| 0 | Speed mode active.    |
| 1 | Speed mode not active |

**D5: Closed Loop Window state**

|   |  |
|---|--|
| 0 | Current position out of the target window. |
| 1 | Current position within the target window. |

**D6: setinfunc safety function state**

|   |                                 |
|---|---------------------------------|
| 0 | setinfunc limitation not active |
| 1 | setinfunc limitation active     |

**D7: Motor disable state (disabled from safety device)**

|   |  |
|---|--|
| 0 | Motor driver enabled                       |
| 1 | Motor driver disabled from external device |

**D8: Joystick button state**

|   |                          |
|---|--------------------------|
| 0 | Joystick button released |
| 1 | Joystick button pressed  |

**Syntax:**

**status** or **st**

**Reply:**

[bit coded decimal value]

**Example:**

**status**

Reply:

**2**

Bit pattern: 01000000


Decoded states:

Move is finished, manual mode active

More examples on the following page.

---

### Command execution



status reply



# **geterror (ge)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

With the command **geterror** the last occurred system error is returned. Afterwards the error code memory is cleared.

The occurrence of an system error is not reflected in the status reply.

## Syntax:

**geterror**

## Reply:

[Error code]

| Error codes  | Description   |
|--------------|---|
| 1....4       | Internal error                                      |
| 1001         | Wrong parameter                                     |
| 1002         | Not enough parameter on the stack                   |
| 1003<br>1007 | Range of parameter is exceeded                      |
| 1004         | Move stopped working range should run over          |
| 1008         | Not enough parameter on the stack<br>(same as 1003) |
| 1009         | Not enough space on the stack                       |
| 1010         | Not enough space on parameter memory                |
| 1015         | Parameters outside the working range                |
| 2000         | Unknown command                                     |

## Example:

**ge**



# **geterror (gme)**

Corvus T, Corvus eco,  
Corvus PCI

## Description:

With the command **geterror** the hardware errors from the machine error stack are returned.

The machine errors are put on a memory stack which can store a maximum of 10 error codes.

The occurrence of a machine error is reflected in the status reply and displayed in the Error-LED in the diagnostic panel.

With each **gme** command the error codes are replied in order of their appearance.

If all errors are returned, the error status is cleared and the Error-LED is deactivated after power up.

## Syntax:

**geterror** or **gme**

## Reply:

[machine error code]

| Error code | Description  |
|------------|--|
| 0          | No machine errors occurred   |
| 1          | Error memory is overflowed   |
| 10         | Motor driver disabled<br>(Motor disable function is active)<br>or defective 12V power supply.            |
| 13         | Maximum positioning error in Closed Loop mode is exceeded, see command <b>setclpara</b> (7th. parameter) |
| 23         | RS422 Encoder error  |

## Example:

**gme**



# ***gsp***

Corvus TT

Corvus eco

Corvus PCI

## **Description:**

The command ***gsp*** returns the number of elements on the parameter stack.

## **Syntax:**

***gsp***

## **Reply:**

[Number]

|          | <b>Range</b> |
|----------|--------------|
| [Number] | 0 -99        |

## **Related command:**

***clear***

## **Example:**

***gsp***

Reply:

2



# getticks (gt)

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **gt** (`get_ticks`) returns the number of processor cycles, since the controllers was started.

Each count equals 250µs.

This function can be used as a time-stamp, to reference data or events.

After 298 hours this counter will overflow and start with zero.

## Syntax:

**gt**

## Example:

**gt**

returns: 10922835

( $10922835 \times 250\mu\text{s} = 2730,708 \text{ s}$ )



---

# **Input / Output functions**

---



# setout

Corvus TT


Corvus eco

Corvus PCI

## Description:

Command **setout** controls the digital outputs.  
A similar function is command *outtrig*.

The outputs are open collector circuits. In ON state the output transistor is switched to DGND.



## Syntax:

[value] **setout**

| Value | Dout-1 | Dout-2 | Dout-3 |
|-------|--------|--------|--------|
| 0     | OFF    | OFF    | OFF    |
| 1     | ON     | OFF    | OFF    |
| 2     | OFF    | ON     | OFF    |
| 3     | ON     | ON     | OFF    |
| 4     | OFF    | OFF    | ON     |
| 5     | ON     | OFF    | ON     |
| 6     | OFF    | ON     | ON     |
| 7     | ON     | ON     | ON     |

## Related command:

**getout**

## Example:

**1 setout**

# **getout**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getout** returns the state of the digital outputs as a decimal value.

## Syntax:

**getout**

## Reply:

[value]

|         | Range |
|---------|-------|
| [value] | 0-7   |

## Example:

**getout**

# setaout

Corvus TT

Corvus eco

Corvus PCI

## Description:

Option



Command **setaout** generates an analog output voltage between 0 and 1000mV with 8 Bit resolution.  
Two outputs channels are provided.



A load resistance of 1 MOhm (or higher) is recommended for proper functionality. A smaller load resistance will reduce the output voltage.

## Syntax:

[voltage] [channel] **setaout**

|           | Range  | Unit |
|-----------|--------|------|
| [voltage] | 0-1000 | mV   |
| [channel] | 1,2    |      |

## Related command:

**getaout**

## Example:

**100 1 setaout**

100mV output voltage is generated at channel-1.

# **getaout**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getaout** returns the adjusted analog output voltage, generated with command **setaout**.

## Syntax:

[channel] **getaout**

unit= [mV]

## Reply:

[voltage]

|           | Range  | Unit |
|-----------|--------|------|
| [voltage] | 0-1000 | mV   |

## Example:

**1 getaout**


## Description:

The command **getin** returns the current status of the three digital Inputs Din-1, Din-2, Din-3 as a decimal value.

Each input is assigned to a binary state from D0 to D2.

If more inputs are active, the decimal values of the states are added.

To get each input state separately, it is necessary to convert the decimal value into a binary and mask the bit pattern.



## Syntax:

**getin**

## Reply:

[decimal value]

|                 | Range |
|-----------------|-------|
| [decimal value] | 0-7   |

## Example:

**getin**

| [decimal value] | Input Din-1 | Input Din-2 | Input Din-3 |
|-----------------|-------------|-------------|-------------|
| 0*              | 0           | 0           | 0           |
| 1**             | 1           | 0           | 0           |
| 2               | 0           | 1           | 0           |
| 4               | 0           | 0           | 1           |

\*0: Input voltage 0-2V

\*\*1: Input voltage 3-24V



---

## **Closed Loop commands**

---



# **setnselpos**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setnselpos** determines whether the internal calculated position value or the actual position value, from a measurement system, is returned.



To display the actual position, the controller must be equipped with a digital or analog encoder interface.  
See in manual chapter "functions".

## Syntax:

[index] [axis] **setnselpos**

|       | Range   |
|-------|---------|
| Index | 0,1     |
| Axis  | 1, 2, 3 |

| [index] | Description                     |
|---------|---------------------------------|
| 0       | returns the calculated position |
| 1       | returns measured position       |

## Related command:

**getnselpos**

## Example:

```
0 3 setnselpos  
1 1 setnselpos
```



# **getnselpos**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getnselpos** returns the settings of *setnselpos*.

## Syntax:

[axis] **getnselpos**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[index]

|         | Range |
|---------|-------|
| [index] | 0, 1  |

## Example:

**3 getnselpos**



## Description:

Command **setclpara** configures the loop controller.



Following settings are possible:

- Adjustment of the proportional gain (P), integral gain (I) and derivative gain (D)
- Safety function  
Disables the axis if the position deviation of the actual position and a desired position exceeds a determined value.
- Limiting the adjustment speed caused from the I-Controller.
- Limiting the influence of the I-Controller (anti windup).

## Syntax:

**[P] [I] [D] [16383] [SP1] [SP2] [dpos] [ivel] [cutoff] [SP3] [np] [axis] setclpara**

The commands exists of a maximum of 10 parameters separated with a space and followed with [np] the number of parameters.

If a single parameter should be changed all prefixed parameters must also be transmitted.



Valid from firmware version 4.50 it is also possible to transmit single closed loop parameters, see command *sp*.

---

| Parameter | Description  |
|-----------|--|
| [P]       | Proportional gain<br>(Only used to adjust linear motors)   |
| [I]       | Integral gain<br>Important by the use of stepper motors  |
| [D]       | Derivative gain<br>(Only used to adjust linear motors)   |
| [16383]   | This setting may not be changed.   |
| [SP1]     | Boost-factor<br>(Only used to adjust linear motors)  |
| [SP2]     | Disables the axis if the load angle deviation exceeds a determined value.<br>Command <b>gme</b> returns error code 13.<br>With value = 0 the function is disabled.<br>(Only used to adjust linear motors)  |
| [dpos]    | Disables the axis if the position deviation of the actual position and a desired position exceeds a determined value.<br>Command <b>gme</b> returns error code 13.<br>With value dpos = 0, the function is disabled.   |
| [ivel]    | This function limits the adjustment velocity caused from the I-Controller during moving and stand still.<br>With value ivel = 0, the function is disabled.   |
| [cutoff]  | The cutoff parameter influences the smoothness of the motors in closed loop mode and optimizes the steady state error and settling time.<br>With cutoff the I-value is dynamically reduced depending on the current velocity.<br>The move is starting with a maximal I-value and is reduced dynamically to a minimum value at the adjusted cutoff velocity.<br>Below the cutoff velocity the I-value has it's maximum again.<br>cutoff = 0 disables this function. |
| [SP3]     | no function  |
| [np]      | The number of parameters that are send with the command.   |
| [axis]    | Axis index   |

| parameter | range   | default setting          | unit |
|-----------|---------|--------------------------|------|
| P         |         | 0                        | -    |
| I         |         | 10                       | 1/s  |
| D         |         | 0                        | s    |
| 16383     |         | 16383<br>(maximal value) |      |
| SP1       |         | 0                        |      |
| SP2       |         | 0                        |      |
| dpos      |         | 0<br>(0 = disabled)      | mm   |
| ivel      |         | 2<br>(0 = disabled)      | mm/s |
| cutoff    |         | 2<br>(0 = disabled)      | mm/s |
| SP3       | 0       | 0                        |      |
| Axis      | 1, 2, 3 |                          |      |

#### Related commands:

***getclpara, sp***

#### Examples:

***0\_20\_2\_1\_setclpara***

The parameters of "P" and "I" will configured for Axis-1, all following controller loop parameters remain unchained.

***0\_15\_0\_16383\_0\_0\_1\_2\_2\_9\_3\_setclpara***

In summary nine controller loop parameters are configured for Axis-3.

# **getclpara**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getclpara** return the settings of the loop controller.

10 parameters are replied.

## Syntax:

[axis] **getclpara**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[P] [I] [D] [16383] [SP1] [SP2] [dpos] [ivel] [cutoff] [SP3]

## Example:

**1 getclpara**

Reply:

0.000000 10.000000 0.000000 16383.000000 0.000000 0.000000 0.000000 2.000000 1.000000 0.000000

# **sets<sub>p</sub>**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.50

## Description:



Command **sets<sub>p</sub>** defines the settings of the loop controller. Unlike the command setclpara, this command allows to change each parameter separately.

- Adjustment of the proportional gain (P), integral gain (I) and derivative gain (D)
- Safety function  
Disables the axis if the position deviation of the actual position and a desired position exceeds a determined value.
- Limiting the adjustment speed caused from the I-Controller.
- Limiting the influence of the I-Controller (anti windup)

## Syntax:

[SP 1-10] [axis] **sets<sub>p</sub>**

| SP | Para     | Description  |
|----|----------|--|
| 1  | [P]      | Proportional gain<br>(Only used to adjust linear motors)   |
| 2  | [I]      | Integral gain<br>Important by the use of stepper motors  |
| 3  | [D]      | Derivative gain<br>(Only used to adjust linear motors)   |
| 4  | [16383]  | This setting may not be changed.   |
| 5  | [SP1]    | Boost-factor<br>(Only used to adjust linear motors)  |
| 6  | [SP2]    | Disables the axis if the load angle deviation exceeds a determined value.<br>Command <b>gme</b> returns error code 13.<br>With value = 0 the function is disabled.<br>(Only used to adjust linear motors)  |
| 7  | [dpos]   | Disables the axis if the position deviation of the actual position and a desired position exceeds a determined value.<br>Command <b>gme</b> returns error code 13.<br>With value dpos = 0, the function is disabled.   |
| 8  | [ivel]   | This function limits the adjustment velocity caused from the I-Controller during moving and stand still.<br>With value ivel = 0, the function is disabled.   |
| 9  | [cutoff] | The cutoff parameter influences the smoothness of the motors in closed loop mode and optimizes the steady state error and settling time.<br>With cutoff the I-value is dynamically reduced depending on the current velocity.<br>The move is starting with a maximal I-value and is reduced dynamically to a minimum value at the adjusted cutoff velocity.<br>Below the cutoff velocity the I-value has it's maximum again.<br>cutoff = 0 disables this function. |
| 10 | [SP3]    | no function  |

| parameter    | range   | default                  | unit |
|--------------|---------|--------------------------|------|
| SP1 (P)      |         | 0                        | -    |
| SP2 (I)I     |         | 10                       | 1/s  |
| SP3 (D)      |         | 0                        | s    |
| SP4 (16383)  |         | 16383<br>(maximum value) |      |
| SP5          |         | 0                        |      |
| SP6          |         | 0                        |      |
| SP7 (dpos)   |         | 0<br>0 = disabled        | mm   |
| SP8 (ivel)   |         | 2<br>0 = disabled        | mm/s |
| SP9 (cutoff) |         | 2<br>0 = disabled        | mm/s |
| SP10         | 0       | 0                        |      |
| axis         | 1, 2, 3 |                          |      |

**Related commands:**

*getsp, setclpara*

**Example:**

**100 2 setsp**

The integral gain of Axis-1 is adjusted to 100 1/s.

# **getsp**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getsp** returns the selected servo parameter (sp) of an axis.

## Syntax:

[SP Index] [axis] **getsp**

|            | range   |
|------------|---------|
| [axis]     | 1, 2, 3 |
| [SP index] | 1 - 10  |

## Reply:

[SP]

## Example:

**1 getsp**

Reply:  
100

# **setscaleinterface**

Corvus T, Corvus eco,  
Corvus PCI

## Description:



Command **setscaleinterface** configures one of the both Closed Loop interfaces.

Corvus is equipped with an On-Board digital encoder interface for RS-422 input signals.

Additionally a separate hardware (sin/cos Module) is provided to support analog measuring systems with 1Vpp or MR signals.



This setting is active if the commands **save** and **reset** are executed.

## Syntax:

[index] [axis] **setscaleinterface**

|         | Range   |
|---------|---------|
| [index] | 0, 1, 2 |
| [axis]  | 1, 2, 3 |

| [index] | Description                               |
|---------|---|
| 0       | Quadrature Interface disabled             |
| 1       | Quadrature Interface enabled              |
| 2       | Analog Interface (sin/cos Module) enabled |

## Example:

**2 1 setscaleinterface**

Initializes the analog encoder interface for Axis-1

# **getscaleinterface**

Corvus T, Corvus eco,  
Corvus PCI

## Description:

Command **getscaleinterface** verifies the type of the enabled encoder interface.

## Syntax

[axis] **getscaleinterface**

|        | Range   |
|--------|---------|
| [axis] | 1, 2, 3 |

## Reply:

[index]

|         | Range   |
|---------|---------|
| [index] | 0, 1, 2 |

## Example:

**1 getscaleinterface**

Reply:  
1

# **setscaletype**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setscaletype** adapts the encoder interface to the type of measurement system.

A distinction is drawn between linear encoders, rotational encoders with analog output and rotational encoders with digital output.

To adjust the encoder interface to the resolution of digital encoders we recommend to use command **setclfactor**.

For linear encoders and analog rotational encoders the command **setclperiod** should be used.

The settings of **setscaletype** and **setscaleinterface** are executed from the factory if a controller is delivered with the option "closed loop".

## Syntax:

[index] [axis] **setscaletype**

|         | Range   |
|---------|---------|
| [index] | 0, 1    |
| [axis]  | 1, 2, 3 |

| [index] | Description   |
|---------|---|
| 0       | linear measurement system (analog/digital)<br>analog rotary encoder |
| 1       | digital rotary encoder  |

## Example:

**1 1 setscaletype**

Adapts the encoder interface for Axis-1 to a digital rotary encoder.

# **getscaletype**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getscaletype** verifies the type of measurement system that is configured for the encoder interface.

## Syntax

[axis] **getscaletype**

|        | Range   |
|--------|---------|
| [axis] | 1, 2, 3 |

## Reply:

[index]

|         | Range |
|---------|-------|
| [index] | 0, 1  |

## Example:

1 **getscaletype**

Reply:

1

# **setclfactor**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **setclfactor** adapts the digital encoder interface to the resolution of a digital rotational encoder. The value is equivalent to the number of pulses per revolution.



With the algebraic sign -/+ it is possible to adapt the count direction to the motor direction.

To support digital rotational encoders, the controller must be equipped with the Corvus digital encoder interface.  
The interface has to be configured as follows.



| Command                  | Value |
|--------------------------|-------|
| <b>setscaletype</b>      | 0     |
| <b>setscaleinterface</b> | 1     |

## Syntax:

[Count direction] [pulses/rev.] [axis] **setclfactor**

| Parameter | Range   | Unit        |
|-----------|---------|-------------|
| + / -     |         |             |
| pulses    | 1-50000 | pulses/rev. |
| Axis      | 1, 2, 3 |             |

## Related command:

**getclfactor, setscaletype, setscaleinterface**

## Example:

- 500 3 **setclfactor**

# **getclfactor**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getclfactor** returns the setting of **setclfactor**

## Syntax:

[axis] **getclfactor**

| Parameter | Range       |
|-----------|-------------|
| Axis      | -1, 1, 2, 3 |

## Reply:

[Count direction] [pulses / rev.]

## Example:

**1 getclfactor**

Reply:

- 500

# **setclperiod**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **setclperiod** adapts the analog or digital encoder interface to the following encoder types:



- Linear encoders (RS-422, 1Vpp, MR)
- Rotational encoders (1Vpp)

The value for **setclperiod** is the resulting move distance within a one signal period of the encoder.

For digital rotational encoders the command **setclfator** is recommended.

The transmission ratio caused from the spindle or gear has to be considered to calculate the **setclperiod** value (see examples).

With the algebraic sign -/+ it is possible to adapt the count direction to the motor direction.

## Syntax:

[Counter direction] [Distance] [axis] **setclperiod**

|             | Description                       |
|-------------|-----------------------------------|
| [Direction] | counting direction                |
| [Distance]  | distance within one signal period |

|             | Range              | Unit |
|-------------|--------------------|------|
| [Direction] | + / -              |      |
| [Distance]  | 0.0000001-1.999999 | mm   |
| [axis]      | 1, 2, 3            |      |

---

### Related command:

***getclperiod, setscaleinterface, setscaletype***

### Examples:

- ***0.002 3 setclperiod***

### Example: Linear stage with linear encoder

Specifications:

Linear stage with following specifications:

Encoder with signal period = 20µm, Spindle pitch = 10mm

The value for ***setclperiod*** is the resulting move distance within a one signal period of the encoder.

Therefore ***setclperiod = 0.020mm***

The value of ***setclperiod*** does **not** depend on the pitch.  
because the resulting move distance is the same as the  
signal period of the encoder.

### Example: Linear stage with rotary encoder

Specifications:

Rotary encoder with 1Vpp output signal,

1000 signal periods / rev., mounted on the motor shaft.

Spindle pitch = 10mm

In this combination the movement distance within one signal period depends on the pitch.

The value for ***setclperiod*** will be calculated as follows:

$$\text{setclperiod} = 10 \text{ mm} / 1000 \text{ periods} = 0.01$$

# **getclperiod**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getclperiod** returns the setting of *setclperiode*.

## Syntax:

[axis] **getclperiod**

| Parameter | Range   |
|-----------|---------|
| [axis]    | 1, 2, 3 |

## Reply:

[Value]

|         | Range              | Unit |
|---------|--------------------|------|
| [Value] | 0.0000001-1.999999 | mm   |

## Example:

**1 getclperiod**

Reply:

0.020



# **setclwindow**

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setclwindow** enables a +/- target window for the closed loop function. Within the target window the position control loop is not active. If the position is beyond the target window, the position control loop gets active.

Status Bit D5 is active if all axes are within the target window.

If the actual position of an axis is out of the target window, the assigned LED in the diagnostic panel is flashing.

The window function is disabled if the target window is set to 0.

## Syntax:

[Window] [axis] **setclwindow**

|          | Range   | Unit | Function           |
|----------|---------|------|--------------------|
| [Window] |         | user | +/- window enabled |
| [Window] | 0 *     | user | window disabled    |
| [axis]   | 1, 2, 3 | -    |                    |

\*factory setting

## Related command:

**getclwindow**

## Example:

**0.001 1 setclwindow**

(User unit = mm)

The target window of Axis-1 is adjusted to +/-1µm

# **getclwindow**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getclwindow** returns the setting of the Closed Loop target window.

## Syntax:

[axis] **getclwindow**

|        | Range     |
|--------|-----------|
| [axis] | -1, 1,2,3 |

## Reply:

+/- [value]

|         | Range | Unit |
|---------|-------|------|
| [value] |       | user |

## Example:

**1 getclwindow**

Reply:  
0.001

**-1 getclwindow**

Reply:  
0.001 0.002 0.000

# setref

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **setref** defines if the encoder reference mark is identified at the rising or falling edge.



## Syntax:

[index] [axis] **setref**

|         | Range   |
|---------|---------|
| [index] | 0, 1, 2 |
| [axis]  | 1, 2, 3 |

| [value] | Description  |
|---------|--------------|
| 0       | rising edge  |
| 1       | falling edge |
| 2       | disabled     |

## Related commands:

**getref / getrefst, setrefvel**

## Example:

**0 1 setref**

The encoder interface identifies the reference mark at the rising edge of the reference signal.

# **getref**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getref** returns the setting of **setref**.

## Syntax:

[axis] **getref**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[index]

|         | Range   |
|---------|---------|
| [index] | 0, 1, 2 |

## Example:

**1 getref**

## Description:

Command **refmove** moves all active axes to the reference mark of the measurement system.

The reference move velocity is adjusted with command **setrefvel**.

If no reference mark is found, the move stops until the specified distance is reached. The status of a reference move is returned with command **getrefst**.

With *Ctrl-C* the reference move will be aborted.

To move only a single axis to the reference mark, the other axes must be adequately configured with command **setref** or disabled with command **setaxis**.

The command is only functional if the following settings are made for all axes.

- **setloop = 1**
- **setaxis = 1**
- **setref = 0 or 1**



While a refmove is performed, the command interpreter of the controller is blocked.

Received commands are stored in the command FIFO but not executed until the refmove is finished.

---

## Syntax:

[direction] [distance] **refmove**

|             | Range   | Unit |
|-------------|---------|------|
| [direction] | +/-     |      |
| [distance]  | +/-1000 | rev. |

## Related commands:

**setref, setrefvel, getrefst**

## Examples:

**100 refmove**

The controller moves all active axes in positive direction.

If the reference mark is found, the controller stops with the defined acceleration (command **sa**).

If no reference mark is found, the axes are moving exactly 100 revolutions before they stop.

**-7 refmove**

With this command the controller moves all active axes in negative direction, to find the zero reference mark.

# getrefst

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getrefst** returns the status of the refmove procedure (command **refmove**).

The following operating states are coded in the binary representation of the returned decimal value.

## Syntax:

[axis] **getrefst**


|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[decimal value]

| [decimal value] |
|-----------------|
| 0, 1, 3, 4, 5   |

|   | Description                                   |
|---|---|
| 0 | Reference mark found, active signal input     |
| 1 | Reference mark not found                      |
| 3 | Reference mark not found, limit switch active |
| 4 | Reference mark found, zero signal input       |
| 5 | Reference not found, zero signal input        |



### Example:

#### **2 getrefst**

Returns the status of the refmove procedure of Axis-2

---

## **Trigger Output functions**

---



# setloop

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **setloop** enables the Closed Loop mode.

This feature requires an external measurement system, the controller must be equipped with an analog or digital encoder interface

**Option**



The On-Board digital encoder interface must be enabled with a release code.

**Option**



The analog encoder interface is a hardware module, that must be installed from the factory or service personal.

For proper Closed Loop configuration see also the following commands:

**setscaletype, setscaleinterface, setclperiod,  
setclpara, setnselpos**

## Syntax:

[index] [axis] **setloop**

|         | Range   |
|---------|---------|
| [index] | 0, 1    |
| [axis]  | 1, 2, 3 |

| [index] | Description          |
|---------|----------------------|
| 0       | Closed Loop disabled |
| 1       | Closed Loop enabled  |

---

**Related command:**

*getloop*

**Example:**

**1 2 setloop**  
**0 3 setloop**

Axis-1 Closed Loop mode enabled  
Axis-3 closed-loop mode disabled

# **getloop**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getloop** returns the Closed Loop status of the controller.

## Syntax

[axis] **getloop**

|        | Range       |
|--------|-------------|
| [axis] | -1, 1, 2, 3 |

## Reply:

[index]

|         | Range |
|---------|-------|
| [index] | 0, 1  |

## Example:

**1 getloop**

Reply:

1



# outrig (ot)

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **ot** generates a trigger output pulse at a specified I/O interface output. If several **ot** commands are performed, they will be stored in a FIFO and executed one by one.

**Option**



To support function "position capture", the controller must be equipped with the feature "Digital Input/Output". Details, see in the hardware manual

## Syntax:

[time] [pol] [output] **ot**

|          | Description             |
|----------|-------------------------|
| [time]   | Trigger out pulse width |
| [pol]    | Trigger out polarity    |
| [output] | I/O-Interface output    |

|          | Range   | Unit            | Function                          |
|----------|---------|-----------------|-----------------------------------|
| [time]   | 1-1000  | ms<br>(integer) |                                   |
| [pol]    | 0, 1    |                 | 0 = active low<br>1 = active high |
| [output] | 1, 2, 3 |                 |                                   |

## Example:

**100 1 1 ot**

A 100ms active high trigger pulse is generated at digital output 1.



# **waitposot (wpot)**

Corvus T, Corvus eco,  
Corvus PCI

## Description:



Command **wpot** (**wait\_pos\_out\_trigger**) enables the position synchronized output function (PSO).  
The maximum output frequency is 2kHz.  
This means the smallest time between two triggers is 500µs.



With command **setotmode** the trigger output can be related to the actual or desired position.

Additionally it is possible to use the trigger as a source to store the actual position data in the position capture memory (see command **setpc**).

## Syntax:


[pos] [dir] [axis] [time] [pol out] [output] **wpot**

|           | Description                                   |
|-----------|---|
| [pos]     | Desired trigger output position               |
| [dir]     | Move direction where trigger out is enabled   |
| [axis]    | Specified axis                                |
| [time]    | Trigger output pulse width                    |
| [pol_out] | Trigger out polarity, active low, active high |
| [output]  | I/O Interface output                          |

|           | <b>Range</b> | <b>Unit</b> | <b>Function</b>                                  |
|-----------|--------------|-------------|--|
| [pos]     | +/-16383     | unit        |  |
| [dir]     | 0, 1         |             | 0 = negative direction<br>1 = positive direction |
| [axis]    | 1, 2, 3      |             | Controller axes                                  |
| [time]    | 0-1000       | ms          |  |
| [pol_out] | 0, 1         |             | 0 = active low<br>1 = active high                |
| [output]  | 1, 2, 3      |             | Equivalent I/O interface outputs                 |

**Example:**

**12.54 1 1 10 0 1 wpot**



# **waitpos (wp)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **wp** (**wait\_pos**) interrupts the execution of all following commands, until the specified axis reaches the desired coordinate.

With Ctrl-C the command is cleared.

## Syntax:

[pos] [dir] [axis] **wp**

|        | Description                                       |
|--------|---|
| [pos]  | desired coordinate                                |
| [dir]  | move direction from where the position is reached |
| [axis] | specified axis                                    |


|        | Range    | Unit | Function   |
|--------|----------|------|--|
| [pos]  | +/-16383 | unit | specified unit for the axis                      |
| [dir]  | 0, 1     |      | 0 = negative direction<br>1 = positive direction |
| [axis] | 1, 2, 3  |      | equivalent controller axes                       |

---

### Example:

axis unit = 2 (mm)

**12.54 1 1 wp**



Command sequence:

**100 10 m [SP] 12.54 1 1 wp [SP] getin [CRLF]**

With this sequence the axes are moving to the coordinates 100mm/10mm. If Axis-1 has reached position 12.54 mm, the controller executes command *getin* and returns the status of the digital inputs.

# **waittime (wt)**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **waittime** (`wait_time`) locks the command interpreter a specified time to disable the command execution.

While the interpreter is locked the controller is further on able to receive commands from the communication interface. These commands are executed if the interpreter gets unlocked.

The **wt** command does not interrupt the momentary executed command.

The **wt** command disables also the manual move.

## Syntax:

[`time_wait`] [`wait_unit`] **wt**


|                            | Description                               |
|----------------------------|---|
| [ <code>time_wait</code> ] | time frame that the interpreter is locked |
| [ <code>wait_unit</code> ] | time unit                                 |

|                            | Range | Function                  |
|----------------------------|-------|---------------------------|
| [ <code>time_wait</code> ] |       |                           |
| [ <code>wait_unit</code> ] | 0     | Ticks<br>(1 Tick = 250µs) |
|                            | 1     | seconds                   |

---

### Example:

**1000 1 wt**



Command sequence:

**1000 0 wt**  
**ge**

The **wt** command configures the controller to reply the **ge** command after 1000 ticks = 0.25s

**1 1 wt**  
**ge**

The **wt** command configures the controller to reply the **ge** command after 1s

# **waitintragot (witot)**

Corvus T, Corvus eco,  
Corvus PCI

## Description:

Command **witot** (wait\_in\_trigger out trigger) is a fast combination of the commands **waitintrag (wit)** and **outtrig (ot)**

See the description in the appropriate descriptions.

## Option



To support this function, the controller must be equipped with the feature "Digital Input/Output".

Details, see in the hardware manual

## Syntax:

[pol\_in] [input] [time] [pol\_out] [output] **witot**

|           | Description                   |
|-----------|-------------------------------|
| [pol_in]  | Trigger input polarity        |
| [input]   | I/O-interface input           |
| [time]    | Trigger output pulse width    |
| [pol_out] | Trigger output pulse polarity |
| [output]  | I/O-interface output          |


|           | Range   | Unit | Function                        |
|-----------|---------|------|---------------------------------|
| [pol_in]  | 0, 1    |      |                                 |
| [input]   | 1, 2, 3 |      | Equivalent I/O interface input  |
| [time]    | 1-1000  | ms   |                                 |
| [pol_out] | 0, 1    |      |                                 |
| [output]  | 1, 2, 3 |      | Equivalent I/O interface output |

---

**Example:**

0    1    10    1    1    **witot**

0    1    10    1    1    **witot**



# **waittimeot (wtot)**

Corvus T, Corvus eco,  
Corvus PCI

## Description:

**wtot** is fast combination of the commands **waittime (wt)** and **outrig (ot)**.

With command **wtot** (wait\_time out\_trigger) a delayed trigger output can be performed.

Details see command description **wt** and **ot**.

## Option



To support this function, the controller must be equipped with the feature "Digital Input/Output".

Details, see in the hardware manual

## Syntax:

[time\_wait] [wait\_unit] [time\_trigger] [pol\_out] [output] **wtot**

|                | Description             |
|----------------|-------------------------|
| [time_wait]    | waiting time            |
| [wait_unit]    | wait time unit          |
| [time_trigger] | trigger pulse width     |
| [pol_out]      | trigger output polarity |
| [output]       | I/O-interface output    |


|                | Range                     | Unit      | Function  |
|----------------|---------------------------|-----------|---|
| [time_wait]    | integer value             | wait unit |   |
| [wait_unit]    | 0, 1                      |           | 0 = ticks<br>(250µs each tick)<br>1 = seconds (s) |
| [time_trigger] | 1-1000<br>(integer value) | ms        |   |
| [pol_out]      | 0, 1                      |           |   |
| [output]       | 1, 2, 3                   |           |   |

---

**Example:**

1000 1 10 0 1 wtot

1000 1 10 0 1 wtot



# **setrptdata**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.5.0

## Description:

Command **setrptdata** initializes the Position-Interval-Triggering.

With this function the controller is able to generate output triggers in a regular frequency.

The trigger positions relate selectively to the desired position or the current (measured) position.

## Option




For this function the controller has to be equipped with the Digital Input/Output function.

## Syntax:

[rpos] [axis] [time] [pol] [output] [selpos] **setrptdata** [*crlf*]

1.234 1 100 1 0 1 setrptdata



|          | <b>Description</b>                             |
|----------|--|
| [rpos]   | Trigger distance (unit defined with setunit)   |
| [axis]   | The Triggers relate to this axis               |
| [time]   | Trigger pulse width                            |
| [pol]    | Polarity of the trigger signal                 |
| [output] | Number of Digital Output                       |
| [selpos] | Trigger relates to current or desired position |

|          | <b>Range</b> | <b>Unit</b> | <b>Function</b>                              |
|----------|--------------|-------------|--|
| [rpos]   | +/-16383mm   | user unit   |  |
| [axis]   | 1, 2, 3      |             |  |
| [time]   | 0,25-16383   | ms          |  |
| [pol]    | 0, 1         |             | 0 = active low<br>1 = active high            |
| [output] | 1, 2, 3      |             |  |
| [selpos] | 0, 1         |             | 0 = desired position<br>1 = current position |

### Example:

**1.234 2 100 1 2 0 setrptdata**

The Position-Interval-Triggering is initialized as follows:

Trigger distance 1.234 units (i.e. mm, µm)

Related axis for triggering is Axis-2

Trigger pulse width = 100ms

Trigger comes at Digital Output-2

The trigger position relates to the desired position

Complete command sequence to generate triggers at equidistant coordinates.

**1.234 2 100 1 2 0 setrptdata**

**0 10 startrpt**

**20 20 m**

# **getrptdata**

## **Description:**

Command **getrptdata** returns the configuration of the Position-Interval-Trigger.

## **Syntax:**

**getrptdata**

Reply:

[rpos] [axis] [time] [pol] [output] [selpos]

|          | <b>Description</b>                             |
|----------|--|
| [rpos]   | Trigger distance (unit defined with setunit)   |
| [axis]   | The Triggers relate to this axis               |
| [time]   | Trigger pulse width                            |
| [pol]    | Polarity of the trigger signal                 |
| [output] | Number of Digital Output                       |
| [selpos] | Trigger relates to current or desired position |

## **Example:**

**getrptdata**

Reply:

**1.234 2 100 1 2 0**



# **startrpt**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.5.0

## Description:

Command **startrpt** enables the Position-Interval-Trigger. Additionally the absolute coordinate is determined where the Trigger starts or stops. If the stop coordinate is reached, the Position-Interval-Trigger is disabled. To execute further triggers, the **startrpt** command must be performed again with new coordinates.

## Option



Option "Digital Input/Output" must be released to use this function.

## Syntax:

[Start] [Stop] **startrpt** [*crif*]

|         | Description                         |
|---------|-------------------------------------|
| [Start] | coordinate where the trigger starts |
| [Stop]  | coordinate where the trigger stops  |

|         | Range      | Unit |
|---------|------------|------|
| [Start] | +/-16383mm | user |
| [Stop]  | +/-16383mm | user |

## related commands:

**setrptdata, getrptdata, setotmode**

---

## Examples:

**10.234 12.56 startrpt**

The trigger starts at coordinate 10.234 and stops at coordinate 12.56

### Complete command sequence example:

Settings

Output: DOUT-1,

Trigger interval: 10µm

Trigger pulse width: 0.5ms

Related axis: Axis-2

Related position: Nominal

**0.010 2 0.5 0 1 0 setrptdata**

**12.234 15.23 startrpt**

**4.5 16.0 move**

---

---

# **Trigger-Input functions**

---



# setotmode

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.5.0

## Description:



Command **setotmode** has two tasks:

1. It assigns the trigger input of the *wpot* command to the calculated position or the measured position.
2. Determines the output trigger as a trigger source to log position data (see command *setpc*).

## Syntax:

[mode] **setotmode**

| [mode] | Trigger position | Data logging |
|--------|------------------|--------------|
| 0      | calculated       | off          |
| 1      | measured *       | off          |
| 2      | measured *       | on           |
| 3      | calculated       | on           |

\* The controller must be equipped with the Closed Loop option

## Example:

**3 setotmode**

# **getotmode**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getotmode** returns settings made with command *setotmode*.

## Syntax:

**getotmode**

Reply:

[mode]

|        | Range      |
|--------|------------|
| [mode] | 0, 1, 2, 3 |

| [mode] | Trigger source      | Position capture |
|--------|---------------------|------------------|
| 0      | calculated position | off              |
| 1      | measured position   | off              |
| 2      | measured position   | on               |
| 3      | calculated position | on               |

## Example:

**getotmode**

# setpcin

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **setpcin** initializes the trigger input for the "position capture" function.



## Option



To support function "position capture", the controller must be equipped with the feature "Digital Input/Output".

Details, see in the hardware manual

## Syntax:

[edge] [input] **setpcin**

| [edge] | Description                            |
|--------|--|
| 0      | data are latched with the rising edge  |
| 1      | data are latched with the falling edge |

| [input] | Description         |
|---------|---------------------|
| 1       | Input DIN 1 (Pin 6) |
| 2       | Input DIN 2 (Pin 2) |
| 3       | Input DIN 3 (Pin 7) |

## Example:

**1 3 setpcin**

To use the function "position capture", input 3 is determined as trigger input. The data will be latched into the "capture memory" with the rising edge of the trigger signal.

# **getpcin**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.2.0

## Description:

The command **getpcin** returns the settings for the function "position capture".

## Syntax:

**getpcin**

Reply:

[edge] [input]

|         | Range   |
|---------|---------|
| [edge]  | 0,1     |
| [input] | 1, 2, 3 |

## Example:

**getpcin**

Reply: 1 3

# setpc

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.2.0

## Description:



The command **setpc** enables or disables the function "position capture". This function stores the actual position data, triggered from an user input signal or internal output signal (see command **setotmode**).

With command **setnselpos** it is determined if the internal calculated position is stored (nominal position) or the actual position, replied from a measurement system.



|

Command **setpc** must be executed again, if the setting of **setnselpos** was changed.

## Syntax:

[On/Off] **setpc**

| [On/Off] | Description          |
|----------|----------------------|
| 0        | position capture Off |
| 1        | position capture On  |

## Example:

**1 setpc**

# getpc

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getpc** returns the status of the function "position capture", additionally the trigger counter is displayed.



If the selected input is triggered, a data record is stored, containing the position of all active axes, as well as the internal time, called ticks.

The stored records are indicated with the counter value of the trigger counter and can be recalled with this index number.

Overall 65000 records can be indicated.

The "capture memory" has a free memory space to store 1000 data records.

If more than 1000 records are captured, the data memory will be overwritten.

## Syntax:

**getpc**

Reply:

[trigger counter] [status]

|                   | Range                 |
|-------------------|-----------------------|
| [trigger counter] | 0-65000               |
| [status]          | 0,1<br>0 = On, 1 =Off |

## Example:

**getpc**

Reply: 1204 1

The function "position capture" is active.

The trigger counter displays 1204 counts. That means the first 204 counts from the data memory are overwritten.

# **waitintrag (wit)**

Corvus T, Corvus eco,  
Corvus PCI

## Description:

Command **wit** (wait\_in\_trigger) configures the controller to interrupt the command interpreter until a specified input signal is active (level triggered).

- The **wit** setting is cleared after the command interpreter is released.
- The command does not interrupt the momentary executed commands.
- The **wit** command always awaits the end of a momentary move command, it has no influence to the manual move.
- With **Ctrl-C** the command is aborted.

## Option



To support this function the controller must be equipped with the feature "Digital Input/Output".  
Details, see in the hardware manual

## Syntax:


[pol\_in] [input] **wit**

|          | Description                   |
|----------|-------------------------------|
| [pol_in] | operate signal input polarity |
| [input]  | I/O-interface input           |

|          | Range   | Function                          |
|----------|---------|-----------------------------------|
| [pol_in] | 0, 1    | 0 = active low<br>1 = active high |
| [input]  | 1, 2, 3 | I/O interface input               |

---

## Example:



Command sequence for example:

**0 1 wit st**

With active low level at digital input-1 the interpreter is locked.  
Venus-1 command **ge** is not executed.  
If the signal level changes to high level, the command **st** will  
be executed and the **wit** setting is removed.

# **getpcdata (gpd)**

Corvus TT, Corvus eco,  
Corvus PCI

## Description:

The command **getpcdata** reads the "position capture data" that are recorded in the "capture memory".

### Details about the function "position capture"

With each trigger input, a data record is stored. Each record contains the position of all active axes, as well as the controller time, called ticks.

Each record uses one memory cell in the "capture memory". The stored records are indicated with the counter value of the trigger counter and can be recalled with this index number, assumed it is not overwritten. Overall 65000 records can be indicated.

The "capture memory" has space for 1000 data records.



The minimum time resolution (tick) is 250 µs, maximum trigger input frequency is 2 kHz.

The trigger input is polled with the controller cycle time of 250 µs or 4 kHz.

## Syntax:

[index record A] [index record B] **getpcdata**

|                  | <b>range</b> |
|------------------|--------------|
| [index record A] | 1-65000      |
| [index record B] | 1-65000      |

Value A<B.

Reply:

[Tick] [Pos. Axis-1] [Pos. Axis-2] [Pos. Axis-3]

|                                   | <b>Range of value</b>   |
|-----------------------------------|---|
| [Tick]                            | 1 Tick = 250 µs<br>Maximum time value after power up is reached in 298 hours. |
| [Pos. Axis-1] until [Pos. Axis-3] | Format depends on the settings of setunit, setdim and setselpos               |

### Example:

#### **3450 3460 getpcdata**

Data records with index 3450 until 3460 are recalled.

| time            | Pos. Axis-1 | Pos. Axis-2 | Pos. Axis-3 |
|-----------------|-------------|-------------|-------------|
| ↓               | ↓           | ↓           | ↓           |
| 296149 9.749368 | 9.749368    | 9.749368    | 0.000000    |
| 296151 9.749868 | 9.749868    | 9.749868    | 0.000000    |
| 296153 9.750368 | 9.750368    | 9.750368    | 0.000000    |
| 296155 9.750868 | 9.750868    | 9.750868    | 0.000000    |
| 296157 9.751368 | 9.751368    | 9.751368    | 0.000000    |
| 296159 9.751868 | 9.751868    | 9.751868    | 0.000000    |
| 296161 9.752368 | 9.752368    | 9.752368    | 0.000000    |
| 296163 9.752868 | 9.752868    | 9.752868    | 0.000000    |
| 296165 9.753368 | 9.753368    | 9.753368    | 0.000000    |
| 296167 9.753868 | 9.753868    | 9.753868    | 0.000000    |

**The values based on the following settings:**

Velocity = 1mm/s,

Trigger frequency = 2 kHz, position unit = mm

296155 - 296153 = 2 Ticks =  $(2 \cdot 250 \mu\text{s}) = 500 \mu\text{s} = 2 \text{ kHz}$

9.750868 mm - 9.750368 mm = 0.5 µm

With an axis speed of 1mm/s and a trigger frequency of 2 kHz, position data with an interval of 0.5 µm are stored in the "capture memory".

---

# **clearpcdata (cpd)**

Corvus TT, Corvus eco,  
Corvus PCI

## Description:

The command **clearpcdata** (cpd) clears the "position capture memory" and the trigger counter.

## Syntax:

**clearpcdata**

or **cpd**

## Examples:

**cpd**



# **setintrigtimeout**

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 4.5.0.

## Description:



With command **sitto** a time-out period can be defined for command *waitintrag*.

If the trigger input is not valid within these time, the *waitintrag* command is executed.

With waiting time setting = 0 the time-out period is infinite.

## Syntax:

[time] **setintrigtimeout**

|          | Description           |
|----------|-----------------------|
| [time] * | waiting time [s]      |
| time = 0 | waiting time infinite |

|        | Range        |
|--------|--------------|
| [time] | 0.01 to 100s |

\*factory setting = 0

## Example:

**10 sitto**

Waiting time for trigger input is 10s.

# **getintrigtimeout**

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 4.5.0.

## Description:

Command **gitto** returns the time-out setting for the trigger input signal of command *waitintrag*.

## Syntax:

**gitto**

## Reply:

[time]

|        | Range             |
|--------|-------------------|
| [time] | 0<br>0.01 to 100s |

## Example:

**gitto**

---

## **Joystick / Handwheel**

---



# **setjoysticktype**

Corvus TT, Corvus eco,  
Corvus PCI

## **Description:**

With command **setjoysticktype** the controller is adjusted to the manual device, Joystick or Handwheel.



## **Syntax:**

[Index\*] **setjoysticktype**

\*factory setting = 3

|         | <b>Range</b> |
|---------|--------------|
| [Index] | 2, 3, 8      |

|   | <b>Description</b> |
|---|--------------------|
| 2 | analog Joystick    |
| 3 | analog Joystick    |
| 8 | Handwheel          |

## **Related command:**

**getjoysticktype**

## **Example:**

**8 setjoysticktype**

# **getjoysticktype**

Corvus TT, Corvus eco,  
Corvus PCI

## **Description:**

Command **getjoysticktype** returns the settings of **setjoysticktype**.

## **Syntax:**

**getjoysticktype**

## **Reply:**

[Index]

| Index | Description     |
|-------|-----------------|
| 2     | analog Joystick |
| 3     | analog Joystick |
| 8     | Handwheel       |

## **Example:**

**getjoysticktype**

# joystick (j)

Corvus TT

Corvus eco

Corvus PCI

## Description:



The command **joystick** enables or disables the manual mode.

The activity of this mode is indicated in status bit D1 and also displayed at the front panel of the controller.

## Special function in Joystick mode



After power up the zero setting of the joystick is checked. A tolerance of +/- 10% is acceptable.

With greater deviations the appropriate axis can not be enabled for the joystick mode.

## Syntax:

[index] **joystick**

|         | Range |
|---------|-------|
| [index] | 0, 1  |

|   | Function             |
|---|----------------------|
| 0 | Manual mode disabled |
| 1 | Manual mode enabled  |

## Related command:

**getjoystick** (valid from Firmware Version 4.50)

## Example:

**1 j**

Enables manual mode.

# **getjoystick (gj)**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 4.50

## Description:

Command **getjoystick** returns status of the manual mode.

The state of the manual mode is also reflected in the status reply, see command *status*.

## Syntax:

**getjoystick**

## Reply:

[value]

| value | Function             |
|-------|----------------------|
| 0     | manual mode disabled |
| 1     | manual mode enabled  |

## Example:

**getjoystick**

# **setjoyspeed (js)**

Corvus TT, Corvus eco,  
Corvus PCI

## Description:



The command **setjoyspeed** defines the maximum velocity for the manual mode for all axes.



The rotational motor speed of each axis depends on the relation between the settings of the manual speed and spindle pitch (command **setpitch**).

If an axis is configured with a low spindle pitch, the resulting rotational speed of the motor, with the given global manual speed setting, can exceed and bring the motor out of its operating range. This can cause the motor to stall.

In this cases it is recommended to configure the manual speed for each axis separately with the command **setjoyspeed**.

## Syntax:

[velocity] **setjoyspeed**

|            | Unit   |
|------------|--|
| [velocity] | units<br>(depends on the settings of<br>0-Axis, see command <b>setunit</b> ) |

|               | Range      |
|---------------|------------|
| min. velocity | 15.62 nm/s |
| max. velocity | 180 mm/s   |

## Related command:

**getjoyspeed**

## Example:

**20 setjoyspeed**

unit = mm

The joystick velocity of each axis is 20 mm/s

# ***getjoyspeed (js)***

Corvus TT, Corvus eco,  
Corvus PCI

## **Description:**

The command ***getjoyspeed*** returns the adjusted maximum global velocity for the manual move.

## **Syntax:**

***getjoyspeed***

## **Reply:**

[velocity]

|            | <b>Unit</b> |
|------------|-------------|
| [velocity] | unit 0-Axis |

## **Example:**

***getjoyspeed***

Reply:

***20.000000***

# ***setnjoyspeed (njs)***

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 3.7.3

## Description:



Command ***setnjoyspeed*** allows to define a individual maximum joystick speed for each axis.

The speed unit is depends on the unit of the 0-Axis, see command ***setunit***



The settings of ***setnjoyspeed*** are overwritten if command ***setjoyspeed*** is executed afterwards.

If an axis is configured with a low spindle pitch, the resulting rotational speed of the motor, with the given global manual speed setting, can exceed and bring the motor out of it's operating range. This can cause the motor to stall.

In this cases it is recommended to configure the manual speed for each axis separately with the command ***setnjoyspeed***.

## Syntax:

[velocity] [axis] ***setnjoyspeed***

|            | Unit                       |
|------------|----------------------------|
| [velocity] | units (see 0-Axis setting) |

|        | Range   |
|--------|---------|
| [axis] | 1, 2, 3 |

## Related command:

***getnjoyspeed***

## Example:

***20 1 setnjoyspeed***

The maximum joystick velocity of Axis-1 is 20 mm/s

# ***getnjoyspeed (njs)***

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 3.7.3

## **Description:**

The command ***getnjoyspeed*** reads the settings of the adjusted axis specific manual speed.

## **Syntax:**

[axis] ***getnjoyspeed***

|        | <b>Range</b> |
|--------|--------------|
| [axis] | 1, 2, 3      |

## **Reply:**

[velocity]

|            | <b>Unit</b>        |
|------------|--------------------|
| [velocity] | unit of the 0-Axis |

## **Example:**

***1 getnjoyspeed***

Reply:

***20.000000***

# ***setjoybspeed***

Corvus TT, Corvus eco,  
Corvus PCI

## Description:



With command ***setjoybspeed*** a second velocity for the manual device can be defined. This velocity gets active by pressing the switch at the Joystick or Handwheel.

## Syntax:

[velocity] ***setjoybspeed***

|            | <b>Unit</b>    |
|------------|----------------|
| [velocity] | unit of 0-Axis |

|               | <b>Range</b>     |
|---------------|------------------|
| min. velocity | 15.62 nm/s       |
| max. velocity | 60 rev/s x pitch |

## Related command:

***getjoybspeed***

## Example:

***0.01 setjoybspeed***

unit = mm

As long as the joystick button is pressed, the maximum joystick velocity is 0.01 mm/s.

# ***getjoybspeed***

Corvus TT, Corvus eco,  
Corvus PCI

## **Description:**

The command ***getjoybspeed*** reads the secondary velocity of the manual device.

## **Syntax:**

***getjoybspeed***

## **Reply:**

[velocity]

|            | <b>Unit</b> |
|------------|-------------|
| [velocity] | unit 0-Axis |

## **Example:**

***getjoybspeed***

Reply:

0.010000

# **setjoyassign**

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 4.40

## Description:



With command **setjoyassign** the moving direction, generated from the Joystick and the assignment of the Joystick axes can be changed.

## Syntax:

[assignment] [motor axis] **setjoyassign**

|              | Range    |
|--------------|----------|
| [assignment] | -3 to +3 |
| [motor axis] | 1, 2, 3  |

| [assignment] | Direction         | Joystick axis |
|--------------|-------------------|---------------|
| 0            | Joystick disabled | -             |
| 1            | positive          | X-Axis        |
| 2            | positive          | Y-Axis        |
| 3            | positive          | Z-Axis        |

| [assignment] | Direction         | Joystick axis |
|--------------|-------------------|---------------|
| 0            | Joystick disabled | -             |
| -1           | negative          | X-Axis        |
| -2           | negative          | Y-Axis        |
| -3           | negative          | Z-Axis        |

Default settings:

**1 1 setjoyassign**  
**2 2 setjoyassign**  
**3 3 setjoyassign**

---

### Examples:

```
2 1 setjoyassign  
1 2 setjoyassign  
-3 3 setjoyassign
```

Motor axis-1 is moved with Joystick axis Y and motor axis-2 is moved with joystick axis X.

Motor axis-3 is moved with Joystick axis Z in a reversed direction

```
3 1 setjoyassign  
3 2 setjoyassign  
0 3 setjoyassign
```

Motor axis-1 and motor axis-2 are moved simultaneously with Joystick axis Z.

Motor axis-3 is disabled. The Joystick axis X and Y are without effect.

# **getjoyassign**

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 4.40

## Description:

The command **getjoyassign** returns the assignment of the axis and moving direction of the Joystick.

## Syntax

[motor axis] **getjoyassign**

|              | Range   |
|--------------|---------|
| [motor axis] | 1, 2, 3 |

## Reply:

[joystick axis]

|                 | Range                  |
|-----------------|------------------------|
| [joystick axis] | -3, -2, -1, 0, 1, 2, 3 |

## Example:

**1 getjoyassign**

Reply:

3



# setjoydiag

Corvus TT, Corvus eco,  
Corvus PCI

Valid from firmware version 4.41

## Description:



Command **setjoydiag** activates the Joystick diagnostic feature.

If the function is enabled, the output voltage of each Joystick axis is returned and displayed in the Terminal window.

The function is available only in the Terminal Mode (1 mode).

VENUS-1 (Corvus) Interpreter Version: 4.52 Copyright 2008 by ITK Dr.Kassen

X: -33.99527 0.016

Y:-171.51511 0.010

[Volt]

Command[ 0]: \_

## Syntax:

[switch] **setjoydiag**

|          | Range |
|----------|-------|
| [switch] | 0, 1  |

|   | Function                |
|---|-------------------------|
| 0 | Joystick diagnostic off |
| 1 | Joystick diagnostic on  |

## Example:

**1 mode**  
**1 setjoydiag**

The Terminal mode and the Joystick diagnosis feature will be enabled.

# ***getjoydiag***

Corvus TT, Corvus eco,  
Corvus PCI

## **Description:**

With command ***getjoydiag*** the Joystick diagnosis setting is returned.

## **Syntax**

***getjoydiag***

## **Reply:**

[switch]

|          | <b>range</b> |
|----------|--------------|
| [switch] | 0, 1         |

## **Example:**

***getjoydiag***

Reply:

0

# setwheel

Corvus TT

Corvus eco

Corvus PCI

## Description:



Command **getwheel** initialises the Handwheel mode.  
To activate the mode it is necessary to perform command **reset** after the **save** command  
The Handwheel is enabled with command **setjoystick**  
It is not possible to use Handwheel and Joystick mode simultaneously.

## Option



For Handwheel operation the Corvus hardware must be prepared in the factory.



The Handwheel occupies the digital encoder interface, therefore the Closed Loop mode is only functional with the analog encoder interface (sin/cos Module).

## Syntax:

[Index] **setwheel**

|         | Range |
|---------|-------|
| [Index] | 0, 1  |

| [Index] | Description              |
|---------|--------------------------|
| 0       | Encoderbetrieb (default) |
| 1       | Handradbetrieb           |

## Example:

**1 setwheel [cr] save [cr] reset [cr]**

Handwheel mode is initialized

# **getwheel**

Corvus TT

Corvus eco

Corvus PCI

## Description:

With command **getwheel** the Handwheel initializing is checked.

## Syntax

**getwheel**

## Reply:

[Status]

|         | Range |
|---------|-------|
| [Index] | 0, 1  |

| [Status] | Description                     |
|----------|---------------------------------|
| 0        | Default setting (Encoder mode ) |
| 1        | Handwheel is initialized        |

## Example:

**getwheel**

# **setwheelres**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **getwheelres** the controller is adapted to the number of electrical and mechanical pulses, the handwheel generates with one revolution (360°).

Factory settings: 100 pulses/rev.

## Syntax:

[pulses] [Axis] **setwheelres**

|          | Range   |
|----------|---------|
| [pulses] | 1-65535 |
| [Axis]   | 1, 2, 3 |

## Example:

**200 1 setwheelres**

# **getwheelres**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getwheelres** returns the expected pulses, generated from one handwheel revolution.

## Syntax

[Axis] **getwheelres**

## Reply:

[Pulses]

|          | Range       |
|----------|-------------|
| [Pulses] | 1.... 65535 |

## Example:

**1 getwheelres**

# **setwheelratio**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setwheelratio** the ratio between one handwheel resolution and total stroke is defined.  
Additionally the moving direction can be determined.

## Example:

**setwheelres = 100 pulses**

**setwheelratio = 1mm (total Stroke with one revolution)**

## Result:

Each handwheel pulse generates a stroke of  
1mm / 100 pulses = 0.01 mm



With the handwheel speed button it is possible to change the total stroke for one handwheel revolution to a predefined value.

This value is parameterized with command **setwheelbratio**.

## Syntax:

[Dir] [Stroke] [Axis] **setwheelratio**

|          | Range             | Unit |
|----------|-------------------|------|
| [Dir]    | Motion direction  | +/-  |
| [Stroke] | -32767...+32767mm | unit |
| [Axis]   | 1, 2, 3           |      |

## Example:

**-10 1 setwheelratio**

# **getwheelratio**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getwheelratio** returns the stroke that is generated with one handwheel revolution.

## Syntax

[Axis] **getwheelratio**

## Reply:

[Dir] [Stroke]

|          | Range              | Unit |
|----------|--------------------|------|
| [Stroke] | -32767mm...32767mm | unit |

## Example:

**1 getwheelratio**

# **setwheelratio**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setwheelratio** a second ratio between one handwheel resolution and total stroke is defined similar to command **setwheelratio**.

This setting is activated with the speed button at the handwheel.

Example:

**setwheelres = 100 pulses**

**setwheelratio = 1mm (fist total stroke)**

**setwheelbratio = 0.1mm (second total stroke)**

Result:

With the settings above, each handwheel revolution generates a stroke of 1mm or  $1/100 = 0.01$  mm with each pulse.

With the handwheel speed button, the resolution can be changed to the predefined value  $0.1\text{mm}/100 = 0.001\text{mm}$

## Syntax:

[Dir] [Stroke] [Axis] setwheelbratio

|          | Range             | Unit |
|----------|-------------------|------|
| [Dir]    | direction         | +/-  |
| [Stroke] | -32767...+32767mm | unit |
| [Axis]   | 1, 2, 3           |      |

## Example:

**0.1 1 setwheelbratio**

# **getwheelratio**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getwheelratio** returns the settings of setwheelratio.

## Syntax

[Axis] **getwheelratio**

## Reply:

[Dir] [Total Stroke generated with one handwheel revolution]

|          | Range             | Unit |
|----------|-------------------|------|
| [Dir]    | direction         | +/-  |
| [Stroke] | -32767...+32767mm | unit |

## Example:

**1 getwheelratio**

---

# **System commands**

---



# save

## Description:

The command **save** stores all active parameters in a non volatile memory. Always the last saved settings are restored after power on.

Parameters which can be saved are declared with following symbol.



Programmable moves are aborted if the **save** command is executed. Manual moves are only interrupted during time of saving.

The end of saving is indicated in Terminal Mode with the character **OK**

In Host Mode an automatic reply can be defined with the command sequence **save** and **status**.

Than the status information is replied after the **save** is finished.

## Syntax:

**save**

## Reply:

In Terminal Mode the characters **OK** are replied if the save is finished.

## Example:

**save**



# **restore**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **restore** reactivates the last saved parameters.

With the command sequence **restore save** the controller replies a status information after the restore is finished.

## Syntax:

**restore**

## Reply:

A reply can be enabled with the following command sequence

**restore**  
**status**

## Related command:

**getfpara**

## Example:

**restore**



# **getfpara**

Corvus TT

Corvus eco

Corvus PCI

## **Description:**

The command **getfpara** activates the factory configuration.



### Attention:

All current parameters are overwritten but can be restored with command *restore*.

## **Syntax:**

**getfpara**

## **Reply:**

The command execution reply can be controlled with the command sequence:

**getfpara  
status**

## **Example:**

**getfpara**



# **clear**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **clear** deletes the content of the parameter stack.

The related command **gsp**, returns the current number of parameters on the stack.

In a accurate operation the number of parameters on the stack will always go to zero if all commands are processed.

It indicates an inaccurate use of a Venus-2 command, (i.e. to many parameters, wrong syntax) if elements remain on the stack. In a worst case the stack will overflow if more than 99 elements are put on the stack and cause a malfunction of the controller



## Syntax:

**clear**

## Related command:

**gsp**

## Example:

**clear**



# **reset**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **reset** performs a device reset which is equal to disconnect the device from the power.

The proper state of the controller after a reset is indicated with beep (1s).

## Syntax:

**reset**

## Example:

**reset**



# beep

Corvus TT

-

-

## Description:

Command beep triggers the internal beeper that produces a 1 Khz sound.

The length of the beep sound can be determined.

Maximum beep length = 10s

## Syntax:

*[beep length ] beep*

|               | Range    | Unit |
|---------------|----------|------|
| [beep length] | 1-10,000 | ms   |

## Example:

**1000 beep**



# **version**

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **version** returns the version of the controller firmware.

## Syntax:

***version***

## Reply:

[Version number]

## Related command:

***identify***

## Example:

***version***

Reply:

4.5.5.



# **getmacadr**

Corvus TT

-

-

## Description:

Command **getmacadr** returns the Ethernet MAC Address.

## Syntax:

**getmacadr**

## Reply

[Mac-Address]

## Example:

**getmacadr**

Reply in Terminal Mode:

Ethernet MAC address: 00:50:C2:10:91:91

Reply in Host Mode:

00:50:C2:10:91:91



# ***identify***

Corvus TT

-

-

## Description:

Command ***identify*** returns the controller hardware and software revision revision.


Additionally the rear Dip-Switch setting is returned.

## Syntax:

***identify***

## Reply:

[Model] [HW-Rev] [SW-Rev] [Board-Sw] [Dip-Sw]

|            | <b>Description</b>  |
|------------|---|
| [Model]    | Model type  |
| [HW-Rev]   | Hardware revision   |
| [SW-Rev]   | Software revision   |
| [Board-Sw] | Internal use  |
| [Dip-Sw]   | Dip-Switch settings<br>The returned value is hex coded.<br><br> |

## Related command:

***version***

## Example:

***identify***

Reply: Corvus 1 312 1 10F



# **getoptions**

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command **getoptions** returns a decimal number that indicates the released options.

Each option is assigned to a binary digit from D0 to D9. If more options are released, the decimal values of the digits are added.

To get each released option separately, it is necessary to convert the decimal value into a binary value and mask the bit pattern.

## Syntax:

**getoptions**

## Reply:

[value]

|                | range   |
|----------------|---------|
| <b>[value]</b> | 0 - 975 |

| Bit | decimal | released option              |
|-----|---------|------------------------------|
| D0  | 1       | Axis-3 enabled               |
| D1  | 2       | Ethernet TCP/IP Interface    |
| D2  | 4       | Closed Loop / all axis       |
| D3  | 8       | digital Inputs/ Outputs, 3/3 |
| D4  | 16      | not used                     |
| D5  | 32      | not used                     |
| D6  | 64      | Closed Loop Axis-1           |
| D7  | 128     | Closed Loop Axis-2           |
| D8  | 256     | Closed Loop Axis-3           |
| D9  | 512     | speed grade 60 U/s           |

---

**Example:**

*getoptions*

Reply: 9

Axis-3 is released

Digital Input/Output is released.

| <b>Bit</b>     | <b>decimal</b> | <b>released option</b>       |
|----------------|----------------|------------------------------|
| <b>D0</b>      | <b>1</b>       | Axis-3 enabled               |
| D1             | 2              | Ethernet TCP/IP Interface    |
| D2             | 4              | Closed Loop / all axis       |
| <b>D3</b>      | <b>8</b>       | digital Inputs/ Outputs, 3/3 |
| D4             | 16             | not used                     |
| D5             | 32             | not used                     |
| D6             | 64             | Closed Loop Axis-1           |
| D7             | 128            | Closed Loop Axis-2           |
| D8             | 256            | Closed Loop Axis-3           |
| D9             | 512            | speed grade 60 U/s           |
| <b>summary</b> | <b>9</b>       |                              |

# getserialno

Corvus TT

Corvus eco

Corvus PCI

## Description:

The command **getserialno** returns the serial number of the controller.

## Syntax:

**getserialno**

## Reply:

YY HW SERI

|        | Description        | Digits |
|--------|--------------------|--------|
| YY     | Year               | 2      |
| HW     | Hardware Revision  | 2      |
| SERIAL | Consecutive number | 4      |

## Related command:

*identify, version*

## Example:

**getserialno**

Reply:

01020105

Description:

Year: 2001

Hardwarerevision 02

Serialnumber: 0105



---

# **Position error correction**

---



# **setpcor**

Corvus TT

Corvus eco

Corvus PCI

## Description:



With command **setpcor** the "Positioning Error Correction" function is switched on or off.

## Syntax:

[function] [axis] **setpcor**

|            | Range   |
|------------|---------|
| [function] | 0, 1    |
| [axis]     | 1, 2, 3 |

| [function] | Description          |
|------------|----------------------|
| 0          | Error correction off |
| 1          | Error correction on  |

## Related command:

**getpcor**

## Example:

**0 1 setpcor**

Axis-1 Positioning Error Correction is switched off.

# **getpcor**

## **Description:**

Command **getpcor** returns the status of the Positioning Error Correction function.

## **Syntax:**

[axis] **getpcor**

|        | <b>Range</b> |
|--------|--------------|
| [axis] | 1, 2, 3      |

## **Reply:**

[0,1]

|     | <b>Function</b>                  |
|-----|----------------------------------|
| [0] | Positioning Error Correction off |
| [1] | Positioning Error Correction on  |

## **Example:**

**1 getpcor**

Returns the status of the Positioning Error Correction of Axis-1

## Description:

Command **setpdat** is used to enter the correction curve for the Positioning Error Correction function.



## A word about positioning accuracy

Corvus was specially developed to control stepper motors with a very high resolution.

This achieves smooth and precise positioning tasks.

However, it should be noted that a precise controlling of the stepper motor is not the solution to get also an accurate positioning system.

Positioning errors occur regardless of the controller, due to mechanical stiction, spindle pitch errors or load dependent positioning inaccuracies.

These disadvantages can be avoided with an additionally mounted measurement system. The controller therefore must work in Closed Loop mode. The gain of accuracy depends on the type of the measurement system.

Due to the costs or critical mechanical circumstances, it is not always possible to use a measurement system.

Alternative a cheap and effective method is to compensate mechanical errors from the controller directly in an open loop mode without the use of a measurement system.

The main principle of this method is to determine the error characteristics curve of a positioning system and store it into the controller. The controller then will calculate the positioning data according to this curve.

---

## Description of the Corvus Positioning Error Correction

The Corvus Error Correction function operates for each axis separately.

The error characteristics curve must be determined from the start point in equidistant nodes and transmitted in ascending order to the controller with command **setpdat**.

The distance between the nodes is fixed to 1mm.

During operation the position error at the nodes are 100% corrected. The error correction between the nodes are calculated from the controller with a linear interpolation.

With command **save** the correction values are stored in controller flash memory.

The Positioning Error Correction operates in manual and programmed mode with a travel range up to 499mm or 500 nodes.

## Syntax:

e<sub>0</sub>....e<sub>499</sub>] [start] [nodes] [axis] **setpdat**

|                                      | Description                                      | Range   | Unit |
|--------------------------------------|--|---|------|
| [e <sub>0</sub> ..e <sub>499</sub> ] | nodes<br>position errors<br>(in ascending order) | +/- 100   | µm   |
| [start]                              | start point                                      | 0-499<br>(integer)<br>[start] + [node]<br>≤ 499 | mm   |
| [nodes]                              | number of nodes                                  | 1-500   |      |
| [axis]                               | axis   | 1, 2, 3   |      |

## Related command:

**getpdat**

## Examples:

0.5 0.1 0.5 1.2 -0.5 1.2 0 6 1 setpdat  
0mm 1mm 2mm 3mm 4mm 5mm (nodes)

Axis-1 is corrected between 0 and 5mm.  
Six error values are transmitted to the controller.

0.3 0.5 0.9 1.5 -0.5 6 5 2 setpdat  
6mm 7mm 8mm 9mm 10mm

Axis-2 is corrected between 6 and 10 mm.  
Five error values are transmitted to the controller.

# **getpdat**

## Description:

Command **getpdat** returns the positioning error data at the nodes in a sequence of 10 subsequent values.  
With the command a start node is defined.

## Syntax:

[start node] [axis] **getpdat**

|              | Range   | Unit |
|--------------|---------|------|
| [start node] | 0-499   | mm   |
| [axis]       | 1, 2, 3 |      |

## Reply:

[E<sub>Start</sub> ... E<sub>Start+9</sub>]

|   | Range  | Unit |
|---|--------|------|
| E <sub>Start</sub> ... E <sub>Start+9</sub> | +/-100 | µm   |

## Example:

**12 1 getpdat**

Reply:

0.992 1.999 2.991 3.998 4.990 0.000 0.000  
0.000 0.000 0.900

12mm 13mm 14mm 15mm 16mm 17mm 18mm  
19mm 20mm 21mm

The command returns 10 error values from node 12 until node 21

# **setblc**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 3.66

## Description:



Command **setblc** enables or disables the backlash compensation.

With this function backlash errors caused by the reversal of travel direction are compensated.

## Syntax:

[Function] [Axis] **setblc**

| [Function] | Description           |
|------------|-----------------------|
| 0          | compensation disabled |
| 1          | compensation enabled  |

|            | Range   |
|------------|---------|
| [Function] | 0, 1    |
| [Axis]     | 1, 2, 3 |

## Related command:

**getblc, setblcd**

## Example:

**1 1 setblc**



# **getblc**

Corvus TT

Corvus eco

Corvus PCI

Valid from firmware version 3.66

## Description:

Command **getblc** returns the status of the function "backlash-compensation"

## Syntax:

[Axis] **getblc**

|        | Range   |
|--------|---------|
| [Axis] | 1, 2, 3 |

## Reply:

[0,1]

|     | Function              |
|-----|-----------------------|
| [0] | compensation disabled |
| [1] | compensation enabled  |

## Example:

**1 getblc**



# setblcd

Corvus TT

Corvus eco

Corvus PCI


Valid from firmware version 3.66

## Description:



Command **setblcd** allows to define the distance value that is compensated with the backlash function.

The compensation is always executed with an abrupt step at the start of a negative move.



## Syntax:

[Distance] [Axis] **setblcd**

|            | Description                         |
|------------|-------------------------------------|
| [Distance] | distance that has to be compensated |

|            | Range     |
|------------|-----------|
| [Distance] | 0 - 0.1mm |
| [Axis]     | 1, 2, 3   |

smallest value: 0.000001mm

## Example:

**0.001 1 setblcd**

# **getblcd**

Valid from firmware version 3.66

## Description:

Command **getblcd** replies the backlash distance value.

## Syntax:

[Axis] **getblcd**

|        | Range   |
|--------|---------|
| [Axis] | 1, 2, 3 |

## Reply:

[0.000000 - 0.1mm]

## Example:

**1 getblcd**

---

---

# **Corvus Macros**

---



---

## Corvus Makro FAQ



In the following description we use the German term makro because it is identical with the Venus-1 syntax.  
The equivalent name in the English language would be macro.

### What is a Corvus Makro:

A Makro in principal is a list of Venus-1 commands, that can be temporary stored and executed in the Corvus controller.

### Example of a Corvus Makro:

```
beginmakro
cal
0 setout
20 sv
1 0 setunit
1 1 setunit
1 2 setunit
2 3 setunit
10000 sa
200 0 1 ot
10000 sv
1 setpc
clearpcdata
1 1 setnselpos
1 2 setnselpos
3 setotmode
1000 1000 m
100.1234 1 1 200 1 2 wpot
10 10 gpd
getpc
endmakro
```

---

## Makro syntax

```
beginmakro [SP]  
[Venus-1 command] [SP]  
[Venus-1 command] [SP]  
[Venus-1 command] [SP]  
endmakro [CR LF]
```

[SP] = Space

[CR LF] = carriage return, line feed

### Example:

```
beginmakro  
0.01 1 1 0 2 1 setrptdata  
0 0.1 startrpt  
0.1 0 0 m  
0 0 0m  
endmakro
```

---

## **Why Makros:**

Makros are used to minimize the communication overhead to reduce CPU load and avoid communication time lag problems.

It is great benefit of the Corvus makro function that it relieves the application software to support high speed scanning applications. It also enhances the performance of the various Corvus trigger features.

## **How to create and execute Corvus Makros**

The Corvus Makro is a simple text file that is transmitted via the RS-232 or Ethernet interface into the Makro-Exe Buffer. After this, the Makro can be executed infinite times with a single start command.

Due to the control words *beginmakro* and *endmakro*. the Makro list is transferred automatically into the Makro-Exe Buffer.

While a Makro is executed, it is only possible to send a abort command via the communication interface, other commands are not possible.

---

## How many Venus-1 commands can be included in a Makro:

The size of a Makro is counted in symbols and not in Venus-1 command lines.

A Venus-1 command line can consist of one or several symbols.



**A maximum of 4000 symbols can be transferred to the Makro-Exe Buffer.**

For example the following Venus-1 command line requires three symbols: 100 100 move

### Examples:

*100<sub>1</sub> 100<sub>2</sub> move<sub>3</sub>*

This command line consist of three symbols.

*100<sub>1</sub> 100<sub>2</sub> 10<sub>3</sub> move<sub>4</sub>*

This command line consist of four symbols.

**st**

This command line consist of one symbol.

The following Makro consist of 13 symbols.

*beginmakro*

*2 setdim* 2 Symbols

*cal* 1 Symbol

*rm* 1 Symbol

*1 setout* 2 Symbol

*1000 beep* 2 Symbol

*0 0 move* 3 Symbol

*2000 beep* 2 Symbol

*endmakro*

---

## Is it possible to execute Makros in a Loop

The command ***startmakro*** can be called within a Makro, therefore it is possible to execute Makros in a endless loop.

### Example:

```
beginmakro
cal
0 setout
20 sv
100 sa
200 0 1 ot
50 50 0 m
10 1 1 200 1 2 wpot pos
20 1 1 200 1 2 wpot pos
30 1 1 200 1 2 wpot pos
40 1 1 200 1 2 wpot pos
50 1 1 200 1 2 wpot pos
ge
startmakro
endmakro
```

## Is it possible to execute a Makro automatically

Not available yet.

To execute commands automatically after power up, use Venus-1 command ***setpowerup***.

## Is it possible to store various Makros

Not available yet.

## Makro commands overview

For Makro controlling and makro administration

---

the following commands are provided.

***beginmakro***

Labels the start of a Makro.

***endmakro***

Labels the end of a Makro.

***startmakro***

Executes Makro in the Makro-Exe Buffer.

***listmakro***

Returns the number of symbols in the Makro-Exe Buffer.

***Ctrl-D***

Interrupts a Makro execution or Makro download.

---

# Macro functions

---



## ***beginmakro / endmakro***

Corvus TT, Corvus eco,  
Corvus PCI

### Description:

The command ***beginmakro*** and ***endmakro*** indicates the begin and the end of a Makro.

### Syntax:

***beginmakro / endmakro***

### Example:

```
beginmakro
cal
100 sa
200 0 1 ot gt
2 sv
100 0 0 m
10 1 1 200 0 2 wpot gt
20 1 1 200 0 2 wpot gt
30 1 1 200 0 2 wpot gt
40 1 1 200 0 2 wpot gt
50 1 1 200 0 2 wpot gt
60 1 1 200 0 2 wpot gt
70 1 1 200 0 2 wpot gt
80 1 1 200 0 2 wpot gt
90 1 1 200 0 2 wpot gt
ge
0 0 0 m
endmakro
```



# **startmakro**

Corvus TT

Corvus eco

Corvus PCI

## Description:

With command **startmakro** the Makro in the Makro-Exe Buffer is executed.

To execute a Makro in a endless loop, call **startmakro** within the Makro.

## Syntax:

**startmakro**

## Example:

**startmakro**



# ***listmakro***

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command ***listmakro*** returns the number of used Symbols in the Makro-Exe buffer.

A maximum of 4000 Symbols can be transferred into the buffer.

Error code 1201 indicates if more symbols are transferred.

## Syntax:

***listmakro***

## Example:

***listmakro***

Return:  
1204



# ***Ctrl-D***

Corvus TT

Corvus eco

Corvus PCI

## Description:

Command ***Ctrl-D*** interrupts a Makro execution or a Makro download.

## Syntax:

***Ctrl-D***

| ASCII sign | decimal value | hex value |
|------------|---------------|-----------|
| Ctrl-D     | 4             | 0x4       |

## Example:

***Ctrl-D***



---

# Venus-1 command overview



---

## Basic settings

**setpitch** ..... 29

Command **setpitch** adapts the controller to the transmission ratio of the drive train.

Example:**4.0009 1 setpitch**

**getpitch** ..... 31

The command **getpitch** returns the pitch setting of the axis.

Example:**2 getpitch -1 getpitch**

**setunit** ..... 33

With command **setunit** the physical units of the Axis-specific parameters are defined.

Example:**2 0 setunit**

**getunit** ..... 35

The command **getunit** returns the settings the physical units.

Example:**1 getunit -1 getunit**

**setumotmin** ..... 37

Command **setumotmin** determines the motor phase voltage at stand still and lower speeds.

Example:**2000 1 setumotmin**

**getumotmin** ..... 38

The command **getumotmin** returns the setting of umotmin.

Example:**1 getumotmin -1 getumotmin**

**setumotgrad** ..... 39

With command **setumotgrad** determines the motor voltage in the middle and upper speed range.

Example:**70 1 setumotgrad**

**getumotgrad** ..... 40

The command **getumotgrad** returns the setting of umotgrad.

Example:**1 getumotgrad -1 getumotgrad**

**setpolepairs** ..... 41

Command **setpolepairs** adapts the controller to the number of the stepper motor pole-pairs.

Example:**50 1 setpolepairs**

**getpolepairs** ..... 42

The command **getpolepairs** returns the configured number of pole-pairs.

---

|  |                     |                     |                     |  |
|--|---------------------|---------------------|---------------------|--|
| Example:1  | <b>getpolepairs</b> | -1                  | <b>getpolepairs</b> |  |
| <b>setaxis</b>   | .....               | 43                  |                     |  |
| Command <b>setaxis</b> enables or disables the specified axis for positioning tasks.   |                     |                     |                     |  |
| Example:1  | 3                   | <b>setaxis</b>      |                     |  |
| <b>getaxis</b>   | .....               | 45                  |                     |  |
| The command <b>getaxis</b> returns the setting of <b>setaxis</b> .   |                     |                     |                     |  |
| Example:2  | <b>getaxis</b>      | -1                  | <b>getaxis</b>      |  |
| <b>setpowerup</b>  | .....               | 47                  |                     |  |
| With command <b>setpowerup</b> it is possible to execute fixed commands automatically after power up.  |                     |                     |                     |  |
| Example:15   | <b>setpowerup</b>   |                     |                     |  |
| <b>getpowerup</b>  | .....               | 49                  |                     |  |
| Command <b>getpowerup</b> returns the Power up command settings of the controller.   |                     |                     |                     |  |
| Example:1  | <b>getpowerup</b>   |                     |                     |  |
| <b>setphaseares</b>  | .....               | 51                  |                     |  |
| With command <b>setphaseares</b> it is possible to reduce the resolution of the motor drivers in incremental steps.                                  |                     |                     |                     |  |
| Example:2  | 1                   | <b>setphaseares</b> |                     |  |
| <b>getphaseares</b>  | .....               | 52                  |                     |  |
| Command <b>getphaseares</b> returns the motor resolution value of the selected axis.   |                     |                     |                     |  |
| Example:2  | <b>getphaseares</b> |                     |                     |  |
| <b>setmotiondir</b>  | .....               | 53                  |                     |  |
| With command <b>setmotiondir</b> the factory assigned relationship between the direction of motor rotation and the motion direction can be reversed. |                     |                     |                     |  |
| Example:1  | 1                   | <b>setmotiondir</b> |                     |  |
| <b>getmotiondir</b>  | .....               | 55                  |                     |  |
| Command <b>getmotiondir</b> indicates, if the relationship between motor direction and motion direction differs from the factory settings.           |                     |                     |                     |  |
| Example:1  | <b>getmotiondir</b> |                     |                     |  |

## Communication

|  |       |    |  |  |
|--|-------|----|--|--|
| <b>mode</b>  | ..... | 59 |  |  |
| Command <b>mode</b> enables Terminal or Host Mode. |       |    |  |  |

---

---

Example:**1 mode**

**setipadr** ..... 61

With the command **setipadr** the controller Ethernet

Example:**192\_168\_128\_0\_setipadr**

**getipadr** ..... 62

The command **getipadr** returns the controller IP-Address.

Example:**getipadr**

## Velocity and acceleration

**setvel (sv)** ..... 65

Command **setvel** configures the programmed move velocity va.

**getvel (sv)** ..... 67

The command **getvel (gv)** returns the setting of **setvel**.

Example:**gv**

**setaccel (sa)** ..... 69

Command **setaccel (sa)** defines the acceleration ramp with which the controller executes the programmed move.

Example:**500 sa**

**getaccel (ga)** ..... 70

The command **getaccel (ga)** returns the setting of **setaccel**.

Example:**ga**

**setaccelfunc** ..... 71

The command **setaccelfunc** defines the acceleration function with which the positioning task is executed.

Example:**1 setaccelfunc**

**getaccelfunc** ..... 72

The command **getaccelfunc** returns the adjusted acceleration function.

Example:**getaccelfunc**

**setmanaccel** ..... 73

Command **setmanaccel** defines the acceleration ramp for the manual operation with Joystick or Handwheel.

Example:**100 setmanaccel**

**getmanaccel** ..... 74

The command **getmanaccel** returns the setting of **setmanaccel**.

---

Example:*getmanaccel*

**setcalvel** ..... 75

Command **setcalvel** defines two velocities for the cal limit-switch move. The setting is significant for all axes.

Example:*2 1 setcalvel*

**getcalvel** ..... 76

The command **getcalvel** returns the adjusted velocities for cal limit-switch move.

Example:*getcalvel*

**setncalvel** ..... 77

Command **setncalvel** defines the two velocities for the ncal limit-switch move.

Example:*2 1 2 setncalvel*

**getncalvel** ..... 78

The command **getncalvel** returns the ncal limit-switch move velocities.

Example:*2 getncalvel*

**setrmvel** ..... 79

The command **setrmvel** defines the two velocities for the rm limit-switch move. The setting is significant for all axes.

Example:*2 1 setrmvel*

**getrmvel** ..... 80

Command **getrmvel** returns the two adjusted **rm** move velocities.

Example:*getrmvel*

**setnrmvel** ..... 81

Command **setnrmvel** configures the two velocities for the **nrm limit switch** move.

Example:*2 1 1 setnrmvel*

**getnrmvel** ..... 82

Command **getnrmvel** returns the two adjusted **nrm** movement velocities.

Example:*2 getnrmvel*

**setrefvel** ..... 83

Command **setrefvel** defines the velocity with which the move to a reference mark is executed.

Example:*0.5 1 setrefvel*

**getrefvel** ..... 84

Command **getrefvel** returns the setting of **setrefvel**.

---

Example:**getrefvel**

## Positioning commands

**move (m)** ..... 87

Command **move** executes point to point positioning tasks to absolute coordinates based on the point of origin. The move profile is calculated in respect to the velocity/acceleration setup and the given hard or software limits.

Example:**12.5 20.0 0.0001 m**

**rmove (r)** ..... 89

Command **rmove** executes point to point positioning tasks relative to the current position.

Example:**0.5 20 0.0001 r**

**speed** ..... 91

Command **speed** starts a constant velocity move.

Example:**10 1 speed**

**stopspeed** ..... 93

Command **stopspeed** interrupts the constant velocity move of all axes with the adjusted acceleration.

See command **sa**.

Example: **stopspeed**

**test** ..... 95

Command **test** preforms a positioning test procedure.

Example:**10 1 test**

**randmove** ..... 97

Command **randmove** moves all active axes to randomized coordinates with a randomized velocity/acceleration setup.

Example:**randmove**

## Limit Switch functions

**calibrate (cal)** ..... 101

The command **cal** executes the limit-switch move to the cal limit-switches. All active axes are simultaneously moved in negative direction, until the cal-switches are in ON state.

Example:**cal**

**rangemeasure (rm)** ..... 103

The command **rm** executes the limit-switch move to the rm limit-switches. All active axes are simultaneously moved in positive direction, until the rm-

---

switches are in ON state.

Example:**rm**

**getcaldone** ..... 105

With command **getcaldone** it can be determined if the calibration moves to the limit-switch **cal** and **rm** are executed or not.

Example:**1 getcaldone**

**setsw** ..... 107

The command **setsw** adapts the specified limit-switch input to the connected switch type of the cal/rm-switch.

Example:**0 0 1 setsw**

**getsw** ..... 108

The command **getsw** returns the setting of the limit-switch inputs.

Example:**3 getsw -1 getsw**

**getswst** ..... 109

The command **getswst** returns the current activity of the limit-switch inputs.

Example:**3 getswst**

**setcalswdist** ..... 111

With command **setcalswdist** an additional distance out of the limit-switches can be defined.

Example:**5 1 setcalswdist**

**getcalswdist** ..... 112

Command **getcalswdist** returns the settings of **setcalswdist**.

Example:**1 getcalswdist -1 getcalswdist**

**setlimit** ..... 113

With command **setlimit** the software limits are defined for the axes.

Example:**0 0 0 12 25 30 setlimit**

**getlimit** ..... 115

Command **getlimit** returns the limit coordinates of all axes.

Example:**getlimit**

**nCAL** ..... 117

The command **nCAL** executes a single axis limit-switch move to the cal limit-switch. This procedure determines the origin and lower limit of the selected axis. The move procedure is similar to the function **cal**.

Example:**1 nCAL**

**NRM** ..... 119

---

---

The command ***nrm*** executes a single axis limit-switch movement to the rm limit-switch. This procedure determines the upper limit of the selected axis.  
Example:**1 nrm**

**getnlimit** ..... 121

The command ***getnlimit*** returns the current limits of a specified axes.

Example:**1 getnlimit**

**org** ..... 123

Command ***org*** a moves the specified axis a relative stroke until the org-switch is in ON state.

Example:**-10 1 org**

**setorg** ..... 125

The command ***setorg*** enables or disables the org-switch input.

Example:**1 1 setorg**

**getorg** ..... 126

Command ***getorg*** returns the org-input settings of the specified axis.

Example:**1 getorg**

**setorgsw** ..... 127

The command ***setorgsw*** adapts the specified org-switch input to the connected switch type.

Example:**0 1 setorgsw**

**getorgsw** ..... 128

The command ***getorgsw*** returns the setting of the org-switch inputs.

Example:**3 getsw**

**getorgswst** ..... 129

The command ***getorgswst*** returns the current activity of the org limit-switch input.

Example:**1 getorgswst**

## Safety functions

**Ctrl-C** ..... 133

Command ***Ctrl-C*** interrupts the current executed command. Moves will be stopped immediately with the acceleration setup, defined with command **sa**.

Example:**Ctrl-C**

---

|               |       |     |
|---------------|-------|-----|
| <b>Ctrl-B</b> | ..... | 135 |
|---------------|-------|-----|

With command **Ctrl+B** the motor current of all axes is

Example:**Ctrl-B**

|              |       |     |
|--------------|-------|-----|
| <b>abort</b> | ..... | 137 |
|--------------|-------|-----|

The command **abort** interrupts the current executed command. All moves will be stopped immediately with the acceleration setup, defined with command sa.

Example:**abort**

|                  |       |     |
|------------------|-------|-----|
| <b>setinfunc</b> | ..... | 139 |
|------------------|-------|-----|

Command **setinfunc** a safety function via the

Digital Input/Output interface can be established.

Example:**1 1 3 setinfunc**

|                  |       |     |
|------------------|-------|-----|
| <b>getinfunc</b> | ..... | 141 |
|------------------|-------|-----|

Command **getinfunc** returns the setting of **setinfunc**.

Example:**1 3 getinfunc**

|              |       |     |
|--------------|-------|-----|
| <b>setmp</b> | ..... | 143 |
|--------------|-------|-----|

With command **setmp** the motor current from a specified axis can be switched off completely. All other functions remain active.

Example:**0 1 setmp**

|              |       |     |
|--------------|-------|-----|
| <b>getmp</b> | ..... | 144 |
|--------------|-------|-----|

Command **getmp** returns the setting of **setmp**.

Example:**1 setmp -1 getmp**

## **position / origin / coordinate system**

|                |       |     |
|----------------|-------|-----|
| <b>pos (p)</b> | ..... | 147 |
|----------------|-------|-----|

Command **pos** return the current coordinate of all active axes.

Example:**pos**

|                    |       |     |
|--------------------|-------|-----|
| <b>setpdisplay</b> | ..... | 149 |
|--------------------|-------|-----|

Command **setpdisplay** the display format of the replied position value can be defined.

Example:**1 3 1 setpdisplay**

|                    |       |     |
|--------------------|-------|-----|
| <b>getpdisplay</b> | ..... | 150 |
|--------------------|-------|-----|

Command **getpdisplay** returns the setting of **setpdisplay**.

Example:**1 getpdisplay**

|               |       |     |
|---------------|-------|-----|
| <b>setpos</b> | ..... | 151 |
|---------------|-------|-----|

With command **setpos** the point of origin of all axes can be defined. The coordinates of the limits will be recalculated if the point origin changes.

Example:**0 0 0 setpos**

---

**align** ..... 153

Command **align** rotates the orthogonal coordinate system of Axis-1 and Axis-2 (X/Y) around it's origin. Axis-3 is not

Example:**0 0 10 10 1 align**

**ico** ..... 155

Command **ico** restores the original coordinate system of the controller.

Example:**ico**

**getico** ..... 157

The command **getico** verifies if the coordinate system is rotated with command **align**.

Example:**getico**

## Status requests

**status (st)** ..... 161

Command **status** returns the current state of the controller.

Example:**status**

**geterror (ge)** ..... 165

With the command **geterror** the last occurred system error is returned.

Afterwards the error code memory is cleared.

Example:**ge**

**getmerror (gme)** ..... 167

With the command **getmerror** the hardware errors from the machine error stack are returned.

Example:**gme**

**gsp** ..... 169

The command **gsp** returns the number of elements on the parameter stack.

Example:**gsp**

**getticks (gt)** ..... 171

Command **gt (get\_ticks)** returns the number of processor cycles, since the controllers was started.

Example:**gt**

## Input / Output functions

**setout** ..... 175

Command **setout** controls the digital outputs.

Example:**1 setout**

---

**getout .....** ..... 176

Command **getout** returns the state of the digital outputs as a decimal value.

Example:**getout**

**setaout .....** ..... 177

Command **setaout** generates an analog output voltage between 0 and 1000mV with 8 Bit resolution.

Example:**100 1 setaout**

**getaout .....** ..... 178

Command **getaout** returns the adjusted analog output voltage, generated with command **setaout**.

Example:**1 getaout**

**getin .....** ..... 179

The command **getin** returns the current status of the three digital Inputs Din-1, Din-2, Din-3 as a decimal value.

Example:**getin**

## Closed Loop commands

**setnselpos .....** ..... 183

Command **setnselpos** determines whether the internal calculated position value or the actual position value, from a measurement system, is returned.

Example:**0 3 setnselpos**

**getnselpos .....** ..... 185

The command **getnselpos** returns the settings of **setnselpos**.

**setclpara .....** ..... 187

Command **setclpara** configures the loop controller.

Example:**0\_15\_0\_16383\_0\_0\_1\_2\_2\_9\_3 setclpara**

**getclpara .....** ..... 190

Command **getclpara** return the settings of the loop controller.

Example:**1 getclpara**

**setsps .....** ..... 191

Command **setsps** defines the settings of the loop controller.

Example:**100 2 setsps**

**getsp .....** ..... 194

Command **getsp** returns the selected servo parameter (sp) of an axis.

Example:**1 getsp**

---

|  |     |
|--|-----|
| <b>setscaleinterface</b> .....   | 195 |
| Command <b>setscaleinterface</b> configures one of the both Closed Loop interfaces.  |     |
| Example: <b>2 1 setscaleinterface</b>  |     |
| <b>getscaleinterface</b> .....   | 196 |
| Command <b>getscaleinterface</b> verifies the type of the enabled encoder interface.   |     |
| Example: <b>1 getscaleinterface</b>  |     |
| <b>setscaletype</b> .....  | 197 |
| Command <b>setscaletype</b> adapts the encoder interface to the type of measurement system.  |     |
| Example: <b>1 1 setscaletype</b>   |     |
| <b>getscalatype</b> .....  | 198 |
| Command <b>getscalatype</b> verifies the type of measurement system that is configured for the encoder interface.  |     |
| Example: <b>1 getscaletype</b>   |     |
| <b>setclfactor</b> .....   | 199 |
| Command <b>setclfactor</b> adapts the digital encoder interface to the resolution of a digital rotational encoder. The value is equivalent to the number of pulses per revolution.   |     |
| Example:- <b>500 3 setclfactor</b>   |     |
| <b>getclfactor</b> .....   | 200 |
| Command <b>getclfactor</b> returns the setting of <b>setclfactor</b>   |     |
| Example: <b>1 getclfactor</b>  |     |
| <b>setclperiod</b> .....   | 201 |
| Command <b>setclperiod</b> adapts the analog or digital encoder interface to the following encoder types:  |     |
| Example:- <b>0.002 3 setclperiod</b>   |     |
| <b>getclperiod</b> .....   | 203 |
| Command <b>getclperiod</b> returns the setting of <b>setclperiod</b> .   |     |
| Example: <b>1 getclperiod</b>  |     |
| <b>setclwindow</b> .....   | 205 |
| Command <b>setclwindow</b> enables a +/- target window for the closed loop function. Within the target window the position control loop is not active. If the position is beyond the target window, the position control loop gets active. |     |
| Example: <b>0.001 1 setclwindow</b>  |     |

---

---

|  |                       |
|--|-----------------------|
| <b>getclwindow .....</b>   | <b>206</b>            |
| Command <b>getclwindow</b> returns the setting of the Closed Loop target window.                         |                       |
| Example: <b>1 getclwindow</b>  | <b>-1 getclwindow</b> |
| <b>setref .....</b>  | <b>207</b>            |
| Command <b>setref</b> defines if the encoder reference mark is identified at the rising or falling edge. |                       |
| Example: <b>0 1 setref</b>   |                       |
| <b>getref .....</b>  | <b>208</b>            |
| Command <b>getref</b> returns the setting of <b>setref</b> .   |                       |
| Example: <b>1 getref</b>   |                       |
| <b>refmove .....</b>   | <b>209</b>            |
| Command <b>refmove</b> moves all active axes to the reference mark of the measurement system.            |                       |
| Example: <b>100 refmove</b>  |                       |
| <b>getrefst .....</b>  | <b>211</b>            |
| Command <b>getrefst</b> returns the status of the refmove procedure (command <b>refmove</b> ).           |                       |
| Example: <b>2 getrefst</b>   |                       |

## Trigger Output functions

|   |            |
|---|------------|
| <b>setloop .....</b>  | <b>215</b> |
| Command <b>setloop</b> enables the Closed Loop mode.<br>This feature requires an external measurement system, the controller must be equipped with an analog or digital encoder interface |            |
| Example: <b>1 2 setloop</b>   |            |
| <b>getloop .....</b>  | <b>217</b> |
| Command <b>getloop</b> returns the Closed Loop status of the controller.  |            |
| Example: <b>1 getloop</b>   |            |
| <b>outtrig (ot) .....</b>   | <b>219</b> |
| Command <b>ot</b> generates a trigger output pulse at a specified I/O interface output. If several <b>ot</b> commands are performed, they will stored in a FIFO and executed one by one.  |            |
| Example: <b>100 1 1 ot</b>  |            |
| <b>waitposot (wpot) .....</b>   | <b>221</b> |
| Command <b>wpot (wait_pos_out_trigger)</b> enables the position synchronized output function (PSO).   |            |
| Example: <b>12.54 1 1 10 0 1 wpot</b>   |            |

---

|   |     |
|---|-----|
| <b>waitpos (wp)</b> .....   | 223 |
| Command <b>wp (wait_pos)</b> interrupts the execution of all following commands, until the specified axis reaches the desired coordinate. |     |
| <b>waittime (wt)</b> .....  | 225 |
| Command <b>waittime (wait_time)</b> locks the command interpreter a specified time to disable the command execution.                      |     |
| Example: <b>1000 0 wt</b>   |     |
| <b>waitintragot (witot)</b> .....   | 227 |
| Example: <b>0 1 10 1 1 witot</b>  |     |
| <b>waittimeot (wtot)</b> .....  | 229 |
| <b>wtot</b> is fast combination of the commands <b>waittime (wt)</b> and <b>outtrig (ot)</b> .  |     |
| Example: <b>1000 1 10 0 1 wtot</b>  |     |
| <b>setrptdata</b> .....   | 231 |
| Command <b>setrptdata</b> initializes the Position-Interval-Triggering.   |     |
| Example: <b>1.234 2 100 1 2 0 setrptdata</b>  |     |
| Example: <b>1.234 2 100 1 2 0 setrptdata</b>  |     |
| <b>getrptdata</b> .....   | 233 |
| Command <b>getrptdata</b> returns the configuration of the Position-Interval-Trigger.   |     |
| Example: <b>getrptdata</b>  |     |
| <b>startrpt</b> .....   | 235 |
| Command <b>startrpt</b> enables the Position-Interval-Trigger.  |     |
| Additionally the absolute coordinate is determined where the Trigger starts or stops.   |     |
| Example: <b>10.234 12.56 startrpt</b>   |     |

## Trigger-Input functions

|  |     |
|--|-----|
| <b>setotmode</b> .....   | 239 |
| Command <b>setotmode</b> has two tasks:  |     |
| 1. It assigns the trigger input of the wpot command to the calculated position or the measured position. |     |
| 2. Determines the output trigger as a trigger source to log position data (see command setpc).           |     |
| Example: <b>3 setotmode</b>  |     |
| <b>getotmode</b> .....   | 240 |
| Command <b>getotmode</b> returns settings made with  |     |

---

command setotmode.

Example:**getotmode**

**setpcin** ..... 241

The command **setpcin** initializes the trigger input for the "position capture" function.

Example:**1 3 setpcin**

**getpcin** ..... 242

The command **getpcin** returns the settings for the function "position capture".

Example:**getpcin**

**setpc** ..... 243

The command **setpc** enables or disables the function "position capture". This function stores the actual position

Example:**1 setpc**

**getpc** ..... 244

The command **getpc** returns the status of the function "position capture", additionally the trigger counter is displayed.

Example:**getpc**

**waitintrig (wit)** ..... 245

Command **wit (wait\_in\_trigger)** configures the controller to interrupt the command interpreter until a specified input signal is active (level triggered).

Example:**0 1 wit st**

**getpcdata (gpd)** ..... 247

The command **getpcdata** reads the "position capture data" that are recorded in the "capture memory".

Example:**3450 3460 getpcdata**

**clearpcdata (cpd)** ..... 249

The command **clearpcdata (cpd)** clears the "position capture memory" and the trigger counter.

Example:**cpd**

**setintragtimeout** ..... 251

With command **sitto** a time-out period can be defined for command waitintrag.

**getintragtimeout** ..... 252

Command **gitto** returns the time-out setting for the trigger input signal of command waitintrag.

Example:**gitto**

---

---

## Joystick / Handwheel

**setjoysticktype** ..... 255

With command **setjoysticktype** the controller is adjusted to the manual device, Joystick or Handwheel.

Example:**8 setjoysticktype**

**getjoysticktype** ..... 256

Command **getjoysticktype** returns the settings of **setjoysticktype**.

Example:**getjoysticktype**

**joystick (j)** ..... 257

The command **joystick** enables or disables the manual mode.

The activity of this mode is indicated in status bit D1 and

Example:**1 j**

**getjoystick (gj)** ..... 258

Command **getjoystick** returns status of the manual mode.

Example:**getjoystick**

**setjoyspeed (js)** ..... 259

The command **setjoyspeed** defines the maximum velocity for the manual mode for all axes.

Example:**20 setjoyspeed**

**getjoyspeed (js)** ..... 260

The command **getjoyspeed** returns the adjusted maximum global velocity for the manual move.

Example:**getjoyspeed**

**setnjoyspeed (njs)** ..... 261

Command **setnjoyspeed** allows to define a individual maximum joystick speed for each axis.

The speed unit is depends on the unit of the 0-Axis, see command **setunit**

Example:**20 1 setnjoyspeed**

**getnjoyspeed (njs)** ..... 262

The command **getnjoyspeed** reads the settings of the adjusted axis specific manual speed.

Example:**1 getnjoyspeed**

**setjoybspeed** ..... 263

With command **setjoybspeed** a second velocity for the manual device can be defined. This velocity gets active by pressing the switch at the Joystick or Handwheel.

---

Example:**0.01 setjoybspeed**

**getjoybspeed** ..... 264

The command **getnjoybspeed** reads the secondary velocity of the manual device.

Example:**getjoybspeed**

**setjoyassign** ..... 265

With command **setjoyassign** the moving direction, generated from the Joystick and the assignment of the Joystick axes can be changed.

Example:**2 1 setjoyassign**

**getjoyassign** ..... 267

The command getjoyassign returns the assignment of the axis and moving direction of the Joystick.

Example:**1 getjoyassign**

**setjoydiag** ..... 269

Command **setjoydiag** activates the Joystick diagnostic feature.

If the function is enabled, the output voltage of each Joystick axis is returned and displayed in the Terminal window.

Example:**1 setjoydiag**

**getjoydiag** ..... 270

With command **getjoydiag** the Joystick diagnosis setting is returned.

Example:**getjoydiag**

**setwheel** ..... 271

Command getwheel initialises the Handwheel mode.

Example:**1 setwheel [cr] save [cr] reset [cr]**

**getwheel** ..... 272

With command getwheel the Handwheel initializing is checked.

Example:**getwheel**

**setwheelres** ..... 273

With command getwheelres the controller is adapted to the number of electrical and mechanical pulses, the handwheel generates with one revolution (360°).

Example:**200 1 setwheelres**

**getwheelres** ..... 274

Command getwheelres returns the expected pulses,

Example:**getwheelres**

**setwheelratio** ..... 275

With command setwheelratio the ratio between one handwheel resolution

---

---

and total stroke is defined.

Example:**-10 1 setwheelratio**

**getwheelratio** ..... 276

Command getwheelratio returns the stroke that is generated with one handwheel revolution.

Example:**1 getwheelratio**

**setwheelratio** ..... 277

With command setwheelratio a second ratio between one handwheel resolution and total stroke is defined similar to command setwheelratio.

Example:**0.1 1 setwheelratio**

**getwheelratio** ..... 278

Command getwheelratio returns the settings of setwheelratio.

Example:**1 getwheelratio**

## System commands

**save** ..... 281

The command **save** stores all active parameters in a non volatile memory. Always the last saved settings are restored after power on.

Example:**save**

**restore** ..... 283

The command **restore** reactivates the last saved parameters.

Example:**restore**

**getfpara** ..... 285

The command **getfpara** activates the factory configuration.

Example:**getfpara**

**clear** ..... 287

The command **clear** deletes the content of the parameter stack.

Example:**clear**

**reset** ..... 289

The command **reset** performs a device reset which is equal to disconnect the device from the power.

Example:**reset**

**beep** ..... 291

Command **beep** triggers the internal beeper that produces a

Example:**1000 beep**

---

|                |       |            |
|----------------|-------|------------|
| <b>version</b> | ..... | <b>293</b> |
|----------------|-------|------------|

The command **version** returns the version of the controller firmware.

Example:**version**

|                   |       |            |
|-------------------|-------|------------|
| <b>getmacaddr</b> | ..... | <b>295</b> |
|-------------------|-------|------------|

Command **getmacaddr** returns the Ethernet MAC Address.

Example:**getmacaddr**

|                 |       |            |
|-----------------|-------|------------|
| <b>identify</b> | ..... | <b>297</b> |
|-----------------|-------|------------|

Command **identify** returns the controller hardware and software revision revision.

Example:**identify**

|                   |       |            |
|-------------------|-------|------------|
| <b>getoptions</b> | ..... | <b>299</b> |
|-------------------|-------|------------|

Command **getoptions** returns a decimal number that indicates the released options.

Example:**getoptions**

|                    |       |            |
|--------------------|-------|------------|
| <b>getserialno</b> | ..... | <b>301</b> |
|--------------------|-------|------------|

The command **getserialno** returns the serial number of the controller.

Example:**getserialno**

## Position error correction

|                |       |            |
|----------------|-------|------------|
| <b>setpcor</b> | ..... | <b>305</b> |
|----------------|-------|------------|

With command **setpcor** the "Positioning Error Correction" function is switched on or off.

Example:**0 1 setpcor**

|                |       |            |
|----------------|-------|------------|
| <b>getpcor</b> | ..... | <b>306</b> |
|----------------|-------|------------|

Example:**1 getpcor**

|                |       |            |
|----------------|-------|------------|
| <b>setpdat</b> | ..... | <b>307</b> |
|----------------|-------|------------|

Command **setpdat** is used to enter the correction curve for the Positioning Error Correction function.

Example:**0.5 0.1 0.5 1.2 -0.5 1.2 0 6 1 setpdat**

|                |       |            |
|----------------|-------|------------|
| <b>getpdat</b> | ..... | <b>310</b> |
|----------------|-------|------------|

Command **getpdat** returns the positioning error data at the nodes in a sequence of 10 subsequent values.

Example:**12 1 getpdat**

|               |       |            |
|---------------|-------|------------|
| <b>setblc</b> | ..... | <b>311</b> |
|---------------|-------|------------|

Command **setblc** enables or disables the backlash compensation.

Example:**1 1 setblc**

|               |       |            |
|---------------|-------|------------|
| <b>getblc</b> | ..... | <b>313</b> |
|---------------|-------|------------|

---

Command ***getplc*** returns the status of the function

"backlash-compensation"

Example:**1 getplc**

**setblcd** ..... 315

Command ***setblcd*** allows to define the distance value that is compensated with the backlash function.

Example:**0.001 1 setblcd**

**getblcd** ..... 316

Command ***getblcd*** replies the backlash distance value.

Example:**1 getblcd**

## Macro functions

**beginmakro / endmakro** ..... 327

The command ***beginmakro*** and ***endmakro*** indicates the begin and the end of a Makro.

**startmakro** ..... 329

With command ***startmakro*** the Makro in the Makro-Exe Buffer is executed.

Example:**startmakro**

**listmakro** ..... 331

Command ***listmakro*** returns the number of used Symbols in the Makro-Exe buffer.

Example:**listmakro**

**Ctrl-D** ..... 333

Command ***Ctrl-D*** interrupts a Makro execution or a Makro download.

Example:**Ctrl-D**

