



User Manual

E-872.401 DRIVER FOR PIEZO INERTIA DRIVES

MOTION | POSITIONING



Contents

1	Lega	Legal Information5			
2	Intro	duction		7	
	2.1	About th	nis Document	7	
		2.1.1	Objective and Target Group	7	
		2.1.2	Other Applicable Documents	7	
		2.1.3	Explanation of Symbols	7	
		2.1.4	Figures	9	
		2.1.5	Downloading Manuals	9	
	2.2	Europea	n Declarations of Conformity	9	
	2.3	Custome	er Service Department	9	
	2.4	Old Equ	ipment Disposal	10	
3	Safet	t y		. 11	
	3.1	Intendeo	d Use	. 11	
	3.2	General	Safety Instructions	11	
	3.3	Organiza	ational Measures	11	
		3.3.1	User Manual	. 11	
		3.3.2	General Personnel Qualification	. 11	
4	Prod	uct Descr	iption	. 12	
	4.1	Front Pa	nel	. 12	
	4.2	Type Pla	ite	. 13	
	4.3	Scope of	f Delivery	13	
	4.4	Accesso	ries	. 13	
	4.5 Communication Interfaces		. 14		
		4.5.1	Controlling PI Systems	. 14	
		4.5.2	E-872.401 Interfaces	. 15	
	4.6	Software	e Overview	. 16	
	4.7	Position	er database	. 18	
	4.8	Functior	nal Principles of the E-872.401	. 19	
		4.8.1	Block Diagram	. 19	
		4.8.2	Important Firmware Components	. 19	
		4.8.3	Commandable Items	. 21	
		4.8.4	Operating Modes	. 23	
		4.8.5	Switching Between the Drive Channels	.26	
		4.8.6	Triggering Motion	. 27	
		4.8.7	Travel Range and Soft Limits	. 30	
5	Unpa	acking / T	ransportation	.31	
	5.1	Unpacki	ng	. 31	
	5.2	Transpo	rtation	.31	
6	Insta	llation		. 32	
	6.1	Mountin	ng the E-872.401	. 32	



	6.2	Connecting the E-872.401 to the Protective Earth Conductor				
	6.3	Connec	ting the Power Supply to the E-872.401	33		
	6.4	Connec	ting the Positioner to the E-872.401	34		
	6.5	Installin	ng the PC Software	35		
		6.5.1	Installing the PC Software for the First Time	35		
		6.5.2	Updating the PC Software	36		
	6.6	Connec	ting the PC	41		
		6.6.1	Connecting the E-872.401 to a PC	41		
		6.6.2	Integrating the E-872.401 into a Network	42		
7	Start	tartup and Operation				
	7.1	Switchi	ng on the E-872.401	43		
	7.2	Establis	shing Communication with the PC	43		
		7.2.1	Establishing Communication via USB	43		
		7.2.2	Establishing Communication via TCP/IP	44		
	7.3	Starting	g Motion	47		
	7.4	Making	Data Backups	50		
		7.4.1	Saving Parameter Values	50		
		7.4.2	Saving Controller Macros	51		
8	F-872	2 401 Fun	actions	53		
U	8.1	Protecti	ive Functions of the F-872 401			
	••••	8.1.1	Protecting Against Overheating	53		
		8.1.2	Restoring Operational Readiness			
		8.1.3	Commands	53		
		8.1.4	Parameters	53		
	8.2	Digital I	Inputs and Outputs			
		8.2.1	Connecting the Digital Outputs	54		
		8.2.2	Connecting the Digital Inputs	54		
		8.2.3	Digital Output Signals	54		
		8.2.4	Digital Input Signals	54		
		8.2.5	Commands	56		
		8.2.6	Parameters	56		
	8.3	Analog	Input Signals			
		8.3.1	Connecting Analog Signal Sources	56		
		8.3.2	Commands	57		
		8.3.3	Parameters	57		
	8.4	Control	ling with HID			
		8.4.1	How it Works	57		
		8.4.2	HID Control Configuration	57		
		8.4.3	Programming HID Control	58		
		8.4.4	Connecting an HID	58		
		8.4.5	Testing the HID and Calibrating the Axes	58		
		8.4.6	Setting Up and Activating the HID Control	61		
		8.4.7	Commands	63		



12 13 14	11.2 Trouk 13.1 13.2 13.3 13.4 Appe 14.1	Updatin Dieshootin Dieshootin Dical Data Specifica Maximu Ambient Dimensi Dimensi Pin Assi 14.1.1 14.1.2 14.1.3 GCS Erre	g the Firmwareng	121 121 124 126 127 127 127 128 129 129 130 131 131
12 13 14	11.2 Trouk 13.1 13.2 13.3 13.4 Appe 14.1	Updatin Deshootin Specifica Maximu Ambient Dimensi Endix Pin Assi 14.1.1 14.1.2 14.1.3	g the Firmware ng ations m Ratings t Conditions and Classifications ons gnment Axis Connector I/O Connector Power Adapter Connector	121 121 124 126 126 127 127 127 128 129 129 130 131
12 13 14	11.2 Trout Techn 13.1 13.2 13.3 13.4 Appe 14.1	Updatin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin bleshootin blesho	g the Firmware ng ations m Ratings t Conditions and Classifications ons gnment Axis Connector I/O Connector	121 121 124 126 127 127 128 129 129 129 130
12 13 14	11.2 Trouk Techn 13.1 13.2 13.3 13.4 Appe 14.1	Updatin Dieshootin Dieshootin Dieshootin Dieshootin Dieshootin Dimensi Dimensi Pin Assi 14 1 1	g the Firmware ng ations m Ratings t Conditions and Classifications ons gnment Axis Connector	121 121 124 126 127 127 128 129 129 129
12 13 14	11.2 Trouk Techn 13.1 13.2 13.3 13.4 Appe 14.1	Updatin bleshootin bleshootin bical Data Specifica Maximu Ambient Dimensi cndix	g the Firmware ng ations m Ratings t Conditions and Classifications ons	121 121 124 126 126 127 127 128 129
12 13	11.2 Trout Techn 13.1 13.2 13.3 13.4 Approx	Updatin Dieshootin Dical Data Specifica Maximu Ambient Dimensi	g the Firmware ng ations m Ratings t Conditions and Classifications ons	121 121 124 126 127 127 128
12 13	11.2 Trout Techn 13.1 13.2 13.3 13.4	Updatin Dieshootin Dical Data Specifica Maximu Ambient	g the Firmware ng ations m Ratings t Conditions and Classifications	121 121 124 126 127 127 127
12 13	11.2 Trout Techn 13.1 13.2	Updatin bleshootin hical Data Specifica Maximu	g the Firmware ng ations m Ratings t Conditions and Classifications	121 121 124 126 127 127
12 13	11.2 Trout Techr 13.1	Updatin Dieshootin Dical Data Specifica	g the Firmware ng ations	121 121 124 126 126
12 13	11.2 Trout Techi	Updatin bleshootii nical Data	g the Firmware	121 121 124 126
12 12	11.2 Trout	Updatin Deshooti	g the Firmware	121 121 124
12	11.2 Trout	Updatin Dieshooti	g the Firmware	121 121 124
	11.2	Updatin	g the Firmware	121
		Olounnig	J	
	11.1	Cleaning	3	101
11	Main	tenance		121
10	Parar	rameter Reference		
9	Com	mand Ref	ference	81
		8.7.4	Creating or Changing Parameter Sets for Positioners	74
		8.7.3	Changing Parameter Values	72
		8.7.2	Saving Parameter Values in a Text File	71
		8.7.1	Parameter Commands	71
	8.7	Adapting	g Settings	71
		8.6.2	Variables	70
		8.6.1	GCS Command Syntax	69
	8.6	Working	with GCS Commands	69
		8.5.9	Parameters	69
		8.5.8	Commands	68
		8.5.7	Example Macros	67
		8.5.6	Saving and Loading Macros	66
		8.5.5	Deleting Macros	66
		8.5.4	Configuring a Startup Macro	66
		8.5.3	Stopping the Macros	66
		8.5.2	Running the Macro	65
		8.5.1	Recording Macros	64
		Controll	er Macros	03
	8.5	• • • •		62



1 Legal Information



The following trademarks are the intellectual property of Physik Instrumente (PI) SE & Co. KG ("PI") and have been entered in the trademark register of the German Patent and Trade Mark Office and, in some cases, also in other trademark registers under the company name of Physik Instrumente (PI) GmbH & Co. KG: PI°, PIC°, PICMA°, PILine°, PIFOC°, PiezoWalk°, NEXACT°, NEXLINE°, PInano°, NanoCube°, Picoactuator°, PicoCube°, PIMikroMove°, PIMag°, PIHera°

The software products provided by PI are subject to the General Software License Terms of Physik Instrumente (PI) SE & Co. KG and may contain and/or use third-party software components. Further information can be found in the <u>General Software License Terms</u> and in the <u>Third-Party Software Notes</u> on our website.

Notes on brand names and third-party trademarks: Microsoft® and Windows® are registered trademarks or trademarks of Microsoft Corporation in the USA and/or other countries. LabVIEW® is a trademark of National Instruments. Neither the driver software nor the software programs offered by PI or other goods and services are connected to or sponsored by National Instruments. Python® is a registered trademark of Python Software Foundation. The following designations are protected company names, trademarks or registered trademarks of other owners: Linux, MATLAB, MathWorks

© 2024 Physik Instrumente (PI) SE & Co. KG, Karlsruhe, Germany. The text, photographs, and drawings in this manual are protected by copyright. With regard thereto, Physik Instrumente (PI) SE & Co. KG reserves all rights. The use of any text, images and drawings is permitted only in part and only when indicating the source.

Original instructions First print: 12/6/2024 Document number: PZ279en, ASt

Subject to change. This manual is superseded by any new release. The latest respective release is available for download on our website (<u>www.pi.ws</u>).



Publisher:

Physik Instrumente (PI) SE & Co. KG Auf der Römerstraße 1 76228 Karlsruhe Germany info@pi.de www.pi.de

Customer service department:

Physik Instrumente (PI) SE & Co. KG Auf der Römerstraße 1 76228 Karlsruhe Germany

service@pi.de www.pi.de



2 Introduction

2.1 About this Document

2.1.1 Objective and Target Group

This user manual contains the information needed for the intended use of the E-872.401. Basic knowledge of closed-loop systems, motion control concepts, and applicable safety measures is assumed.

2.1.2 Other Applicable Documents

The devices and software tools that are mentioned in this documentation are described in separate manuals.

Document number	Document type	Product
SM148E	Software Manual	PIMikroMove
SM146E	Software Manual	GCS Array Data Format Description
SM151E	Software Manual	PI GCS 2.0 DLL
SM155E	Software Manual	PI MATLAB Driver GCS 2.0
SM164E	Software Manual	PIFirmwareManager for updating the firm- ware
A000T0028	User Manual	PIUpdateFinder: Updating PI Software

The latest versions of the user manuals can be downloaded (p. 9) at www.pi.ws.

2.1.3 Explanation of Symbols

This chapter explains the symbols and markings used by PI in their user manuals.



Symbol / label	Meaning
1. 2.	Action consisting of one or several steps with strict sequential order
•	Action consisting of one or more steps without relevant sequential or- der
-	Lists
p. 5	Cross-reference to page 5
RS-232	Label on the product indicating an operating element (example: RS-232 interface socket)
Start > Settings	Menu path in the PC software (example: to open the menu, <i>Start</i> and <i>Settings</i> must be clicked successively)
POS?	Command line or a command from PI's General Command Set (GCS) (example: command to get the axis position)
Device S/N	Parameter name (example: parameter where the serial number is stored)
5	Value that must be entered or selected via the PC software

Symbols Used

Symbol / Label	Meaning
	General hazard symbol
4	Electrical voltage

DANGER

Dangerous situation

Failure to comply could lead to death or serious injury.

Precautionary measures for avoiding the risk.

WARNING

Dangerous situation

Failure to comply could lead to serious injury.

Precautionary measures for avoiding the risk.

CAUTION

Dangerous situation

Failure to comply could lead to minor injury.

Precautionary measures for avoiding the risk.

NOTICE



Dangerous situation

Failure to comply could lead to material damage.

Precautionary measures for avoiding the risk.



Information

Additional information on the E-872.401 that can affect your application.

2.1.4 Figures

For better understandability, the colors, proportions and degree of detail in illustrations can deviate from the actual circumstances. Photographic illustrations may also differ and must not be seen as guaranteed properties.

2.1.5 Downloading Manuals

Information

If a manual is missing or problems occur with downloading:

Contact our <u>customer service department (p. 9)</u>.

Downloading Manuals

- 1. Open the website <u>www.pi.ws</u>.
- 2. Search the website for the product number (e.g., E-872).
- 3. In the search results, select the product to open the product detail page.
- 4. Select Downloads.
- → The manuals are shown under Documentation. Software manuals are shown under General Software Documentation.
- 5. For the desired manual, select *ADD TO LIST* and then *REQUEST*.
- 6. Fill out the request form and select SEND REQUEST.
- → The download link will be sent to the email address entered in the form.

2.2 European Declarations of Conformity

For the E-872.401, declarations of conformity were issued according to the following European statutory requirements:

- Low Voltage Directive
- EMC Directive
- RoHS Directive

The standards applied for certifying conformity are listed below.

- Safety (Low Voltage Directive): EN 61010-1
- EMC: EN 61326-1
- RoHS: EN IEC 63000

2.3 Customer Service Department

For enquiries and orders, contact your PI representative or send us an <u>email</u>.

If you have any questions concerning your system, provide the following information:

- Product and serial numbers of all products in the system
- Firmware version of the controller (if applicable)
- Version of the driver or the software (if applicable)
- Operating system on the PC (if applicable)

If possible: Take photographs or make videos of your system that can be sent to our customer service department if requested.



Customer service address:

Physik Instrumente (PI) SE & Co. KG Auf der Römerstraße 1 76228 Karlsruhe Germany <u>service@pi.de</u> www.pi.de

2.4 Old Equipment Disposal

In accordance with EU law, electrical and electronic equipment may not be disposed of in EU member states via the municipal residual waste.

Dispose of your old equipment according to international, national, and local rules and regulations.

In order to fulfill the responsibility as the product manufacturer, PI undertakes environmentally correct disposal of all PI equipment free of charge, if it was made available to the market after August 13, 2005.

Any old PI equipment can be sent free of charge to the following address:

Physik Instrumente (PI) SE & Co. KG Auf der Römerstraße 1 76228 Karlsruhe Germany

info@pi.de www.pi.de



MOTION | POSITIONING



3 Safety

3.1 Intended Use

The E-872.401 is a laboratory device as defined by DIN EN 61010-1. It is intended for indoor use and use in an environment that is free of dirt, oil, and lubricants.

In accordance with its design, the E-872.401 is intended for operating positioners with piezo inertia drives (Q-Motion®, PiezoMike). The channels are controlled sequentially. The E-872.401 is intended for open-loop control.

The E-872.401 may not be used for purposes other than those stated in this user manual. The E-872.401 may only be used in compliance with the technical specifications and instructions in this user manual.

3.2 General Safety Instructions

The E-872.401 is built according to state-of-the-art technology and recognized safety standards. Improper use of the E-872.401 may result in personal injury and/or damage to the E-872.401.

- ▶ Use the E-872.401 only for its intended purpose and when it is in perfect condition.
- ► Read the user manual.
- Eliminate any malfunctions that may affect safety immediately.

The operator is responsible for installing and operating the E-872.401 correctly.

- Install the E-872.401 near the power adapter so that the power plug can be quickly and easily disconnected from the mains.
- ► Use sufficiently dimensioned components to connect the E-872.401 to the power supply.
- Only use cables and connections that comply with local safety regulations.

3.3 Organizational Measures

3.3.1 User Manual

- Always keep this user manual available with the E-872.401. The latest versions of the user manuals can be <u>downloaded (p. 9)</u> at <u>www.pi.ws</u>.
- Add all information from the manufacturer such as supplements or technical notes to the user manual.
- If you give the E-872.401 to a third party, also include this user manual as well as other relevant information provided by the manufacturer.
- Only use the device on the basis of the complete user manual. Missing information due to an incomplete user manual can result in minor injury and damage to equipment.
- Only install and operate the E-872.401 after you have read and understood this user manual.

3.3.2 General Personnel Qualification

The E-872.401 may only be installed, started up, operated, maintained, and cleaned by authorized and appropriately qualified personnel.



4 Product Description

4.1 Front Panel

Power STA Power STA 24 VDC ERR		Ch1 C	
Element	Labeling	Туре	Function
0 -	Power	Toggle switch	On/Off switch O: E-872.401 switched off —: E-872.401 switched on
	24 V DC	M8 connector, 4-pole (m)	Connector for the supply voltage (p. 131) On delivery, a protective cap is screwed on the connector:
۲	STA	LED, green	Device status: Green - lights up continuously: E-872.401 ready for normal operation Green - flashing: E-872.401 in firmware up- date mode Off: E-872.401 not connected to the supply voltage
9	ERR	LED red	Error indicator: On: Error (error code not equal to 0) Off: No error (error code = 0) The error code can be queried with the ERR? command. The query resets the er- ror code to zero and the LED is switched off.
	● 	USB type B	Universal serial bus for connecting to the PC
		RJ45 socket	Ethernet interface for communication via TCP/IP
		USB type A	Connector for digital HID (Human Interface Device), e.g., joystick



Function

tor (p. 130)

Phoenix Contact MC 1,5/14-

LEMO EPL.0S.303.HLN con-

nectors (p. 129) for positioner

GF-3,5-LR I/O connec-



4.2 Type Plate



Figure 1: Type plate of the E-872.401

- 1. Data matrix code (example; contains the serial number)
- 2. Product number (example)
- 3. Serial number (example), individual for each E-872.401
- 4. Warning and conformity symbols (old equipment disposal (p. 10), CE mark (p. 9))

4.3 Scope of Delivery

Product number	Description
E-872.401	Drive electronics according to the order
C-501.24050H	Wide range input power supply 24 V, 50 W
K050B0003	Power supply adapter, barrel connector to M8 (f)
3763	Power cord
MS242EK	Short instructions for digital motor control- lers and drivers
000011448	USB cable (type A to B) for connecting to the PC
C-990.CD1	Data storage medium with PC software from PI

4.4 Accessories

The following articles are not in the scope of delivery of the E-872.401 and must be ordered separately, if required.



Product number	Description
C-815.553	Straight-through network cable for connecting the PC via a TCP/IP net- work
C-815.563	Crossover network cable for direct connection to the PC via TCP/IP
- -	

To order, contact our <u>customer service department (p. 9)</u>.

4.5 Communication Interfaces

4.5.1 Controlling PI Systems

Basically, PI systems can be controlled as follows:





4.5.2 E-872.401 Interfaces

The E-872.401 can be controlled via the following communication interfaces:

- PC interfaces, via <u>software (p. 16)</u> or PI General Command Set:
 - TCP/IP
 - USB
- SPI (reserved for future extensions)
- Analog signals
- Digital Signals: TTL



The interface parameters in the E-872.401's volatile memory can be queried with the <u>IFC</u>? command and changed with <u>IFC</u> command. The <u>IFS</u>? and <u>IFS</u> commands are available for querying and changing the interface parameters in the E-872.401's nonvolatile memory. The number of available digital input and output lines to and from the E-872.401 can be queried with the <u>TIO</u>? (p. 109) command. The status of the digital input lines can be queried with the <u>DIO</u>? (p. 87) command.

TCP/IP

Interface parameters of the E-872.401 for TCP/IP communication:

Interface property (pa- rameter name)	Factory setting	Note
Default IP address (IPADR)	192.168.0.75	Is not used when an IP address is assigned to the E-872.401 by a DHCP server (IPSTART).
Port for communication with the E-872.401	:50000	Not editable.
Subnet mask (IPMASK)	255.255.255.0	
Start-up behavior for configuring the IP ad- dress for TCP/IP commu-	DHCP active	The IP address of the E-872.401 is assigned via DHCP by the default setting of the startup behavior.
nication (IPSTART)		The default setting of the startup behavior must only be changed if the network devices are to use static addresses instead.
Auto MDI-X	No (MDI)	Not editable.
		If the E-872.401 is to be connected directly to the PC via TCP/IP, a crossover cable must be used.

4.6 Software Overview

A data storage device with the PI Software Suite is included in the E-872.401's <u>scope of</u> <u>delivery (p. 13)</u>. Some components of the PI Software Suite are described in the table below. For information on the compatibility of the software with PC operating systems see the C-990.CD1 Release News in the root directory of the data storage device.



PC software	Opera- ting sys- tem	Short description	Recommended use
Dynamic program- libraries for GCS	Win- dows,Li- nux	Allows software pro- gramming of the E-872.401 with pro- gramming languages such as C++. The func- tions in dynamic pro- gram libraries are based on the PI General Com- mand Set (GCS).	For users who would like to use a dynamic program li- brary for their application. Is required for PIMikroMove. Is required for NI LabVIEW drivers if communication is to be established via USB (with Linux only via virtual COM port) or a daisy chain network.
Drivers for use with NI LabVIEW soft- ware	Win- dows,Li- nux	NI LabVIEW is a soft- ware for data acquisi- tion and process control (must be ordered sepa- rately from National In- struments). The NI Lab- VIEW software from PI is a collection of virtual instrument drivers (VI drivers) for PI control- lers. These drivers sup- port GCS commands.	For users who wish to use NI LabVIEW to program their ap- plication.
MATLAB drivers	Win- dows	MATLAB is a develop- ment environment and programming language for numerical calcula- tions (must be ordered separately from Math- Works). The PIMATLAB driver consists of a MATLAB class that can be inclu- ded in any MATLAB script. This class sup- ports the PI General Command Set. The PI MATLAB driver does not require any addi- tional MATLAB toolbox- es.	For users who wish to use MATLAB to program their ap- plication.
USB driver	Win- dows	Driver for the USB inter- face	For users who want to con- nect the controller to the PC via the USB interface.

Libraries, drivers



PC software	Operat- ing sys- tem	Short description	Recommended use
PIMikroMove	Win- dows	 Graphical user interface for Windows, which can be used for controllers from PI: Start the system without program- ming effort Graphic representa- tion of the motion Macro functionality for storing command sequences on the PC (host macros) Complete environ- ment for command entry PIMikroMove uses the dynamic program li- brary to supply com- mands to the controller. 	For users who want to per- form simple automation tasks or test their equipment before or instead of programming an application. No command knowledge is necessary to operate PIMikro- Move. A log window showing the commands sent makes it pos- sible to learn how to use the commands.
PIStages3Editor	Win- dows	Program opening and editing positioner data- bases in .db format.	For users who want to deal with the contents of position- er databases more intensive- ly.
PITerminal	Win- dows,Li- nux	Simple user interface that can be used for nearly all PI controllers.	For users who want to send GCS commands directly to the controller.
PIFirmwareManag- er	Win- dows	Program for updating the firmware of the E-872.401	For users who want to update the firmware
PIUpdateFinder	Win- dows	Checks the PI software installed on the PC. If newer versions of the PC software are availa- ble on the PI server, they are offered for download.	For users who want to update the PC software.

User software

4.7 Positioner database

You can select a parameter set appropriate for your positioner from a positioner database in the PC software from PI. The software transfers the values of the selected parameter set to the controller's volatile or nonvolatile memory.



Database file name	Description
PISTAGES3.DB	Delivery includes parameter sets for all standard positioners from PI and PI miCos, and is saved to the PC automatically dur- ing installation of the PC software. New parameter sets can be created, edited, and saved.
Product code.db	Includes the parameter set for the custom positioner "product code". In order for the parameter set to be selectable in the PC software, it must be <u>imported (p. 35)</u> into PISTAGES3.DB first.

The positioner database only contains some of the information that is required to operate a positioner with the E-872.401. When the positioner connected to the E-872.401 is equipped with an ID chip: Further information is loaded as parameter values from the ID chip to the volatile memory of the E-872.401 when the E-872.401 is switched on or rebooted.

4.8 Functional Principles of the E-872.401

4.8.1 Block Diagram

The E-872.401 controls the motion of a positioner's logical axis. The following block diagram shows how the E-872.401 generates the piezo voltage for the axis connected:



The E-872.401 supports positioners with Q-Motion® or PiezoMike inertia drive.

4.8.2 Important Firmware Components

The functional units of the E-872.401's firmware are described in the following. The firmware can be updated with a tool. The current firmware version can be ascertained with the VER? command.



Component	Description
Parameters	Parameters reflect the properties of the positioner connected (e.g., travel range) and specify the behavior of the E-872.401 (e.g., set- tings for the servo algorithm).
	The parameters can be divided into the following categories:
	 Protected parameters whose default settings cannot be changed
	 Parameters that must be set by the user to adapt to the applica- tion
	In the case of positioners with ID chip, the values of some parame- ters are stored on the ID chip. They are loaded to the volatile memory when switching on or rebooting the E-872.401.
	Command levels determine the write permission for the parameters. The current command level can be queried with the \underline{CCL} ? command and changed with the \underline{CCL} command. This may require entering a password.
	The list of parameters available in the E-872.401 can be queried with the <u>HPA?</u> command.
	Refer to <u>Adapting Settings (p. 71)</u> for more information on parameters
ASCII commands (GCS)	Communication with the E-872.401 can be made with <u>com-</u> <u>mands (p. 81)</u> from the PI General Command Set (GCS). The <u>GCS</u> <u>syntax version (p. 69)</u> can be queries with the <u>CSV?</u> command. Examples of the use of GCS:
	Configuring the E-872.401
	 Setting the operating mode Starting positionar motion
	 Getting system and position values
	The list of commands available in the E-872.401 can be queried with the <u>HLP?</u> command.
Macros	The E-872.401 can save macros. Command sequences can be de- fined and stored permanently in the nonvolatile memory of the device via the macro function. A startup macro can be defined that runs each time the E-872.401 is switched on or rebooted. The start- up macro simplifies stand-alone operation (operation without a connection to the PC).
	Refer to Controller Macros (p. 63) for information

Commands

С		Page
CCL	Set Command Level	85
CCL?	Get Command Level	85
CSV?	Get Current Syntax Version	86
н		Page
HLP?	Get List Of Available Commands	93
HPA?	Get List Of Available Parameters	94



V		Page
VER?	Get Versions Of Firmware And Drivers	110

Parameters

4.8.3 Commandable Items

The following table contains the elements of the E-872.401 that can be commanded with GCS commands.



Element	Quan- tity	ID	Description
Drive channels	4	1 to 4	The E-872.401 supports drive channels for position- ers with piezo inertia drive. The E-872.401 controls the axis of a positioner connected to it via a drive channel.
			One axis each is driven by the integrated amplifier. Switching between the channels is done via com- mands or via the digital input lines. This allows seri- al control of up to 4 axes with a piezo inertia drive.
			For information, see: <u>Switching between the Drive</u> <u>Channels (p. 26)</u>
			Depending on the command mode set, it is possible to command motion in step mode with the <u>OSM</u> command or via HID, or via digital input lines. Mo- tion in linear mode can only be commanded via an analog input signal.
			For information, see: Triggering Motion (p. 27) The drive channel's identifier can be queried with the SAI? command and the connected positioner type with the CST? command. If the Stage Name pa- rameter (0x3C) has the NOSTAGE value, the connec- ted axis is "deactivated". A deactivated axis is not accessible for axis-related commands (e.g., motion commands or position queries). The identifier of a deactivated axis can only be queried with SAI? ALL.
Analog input	1	1	The input signal for analog signals (0 to 4.8 V) is at the E-872.401's I/O socket. The analog input can be used for controlling the connected piezo inertia drive in linear mode.
Digital inputs	6	1 to 6	1 to 6 identify digital input lines 1 to 6 of the I/O socket. For information, see: <u>Digital Input Signals (p. 54)</u>
Digital outputs	1	1	1 identifies digital output line 1 of the I/O socket. For information, see: <u>Digital Output Signals (p. 54)</u>
HID (Human In- terface Device)	1	1	A digital HID can be connected to the USB socket of the E-872.401. The HID (e.g.,. joystick) is used for HID control of the axes connected to the E-872.401. Information on the HID's axes and buttons can be queried with the HIS? command. For information, see: <u>Controlling with an</u> <u>HID (p. 57)</u>
HID axes	х	1 to x	The number of commandable axes per HID depends on the HID connected. The E-872.401 assigns IDs 1 to x to the HID axes.
HID buttons	x	1 to x	The number of commandable buttons per HID depends on the HID connected.



Element	Quan- tity	ID	Description
			The E-872.401 assigns IDs 1 to x to the HID buttons.
Overall system	1	1	E-872.401 as an overall system Information on name, serial number, and firmware version of the E-872.401 can be queried with the <u>*IDN?</u> command. The ready state of the E-872.401 can be queried with the <u>#7</u> command.

Commands

#		Page
#7	Request Controller Ready Status	83
*		Page
*IDN?	Get Device Information	84
C		Page
CST?	Get Assignment Of Stages To Axes	86
Н		Page
HIS?	Get Configuration Of HI Device	92
0		Page
OSM	Open-Loop Step Moving	105
S		Page
SAI?	Get List Of Current Axis Identifiers	107

Parameters

0x3C	Stage Name	Positioner name.
	-	Default value: NOSTAGE
		String up to 20 characters

4.8.4 Operating Modes

The E-872.401 is a driver for piezo inertia drives without position sensor, i.e., motion is done in open-loop operation.

A distinction between the following modes is made in drive mode:

- Step mode
- Linear mode

Drive mode

Piezo inertia drives are piezo-based drives with virtually unlimited travel range. They use the stick-slip effect (inertia effect) – a cyclical alternation of static and sliding friction between a moving runner and the piezo actuator generated by the piezo element – for a continuous feed of the runner. The operating voltage is therefore output by the E-872.401 as a modified sawtooth signal with a maximum frequency of 25 kHz. The output of one period of the modified sawtooth signal generates one "step" of the runner.







In the case of a piezo inertia drive, a piezo actuator acts on a moving runner to generate motion. The E-872.401 supports the following drive modes for piezo inertia drives in open-loop operation:

Step mode

The drive electronics of the E-872.401 convert the control value to a modified sawtooth signal with a maximum frequency of 25 kHz and output the corresponding piezo voltage. The piezo voltage generates a cyclic alternation of static and sliding friction between the runner and the piezo actuator and therefore continuous feed of the runner. The output of one period of the modified sawtooth signal generates one "step" for the runner.

The travel range is only limited by the physical limits of the positioner.

Linear mode

The drive electronics of the E-872.401 convert the control value to an analog signal. The output piezo voltage corresponds to 10 times this analog signal. The feed to the runner is generated by the expansion of the piezo actuator caused by the piezo voltage. The piezo actuator achieves its maximum expansion when the E-872.401 outputs the maximum permitted piezo voltage.

The travel range is limited by the maximum expansion of the piezo actuator.

Configuration

The drive mode is selected via the digital input line on pin 9 (ST) of the E-872.401'S I/O socket:

- High: Linear mode
- Low: Step mode

The E-872.401's drive channels are configured for the piezo inertia drive with the following parameters:

- **<u>Q-Motion Upper Supply Voltage (V)</u>** (0x1F000000)
- <u>Q-Motion Lower Supply Voltage (V)</u> (0x1F000100)
- <u>Q-Motion Forward Current (A)</u> (0x1F000200)
- <u>Q-Motion</u> <u>Backward Current (A)</u> (0x1F000300)
- <u>**Q-Motion Frequency (Hz)**</u> (0x1F000400)
- <u>**Q-Motion Charge Cycle**</u> (0x1F000500)
- <u>**Q-Motion Delay (ms)**</u> (0x1F000701)

Commands

Parameters



0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000100	Q-Motion Lower Supply Voltage (V)	Minimum output voltage for piezo inertia drives. The value depends on the type of the drive.
0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000200	Q-Motion Forward Current (A)	Maximum output current for piezo inertia drives during forward motion. The value depends on the type of the drive.
0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000300	Q-Motion Backward Current (A)	Maximum output current for piezo inertia drives during backward motion. The value depends on the type of the drive.



0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000400	Q-Motion Frequency (Hz)	Frequency of the piezo voltage for open-loop operation of piezo inertia drives. Determines the velocity of a drive in open-loop operation. The value of this parameter must be chosen higher than the value of the 0x9 (Maximum Motor Output) parameter. Recommended: $0x1F000400 = 0x9 \times 1.25$
0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000500	Q-Motion Charge Cycle	Duty cycle of the current source during output of a step. Specified as part of a period which the current source is switched on for. 0 to 1 The value depends on the type of the drive.
0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000701	Q-Motion Delay (ms)	Delay time when switching between two operating modes (e.g., step mode and linear mode). 0 to 2000 [ms]

4.8.5 Switching Between the Drive Channels

The E-872.401 has 4 drive channels. One axis each is driven by the integrated amplifier of the E-872.401. Switching between the drive channels is done via commands or via the digital input lines. This allows serial control of up to 4 axes with a piezo inertia drive.



The drive channel can be selected in one of the following ways:

- Via interface: Sending commands or selecting in the PC program
- Via digital inputs: Pin 3 (M0) and pin 4 (M1) of the E-872.401's I/O socket

Configuring via interface overwrites the settings of the digital inputs and ignores them until the E-872.401 is rebooted.

Selecting the drive channel via communication interface

The drive channel is selected by

- Specifying the channel ID when sending commands, e.g.,
 0SM 1 10 moves the axis connected to drive channel 1 10 steps in a positive direction.
- Triggering motions for a drive channel in the main window of PIMikroMove

ſ	Axes		er macros Drive chan	nels	🖶 Host macros		
		StageName	Open-Loop Analog Driving	<	Open-Loop Number of Steps	>	Oper
	1	Q-522.100	0.000000	<	10	>	
	2	N-470.410	0.000000	<	0	>	

Triggering a motion for a channel causes the previously controlled channel to be reset to 0 and the position of the axis connected to it changes correspondingly.

Selecting the drive channel via digital inputs

The drive channel is selected via the digital input lines on pins 3 (M0) and 4 (M1) of the E-872.401's I/O socket:

Function	Level of the Input Line	
Activating the drive channel	M0	M1
1	OFF / LOW	OFF / LOW
2	ON / HIGH	OFF / LOW
3	OFF / LOW	ON / HIGH
4	ON / HIGH	ON / HIGH

Commands

Parameters

4.8.6 Triggering Motion

The E-872.401 is a driver for piezo inertia drives without position sensor, i.e., motion is done in open-loop operation.

The piezo inertia drive executes motion in step mode or in linear mode.

Step mode

Depending on the command mode, motion is triggered in step mode via digital input lines or via commands or via HID.

The command mode is selected via the digital line on pin 7 (CMD) of the E-872.401's I/O socket:



High: Commanding via digital I/O lines

■ Low: Commanding via interface: Commands from PC, HID control

Configuring via interface overwrites the settings of the digital inputs and ignores them until the E-872.401 is rebooted.

Linear mode

Motion in linear mode can only be commanded via an analog input signal. The analog input voltage is connected to pin 8 (AN) of the E-872.401's I/O socket. The permissible voltage range amounts to a tenth of the piezo inertia drive's permissible operating voltage range. Example:

Permissible operating voltage range of the piezo inertia drive: 0 to 48 V Permissible range of analog input voltage: 0 to 4.8 V

Triggering motion in open-loop operation

Commanding via input lines

Motion in step mode can be commanded via the digital inputs at pins 5 (DIR) and 6 (EN) of the E-872.401's I/O socket:

The direction signal for step mode can be fed via pin 5:

- High: Forward motion
- Low: Backward motion

The drive is activated in step mode via pin 6:

- High: Steps are done; the velocity (i.e., the current step frequency) is specified by the <u>**Q**</u>-<u>**Motion Frequency (Hz)**</u> parameter (0x1F000400) and remains constant.
- Low: No motion

Commanding via interface

Motion is triggered in step mode either via commands or via an HID, e.g., a joystick. Motion commands for an axis are not permitted when HID control is activated for the axis. Options for commanding via interface:

- Software on the PC (connected via one of the E-872.401's communications interfaces): The number of steps to be made and the direction can be specified in PIMikroMove; the velocity (i.e., the current step frequency) is specified by the Q-Motion Frequency (Hz) parameter and remains constant.
- Commands (via PC or controller macro): Sending the <u>OSM</u> command specifies the number of steps to be made and the direction; the velocity (i.e., the current step frequency) is specified by the **Q-Motion Frequency (Hz)** parameter and remains constant.
 Example: Sending OSM 1 200 starts 200 steps forwards, OSM 1 -550 starts 550 steps backwards.
- HID, e.g., joystick (connected via USB): Displacement of the HID's axis determines the velocity (i.e., the current step frequency) and the direction.

The motion status of the axes connected to the E-872.401 can be queried with the #5 command.

Motion triggered by commands can be **stopped** with the following commands:

- <u>#24</u>, <u>STP</u>: Abrupt stop
- <u>HLT</u>: Gentle stop

In both cases, the error code 10 is set for information.

Motion is triggered by the following commands:



Commands	Description
<u>OSM</u>	Moves an axis by a particular number of steps The number of steps that the axis still must do can be queried with the OSN? command.
<u>OAD</u>	Determines the control value for the specified axis of the E-872.401 and starts motion immediately.
	In the case of piezo inertia drives, the control value corresponds to the analog output voltage [V].
	The current control value can be queried with the $\underline{OAD?}$ command.

The HID control is configured with and activated by the following commands:

Commands	Description
HIN	Activates or deactivates control of the E-872.401's channels via the HID's axes
HIA	 Configures HID control for the E-872.401's channels. HID axes can control the following motion parameters of axes connected to the E-872.401: Velocity of the axis connected to the channel

Commands

#		Page
#24	Stop All Axes	84
#5	Request Motion Status	83
Н		Page
HIA	Configure Control Done By HID Axis	89
HIN	Set Activation State For HID Control	91
HLT	Halt Motion Smoothly	94
0		Page
O OAD	Set Open-Loop Control Value (starts motion)	Page 104
O OAD OAD?	Set Open-Loop Control Value (starts motion) Get Control Value	Page 104 105
O OAD OAD? OSM	Set Open-Loop Control Value (starts motion) Get Control Value Open-Loop Step Moving	Page 104 105 105
O OAD OAD? OSM OSN?	Set Open-Loop Control Value (starts motion) Get Control Value Open-Loop Step Moving Read Number Steps	Page 104 105 105 106
O OAD OAD? OSM OSN? S	Set Open-Loop Control Value (starts motion) Get Control Value Open-Loop Step Moving Read Number Steps	Page 104 105 105 106 Page

Parameters



0x1F000400 Q-Motion Frequency (Hz)	Frequency of the piezo voltage for open-loop operation of piezo inertia drives. Determines the velocity of a drive in open-loop operation. The value of this parameter must be chosen higher than the value of the 0x9 (Maximum Motor Output) parameter. Recommended: $0x1F000400 = 0x9 \times 1.25$
---------------------------------------	---

4.8.7 Travel Range and Soft Limits

The physical limits of the travel range can be represented by the following items of a positioner:

- Limit switches
- If the positioner does not have integrated limit switches: Hard stops

Commands

Parameters



5 Unpacking / Transportation

5.1 Unpacking

Unpacking the E-872.401

- 1. Unpack the E-872.401 with care.
- 2. If the E-872.401 was supplied with ESD protective caps on the connectors: Do **not** remove the ESD protective caps.
- 3. Compare the contents with the scope of delivery according to the contract and the delivery note.
- 4. Inspect the contents for signs of damage. If any parts are damaged or missing, contact our <u>customer service department (p. 9)</u> immediately.
- 5. Keep all packaging materials in case the product needs to be returned.

5.2 Transportation

Pay attention to the <u>ambient conditions and classifications (p. 127)</u> when transporting the E-872.401.

- 1. Pack the E-872.401 in the original packaging.
- 2. If the E-872.401 is to be sent, use a stable outer box.



6 Installation

6.1 Mounting the E-872.401

The E-872.401 can be used as a benchtop device or mounted on a surface in any orientation or installed in a control cabinet.

Overview



Figure 3: Dimensions and position of the recesses for mounting

Tools and Accessories

- Suitable screws
- Suitable screwdriver

Requirements

✓ You have read and understood the general safety instructions (p. 11).

NOTICE

Heating up of the E-872.401 during operation!

High temperatures can overheat the E-872.401.

- Install the E-872.401 with a gap of at least 10 cm to the top and rear panels and at least 5 cm to its sides. If this is not possible, make sure that the surroundings are cooled sufficiently.
- Ensure sufficient ventilation at the place of installation.
- ► Keep the ambient temperature at a noncritical level.

Mounting the E-872.401 on a Surface

- Drill the holes required into the surface. The arrangement of the recesses in the mounting rails of the E-872.401 can be seen in the figure.
- 2. Tighten the E-872.401 to the recesses provided with suitable screws.

6.2 Connecting the E-872.401 to the Protective Earth Conductor

The E-872.401 is not grounded via the voltage connection and must therefore be connected to the protective earth conductor.





Figure 4: Connecting the protective earth conductor to the threaded bolt

- 1. Flat washer
- 2. Cable lug of the protective earth conductor
- 3. Spring washer
- 4. Nut

Tools and Accessories

- Suitable protective earth conductor with cable lug:
 - Cable cross section ≥ 0.75 mm²
 - Contact resistance < 0.1 ohm at 25 A at all connection points relevant for attaching the protective earth conductor
- Suitable wrench

Requirements

- ✓ You have read and understood the general safety instructions (p. 11).
- ✓ The E-872.401 is not connected to the power supply.

Information

▶ Pay attention to the applicable standards for connecting the protective earth conductor.

Connecting the E-872.401 to the Protective Earth Conductor

- 1. If necessary, attach a suitable cable lug to the protective earth conductor.
- 2. Remove the outer nut and the spring washer from the threaded bolt of the protective earth connector.
- 3. Push the cable lug of the protective earth conductor and the spring washer onto the threaded bolt.
- 4. Screw the nut onto the threaded bolt again.
- → The cable lug of the protective earth conductor is clamped between the flat washer and the spring washer.
- 5. Tighten the nut with at least three turns and a torque of 1.2 Nm to 1.5 Nm.

6.3 Connecting the Power Supply to the E-872.401

Tools and Accessories

- Included power supply (alternative: Sufficiently rated power supply)
- Adapter included for power supply connection (alternative: Sufficiently rated adapter)
- Included power cord (alternative: Sufficiently rated power cord)



Requirements

- ✓ The power supply is **not** connected to the power socket via the power cord.
- ✓ The E-872.401 is installed near the power supply so that the power plug can be quickly and easily disconnected from the mains.

Connect the Power Adapter to the E-872.401

- 1. If necessary: Remove the protective cap from the E-872.401's voltage connector.
- 2. Connect the M8 4-pole connector (f) of the adapter to the voltage connector of the E-872.401.
- 3. Secure the adapter against unintentional removal.
- 4. Connect the barrel connector on the adapter to the barrel connector socket of the power adapter.



5. Connect the power cord to the power adapter.

6.4 Connecting the Positioner to the E-872.401

Tools and Accessories

- Compatible positioner with Q-Motion® or PiezoMike piezo inertia drive
- If necessary: Suitable adapter cable from PI, available as optional accessory for the positioner
- If the distance between the E-872.401 and the positioner is too long: Suitable drive or extension cable from PI, available as optional accessory for the positioner

Requirements

- ✓ The power adapter is not connected to the power socket via the power cord or the E-872.401 is switched off.
- ✓ You have read and understood the user manual for the positioner to be connected.
- ✓ You have installed the positioner to be connected according to the instructions in its respective user manual.

NOTICE

Damage if a wrong drive type is connected!

Connecting a positioner with incompatible drive type can cause irreparable damage.

 Connect the E-872.401 only to positioners with Q-Motion[®] or PiezoMike piezo inertia drive.

Connecting the Positioner to the E-872.401

- 1. If necessary: Connect a suitable adapter to the positioner's drive connector.
- 2. Insert the drive connector of the positioner or the adapter into one of the sockets on the drive of the E-872.401.





6.5 Installing the PC Software

6.5.1 Installing the PC Software for the First Time

Tools and Accessories

- PC with <u>Windows or Linux (p. 16)</u> operating system and at least 30 MB free storage space
- Software from PI: On the storage device supplied or available for download from our website <u>www.pi.de</u>.
- Optional for custom positioners: Data storage device or archive file with the following content:
 - Import Pl CustomStage program
 - Custom positioner database with the parameter set for the positioner

Installing the PC software in Windows

- 1. Insert the data storage device into the PC or go to the directory where you saved the downloaded software to.
- 2. Start the install wizard by double-clicking PISoftwareSuite.exe.
- → The InstallShield Wizard window opens for installing the PC software from Pl.
- 3. Follow the instructions on the screen.

The PI software suite includes the following components:

- Driver for use with NI LabVIEW software
- Dynamic program library for GCS
- PIMikroMove
- PC software for updating the firmware of the E-872.401
- PIUpdateFinder for updating the PC software
- USB driver

Installing a Custom Positioner Database in Windows

If you have a custom positioner database, this must also be installed on the PC.

- 1. Insert the data storage device into the PC or go to the directory where you saved the downloaded software to.
- 2. Run the installation assistant for the custom positioner database by clicking *Import_PI_CustomStage.exe*.
- → The Import PI Custom Stage program is run and the parameter set is imported from the custom positioner database into PIStages3.
- 3. If a message appears that installation of the custom positioner database failed:
 - a) Update the PIStages3 positioner database on your PC (p. 36).
 - b) Repeat the installation of the custom positioner database.



Installing the PC Software in Linux

- 1. Insert the data storage device into the PC or go to the directory where you saved the downloaded software to.
- 2. Unzip the tar archive from the /linux directory into a directory on your PC.
- 3. Open a terminal and go to the directory where you unpacked the tar archive.
- 4. Log in as superuser (root privileges).
- Enter ./INSTALL to start the installation.
 Pay attention to lower and upper case when entering commands.
- 6. Follow the instructions on the screen.
- 7. If you have received a **custom positioner database**: Copy the positioner database file into the following directory: /usr/local/Pl/pi_gcs_translator/

6.5.2 Updating the PC Software

PI is constantly improving the PC software. Always install the latest version of the PC software and the positioner database.

PIUpdateFinder is a program which helps you find updates for your PI software on the PI server. It identifies the PI software installed on your computer and compares it with the software available on the PI server. This comparison is made using the Internet. If newer software versions are available on the PI server, you can download the software via a corresponding link.

Confidential customer data is not transmitted when comparing the software versions. The following information is transmitted:

- Software component and version
- Internet browser
- Operating system
- IP address

Updating the PC Software and Positioner Database in Windows

Requirements

- ✓ You have installed the PIUpdateFinder on the PC to be updated.
- ✓ In addition when updating the software on a PC without Internet connection:
 - PC with Internet connection
 - Portable data storage device, e.g., USB stick, for the data exchange between the computers

Updating the Software on a PC with Internet Connection

- 1. Start PIUpdateFinder on the PC to be updated.
- → A table is displayed with information on the PI software installed on your computer.


PIUpdateFinder 1.7.2.0		-		\times
MOTION POSITIONING		1.1	D	Т
PIUpdateFinder				
This tool will help you to keep your PI software components up to date by sending information about their download and install.	versions to the PI server. You can then de	ecide what	to	
The following software components have been found:				
Module	Version			
PI API Components	1.0.0.0			
PI Base Components	1.0.0.0			
PI Extra Components	1.0.0.0			
PI Software Suite	1.0.0.0			
PI USB Drivers	1.0.0.0			
PlUpdateFinder will search for Pl software in the standard installation directories only.		Sea	rch agai	in
If your PI software is installed elsewhere, PIUpdateFinder cannot find it. In this case, specify the directories where your PI software components are installed				
Once you are finished, PlUpdateFinder will search again for your Pl software.				
Click Find Updates to send the above version information to the PI server and get information on which	nodules can be updated.	Find	l Update	s
If your computer is not connected to the Internet, click Use Offline Mode.		Use O)ffline M	ode
Click the directory links above to access the destination folders for the software you download.		About PI	UpdateF	inder

If the table is empty or incomplete, proceed as follows:

- a) Click specify the directories where your PI software components are installed.
- → A dialog window is opened, in which all directories are listed that PIUpdateFinder finds while searching for and comparing the software versions.

PIUpdateFinder				\times
PIUpdateFinder will search for PI software i	n these director	ries:		
C:/ProgramData/PI/GCSTranslator/ C:/Program Files (x86)/PI/ C:/Users/Public/Documents/PI/ C:/Users/cbo/Documents/PI/ C:/Users/Public/Documents/MercuryGCS/ C:/Users/cbo/Documents/MercuryGCS/	1			^
Remove selected directory from list	Add d	efault	directori	ies
Include s	ubdirectories		Add	
	<u>О</u> К		<u>C</u> ancel	

- b) Click the ... button and select the directory on your hard disk, where the PI software is installed.
- → The directory is displayed in the input field at the bottom left of the window. You can also manually enter directories there.
- c) Activate the Include subdirectories checkbox to include subdirectories as well.
- d) Click the *Add* button.
- → The directory, and any subdirectories, appear at the end of the list.
- e) Click OK to finalize input of the installation directory.
- → If PI software is found in the specified directories, it will be displayed in the table on the initial screen of the PIUpdateFinder.
- 2. Click the *Find Updates* button.
- → A browser window opens and a table is displayed with the software information. Updates are available from the column Download Link via the PI server link.



ΡΤ

PI Update Finder



Name	Installed Version	Version on PI Server	Release Notes	Download Lin
PI API Components	V1.0.0.0	V1.1.0.0	Release note	PI server
PI Base Components	V1.0.0.0	V1.1.0.0	Release note	PI server
PI Extra Components	V1.0.0.0	V1.1.0.0	Release note	PI server
PI Software Suite	V1.0.0.0	V1.1.0.0	Release note	PI server
PI USB Drivers	V1.0.0.0	V1.1.0.0	Release note	PI server

Important note: Before downloading and installing your update, read the corresponding release note to check if there are any known compatibility issues.

If you have any questions or problems please contact us © 2011-2018 by Physik Instrumente (PI) GmbH & Co. KG

- 3. To download an update, click *Pl server* in the *Download Link* column.
- → You are then asked to specify whether the file is to be downloaded or run directly. Depending on the browser settings, it is possible that the update file is downloaded directly. It is then in the download directory of your computer.
- 4. Activate the option in the browser query to save the update file to the your computer's hard disk.
- → The file is saved to the download directory of your computer. Depending on the browser settings, it is also possible to run the file directly or open it. In this case, continue with step 6.
- 5. Install the update:
 - Executable setup files (.exe): Run the downloaded update file.
 - Data archive (.zip): Unpack the archive to a directory on your PC. Open this directory and run the desired setup file (.exe).

You may have to confirm running the file.

→ This opens the InstallShield Wizard, e.g., for PI API Components:

👷 PI API Components - Install	Shield Wizard	Х
	PI Welcome to the InstallShield Wizard for PI API Components The InstallShield(R) Wizard will install PI API Components on your computer. To continue, click Next.	
	WARNING: This program is protected by copyright law and international treaties.	
	A Rack Next > Cancel	
	Cancel	

6. Follow the instructions in the InstallShield Wizard.

Updating the Software on a PC without Internet Connection

- 1. Connect the portable data storage device, e.g., an USB stick, with the PC to be updated.
- 2. Start PIUpdateFinder on the PC to be updated.
- → A table is displayed with information on the PI software installed on your computer.



PIUpdateFinder 1.7.2.0		-		×
MOTION POSITIONING			D.	г
PIUpdateFinde	er			
This tool will help you to keep your PI software components up to date by sending information about t download and install.	heir versions to the PI server. You can	then decide what t	0	
The following software components have been found:				
Module	Version			
PI API Components	1.0.0.0			
PI Base Components	1.0.0.0			
PI Extra Components	1.0.0.0			
PI Software Suite	1.0.0.0			
PI USB Drivers	1.0.0.0			
PlUpdateFinder will search for Pl software in the standard installation directories only. If your Pl software is installed elsewhere. Pll IndateFinder cannot find it		Searc	ch agai	n
In this case, specify the directories where your PI software components are installed.				
Once you are finished, PlUpdateFinder will search again for your Pl software.				
Click Find Updates to send the above version information to the PI server and get information on wh	ich modules can be updated.	Find U	Jpdate	s
If your computer is not connected to the Internet, click Use Offline Mode.		Use Off	line Mo	ode
Click the directory links above to access the destination folders for the software you download.		About PIU	pdateF	inder

If the table is empty or incomplete, proceed as follows:

a) Click specify the directories where your PI software components are installed.

→ A dialog window is opened, in which all directories are listed that PlUpdateFinder finds while searching for and comparing the software versions.

PIUpdateFinder				×
PIUpdateFinder will search for PI software in the	se director	ies:		
C:/ProgramData/PI/GCSTranslator/ C:/Program Files (x86)/PI/ C:/Users/Public/Documents/PI/ C:/Users/cbo/Documents/PI/ C:/Users/cbo/Documents/MercuryGCS/				^
C:/Users/cbo/Documents/MercuryGCS/				~
Remove selected directory from list	Add de	fault	directorie	:5
Include subdir	ectories		Add	
9	<u>0</u> K		<u>C</u> ancel	

- b) Click the ... button and select the directory on your hard disk, where the PI software is installed.
- → The directory is displayed in the input field at the bottom left of the window. You can also manually enter directories there.
- c) Activate the Include subdirectories checkbox to include subdirectories as well.
- d) Click the Add button.
- → The directory, and any subdirectories, appear at the end of the list.
- e) Click *OK* to finalize input of the installation directory.
- → If PI software is found in the specified directories, it will be displayed in the table on the initial screen of the PIUpdateFinder.
- 3. In the main window, click the Use Offline Mode button.
- → The window Create Version Information File will open.



Create Version Information File	×
PI Update Finder will save the information gathered on this computer to an HTML file. You can transfer this file to a computer with Internet connection and download software updates from the PI server by opening the file in a web browser. To create the HTML file, click "Save Version Information" and choose a location where the file should be stored.	
Save Version Information Cancel	

- 4. Click the *Save Version Information* button to save the software version information to a HTML file on your portable data storage device.
- 5. Transfer the HTML file to a computer connected to the Internet.
- 6. Open the HTML file in a web browser on the computer connected to the Internet.
- → A browser window opens and a table is displayed with the software information. Updates are available from the column **Download Link** via the **PI server** link.
- 7. Download your updates and save them to your portable data storage device.
- 8. Transfer the updates to the PC without Internet connection.
- 9. Install the updates.
 - Executable setup files (.exe): Run the downloaded update file.
 - Data archive (.zip): Unpack the archive to a directory on your PC. Open this directory and run the desired setup file (.exe).

You may have to confirm running the file.

→ This opens the InstallShield Wizard, e.g., for PI API Components:

👷 PI API Components - Inst	allShield Wizard	×
	Welcome to the InstallShield Wizard for PI API Components The InstallShield(R) Wizard will install PI API Components on your computer. To continue, dick Next.	
	WARNING: This program is protected by copyright law and international treaties.	
	WWW.PI.WS	
	< Back Next > Cancel	

10. Follow the instructions in the InstallShield Wizard.

Updating the PC Software and Positioner Database in Linux

Requirements

✓ Active connection to the Internet.

Updating the PC software in Linux

- 1. Open the website www.physikinstrumente.com/en/products/software-suite
- 2. Scroll down to Downloads.
- 3. Click ADD TO LIST for the PI Software Suite C-990.CD1.
- 4. Click *REQUEST*.
- 5. Fill out the download request form and send the request.
- → The download link will then be sent to the e-mail address entered.



- 6. Via the link download the archive file with the *PI Software Suite*.
- 7. Unpack the archive file on your PC to a separate directory.
- 8. Go to the *linux* subdirectory in the directory with the unpacked files. You will find an additional archive file there.
- 9. Unpack the archive file in the *linux* directory by entering the command tar -xvpf <name of the archive file> on the console.
- 10. Log into the PC as superuser (root privileges).
- 11. Install the update.
- 12.If you also received an updated PISTAGES3.DB database from our customer service department: Install that update onto the PC.

6.6 Connecting the PC

Communication between the E-872.401 and a PC is required to configure the E-872.401 and to command motion using the GCS commands.

NOTICE

Damage due to noncompliant USB cable

The type A USB connection (USB) of the E-872.401 is only intended for connection to a USB human interface device. If a USB host (e.g., PC) is connected to the type A USB connection of the E-872.401 via a noncompliant USB cable, the E-872.401 or the host could be damaged.

▶ Use a standard-compliant USB cable only.

For connecting to a PC, use the type B () or type Mini-B () USB connection only.

Information

►

The E-872.401's communication interfaces are active at the same time. Commands are executed in the order in which the complete command lines arrive. However, simultaneous use of several communication interfaces can cause problems with the PC software.

► Always only use one interface of the E-872.401.

6.6.1 Connecting the E-872.401 to a PC

Tools and Accessories

 Suitable cable for the selected communication interface (in the scope of delivery (p. 13) or available as optional accessory (p. 13))

Requirements

- ✓ The PC has a connection available for the selected communication interface.
- ✓ If necessary: The interface parameters of the PC have been adapted for the <u>E-872.401 (p. 15)</u>.

Connecting the E-872.401 to the PC

- 1. Connect the cable to the selected communication interface of the E-872.401.
- 2. Connect the cable to an unused port on the PC.



6.6.2 Integrating the E-872.401 into a Network

Tools and Accessories

Suitable network cable (in the scope of delivery (p. 13) or available as optional accessory (p. 13))

Requirements

- ✓ A network access point is available for the E-872.401.
- ✓ The <u>default settings of the TCP/IP interface (p. 16)</u> do not collide with the settings of other devices in the network.

Integrating the E-872.401 into a TCP/IP Network

- 1. Connect the RJ45 socket of the E-872.401 to the network cable.
- 2. Connect the network cable to the network access point.



7 Startup and Operation

7.1 Switching on the E-872.401

Requirements

- ✓ You have read and understood the general safety instructions (p. 11).
- ✓ The E-872.401 has been installed properly (p. 32).



CAUTION

Risk of electric shock if the protective earth conductor is not connected!

If the protective earth conductor is missing or not properly connected, dangerous touch voltages can occur on the E-872.401 in the event of malfunction or failure of the system. If there are touch voltages, touching the E-872.401 can lead to minor injury due to electric shock.

- ► Connect the E-872.401 to a protective earth conductor (p. 32) before startup.
- ▶ Do **not** remove the protective earth conductor during operation.
- ► If the protective earth conductor has to be removed temporarily (e.g., for modification), reconnect the E-872.401 to the protective earth conductor before restarting.

Switching the E-872.401 On

- 1. Connect the power cord of the power adapter to the power socket.
- 2. Switch on the E-872.401.
- → The E-872.401 boots the firmware and loads information from the nonvolatile memory to the volatile memory.
- 3. Wait until the STA LED lights up green.
- → The information has loaded and the E-872.401 is ready for normal operation.
- 4. If the **STA** LED does not light up a few seconds after switching on, contact our <u>customer</u> <u>service department (p. 9)</u>.

7.2 Establishing Communication with the PC

The procedure for PIMikroMove is described in the following.

The figures show the procedure for any electronics; the procedure for the E-872.401 corresponds.

7.2.1 Establishing Communication via USB

If the controller is connected via the USB connection and switched on, the USB interface in the PC software is also shown as a COM port.

Requirements

- ✓ The E-872.401 is connected to the USB interface of the PC (p. 41).
- ✓ The E-872.401 is <u>switched on (p. 43)</u>.
- \checkmark The PC is switched on.
- ✓ The required software and drivers are installed (p. 35) on the PC.
- ✓ You have read and understood the manual for the PC software. The links to the software manuals are in the A000T0081 file on the PI software data carrier.



Establishing Communication via USB

- 1. Start PIMikroMove.
- → The Start up controller window opens with the Connect controller step.
- If the *Start up controller* window does not open automatically, select the *Connections > New...* menu item in the main window.
- 3. Select *E-872* in the controller selection field.
- 4. Select the *USB* tab on the right-hand side of the window.

Start Up Controller		
1. Connect controller		C-884 Controller
2. Select connected stages	C-884	Description C-884 SN 117012192
3. Start up axes	C-885 C-891	
	Version Info	Serial settings
		<u>H</u> elp Cancel

- 5. Select the connected E-872.401 in the USB tab.
- 6. Click *Connect* to establish communication.
- → If communication could not be established, look for a solution to the problem in the "<u>Troubleshooting (p. 124)</u>" chapter.
- → If communication was established successfully, PIMikroMove guides you through the configuration of the E-872.401 for the connected positioner, refer to "<u>Starting</u> <u>Motion (p. 47)</u>".

7.2.2 Establishing Communication via TCP/IP

Before communication is established, it can be necessary to adapt the interface parameters once, depending on the type of networking:

- Network with DHCP server: No adjustment of the factory settings of the E-872.401 interface parameters is required. You can begin with setup of the communication (p. 46).
- Network without DHCP server or direct connection of the E-872.401 to the PC's Ethernet socket: it is necessary to <u>adapt the E-872.401's interface parameters (p. 45)</u>. Make the necessary adaptations before establishing communication.

Requirements

- ✓ The E-872.401 is <u>connected (p. 42)</u> to the network or directly to the PC via the RJ45 Ethernet socket.
- ✓ If several E-872.401s are connected to the same network via their TCP/IP interfaces: You have the serial number of the E-872.401 ready with which the communication is to be established. The serial number can be found on the type plate of the E-872.401 (p. 13).
- ✓ The E-872.401 is <u>switched on (p. 43)</u>.
- ✓ The PC is switched on.
- ✓ The required software and drivers are installed (p. 35) on the PC.



✓ You have read and understood the manual for the PC software. The links to the software manuals are in the A000T0081 file on the PI software data carrier.

Adapting the TCP/IP Interface Parameters of the E-872.401

If you need to adapt the interface parameters of the E-872.401 to use the E-872.401 in a network, proceed as follows.

- 1. Establish communication between the E-872.401 and the PC via a different interface (e.g., USB (p. 43)).
- Select the *E-872.401 > Configure interface* menu item in the main window of PIMikroMove.
- → The Configure Interface window opens.
- 3. Select the TCP/IP tab in the Stored Settings area in the Configure Interface window.

urrent Setting	<u>js</u>	Stored Settings	
RS-232 TC	P/IP	RS-232 TCP/IP	
IP address:	172.17.72.85:50000	IP address: 192.168.0.75:50000	
IP mask:	255.255.0.0	IP mask: 255.255.0.0	
IP start:	DHCP 🔻	IP start: manual	
MAC address: 00:04:A3:39:E2:1C		MAC address:	
	Apply	Store	

Figure 5: "Configure Interface" window with examples of settings

- 4. Make the necessary adaptations in the *TCP/IP* tab in the *Stored Settings* area:
 - a) IP address field: E-872.401's IP address in format xxx.xxx.xxx.xxx:50000
 - b) IP mask mask: Network's subnet mask
 - c) IP start field: E-872.401's startup behavior

manual: Manually specified, static IP address is used

DHCP: IP address is assigned automatically by a DHCP server.

- 5. Save the changed settings to the nonvolatile memory of the E-872.401 by clicking Store.
- → The Store interface settings dialog opens.
- 6. Click Store settings in the Store interface settings dialog.
- → The dialog closes. The settings were stored in the nonvolatile memory of the E-872.401 .
- 7. Close the *Configure Interface* window.
- 8. Close the connection with the E-872.401 by selecting the *Connections* > *Close* > *E-872.401* menu item in the main window of PIMikroMove.
- 9. Switch the E-872.401 off and on again via its toggle switch.





A

CAUTION

Risk of crushing from unexpected motion!

When the communication between the E-872.401 and the PC is established via TCP/IP, the PC software offers all electronics for selection that are available in the same network. After selecting a E-872.401 for the connection, all commands are transmitted to this device. If the wrong device is selected, unexpected motion could be commanded and result in bruising injuries to the operating and maintenance staff of the positioner connected.

If several E-872.401 entries are displayed in the PC software, make sure that you select the right E-872.401.

Information

Communication via TCP/IP can fail if the network cable was connected to the Ethernet socket of the E-872.401 while the E-872.401 was switched on.

If communication cannot be established, switch the E-872.401 off, connect the network cable, and switch the E-872.401 on again.

Information

For communication via TCP/IP, the E-872.401 only has one unchangeable port (50000) available that cannot be used for more than one connection at a time.

Establishing Communication via TCP/IP

- 1. Start PIMikroMove.
- → The Start up controller window opens with the Connect controller step.
- If the Start up controller window does not open automatically, select the Connections > New... menu item in the main window.
- 3. Select *E-872* in the controller selection field.
- 4. Select the *TCP/IP* tab on the right-hand side of the window.
- → The software now searches the network for all controllers of the E-872 type.

Click Start Search if the search for E-872 type controllers does not start automatically.

→ Searching the network for the E-872 type of controller has started.

As long as the search is running, the **Connect** button is deactivated. If the search was successful, all E-872 controllers in the same network are displayed in the **PI Controllers** field.

Start Up Controller			
1. Connect controller	C-843	C-884 Controller	
2. Select connected stages 3. Start up axes	C-867	Hostname / TCP/IP Address Port 0 PI Controllers 0 Identification IP-Address Port C-684.60C SN 117012191 (4 connections - 3 listening) 192.168.90.137 50000 - 684.60.5 SN 117012191[1] - connected to 172.16.50.19 - 192.168.90.137 50000 C-684.60C SN 117012191[2] - listening on port 50000 - 192.168.90.137 50000 - 192.168.90.137 50000 - 684.60.5 SN 117012191[3] - listening on port 50000 - 192.168.90.137 50000 C-684.60C SN 117012191[4] - listening on port 50000 - 192.168.90.137 50000 - 192.168.90.137 50000 - 192.168.90.137 50000	
	C-884	* searching for controllers*	Start Search
	Version Info		Connect
			Help Cancel



- 5. Click the entry for your E-872.401 found in the list of controllers. This must show the status "listening on port 50000".
 - Do not select a controller that is already connected via TCP/IP (status "connected to ..."). Otherwise, an error message will be displayed as soon as you try to establish communication with this controller.
 - If several entries with the same name are shown, identify your E-872.401 on the basis of its nine-digit serial number.
 - If the E-872.401 is not displayed in the list of the controllers found, check the network settings. Consult your network administrator if necessary.
- → After a controller is selected in the list, its data is shown in the Hostname / TCP/IP Address and Port fields.

Start Up Controller				
1. Connect controller	C-843	C-884 Controlle RS-232 USB TCP/IP	r	
2. Select connected stages	C-863	Hostname / TCP/IP Address Port 0 PI Controllers		
3. Start up axes	C-867 C-877 C-877	Identification B: <u>CS04 607 SN 117012191 (4 connections - 3 listening</u>) C-C984.60C SN 117012191[1] connected to 172.16.50.19 C-884.60C SN 117012191[2] listening on port 50000 C-884.60C SN 117012191[3] listening on port 50000 C-884.60C SN 117012191[4] listening on port 50000 C-884.60C SN 117012191[4] listening on port 50000	IP-Address 192.168.90.137 5 192.168.90.137 5 192.168.90.137 5 192.168.90.137 5 192.168.90.137 5	Cont 00000 00000 00000 00000 00000 00000 0000
				Help Cancel

- 6. Click *Connect* to establish communication.
- → If communication could not be established, look for a solution to the problem in the "Troubleshooting (p. 124)" chapter.
- → If communication was established successfully, PIMikroMove guides you through the configuration of the E-872.401 for the connected positioner, refer to "<u>Starting</u> <u>Motion (p. 47)</u>".

7.3 Starting Motion

The procedure for PIMikroMove is described in the following.

After communication has been established between the E-872.401 and the PC, PIMikroMove guides you through the configuration of the E-872.401 for the positioner. It is then possible to run the first motion tests of the positioner.

Selection of the configuration steps offered by PIMikroMove is based on evaluation of the following parameter values in the volatile memory of the E-872.401:

- Stage Name (0x3C): The value is used by PIMikroMove as criterion for finding a suitable parameter set in the positioner databases.
- Stage Type (0x0F000100): The value was loaded from the ID chip of the connected positioner when the E-872.401 was switched on.

Possible configuration steps:

If the values of the parameters 0x3C and 0x0F000100 are not identical, the Stage Type Configuration window opens. A corresponding message is displayed when a suitable parameter set is not in the positioner database.



- If the value of parameter 0x0F000100 is empty, e.g., because the positioner does not have an ID chip, the Start up controller window switches to the Select connected stages step.
- When the values of the parameters 0x3C and 0x0F000100 are identical, PIMikroMove assumes that all parameters of the E-872.401 have already been adapted to the connected positioner. The *Start up controller* window goes directly to the *Start up axes* step.

The figures show the procedure for any electronics; the procedure for the E-872.401 corresponds.

Requirements

- ✓ PIMikroMove is installed on the PC (p. 35).
- ✓ You have installed the latest version of the PISTAGES3.DB database onto your PC (p. 35).
- ✓ If PI provided a custom positioner database for your positioner, the <u>dataset was imported</u> <u>into PIStages3 (p. 35)</u>.
- ✓ You have installed the positioner in the same way as it will be used in your application (corresponding load, orientation, and mounting).
- ✓ You have connected the positioner to the E-872.401 (p. 34).
- ✓ You have established communication between the E-872.401 and the PC with PIMikroMove (p. 43).

NOTICE



Selection of an incorrect positioner type!

Selection of an incorrect positioner type in the PC software can cause damage to the positioner.

Make sure that the positioner type selected in the PC software matches the positioner connected.

Starting motion with PIMikroMove

- 1. Load the parameter set from the positioner database into the E-872.401:
 - When the Stage Type Configuration dialog has opened: Click the Yes, configure for ... button to load the matching parameter set from a positioner database into the E-872.401.



■ If the **Select connected stages** step is displayed in the **Start up controller** window:



and the second	Stage database entries			Contro	ller axes		
1. Connect controller 2. Select connected stages 3. Start up axes	DEFAULT_STAGE DEFAULT_STAGE 6:3399120 6:3399120 6:3399120 6:3399130 6:3399140 6:3399140 6:3399150 6:3399160 6:3399160 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:3399180 6:339180 6:34918000 6:349180000000000000000000000000000	4 III	Assign -> Assign Type from ID Chip No Stage -> Reset Reload	Axis 1 2 3 4 5 6	Current stage type NOSTAGE NOSTAGE NOSTAGE NOSTAGE NOSTAGE NOSTAGE	Action <do change="" not=""> <do change="" not=""> <do change="" not=""> <do change="" not=""> <do change="" not=""> <do change="" not=""> <do change="" not=""></do></do></do></do></do></do></do>	
	Stage database not up to o	date? Do	wnload the <u>PI Update Finder</u> t	o get the	e latest version of data	abase DAT file(s).	<u></u> K

- a) Select the appropriate positioner type: Click either **Assign Type from ID Chip** or mark the matching positioner type in the **Stage database entries** list and click **Assign**.
- b) Confirm selection with **OK** to load the parameter settings for the selected positioner type from the positioner database into the E-872.401.
- → The Save all changes permanently? dialog is opened.



- 2. Specify how you want to load the parameter settings into the E-872.401 in the **Save all** *changes permanently*? dialog box:
 - Temporary load: Click Keep the changes temporarily to load the parameter settings into the volatile memory of the E-872.401. The settings are lost when the E-872.401 is switched off or rebooted.
 - Load as default values: Click Save all settings permanently on controller to load the parameter settings into the nonvolatile memory of the E-872.401. The settings are available immediately after switching on or rebooting the E-872.401 and do not need to be reloaded.
- → The Start up controller window with the Start up axes step is displayed.
- 3. Click *Close* to close the *Start up controller* window.
- → The main window of PIMikroMove opens.



PI PIMikroMove 2.27.0.1									
Connections E-872 (USB SN 0117052049) Tools View Help									
Axes Host macros									
	StageName	Open-Loop Analog Driving	<	Open-Loop Number of Steps	>	Open-Loop Remaining Steps	State	HALT	
1	N-470.110	0,000000	<	0	>	0	Ready	HALT	ø
2	N-470.110	0,000000	<	0	>	0	Ready	HALT	A*
3	N-470.43VY	0,000000	<	0	>	0	Ready	HALT	Α-
4	N-470.210	0,000000	<	0	>	0	Ready	HALT	9
E-872 (USE	3 SN 011705204	9):	_				_		
									a

- 4. Test the motion several times in step mode:
 - a) Enter the number of steps for the channel to move into the **Open-Loop Number of Steps** column.
 - b) Click one of the < or > arrows to do the motion in corresponding direction.



- 5. Run several motion tests in analog mode:
 - a) Enter a value in volts into the Open-Loop Analog Driving column for the analog output voltage.
 - b) Confirm with the Enter button.

7.4 Making Data Backups

Saving the Parameter Set to the Positioner Database

- 1. Click *Load and Save Parameters -> Save parameters to stage database...* in the expanded single axis window in PIMikroMove.
- → The Save Parameters as User Stage Type dialog opens.
- 2. Save the changed parameter values as new positioner type in the *Save Parameters as User Stage Type* dialog:
 - a) Leave the entry in the *Parameters of axis* field unchanged.
 - b) Enter the name for the new positioner type into the Save as field.
 - c) Click OK.
- → The new positioner type was saved to the PISTAGES3.DB database. The display of the connected positioner type was updated in the single axis window and in the main window of PIMikroMove.

7.4.1 Saving Parameter Values

The E-872.401 is configured via parameters, e.g., for adapting to the connected positioner. The parameter values can be saved to a text file so that they can be restored at a later time.



Information

Changing parameter values can cause undesirable results.

- Create a backup copy on the PC before changing the parameter settings of the E-872.401. You can then restore the original settings at any time.
- Create an additional backup copy with a new file name each time after optimizing the parameter values or adapting the E-872.401 to a particular positioner.

Parameter values saved in a text file on the PC can be loaded back to the E-872.401 in PIMikroMove or PITerminal. The **Send file...** button is available for this purpose in the send command window. Before loading into the E-872.401, the individual lines of the text files must be converted into command lines that contain the corresponding SPA or SEP commands.

Requirements

✓ You have established <u>communication between the E-872.401 and the PC with</u> <u>PIMikroMove (p. 43)</u> or PITerminal.

Saving Parameter Values in a Text File

- If you are using PIMikroMove, open the window for transmitting commands: Select *Tools Command entry* in the main window or press F4 on the keyboard.
- → After communication has been established, the main window is opened in PITerminal automatically and commands can then be sent.
- 2. Query the parameter values that you want backup.
 - If you want to save the parameter values from the volatile memory of the E-872.401: Send the SPA? command.
 - If you want to save the parameter values from the nonvolatile memory of the E-872.401: Send the SEP? command.
- 3. Click the **Save...** button.
- → The Save content of terminal as textfile window opens.
- 4. Save the queried parameter values to a text file on your PC in the *Save content of terminal as textfile* window.

7.4.2 Saving Controller Macros

For example, making backups of controller macros on the PC can be useful before updating the firmware.

The procedure for PIMikroMove is described in the following.

Saving Controller Macros on the PC

- 1. Select the *Controller macros* tab in PIMikroMove's main window.
- 2. Select the macros in the *Macros on controller* list that you want to back up to the PC:
 - Click the desired entry in the list to select a macro.
 - To select several macros, hold down the Shift button and click the desired entries in the list.
 - To deselect, click an open area in the list.

By selecting one or more macros, the 🤗 (Save selected macros to PC) button becomes active.

- 3. Save the selected macros on the PC:
 - a) Click the 🕮 button to open a directory selection window.
 - b) Select the directory on the PC where you want to save the macros.



c) Click Save.

→ The macros are saved as text files (<macro name>.txt) in the directory selected of the PC.

Loading Controller Macros from the PC to the E-872.401

- 1. Select the *Controller macros* tab in PIMikroMove's main window.
- 2. Load macros from the PC to the E-872.401:
 - ^{a)} Click the 🎐 button to open a file selection window.
 - b) Select the text files (<macro name>.txt) in the file selection window whose contents you want to load as a macro from the PC to the E-872.401.
 - c) Click Open.
- → For each selected text file (<macro name>.txt), the content is loaded as a macro <macro name> into the E-872.401.



8 E-872.401 Functions

8.1 Protective Functions of the E-872.401

The E-872.401 has functions that are intended to protect it against damage.

8.1.1 Protecting Against Overheating

If a certain internal temperature (70°C) is reached, the E-872.401 reacts as follows to protect the system against damage:

- The control value is set to zero for the axis concerned.
- Error code 603 is output.

Then restore the operational readiness (p. 53) for the E-872.401.

8.1.2 Restoring Operational Readiness

Restoring the E-872.401's Operational Readiness

- 1. Send the ERR? command to read out the error code.
- → ERR? resets the error code to zero during the query.
- 2. Check your system and make sure that the following points are fulfilled:
 - The axis can be moved without danger.
 - The E-872.401 has not overheated.

8.1.3 Commands

E		Page
ERR?	Get Error Number	87

8.1.4 Parameters

8.2 Digital Inputs and Outputs

The E-872.401's digital inputs and outputs are at the device's I/O connector, Phoenix Contact MC 1,5/14-GF-3,5-LR. The number of available input and output lines to the E-872.401 can be queried with the \underline{TIO} ? command.

Overview



The E-872.401's I/O connector with pin M0, M1, DIR, EN, CMD, and ST for digital input signals and pin ERR for digital output signals



8.2.1 Connecting the Digital Outputs

Tools and Accessories

- Suitable Phoenix Contact MC 1,5/14-ST-3,5 plug, with cable
- Device to be triggered having digital input for TTL signals

Information

Digital output signals are available on pin 10 of the E-872.401's I/O socket.

Connecting a Device to be Triggered

1. Connect a suitable device to the E-872.401's I/O socket with a Phoenix Contact MC 1,5/14-ST-3,5 plug.

8.2.2 Connecting the Digital Inputs

Tools and Accessories

- Suitable signal source
- Suitable Phoenix Contact MC 1,5/14-ST-3,5 plug, with cable

Information

Digital TTL input signals can be fed to the E-872.401 via pins 3, 4, 5, 6, 7, and 9 of the I/O socket.

Connecting a Digital Signal Source

1. Connect a suitable signal source to the E-872.401's I/O socket with a Phoenix Contact MC 1,5/14-ST-3,5 plug.

8.2.3 Digital Output Signals

The number of output lines available on the E-872.401 can be queried with the $\underline{\text{TIO}}$? command.

External devices can be triggered via the digital outputs of the E-872.401. The E-872.401's I/O socket has 1 digital output (ID 1) with the following function:

ID	Pin	Labeling	Function
1	10	ERR	Error signal
			■ High: Error (error code ≠ 0)
			Low: No error

8.2.4 Digital Input Signals

The number of input lines available on the E-872.401 can be queried with the <u>TIO</u>? command. The status of the digital input lines can be queried with the DIO? <u>command</u>. The E-872.401's I/O socket has 6 digital output lines (IDs 1 to 6) with the following functions:



ID	Pin	Labeling	Function
1	3	M0	Selecting the drive channel
2	4	M1	Refer to <u>"Switching Between the Drive Channels" (p. 26)</u>
3	5	DIR	 Direction signal for step mode High: Forward motion Low: Backward motion Refer to <u>"Triggering Motion" (p. 27)</u>
4	6	EN	Activating the drive in step mode Refer to <u>"Triggering Motion" (p. 27)</u>
5	7	CMD	 Selecting the command mode High: Commanding via digital I/O lines Low: Commanding via PC or HID Refer to <u>"Triggering Motion" (p. 27)</u>
6	9	ST	 Selecting the drive mode High: Linear mode Low: Step mode Refer to <u>"Drive Modes for Piezo Inertia Drives" (p. 23)</u>

Timing

The following graph shows the timing of the digital input signals.



Figure 6: Timing of the E-872.401's I/O interface

The evaluation of the signal state is carried out cyclically with the frequency set via $\underline{\mathbf{Q-Motion}}$ Frequency (0x1F000400).

For the EN signal, the following must be taken into account:

- A change in level from LOW to HIGH only takes effect one clock pulse later on the output. Instead, a change in level from HIGH to LOW takes effect directly on the output. Also with the other signals (DIR, M0, M1, CMD, ST), changes in level take effect directly on the output.
- The LOW pulse (T_L) should have a pulse width of at least **one** sampling rate.



The HIGH pulse (T_H) should have a pulse width of at least **twice** the sampling rate (T_S). Recommended pulse widths:

- To drive a single step, the following requirements should be fulfilled: T_H ≥ 2.0 × T_S T_L ≥ 1.0 × T_S
- To drive two steps, the following requirements should be fulfilled: $T_H \ge 3.0 \times T_S$ $T_L \ge 1.0 \times T_S$

8.2.5 Commands

D		Page
DIO?	Get Digital Input Lines	87
Т		Page
TIO?	Tell Digital I/O Lines	109

8.2.6 Parameters

0x1F000400	Q-Motion Frequency (Hz)	Frequency of the piezo voltage for open-loop operation of piezo inertia drives. Determines the velocity of a drive in open-loop operation. The value of this parameter must be chosen higher than the value of the 0x9 (Maximum Motor Output) parameter. Recommended: $0x1F000400 = 0x9 \times 1.25$
------------	----------------------------	---

8.3 Analog Input Signals

The E-872.401's analog input is available on the device's I/O socket, Phoenix Contact MC 1,5/14-GF-3,5-LR:

Pin	Labeling	Function
8	AN	Analog input voltage for linear mode (0 - 4.8 V) Vch = Van × 10
		$(V_{Ch} = output voltage of the channel, V_{AN} = analog input voltage)$

8.3.1 Connecting Analog Signal Sources

Overview



E-872.401's I/O socket with AN pin for analog input signals



Tools and Accessories

- Suitable signal source
- Suitable Phoenix Contact MC 1,5/14-ST-3,5 plug, with cable

Connecting an Analog Signal Source

1. Connect a suitable signal source to the E-872.401's I/O socket with a Phoenix Contact MC 1,5/14-ST-3,5 plug.

8.3.2 Commands

8.3.3 Parameters

8.4 Controlling with HID

HID (Human Interface Device) denotes an input or output device connected to the E-872.401 and is intended to be operated manually. Joysticks and gamepads are typical HIDs.HID control means controlling motion variables of a positioner's axis connected to the E-872.401 by displacing an axis of the HID.

8.4.1 How it Works

An HID's axis can control the following motion variables of a positioner's axis connected to the E-872.401:

- Velocity of the axis connected: Product from the lookup table value that corresponds to the current displacement of the HID's axis as well as the currently valid maximum velocity of the axis connected. The currently valid maximum velocity is specified by one of the following sources:
 - Maximum Motor Output parameter (0x9)
 - Displacement of an HID's axis

8.4.2 HID Control Configuration

Control of the axis/axes connected to the E-872.401 by the HID's axes is configured via the <u>HIA</u> command. The current HID control configuration can be queried with the <u>HIA?</u> command. The direction of motion of HID-controlled axes can be inverted via the <u>Invert</u> <u>Direction Of Motion For Joystick-Controlled Axis?</u> parameter (0x61).

Assigning a lookup table to an HID axis is done with the <u>HDT</u> command. The current lookup table assignments to HID axes can be queried with the <u>HDT</u>? command. The values in the lookup table are factors that are applied to the motion parameter to be controlled during HID control. The E-872.401's firmware gives a choice of two predefined lookup table types (linear and parabolic) and allows four customer-specific lookup tables to be filled with individual values. Lookup tables can be filled with values with the <u>HIT</u> command. <u>HIT</u>? queries the values of the points in the lookup tables.

Use the <u>HIN</u> command to activate/deactivate HID control of the axes connected to the E-872.401. The <u>HIN</u>? command queries the activation state of HID control. When HID control is deactivated, the target position is set to the current position of the controlled axis.

The <u>HIS</u>? command queries the properties of the HID's operating elements. The current status of the HID buttons can be queried with <u>HIB</u>? and the current displacement of HID axes with <u>HIE</u>?.



8.4.3 Programming HID Control

HID output units (e.g., buttons and LEDs) can be used for example, in controller macros to program HID control.

8.4.4 Connecting an HID

Overview



E-872.401's connector for a manually operated device such as a joystick or gamepad

Tools and Accessories

Suitable HID with type A USB connector such as a joystick or gamepad

Connecting an HID to the E-872.401

1. Connect the HID to the E-872.401's type A USB connector.

First of all, we recommend testing the HID's operating elements after connecting it to the E-872.401. If the response behavior of the HID's axes does not meet your requirements, it is possible to calibrate its axes.

HID control can be set up and activated after testing and optional calibration of the axes. The procedure for PIMikroMove is described in the following.

8.4.5 Testing the HID and Calibrating the Axes

The positioner does not need to be connected to the E-872.401 for testing the HID and calibrating its axes.

When calibrating the HID's axes in PIMikroMove, the appropriate lookup table must be selected. The parabolic lookup table allows for greater sensitivity when moving slowly. Lookup tables named "User Table" are intended to be filled with individual values.

Requirements

- ✓ PIMikroMove is installed on the PC (p. 35).
- ✓ PIMikroMove has established communication between the E-872.401 and the PC (p. 43).
- ✓ The E-872.401 has been connected to the HID (p. 58).

Testing the HID

- Open the window for configuring HID control via the *E-872.401 > Configure controller HIDevice(s)...* menu item in PIMikroMove's main window.
- → The Configure Human Interface Devices window opens.



Configure Huma	n Interface Devi	ces 💌					
Human Interface Devices connected to controller							
Device 1: USB Test and calibrate							
-Functions for co	ntroller axes						
1 - N-470.410	Velocity	<not active=""></not>					
	HID control						
	Invert direction						
2 - Q-522.100	Velocity	<not active=""></not>					
	HID control						
	Invert direction						
	<u></u> K	Cancel Apply					

- 2. Open the window for testing and calibrating the HID by clicking Test and calibrate....
- → The Test and Calibrate HIDevice window opens.
- 3. Select the *Test device* tab in the *Test and Calibrate HIDevice* window and test the HID's operating elements:
 - a) Move the HID's axes and at the same time, watch the status indicators in the *State of axes* area.
 - b) Press the HID's buttons and at the same time, watch the status indicators in the *State of buttons* area.
 - c) Enter various values into the fields in the *State of LEDs* area (if any) and at the same time, watch the behavior of the corresponding operating elements on the HID.
 - → Displacement of the HID's axes is shown in the State of axes area. Any of the HID'S buttons pressed are displayed green in the State of buttons area.
- 4. Depending on what is next, do the following:
 - If you want to calibrate the HID's axes directly afterwards, proceed as <u>described</u> <u>below (p. 59)</u>.
 - If you want to set up and activate HID control for the E-872.401 directly afterwards, close the *Test and Calibrate HIDevice* window with *Close* and continue as described in "<u>Setting up and Activating HID Control (p. 61)</u>".
 - If you do not want to make any further settings at this point, close Test and Calibrate HIDevice with Close and the Configure Human Interface Devices window with OK.

Calibrating HID Axes

- If necessary, open the window for configuring HID control via the *E-872.401 > Configure* controller HIDevice(s)... menu item in PIMikroMove's main window.
- → The Configure Human Interface Devices window opens.



Configure Human Interface Dev	rices 🔀						
Human Interface Devices connected to controller							
Device 1: USB Test and calibrate							
Functions for controller axes							
1 - N-470.410 Velocity	<not active=""></not>						
HID control							
Invert direction							
2 - Q-522,100 Velocity	<not active=""></not>						
HID control							
Invert direction							
<u>OK</u>	Cancel Apply						

- 2. If necessary, open the window for calibrating the HID and click the *Test and calibrate...* button.
- → The Test and Calibrate HIDevice window opens.
- 3. Select the Calibrate axes tab in the Test and Calibrate HIDevice window.
- 4. Select the respective lookup tables to be used for the HID's axes via the selection fields in the *Calibrate axes* tab.
- → The example shows that a user-defined lookup table was selected for axis 1. The respective predefined parabolic lookup table was retained for axes 2 and 3.

Test and Calibrate HIDevice	—
Test device Calibrate axes	
Axis 1 - X: User Table 101	▼ Calibrate
Axis 2 - Y: Table 2 (paraboli	c) 🔻 Calibrate
Axis 3 - Z: Table 2 (paraboli	c) 🔻 Calibrate
	Close

5. If you have selected a user-defined lookup table and want to fill the table with values:
a) Click the corresponding *Calibrate...* button to open the *Controller Joystick Calibration* window.



Controller Joystick Cal	ibration				X
Move the joystick in all o	directions to the Afte	e maximum erwards cli	position and ick OK.	d then back to cent	er position.
Axis: X -0.000000	Dead band:	,	0	5,0 % 🔲 Parab	olic curve
				ок <u>с</u>	ancel

- b) Move the HID's axes to all extreme positions. The custom lookup table values are determined in this way.
- c) Let go of the axis.
- d) If you want to change the neutral area of the axis (i.e., the area around the center position of the axis where no change in the controlled motion variable is triggered), set the *Dead band* slider accordingly.
- e) If the values in the user-defined lookup table are to describe a parabolic waveform, click the *Parabolic curve* checkbox.
- f) Click **OK** in the **Controller Joystick Calibration** window to copy the appropriate values from the lookup table.
- → The lookup table values are written to the E-872.401's volatile memory. The writing progress is indicated in a separate window. The window for the writing process and the Controller Joystick Calibration window automatically close after the writing process has finished.
- 6. Close the Test and Calibrate HIDevice window with Close.
- 7. Depending on what is next, do the following:
 - If you want to set up and activate HID control for the E-872.401 directly afterwards, continue as described in "Setting up and Activating HID Control (p. 61)".
 - If you want to save the lookup table assignments to the HID's axes and the content of user-defined lookup table to the E-872.401's nonvolatile memory directly afterwards, close the Configure Human Interface Devices window with OK and continue as described in "Saving the Configuration of HID Control Permanently (p. 63)".
 - If you do not want to make any further settings at this point, close the Configure Human Interface Devices window with OK.

8.4.6 Setting Up and Activating the HID Control

The following motion variables for the axes connected to the E-872.401 can be controlled by HID:

Velocity - Velocity for motion of the axis

Before activating HID control, the following steps are recommended:

- Testing the HID
- Calibrating the HID axes

See "Testing the HID and Calibrating the Axes (p. 58)" for a description of these steps.

Requirements

- ✓ You have <u>connected the HID to the E-872.401 (p. 58)</u>.
- ✓ All devices are still ready for operation.



Setting Up and Activating HID Control

- If necessary, open the window for configuring HID control via the *E-872.401 > Configure* controller HIDevice(s)... menu item in PIMikroMove's main window.
- → The Configure Human Interface Devices window opens.

Configure Huma	n Interface Devi	ces 💽
Human Interface Devices connected to controller		
Device 1: USB	Test and calibr	ate
Functions for controller axes		
1 - N-470.410	Velocity	<not active=""></not>
	HID control	
	Invert direction	
2 - Q-522.100	Velocity	<not active=""></not>
	HID control	
	Invert direction	
	<u>O</u> K	<u>Cancel</u> <u>Apply</u>

- 2. Make the following respective settings for the E-872.401's axes displayed in the *Functions for controller axes* area:
 - a) Select the HID's axis in the corresponding field that is to be used for the motion variable to be controlled.
 - b) Activate HID control by clicking the HID control checkbox.
 - c) If the direction of motion is to be inverted during HID control, click the *Invert direction* checkbox.
 - → In the example illustrated, the E-872.401's X axis is connected to channel 1 and its Y axis is connected to channel 2 of HID 1 (USB joystick) and HID control is activated.

Configure Huma	in Interface Devic	es 💌
Human Interface Devices connected to controller		
Device 1: USB	Test and calibra	ate
Functions for co	ntroller axes	
1 - N-470.410	Velocity	Device 1 (USB), Axis 1 (X) 🔹
	HID control Invert direction	
2 - Q-522.100	Velocity	<not active=""></not>
	HID control Invert direction	<pre><not active=""> Device 1 (USB), Axis 1 (X) Device 1 (USB), Axis 2 (Y) Device 1 (USB), Axis 3 (Z)</not></pre>
	<u>о</u> к	Cancel Apply

- Click the *Apply* button in the *Configure Human Interface Devices* window to activate the settings.
- 4. Send the settings for setting up HID control to the E-872.401 by clicking the **OK** button.



- → The Configure Human Interface Devices window closes.
- 5. Make sure that servo mode for the E-872.401's axes is switched on in PIMikroMove (e.g., by clicking the **Servo** checkbox in the **Axes** tab in PIMikroMove's main window).
- → The E-872.401's axes can now be controlled by the HID according to the settings made.
- If you want to save the new settings for HID control to the E-872.401's nonvolatile memory, continue as described in "<u>Saving the Configuration of HID Control</u> <u>Permanently (p. 63)</u>".

Saving the Configuration of the HID Control Permanently

Select the *E-872.401* > *Save parameters to non-volatile memory* menu item in PIMikroMove's main window.

- → The Save Parameters to Non-Volatile Memory dialog opens.
- 1. Enter either the password HID in the selection field of the *Save Parameters to Non-Volatile Memory* dialog, or select the *Settings of HDT, HIA, HIT (HID)* entry.
- 2. Click **OK** to save and to close the dialog.

8.4.7 Commands

н		Page
HDT	Set HID Default Lookup Table	87
HDT?	Get HID Default Lookup Table	88
HIA	Configure Control Done By HID Axis	89
HIA?	Get Configuration Of Control Done By HID Axis	90
HIB?	Get State Of HID Button	90
HIE?	Get Deflection Of HID Axis	91
HIN	Set Activation State For HID Control	91
HIN?	Get Activation State Of HID Control	91
HIS?	Get Configuration Of HI Device	92
HIT	Fill HID Lookup Table	93
HIT?	Get HID Lookup Table Values	93

8.4.8 Parameters

0x9	Maximum Motor Output	Maximum control value for driving an axis respectively a channel. See the response to HPA? for possible values
0x61	Invert Direction Of Motion For Joystick- Controlled Axis?	Inverts the direction of motion for HID-controlled axes. 0 Direction of motion not inverted (default) 1 Direction of motion inverted

8.5 Controller Macros

The E-872.401 can save and process command sequences as macros.



The following functionalities make macros an important tool in many application areas:

- Several macros can be stored at the same time.
- Any macro can be defined as the startup macro. The startup macro runs each time the E-872.401 is switched on or rebooted.
- Processing a macro and stopping a macro can be linked to conditions. In this way, loops can be realized as well.
- Macros can call up themselves or other macros at several nesting levels.
- Variables can be set for the macro and in the macro itself and used in different operations.
- Input signals can be evaluated for conditions and variables.

Working with Macros

- The E-872.401 can save up to 32 macros simultaneously.
- Up to 10 nesting levels are possible in macros.
- Local and global variables can be used in macros.
- A macro is overwritten if a macro with the same name is rerecorded.
- For working with controller macros, it is recommended to use the *Controller macros* tab in PIMikroMove. There you can conveniently record, start, and manage controller macros.
- ThePITerminal or the PIMikroMove's Command entry window can be used for entering commands, e.g., for starting macros.

GCS commands in macros

Basically all GCS commands can be included in a macro. Exceptions:

- RBT for rebooting the E-872.401
- MAC BEG and MAC END for macro recording
- MAC DEL for deleting a macro

Query commands can be used in macros in conjunction with the CPY, JRC, MEX, and WAC commands. Otherwise they have no effect because macros do not send responses to interfaces.

8.5.1 Recording Macros

The MAC BEG and MAC END commands may not be specified when macros are recorded in the *Controller macros* tab in PIMikroMove.

A macro is overwritten if a macro with the same name is rerecorded.

If you record a macro on a controller whose address differs from 1, pay attention to the following when entering commands that need to be an integral part of the macro:

- If you are working with PITerminal and have established communication via the Connect... button, the target address must typed into every command line.
- If you are working with PIMikroMove or have established PITerminal communication via the GCS DLL... button, the target address is sent automatically and may not be typed in.

Recording macros for PITerminal and PIMikroMove is described in the following.

- 1. Start macro recording.
 - If you are working with PITerminal or in the Command entry in the PIMikroMove's window: Send the MAC BEG macro name command where "macro name" is the name of the macro.
 - If you are working in PIMikroMove in the Controller macros tab: Click the Create new empty macro icon to create a tab for entering a new macro.
- 2. Enter the commands to be included in the "macro name macro" line-by-line using the normal command syntax.
 - Macros can call up themselves or other macros at several nesting levels.
- 3. End the macro recording.
 - If you are working with PITerminal or in PIMikroMove's Command entry window: Send the MAC END command.



- If you are working in PIMikroMove in the Controller macros tab: Click the Send macro to controller symbol and enter the macro name into a separate dialog window.
- → The macro has been stored in the nonvolatile memory of the E-872.401.
- 4. If you want to check in PITerminal or in the PIMikroMove's **Command entry** window whether the macro was recorded correctly:
 - a) Query which macros are saved in the E-872.401 by sending the MAC? command.
 - b) Query the content of "macro name" with the MAC? macro name command.
- 5. If you want to check PIMikroMove's *Controller macros* tab to see whether the macro was recorded correctly:
 - a) Click the Read list of macros from controller icon.
 - b) Mark the macro to be checked in the list on the left-hand side and click the *Load* selected macro from controller icon.

Example macro: Move the axes one after the other

Axes 1 and 2 are to move 5000 steps respectively in a positive direction one after the other. A macro is recorded for this purpose. The macro starts the motion and waits until the axis has completed motion.

Record the macro by sending:

MAC BEG macrol OSM 1 5000 WAC OSN? 1 = 0 OSM 2 5000 WAC OSN? 2 = 0 MAC END

8.5.2 Running the Macro

All commands can be sent from the command line while a macro is running on the controller. The macro content and motion commands received from the command line can overwrite each other.

It is not possible to run several macros simultaneously. Only one macro can be run at a time. You can link the conditions for running the macro with the <u>JRC</u> and <u>WAC</u> commands. The commands must be included in the macro.

A delay time for running the macro can be specified with <u>DEL</u>.

Variables can be used in macros. Setting is done via the <u>VAR</u> command and querying variable values via <u>VAR?</u>. Returns on query commands can be copied into variables with <u>CPY</u>. In the following, PITerminal or PIMikroMove's *Command entry* window is used to enter commands.

- 1. If the macro should continue running despite an error: Set the <u>Ignore Macro Error?</u> parameter (0x72) accordingly: Send the SPA 1 0x72 Status command where "Status" can take the value 0 (stop macro on error [standard]) or 1 (ignore macro error).
- 2. Start the macro:
 - If the macro is to be run once, send <u>MAC START</u> macro name string where "macro name" is the name of the macro.
 - If the macro is to be run n times, send the <u>MAC NSTART</u> macro name n string command where "macro name" is the name of the macro and "n" indicates the number of times to be run.

Specifying "string" is optional and stands for the values of local variables. The values only need to be specified when the macro contains corresponding local variables. The sequence of the values in the input must correspond to the numbering of the appropriate



local variables, starting with the value of the local variable 1. The individual values must be separated from each other by spaces.

- 3. If you want to check that the macro is running:
 - Query whether a macro is running on the controller by sending the <u>#8</u> command.
 - Query the name of the macro currently running on the controller by sending the <u>RMC</u>? command.

8.5.3 Stopping the Macros

Stopping the macro can be linked to a condition with the \underline{MEX} command. The command must be included in the macro.

- 1. Stop the macro with the $\frac{#24}{2}$ or <u>STP</u> commands.
- 2. If you want to check whether an error occurred while the macro was running, send the <u>MAC ERR?</u> command. The response shows the last error that has occurred.

8.5.4 Configuring a Startup Macro

Any macro can be defined as the startup macro. The startup macro runs each time the E-872.401 is switched on or rebooted.

Deleting a macro does **not** delete its selection as a startup macro.

- 1. Set a macro as the startup macro:
 - Send the <u>MAC DEF</u> macro name command to set a macro as startup macro where "macro name" is the name of the macro.
 - If you want to cancel the selection of the startup macro and do not want to define another macro as the startup macro, send MAC DEF only.
- 2. Query the name of the currently defined startup macro by sending the <u>MAC_DEF?</u> command.

8.5.5 Deleting Macros

A macro cannot be deleted while it is running.

Deleting a macro does not delete its selection as a startup macro.

1. Delete a macro with the <u>MAC DEL</u> macro name command where "macro name" is the name of the macro.

8.5.6 Saving and Loading Macros

For example, making backups of controller macros on the PC can be useful before updating the firmware.

The use of the *Controller macros* tab in PIMikroMove is recommended for backing up and loading controller macros.

Saving and loading controller macros with PIMikroMove is described in the following.

Saving Controller Macros on the PC

- 1. Select the *Controller macros* tab in PIMikroMove's main window.
- 2. Select the macros in the *Macros on controller* list that you want to back up to the PC:
 - Click the desired entry in the list to select a macro.
 - To select more than one macro, press and hold down the shift key and click the desired entries in the list.
 - To deselect, click an open area in the list.
- → The Save selected macros to PC button becomes active when selecting one or more macros.



ð

- 3. Save the selected macros on the PC:
 - a) Click the 🎐 button to open a directory selection window.
 - b) Select the directory on the PC where you want to save the macros.
 - c) Click Save.
- → The macros are saved as text files (<macro name>.txt) in the selected directory of the PC.

Loading Controller Macros from the PC to the E-872.401

- 1. Select the *Controller macros* tab in PIMikroMove's main window.
- 2. Load macros from the PC to the E-872.401:
 - ^{a)} Click the ᆋ button to open a file selection window.
 - b) Select the text files (<macro name>.txt) in the file selection window whose contents you want to load as a macro from the PC to the E-872.401.
 - c) Click Open.
- → For each selected text file (<macro name>.txt), the content is loaded as a macro <macro name> into the E-872.401.

8.5.7 Example Macros

Example macro: Move the axes back and forth one after the other

The MOVWAI macro moves axes 1 and 2 one after the other. It moves the respective axes and waits until motion is completed.

The MOVLR macro calls the MOVWAI macro, first for motion in a positive direction, then for motion in a negative direction. The MOVLR macro uses a variable where the number of motion steps is defined. This variable is passed to the MOVWAI macro when called. Create the variable either in the MOVLR macro or each time the E-872.401 is rebooted.

Creating a variable:

VAR STEPS 5000

MOVLR macro:

MAC START MOVWAI \${STEPS} MAC START MOVWAI -\${STEPS}

MOVWAI macro:

OSM 1 \$1 WAC OSN? 1 = 0 OSM 2 \$1 WAC OSN? 2 = 0

Calling:

MAC START MOVLR

Example macro: Activate HID control for axis The following macro activates HID control for axis 2.



Command	Explanation
HIN 2 0	Deactivate HID control for axis 2
HIA 2 0 0 0	Delete current configuration of HID control for axis 2
HIA 2 3 1 2	Set HID configuration for axis 2: Control velocity (3) via HID 1, HID axis 2
SPA 2 0x61 0	Set the value of the parameter $0x61$ (invert direction of motion?) for axis 2 to 0 (do not invert)
HIN 2 1	Activate HID control for axis 2

8.5.8 Commands

#		Page
#24	Stop All Axes	84
#8	Query If Macro Is Running	84
С		Page
CPY	Copy Into Variable	85
D		Page
DEL	Delay The Command Interpreter	86
J		Page
JRC	Jump Relatively Depending On Condition	100
М		Page
MAC BEG	Call Macro Function: BEG	101
MAC DEF	Call Macro Function: DEF	101
MAC DEF?	Call Macro Function: DEF?	101
MAC DEL	Call Macro Function: DEL	101
MAC END	Call Macro Function: END	101
MAC ERR?	Call Macro Function: ERR?	102
MAC NSTART	Call Macro Function: NSTART	102
MAC START	Call Macro Function: START	102
MAC?	List Macros	103
MEX	Stop Macro Execution Due To Condition	104
R		Page
RBT	Reboot System	106
RMC?	List Running Macros	106
S		Page
STP	Stop All Axes	109
V		Page
VAR	Set Variable Value	110
VAR?	Get Variable Values	110



W		Page
WAC	Wait For Condition	111

8.5.9 Parameters

0x72 Ignore Macro Error	 Ignore macro error? 0 Stop macro on error (default) 1 Ignore error
-------------------------	--

8.6 Working with GCS Commands

8.6.1 GCS Command Syntax

Notation

The following notation is used to define the GCS syntax and to describe the commands:

<>	Angle brackets indicate an argument of a command, can be an element identifier or a command-specific parameter.
[]	Square brackets indicate an optional entry
{}	Braces indicate repeated specifications, i.e., it is possible to access more than one element (e.g., several axes) in one command line.
L _F	Line Feed (ASCII character 10), default termination character (character at the end of a command line)
_	Space (ASCII character 32), empty space
\rightarrow	Horizontal tab (ASCII character 9)
#	Single-character command, "" indicates the ASCII character in decimal notation, e.g., #7 for ASCII character *.

Syntax

A GCS command consists of three letters, e.g., CMD, or three letters and a question mark, e.g., CMD?.

Exceptions:

- Single-character commands consist of only one ASCII character. In this manual, the ASCII character is written as combination of # and the character code in decimal format, e.g., as #24.
- *IDN? (for GPIB compatibility).

The command mnemonic is not case sensitive. The command mnemonic and all arguments (e.g., axis and channel identifiers, parameters etc.) must be separated from each other by a space (_). The command line ends with the termination character (${}^{\circ}$).

- CMD[{{_}<Argument>}]
- CMD?[{{_}<Argument>}]

Exception:

• Single-character commands are not followed by a termination character. However, the response to a single-character command is followed by a termination character.



More than one command mnemonic per line is not allowed. Several groups of arguments following a command mnemonic are allowed.

When all arguments are optional and not specified, the command is executed for all possible argument values.

Sending a Command

The axis identified with "1" is to be moved to position 10.0. The unit depends on the controller (e.g., μm or mm).

1. Send

MOV_1_10.04

→ Axis 1 moves to position 10.0 (physical unit).

Sending the Command with Several Arguments

Two axes are to be moved that are connected to the same controller: The axis with axis identifier "1" is to be moved to position 17.0 and the axis with axis identifier "2" is to be moved to position 2.05. The unit depends on the controller (e.g., μ m or mm).

Information

When a part of a command line cannot be executed, the line is not executed at all.

1. Send

```
MOV_1_17.3_2_2.05
```

→ Axis 1 moves to position 17.0 (physical unit), axis 2 moves to position 2.05 (physical unit).

Sending commands without arguments

The position of all axes is to be queried.

- 1. Send POS?
- → Outputs the position of all axes. The response syntax is as follows: {[<Argument>[{_<Argument>}]"="]<Wert>_५} [<Argument>[{_<Argument>}]"="]<Wert>५ (for the last line)

8.6.2 Variables

The electronics support variables for more flexible programming. While global variables are always available, local variables are only valid for a specified macro. Typically, variables are used when working with macros.

Variables are in volatile memory (RAM) only. The variable values are the STRING data type. The following conventions apply to variable names:

- Variable names may not contain special characters (especially not "\$").
- The maximum number of characters is 8.
- Names of global variables can consist of characters A to Z and 0 to 9. They must begin with a letter.
- Names of local variables must not contain alphabetic characters. Possible characters are 0 to 9.
- The variable name can also be specified via the value of another variable.
- If the value of a variable is to be used, the notation must be as follows:
- The variable name must be preceded by the dollar sign (\$).
- Variable names consisting of multiple characters must be put in braces.

If the variable name consists of a single character, no braces are necessary.



Note that when braces are omitted for multicharacter variable names, the first character after the "\$" is interpreted as the variable name.

8.7 Adapting Settings

The properties of the E-872.401 and the mechanics connected are stored in the E-872.401 as parameter values.

The parameters can be divided into the following categories:

- Protected parameters whose default settings cannot be changed
- Parameters that can be set by the user to adapt to the application

Write permission for the parameters is determined by command levels.

Each parameter is in the E-872.401's volatile and nonvolatile memory. The values in the nonvolatile memory are loaded to the volatile memory as default values when switching on or rebooting the E-872.401. The values in the volatile memory determine the current behavior of the system.

The designation "Active Values" is used for the parameter values in the volatile memory and "Startup Values" is used for the parameter values in the nonvolatile memory in the PC software from Pl.

Use the HPA? command to query the parameters available in the E-872.401.

NOTICE

Unsuitable parameter settings!

The values in the nonvolatile memory are loaded to the volatile memory as default values when switching on or rebooting the E-872.401 and take effect immediately. Unsuitable parameter settings can cause damage to the mechanics.

- ► Change parameter values only after careful consideration.
- Save the current parameter values to the PC before you make changes in the nonvolatile memory.

8.7.1 Parameter Commands

The following general commands are available for changing parameters:

Command	Function
CCL	Change to another command level
CCL?	Query active command level
HPA?	Query available controller parameters
<u>SEP</u>	Modify parameter value in nonvolatile memory
SEP?	Query parameter values from the nonvolatile memory
<u>SPA</u>	Modify parameter value in volatile memory
SPA?	Query parameter values from the volatile memory
<u>WPA</u>	Copy a current parameter value from the volatile to the nonvola- tile memory. Here it is used as a default value.

8.7.2 Saving Parameter Values in a Text File

Overview

The E-872.401 is configured via parameters, e.g., for adapting to the mechanics. Changing parameter values can cause undesirable results.



- Create a backup copy on the PC before changing the parameter settings of the E-872.401. You can then restore the original settings at any time.
- Create an additional backup copy with a new file name each time after optimizing the parameter values or adapting the E-872.401 to specific mechanics.

Parameter values saved in a text file on the PC can be loaded back to the E-872.401 in PIMikroMove or PITerminal. The *Send file...* button is available for this purpose in the send command window. Before loading into the E-872.401, the individual lines of the text files must be converted into command lines that contain the corresponding SPA or SEP commands.

Requirements

✓ You have <u>established communication between the E-872.401 and the PC (p. 43)</u> with PIMikroMove or PITerminal.

Saving Parameter Values in a Text File

- If you are using PIMikroMove, open the window for transmitting commands: Select *Tools > Command entry* in the main window or press F4 on the keyboard.
 After communication has been established, the main window is opened PITerminal
 automatically and commands can be sent.
- 2. Query the parameter values that you want to create a backup.
 - If you want to save the parameter values from the volatile memory of the E-872.401: Send the <u>SPA?</u> command.
 - If you want to save the parameter values from the nonvolatile memory of the E-872.401: Send the <u>SEP?</u> command.
- 3. Click the *Save...* button.
- 4. The Save content of terminal as textfile window opens.
- 5. Save the queried parameter values to a text file on your PC in the *Save content of terminal as textfile* window.

8.7.3 Changing Parameter Values

Overview

The following procedure is generally recommended for changing parameter values:

- 1. Change the parameter values in the volatile memory.
- 2. Check whether the E-872.401 works correctly with the changed parameter values. If so:
 - Write the changed parameter values into the nonvolatile memory.
 If not:
 - Change and check the parameter values in the volatile memory again.

Requirements

- ✓ If you want to change parameter values in the E-872.401's nonvolatile memory: You have saved the E-872.401's parameter values in a text file on the PC (p. 71).
- ✓ You have <u>established communication between the E-872.401 and the PC (p. 43)</u> with PIMikroMove or PITerminal.

Information

Write access for the parameters of the E-872.401 is defined by command levels. After the controller is switched on or rebooted, the active command level is always 0. On command levels > 1, write access is only available to PI service personnel.


Changing Parameter Values

- 1. If you want to change the axis-related parameters of the E-872.401:
 - a) Open the parameter window for the connected positioner in the PIMikroMove's main window by clicking the corresponding line in the *Drive channels* tab with the right mouse button and selecting *Show drive channel parameter window* in the context menu.
 - b) If the parameter to be modified is not included in the list on the right-hand side of the window, click *Configure View > Select parameters...* and add it to the list. You can also display certain groups of parameters or all axis-related parameters.
- → The list of channel-related parameters is displayed.

Parameter pannel channel: 1						
Load and Save Parameters \equiv Config	ure View		Ξ			
Name	ID	Active Value	CCL			
Maximum Motor Output	0x9	2000	0			
Is Rotary Stage?	0x13	yes (1) 💌	0			
Stage Name (max. 20 characters)	0x3C	N-470.410	0			
Invert Direction Of Motion For Joystick-Controlled Axis?	0x61	no (0) 💌	0			
Stage Type	0xF000100	Â	2			
Stage Serial Number	0xF000200	Â	2			
Stage Assembly Date	0xF000300	Â	2			
Stage HW Version	0xF000400	0 🖻	2			
Q-Motion Upper Supply Voltage (V)	0×1F000000	80.000000 间	1			
O-Motion Lower Supply Voltage (V)	0×1F000100	0.000000 间	1			

- 2. If you want to change the system-related parameters of the E-872.401:
 - a) Open the window for the system-related parameters of the E-872.401 in the main window of PIMikroMove by selecting *E-872.401 > Show system parameters* in the menu.
- → The list of system-related parameters is displayed.

	2 on USB SN 0117023	916			
Lo	ad and Save Parameter	rs ≡ C	Configure View		
	Name	ID	Active Value	CCL	
[Ignore Macro Error?	0x72	no (0) 🔽	0	
	Controller Device S/N	0xD000000	0 间	2	
	Q-Motion Delay (ms)	0x1F000701	1000.000000 间	1	

3. If you want to change the parameter values in the E-872.401's **volatile memory**, you have the following options:



- a) Type the new parameter values into the corresponding input field in the *Active Value* column and press the enter key on the PC's keyboard or click the mouse button outside of the input field.
- → The modified parameter value is transferred to the E-872.401's volatile memory.
- b) Click Load and Save Parameters -> Load all startup parameters of the axis / system from controller.
- → The values of all channel-related / system-related parameters are loaded from the E-872.401's nonvolatile memory.
- c) Click *Load and Save Parameters > Load parameters from stage database...* in the parameter window.

You can use *Load and Save Parameters > Reload parameters from stage database...* to reload the currently loaded parameter set.

- → A selected parameter set for channel A is loaded from the positioner database.
- 4. If you want to change parameter values in the E-872.401's **nonvolatile memory**, you have the following options:
 - a) Type the new parameter value into the corresponding input field in the list's *Startup Value* column and press the enter key on the PC's keyboard or click the mouse button outside of the input field.
 - → The changed parameter value is transferred to the E-872.401's volatile memory.
 - b) Click Load and Save Parameters -> Save all currently active axis / system parameters as startup parameters to controller.

You can skip parameters that do not have write access on the current command level.

→ The values of all channel-related / system-related parameters are written from the E-872.401's volatile memory to the nonvolatile memory.

If a parameter value in the volatile memory (*Active Value* column) is different from the parameter value in the nonvolatile memory (*Startup Value* column), the line in the list is highlighted in color.

8.7.4 Creating or Changing Parameter Sets for Positioners

Overview

You can create and edit new parameter records in the PIStages3 database. This can be required in the following cases, for example:

- You want to operate a positioner with different servo control parameter settings than the one from the default parameter set.
- You want to adapt the soft limits of the positioner to your application.
- You have a custom positioner.

Possibilities for creating and editing parameter sets in the PISTAGES3.DB database:

- You can create a new positioner type easily by changing an existing parameter set in PIMikroMove and saving it under a new name.
- You can open and edit the positioner database directly with the PIStages3Editor.

The following describes how to use PIMikroMove to create and change a parameter set for a positioner.

Requirements

✓ You have installed the latest version of the PISTAGES3.DB database onto your PC.

- ✓ If PI provided a custom positioner database for your positioner, the dataset was imported into PIStages3.
- ✓ PIMikroMove has established communication between the E-872.401 and the PC.



Creating a Parameter Set for Positioners

- Select the *E-872.401 > Select connected stages...* menu item in the main window of PIMikroMove.
- → The Start up stages/axes for E-872.401 window opens and the Select connected stages step is active.
- 2. Select an appropriate type of positioner during the Select connected stages step:a) Click Assign Type from ID Chip.
 - or
 - a) Highlight the positioner in the Stage database entries list.

b) Click Assign.

Start up stages/axes	for E-872 on USB SN 011702	3916					X
-hte	Stage database entries			Control	ller axes		
	N-470.230	*		Axis	Current stage type	Action	
Select connected	N-470.23U			1	N-470.410	<do change="" not=""></do>	
stages	N-470.230 N-470.23V			2	Q-522.100 NOSTAGE	<do change="" not=""></do>	
	N-470.23VY N-470.410		Assign ->	4	NOSTAGE	<do change="" not=""></do>	
	N-470.410Y N-470.41U		Assign Type from ID Chip				
	N-470.41UY	=					
	N-470.41VY		No Stage ->				
	N-470.420 N-470.420Y						
	N-470.42U N-470.42UY		Reset				
	N-470.42V N-470.42VY		Reload				
	N-470.430						
	N-470.43U						
	N-470.430Y N-470.43V						
	N-470.43VY Q-521.100	-		•		m	•
	Stage database not up to d	ate?	Start the <u>PI Update Finder</u> to ge	t the la	test version of the sta	ge database.	OK
						Help	Close

c) Confirm the selection with OK.

→ The Save all changes permanently? dialog is opened.



- 3. Click *Keep the changes temporarily* in the *Save all changes permanently* dialog to load the parameter settings into the volatile memory of the E-872.401.
- → The Start up stages/axes window changes to the Start up axes step.
- 4. Click Close to close the Start up stages/axes window.



 Open the parameter window for the selected positioner type in the PIMikroMove's main window by clicking the corresponding line in the *Drive channels* tab and selecting the *Show drive channel parameter window* in the context menu.

Show drive channel parameter window
Clear Error
Select connected stages Save parameters as User Stage type Reload settings from stage database
Change number of displayed decimal places

6. Enter new values for the parameters to be changed:

Par	Parameter pannel channel: 1							
L	oad and Save Parameters \equiv Config	igure View						
	Name	ID	Active Value	CCL				
	Maximum Motor Output	0x9	1800	0				
	Is Rotary Stage?	0×13	yes (1) 🔽	0				
	Stage Name (max. 20 characters)	0x3C	N-470.410	0				
	Invert Direction Of Motion For Joystick-Controlled Axis?	0x61	no (0) 🔽	0				
	Stage Type	0×F000100	â	2				
	Stage Serial Number	0×F000200	â	2				
	Stage Assembly Date	0xF000300	â	2				
	Stage HW Version	0xF000400	0 向	2				
	Q-Motion Upper Supply Voltage (V)	0×1F000000	80.000000 🔒	1				
	Q-Motion Lower Supply Voltage (V)	0×1F000100	0.000000 向	1				

- a) If the parameter to be modified is not included in the list on the right-hand side of the window, click Configure view > Select parameters... and add it to the list. You can also display certain groups of parameters or all channel-related parameters.
- b) Type the new parameter value into the corresponding input field in the *Active Value* column of the list.
- c) Press the Enter key on the PC keyboard or click outside the input field with the mouse to transfer the parameter value to the volatile memory of the controller. Note: If a parameter value in the volatile memory (*Active Value* column) is different to the parameter value in the nonvolatile memory (*Startup Value* column), the line in the list is highlighted in color.
- 7. Click Load and Save Parameters > Save parameters to stage database....



Load and Save Parame≡ Configure View ≡
Load all startup parameters of the axis from controller
Save all currently active axis parameters as startup parameters to controller
Load parameters from stage database
Save parameters to stage database
Reload parameters from stage database
Refresh parameter view
Denominator OF the Counts-Per OXP

- 8. The Save Parameters as User Stage Type dialog opens.
- 9. Save the changed parameter values as new positioner type in *Dialog Save Parameters as User Stage Type*:
 - a) Leave the entry in the *Parameters of axis* field unchanged.
 - b) Enter the name for the new positioner type into the Save as field.
 - c) Click OK.
- → The new positioner type was saved in the positioner database. The displayed positioner type was updated in PIMikroMove. The new positioner type is also available immediately for selection in the Select connected stages step.

Changing a Positioner's Parameter Set

- Select the *E-872.401 > Select connected stages...* menu item in the main window of PIMikroMove.
- → The Start up stages/axes for E-872.401 window opens and the Select connected stages step is active.
- 2. Select a positioner type that you created during the **Select connected stages** as described above:
 - a) Click Assign Type from ID Chip.

or

- a) Highlight the positioner in the Stage database entries list.
- b) Click Assign.



BES WAR	Stage database entries			Control	ler axes		
1. 10 L	N-470.230 N-470.230V	~		Axis	Current stage type	Action	
elect connected	N-470.23U			1	N-470.410	<do change="" not=""></do>	
stages	N-470.23UY			2	Q-522.100	<do change="" not=""></do>	
	N-470.23V			3	NOSTAGE	<do change="" not=""></do>	
	N-470.23VY	_	Assign ->	4	NOSTAGE	<do change="" not=""></do>	
	N-470,410Y			'	NODIHAL	sao not changos	
	N-470.41U		Assign Type from ID Chip				
	N-470.41UY	=					
	N-470.41V	=					
	N-470.41VY		No Stage ->				
	N-470.420						
	N-470.4201 N-470.4211						
	N-470.42UY		Reset				
	N-470.42V						
	N-470.42VY		Reload				
	N-470.430						
	N-470.430Y						
	N-470.43U						
	N-470 43V						
	N-470.43VY						
	Q-521.100	-		٠			
	Channel Haberbarra						OK
	Stage database not up t	o dater	Start the <u>PI Opdate Finder</u> to ge	t the la	test version or the sta	ge database.	

c) Confirm the selection with OK.

→ The Save all changes permanently? dialog is opened.



- 3. Click *Keep the changes temporarily* in the *Save all changes permanently* dialog to load the parameter settings into the volatile memory of the E-872.401.
- → The Start up stages/axes window changes to the Start up axes step.
- 4. Click Close to close the Start up stages/axes window.
- 5. Open the parameter window for the selected positioner type in the PIMikroMove's main window by clicking the corresponding line in the *Drive channels* tab and selecting the *Show drive channel parameter window* in the context menu.

Show drive channel parameter window
Clear Error
Select connected stages
Save parameters as User Stage type
Reload settings from stage database
Change number of displayed decimal places



6. Enter new values for the parameters to be changed:

Pa	Parameter pannel channel: 1							
	Load and Save Parameters 📃 🖸	onfigure Vie	igure View					
Γ	Name		ID	Active Value	CCL			
	. Maximum Motor Output	0x9		1800	0			
	. Is Rotary Stage?	0×13		yes (1) 🔽	0			
	. Stage Name (max. 20 characters)	0x3C		N-470.410	0			
	Invert Direction Of Motion For Joystick-Controlled A	is? 0x61		no (0) 🔽	0			
	. Stage Type	0×F00	00100	Â	2			
	. Stage Serial Number	0×F00	00200	Â	2			
	. Stage Assembly Date	0×F00	00300	Â	2			
	. Stage HW Version	0×F00	00400	0 🖬	2			
	. Q-Motion Upper Supply Voltage (V)	0×1F0	000000	80.000000 间	1			
	. Q-Motion Lower Supply Voltage (V)	0×1F0	000100	0.000000 间	1			

- a) If the parameter to be modified is not included in the list on the right-hand side of the window, click *Configure view > Select parameters...* and add it to the list. You can also display certain groups of parameters or all channel-related parameters.
- b) Type the new parameter value into the corresponding input field in the *Active Value* column of the list.
- c) Press the Enter key on the PC keyboard or click outside the input field with the mouse to transfer the parameter value to the volatile memory of the controller. Note: If a parameter value in the volatile memory (*Active Value* column) is different to the parameter value in the nonvolatile memory (*Startup Value* column), the line in the list is highlighted in color.
- 7. Click Load and Save Parameters > Save parameters to stage database....

Load and Save Parame≡ Configure View ≡
Load all startup parameters of the axis from controller
Save all currently active axis parameters as startup parameters to controller
Load parameters from stage database
Save parameters to stage database
Reload parameters from stage database
Refresh parameter view
Denominator OF The Counts-Per OXP
Ta Datary Stage 2 0v12

- 8. The Save Parameters as User Stage Type dialog opens.
- 9. Save the modified parameter values of the positioner type in the **Save Parameters as User Stage Type** dialog:
 - a) Leave the entry in the *Parameters of axis* field unchanged.
 - b) Leave the entry in the Save as field unchanged.
 - c) Click OK.
 - d) Click *Change settings* in the *Stage type already defined* dialog. The *Save Parameters as User Stage Type* dialog closes automatically after a short time.



→ The parameter values of the positioner type were updated in the positioner database and in the main window of PIMikroMove.



9

Command Reference

#		Page
#24	Stop All Axes	84
#5	Request Motion Status	83
#7	Request Controller Ready Status	83
#8	Query If Macro Is Running	84
*		Page
*IDN?	Get Device Information	84
С		Page
CCL	Set Command Level	85
CCL?	Get Command Level	85
CPY	Copy Into Variable	85
CST?	Get Assignment Of Stages To Axes	86
CSV?	Get Current Syntax Version	86
D		Page
DEL	Delay The Command Interpreter	86
DIO?	Get Digital Input Lines	87
E		Page
ERR?	Get Error Number	87
Н		Page
H HDT	Set HID Default Lookup Table	Page 87
H HDT HDT?	Set HID Default Lookup Table Get HID Default Lookup Table	Page 87 88
H HDT HDT? HIA	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis	Page 87 88 89
H HDT HDT? HIA HIA?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis	Page 87 88 89 90
H HDT HDT? HIA HIA? HIB?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button	Page 87 88 89 90 90
H HDT HDT? HIA HIA? HIB? HIE?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis	Page 87 88 89 90 90 90
H HDT HDT? HIA HIA? HIB? HIE? HIN	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis Set Activation State For HID Control	Page 87 88 89 90 91 91
H HDT HDT? HIA HIA? HIB? HIB? HIB? HIN HIN?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis Set Activation State For HID Control Get Activation State Of HID Control	Page 87 88 89 90 90 90 91 91 91
H HDT HDT? HIA HIA? HIB? HIB? HIB? HIN HIN? HIN?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis Set Activation State For HID Control Get Activation State Of HID Control Get Configuration Of HI Device	Page 87 88 89 90 90 91 91 91 91 91
H HDT HDT? HIA HIA? HIB? HIB? HIB? HIN HIN? HIN? HIN? HIN?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis Set Activation State For HID Control Get Activation State Of HID Control Get Configuration Of HI Device Fill HID Lookup Table	Page 87 88 89 90 90 91 91 91 91 91 92 92
H HDT HDT? HIA HIA? HIA? HIB? HIB? HIB? HIN? HIN? HIN? HIN? HIN? HIN?	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis Set Activation State For HID Control Get Activation State Of HID Control Get Configuration Of HI Device Fill HID Lookup Table	Page 87 88 89 90 90 90 91 91 91 91 91 92 93 93 93
H HDT HDT? HIA HIA? HIA? HIB? HIB? HIB? HIN? HIN? HIN? HIN? HIN? HIN? HIN? HIN	Set HID Default Lookup TableGet HID Default Lookup TableConfigure Control Done By HID AxisGet Configuration Of Control Done By HID AxisGet State Of HID ButtonGet Deflection Of HID AxisSet Activation State For HID ControlGet Activation State Of HID ControlGet Configuration Of HID DeviceFill HID Lookup TableGet HID Lookup Table ValuesGet List Of Available Commands	Page 87 88 89 90 90 90 91 91 91 91 91 91 92 93 93 93 93
H HDT HDT? HIA? HIA? HIA? HIB? HIB? HIS? HIN? HIN? HIN? HIN? HIN? HIN? HIN? HIN	Set HID Default Lookup TableGet HID Default Lookup TableConfigure Control Done By HID AxisGet Configuration Of Control Done By HID AxisGet State Of HID ButtonGet Deflection Of HID AxisSet Activation State For HID ControlGet Activation Of HID DeviceFill HID Lookup TableGet HID Lookup Table ValuesGet List Of Available CommandsHalt Motion Smoothly	Page 87 88 89 90 90 90 91 91 91 91 91 91 91 93 93 93 93 93 93 93
H HDT HDT? HIA? HIA? HIA? HIB? HIB? HIB? HIS? HIN? HIN? HIN? HIT? HIT? HIT? HLT? HIT? HIT?	Set HID Default Lookup TableGet HID Default Lookup TableConfigure Control Done By HID AxisGet Configuration Of Control Done By HID AxisGet State Of HID ButtonGet Deflection Of HID AxisSet Activation State For HID ControlGet Activation Of HI DeviceFill HID Lookup TableGet List Of Available CommandsHalt Motion SmoothlyGet List Of Available Parameters	Page 87 88 89 90 90 90 91 91 91 91 91 91 91 91 91 93 93 93 93 93 93 93 93 93 93
H HDT HDT? HIA? HIA? HIA? HIB? HIB? HIB? HIN? HIN? HIN? HIN? HIN? HIN? HIN? HIN	Set HID Default Lookup TableGet HID Default Lookup TableConfigure Control Done By HID AxisGet Configuration Of Control Done By HID AxisGet State Of HID ButtonGet Deflection Of HID AxisSet Activation State For HID ControlGet Activation State Of HID ControlGet Configuration Of HI DeviceGet HID Lookup TableGet List Of Available CommandsHalt Motion SmoothlyGet List Of Available ParametersGet Parameter Value Description	Page 87 88 89 90 91 91 91 91 91 93 93 94 94 95
H HDT HDT? HIA? HIA? HIA? HIB? HIB? HIB? HIB? HIB? HIT? HIN? HIN? HIN? HIN? HIN? HIN? HIN? HIN	Set HID Default Lookup Table Get HID Default Lookup Table Configure Control Done By HID Axis Get Configuration Of Control Done By HID Axis Get State Of HID Button Get Deflection Of HID Axis Set Activation State For HID Control Get Activation State Of HID Control Get Configuration Of HI Device Fill HID Lookup Table Get HID Lookup Table Values Get List Of Available Commands Halt Motion Smoothly Get List Of Available Parameters Get Parameter Value Description	Page 87 88 89 90 91 91 91 91 92 93 93 94 95 Page



IFC?	Get Current Interface Parameters	97
IFS	Set Interface Parameters As Default Values	98
IFS?	Get Interface Parameters As Default Values	99
J		Page
JRC	Jump Relatively Depending On Condition	100
М		Page
MAC	Call Macro Function	100
MAC BEG	Call Macro Function: BEG	101
MAC DEF	Call Macro Function: DEF	101
MAC DEF?	Call Macro Function: DEF?	101
MAC DEL	Call Macro Function: DEL	101
MAC END	Call Macro Function: END	101
MAC ERR?	Call Macro Function: ERR?	102
MAC NSTART	Call Macro Function: NSTART	102
MAC START	Call Macro Function: START	102
MAC?	List Macros	103
MAN?	Get Help String For Command	103
MEX	Stop Macro Execution Due To Condition	104
0		Page
OAD	Set Open-Loop Control Value (starts motion)	104
OAD?	Get Control Value	105
OSM	Open-Loop Step Moving	105
OSN?	Read Number Steps	106
R		Page
RBT	Reboot System	106
RMC?	List Running Macros	106
S		Page
SAI?	Get List Of Current Axis Identifiers	107
SEP	Set Nonvolatile Memory Parameters	107
SEP?	Get Nonvolatile Memory Parameters	108
SPA	Set Volatile Memory Parameters	108
SPA?	Get Volatile Memory Parameters	109
STP	Stop All Axes	109
т		Page
TIO?	Tell Digital I/O Lines	109
TVI?	Tell Valid Character Set For Axis Identifiers	110
V		Page
VAD		110



VAR?	Get Variable Values	110
VER?	Get Versions Of Firmware And Drivers	110
W		Page
WAC	Wait For Condition	111

#5 Request Motion Status

Used in: Triggering motion in open-loop operation (28)

Description:	Queries the motion status of the axes.		
Format:	#5		
	#5 correspond	is to the ENQ control character in ISO/IEC 6429.	
Response:	<motionstatus></motionstatus>		
	<motionstatus> motion status (HEX)</motionstatus>		
	<motionstatu the bit value o</motionstatu 	s> is bit-mapped. Each axis corresponds to one bit and corresponds to the axis number, e.g.,	
	Response	Description	
	1	Axis 1 is moving	

nooponoo	Docomption
1	Axis 1 is moving
2	Axis 2 is moving
5	Axis 3 and 1 are moving

#7 Request Controller Ready Status

Used in: Commandable Item	s (21)		
Description:	Queries the controller's ready state.		
	The controller is ready as soon as a new command can be executed.		
Format:	#7		
	#7 corresponds to the 🛯 در control character in ISO/IEC 6429.		
Response:	<readystatus></readystatus>		
	<readystatus> ready state (HEX)</readystatus>		
	Possible answers:		
	Response from con- troller	Character in ISO/IEC 8859-1	Description
	0xB1	±	Controller is ready
	0xB0	0	Controller is not ready
Troubleshooting:	The response character acter sets.	rs may be displayed dif	ferently in other char-



#8 Query If Macro Is Running

Used in: (65)				
Description:	Tests if a macro is ru	Tests if a macro is running on the controller.		
Format:	#8			
	#8 corresponds to the	e BS control character in ISO/IEC 6429.		
Response:	<macrorunning></macrorunning>			
	<macrorunning></macrorunning>	Macro is running (UINT)		
	<macrorunning></macrorunning>	Description		
	1	A macro is running.		
	0	No macro is running.		

#24 Stop All Axes

Used in: (66), Triggering motion in open-loop operation (28)

Description:	Stops all axes abruptly.
	Stops all motion started by motion commands (e.g., MOV, MVR, MVE, STE, SMO), referencing commands (FNL, FPL, FRF), and macros.
	Also stops the macro.
	Sets the error code to 10.
	After the axes are stopped, their target positions are set to their current positions.
	This command is identical in function to <u>STP (p. 109)</u> except only one character is sent via the interface. Therefore, #24 can also be used when the controller is doing time-consuming tasks.
Format:	#24
	#24 corresponds to the CAN control character in ISO/IEC 6429.

* IDN? Get Device Identification

Used in: Commandable Items (21)

Description:	Queries the device iden	Queries the device identification string.		
Format:	*IDN?	*IDN?		
Response:	<deviceinformation>LF</deviceinformation>	<deviceinformation>LF</deviceinformation>		
	<deviceinformation></deviceinformation>	Device identification string with controller name, serial number, and firmware version. (STRING)		



CCL Set Command Level

Used in: (20), Parameter Commands (71)

Description:	Changes the active command level.		
	The comman write access	nd level determines the availability of commands and to system parameters.	
	Command le	evel: 0 - standard; 1 - expert mode; > 1 - PI service mode	
	Command levels > 1 cannot be activated; they are intended for PI service personnel. Contact the customer service department if there are problems with the parameters for command level 2 or <u>high-</u> er (p. 9).		
	The active command level is always 0 when the electronics are switched on or rebooted.		
	The <u>HPA? (p. 94)</u> command lists the parameters and includes infor- mation on which command level allows write access to them.		
Format:	CCL_ <level>[_<pswd>]</pswd></level>		
Arguments:	<level></level>	Controller command level (UINT)	
	<pswd></pswd>	Password for changing to the corresponding command level	
		Password for changing to command level 1: advanced	
Troubleshooting:	Wrong pass	word	

CCL? Get Command Level

Used in: (20), Parameter Commands (71)

Description:	Queries the active command level.	
Format:	CCL?	
Response:	<level>LF</level>	
	<level></level>	Command level (UINT)

CPY Copy Into Variable

Used in: Running the Macro (65)

Description:	Copies the resp	Copies the response to a command into a variable.	
Format:	CPY_ <variable></variable>	CPY_ <variable>_<cmd?></cmd?></variable>	
Arguments:	<variable></variable>	Name of the variable to be copied to	
	<cmd?></cmd?>	Query command that responds with a single val- ue	



CST? Get Assignment Of Stages To Axes

Used in: Commandable Items (21)

Description:	Queries the nar specified axis.	ne of the positioner type that is configured for the	
	The positioner rameter has the	name is read from parameter <u>0x3C (p. 115)</u> . If the pa- e value "NOSTAGE", the axis is deactivated.	
Format:	CST? [{ <axisi< td=""><td colspan="2">CST? [{<axisid>}]</axisid></td></axisi<>	CST? [{ <axisid>}]</axisid>	
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is con- nected	
Response:	{ <axisid>=<str< td=""><td>ing>⊥F}</td></str<></axisid>	ing>⊥F}	
	<axisid></axisid>	ID of the drive channel to which the axis is con- nected	
	<string></string>	Name of the positioner type (STRING)	

CSV? Get Current Syntax Version

Used in: (20)			
Description:	Get current GCS syntax version used in the firmware.		
Format:	CSV?		
Response:	<syntaxversion></syntaxversion>		
	<syntaxversion></syntaxversion>	GCS syntax version (STRING)	
	<syntaxversion></syntaxversion>	Description	
	1.0	GCS syntax version 1.0	
	2.0	GCS syntax version 2.0	

DEL Delay The Command Interpreter

Used in: Running the Macro (65)

Description:	Delays runnin	Delays running the macro for a fixed period of time.		
	DEL can only	DEL can only be used in macros.		
	Note: Do not macros).	Note: Do not mix up DEL (delayed) with <u>MAC DEL (p. 101)</u> (deletes macros).		
Format:	DEL_ <uint></uint>			
Arguments:	<uint></uint>	Delay time span in milliseconds [UINT]		



DIO? Get Digital Input Lines

Used in: Digital Input Signals	s (54)		
Description:	Queries the status of a digital input line.		
	Use <u>TIO? (p. 109)</u> to	query the number of available digital I/O lines.	
Format:	DIO?[{_ <dioid>}]</dioid>		
Arguments:	<dioid></dioid>	Digital input line of the electronics	
	The state of all digita ped hexadecimal nu	al input lines is queried and output as bit-map- mber if no arguments are specified.	
Response: { <dioid>=<inputon>LF}</inputon></dioid>		>LF }	
	<dioid></dioid>	Digital input line of the electronics	
	<inputon></inputon>	Digital input line state (HEX)	

ERR? Get Error Number

Used in: Restoring the E-872.401's Operational Readiness (53)

Description:	Queries the error code of the last error that occurred and resets the error code to 0.		
	Only the last error is buffered; therefore, in the case of a problem, ERR? should be called after each command.		
Format:	ERR?		
Response:	<errornumber></errornumber>		
	<errornumber></errornumber>	Code for the last error (INT)	
Troubleshooting:	Communication breakdown		

HDT Set HID Default Lookup Table

Used in: HID Control Configuration (57)

Description:	Assigns a lookup table to the specified axis of the specified HID.		
Format:	HDT{_ <hideviceid>_<hideviceaxis>_<hidtableid>}</hidtableid></hideviceaxis></hideviceid>		
Arguments:	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hideviceaxis></hideviceaxis>	HID axis	
	<hidtableid></hidtableid>	Lookup table identifier	



HDT? Get HID Default Lookup Table

Used in: HID Control Configuration (57)

Description:	Queries the currently assigned lookup table for the specified axis of an HID.		
Format:	HDT?[{_ <hideviceid>_<hideviceaxis>}]</hideviceaxis></hideviceid>		
Arguments:	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hideviceaxis></hideviceaxis>	HID axis	
Response:	{ <hideviceid>_<hide< td=""><td>eviceAxis>=<hidtableid> LF }</hidtableid></td></hide<></hideviceid>	eviceAxis>= <hidtableid> LF }</hidtableid>	
	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hideviceaxis></hideviceaxis>	HID axis	
	<hidtableid></hidtableid>	Lookup table identifier	



HIA Configure Control Done By HID Axis

.

Used in: HID Control Configuration (57), Triggering motion in open-loop operation (28)

Description:

Assigns an HID axis to the specified motion variable.

The configuration of the HID control is saved only to the volatile memory (RAM) of the electronics.

Configures control of electronics' axes via HID axes (HID control).

HID control may not be activated for the corresponding axis.

Motion variables that can be controlled by HIDs (depending on the controller; use the <u>HIA? (p. 90)</u> command to query the current configuration of the HID controlled motion variables):

	am>	Description
	0	Deletes the current configuration of the HID control. Can be sent from <hideviceid> and <hideviceaxis> without specification.</hideviceaxis></hideviceid>
	1	Absolute target position The lookup table value corresponding to the current displacement of the human interface device axis is mapped to the travel range of the E-872.401 axis to be controlled.
	2	Relative target position Each pulse received (if applicable: Each mechanical detent) triggers relative motion over the distance set with the SST command. No lookup tables are used to control the relative target position.
	3	Velocity of the axis Product of the lookup table value corresponding to the current displacement of the HID axis and the currently valid maximum velocity of the controller axis.
	4	Maximum velocity of the axis Product of the lookup table value corresponding to the current displacement of the HID axis and the currently valid maximum velocity of the controller axis. Motion variable 4 can only be assigned to an HID axis when motion variable 3 has been assigned to a differ- ent HID axis.
Format:	HIA{_ <axisid< td=""><td><pre>>_<motionparam>_<hideviceid>_<hideviceaxis>}</hideviceaxis></hideviceid></motionparam></pre></td></axisid<>	<pre>>_<motionparam>_<hideviceid>_<hideviceaxis>}</hideviceaxis></hideviceid></motionparam></pre>
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is con- nected
	<motionparan< td=""><td>Axis motion variable</td></motionparan<>	Axis motion variable
	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics
	<hideviceaxis< td=""><td>s> HID axis</td></hideviceaxis<>	s> HID axis
Troubleshooting:	<motionparam> has the value zero, i.e., function to be controlled has not been selected for the axis</motionparam>	



<HIDeviceID> has the value zero, i.e., HID has not been selected <HIDeviceAxis> has the value zero, i.e., HID's axis has not been selected for HID control

HIA? Get Configuration Of Control Done By HID Axis

Used in: HID Control Configuration (57)

Description:	Queries an HID's axis assigned to the specified motion variable of the specified motion variable.		
Format:	HIA?[{_ <axisid>_<motionparam>}]</motionparam></axisid>		
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	<motionparam></motionparam>	Axis motion variable	
Response:	{ <axisid>_<motionparam>=<hideviceid>_<hideviceaxis> LF }</hideviceaxis></hideviceid></motionparam></axisid>		
	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	<motionparam></motionparam>	Axis motion variable	
	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hideviceaxis></hideviceaxis>	HID axis	

HIB? Get State Of HID Button

Used in: HID Control Configuration (57)

Description:	Queries the current state of the specified button of the specified HID.		
Format:	HIB?[{_ <hideviceid>_<hidevicebutton>}]</hidevicebutton></hideviceid>		
Arguments:	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hidevicebutton></hidevicebutton>	HID button	
Response:	{ <hideviceid>_<hidevicebutton>=<hidbuttonstate>LF}</hidbuttonstate></hidevicebutton></hideviceid>		
	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hidevicebutton></hidevicebutton>	HID button	
	<hidbuttonstate></hidbuttonstate>	Button status (INT)	
	Any possible values of <hidbuttonstate> depend on the button type. The value range can be queried with <u>HIS? (p. 92)</u>.</hidbuttonstate>		



HIE? Get Deflection Of HID Axis

Used in: HID Control Configuration (57)

Description:	Queries the current fied HID.	displacement of the specified axis of the speci-	
Format:	HIE?[{_ <hideviceid>_<hideviceaxis>}]</hideviceaxis></hideviceid>		
Arguments:	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hideviceaxis></hideviceaxis>	HID axis	
Response:	{ <hideviceid>_<hideviceaxis>=<hiddeflection> LF }</hiddeflection></hideviceaxis></hideviceid>		
	<hideviceid></hideviceid>	Identifier of an HID connected to the electronics	
	<hideviceaxis></hideviceaxis>	HID axis	
	<hiddeflection></hiddeflection>	Displacement of the HID's axis (FLOAT)	
	<hiddeflection> is a equal to 0.0 corresp</hiddeflection>	a value between -1.0 and 1.0. A value almost onds to the axis' center position, -1.0 respective-	

CHIDDeflections is a value between -1.0 and 1.0. A value almost equal to 0.0 corresponds to the axis' center position, -1.0 respectively 1.0 of the maximum displacement in a negative respectively positive direction.

HIN Set Activation State For HID Control

Used in: HID Control Configuration (57), Triggering motion in open-loop operation (28)

Description:	Sets the status of HID control for the specified axis.		
Format:	HIN{_ <axisid>_<hidcontrolstate>}</hidcontrolstate></axisid>		
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	<hidcontrolstate></hidcontrolstate>	HID control's activation state (BOOL)	
Troubleshooting:	Illegal axis identifier HID control is not suitably configured (p. 89)		

HIN? Get Activation State Of HID Control

Used in: HID Control Configuration (57)

Description:	Queries status of HI	Queries status of HID control for the specified axis.		
Format:	HIN?[{_ <axisid>}]</axisid>	HIN?[{_ <axisid>}]</axisid>		
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is connected		
Response:	{ <axisid>=<hidcon< td=""><td>trolState>LF}</td></hidcon<></axisid>	trolState>LF}		
	<axisid></axisid>	ID of the drive channel to which the axis is connected		
	<hidcontrolstate></hidcontrolstate>	HID control's activation state (BOOL)		



HIS? Get Configuration Of HI Device

Used in: Commandable Items (21), HID Control Configuration (57)

Description:	Queries the an HID.	ries the specified property for the specified operating element of ID.	
Format:	HIS?[{_ <hideviceid>_<h< td=""><td><pre>D>_<hiditemid>_<hidpropid>}]</hidpropid></hiditemid></pre></td></h<></hideviceid>		<pre>D>_<hiditemid>_<hidpropid>}]</hidpropid></hiditemid></pre>
Arguments:	<hidevicell< td=""><td>D></td><td>Identifier of an HID connected to the electronics</td></hidevicell<>	D>	Identifier of an HID connected to the electronics
	<hiditemid< td=""><td>)></td><td>HID operating element</td></hiditemid<>)>	HID operating element
	<hidpropic< td=""><td>)></td><td>Property of the operating element</td></hidpropic<>)>	Property of the operating element
	If no arguments are specified, information is queried on the suppor- ted operating elements of all HIDs.		
Response:	{ <hidevice< td=""><td>ID>_<hidi< td=""><td>temID>_<hidpropid>=<hidpropvalue> LF }</hidpropvalue></hidpropid></td></hidi<></td></hidevice<>	ID>_ <hidi< td=""><td>temID>_<hidpropid>=<hidpropvalue> LF }</hidpropvalue></hidpropid></td></hidi<>	temID>_ <hidpropid>=<hidpropvalue> LF }</hidpropvalue></hidpropid>
	<hidevicell< td=""><td>D></td><td>Identifier of an HID connected to the electronics</td></hidevicell<>	D>	Identifier of an HID connected to the electronics
	<hiditemid< td=""><td>)></td><td>HID operating element</td></hiditemid<>)>	HID operating element
	<hidpropic< td=""><td>)></td><td>Property of the operating element</td></hidpropic<>)>	Property of the operating element
	<hidpropva< td=""><td>The property of the operating element is set to this value (STRING)</td></hidpropva<>		The property of the operating element is set to this value (STRING)
	Possible values:		
	<hidpro- pID></hidpro- 	Descripti	on
		Axis_ <x>: HID axis, e.g., joystick axis or continuous slider, <x> indicates the identifier</x></x>	
		Button_ <x>: HID button, <x> indicates the identifier</x></x>	
		Led_ <x>: Output unit, e.g., LED or vibration motor on/off time, <x> indicates the identifier</x></x>	
	2	Operating element status, e.g., axis displacement or LED activation status (FLOAT)	
	3	Name of the operating element (STRING)	
	4	HID Name (STRING)	

- 5 Smallest possible value for the status of a "Button"- or "Led"-type operating element (INT)
- 6 Largest possible value for the status of a "Button"- or "Led"-type operating element (INT)



HIT Fill HID Lookup Table

Used in: HID Control Configuration (57)

Description:	Fills the specified l	Fills the specified lookup table with values.			
	HIT can only be use ≤ 100 are predefine	HIT can only be used to fill user-defined tables. Tables with identifier < 100 are predefined and write-protected.			
	The first point of a displacement of the corresponds to the The values for point default, while the r the values determinaxis. Parameter <u>0x4</u> rection that is spect controlled axis.	The first point of a lookup table corresponds to the maximum axis displacement of the HID in the negative direction; the 256th point corresponds to the maximum displacement in the positive direction. The values for points 1 to maximally 127 have a negative sign by default, while the remaining values have a positive sign. The sign of the values determines the direction of motion of the HID-controlled axis. Parameter $0x61$ (p. 115) can be used to reverse the assigned direction that is specified by the values in the lookup table for an HID-controlled axis.			
	The <u>HDT (p. 87)</u> command assigns the lookup tables to HID axes.				
Format:	HIT{_ <hidtableid< td=""><td>>_<hidtableaddr>_<hidtablevalue>}</hidtablevalue></hidtableaddr></td></hidtableid<>	>_ <hidtableaddr>_<hidtablevalue>}</hidtablevalue></hidtableaddr>			
Arguments:	<hidtableid></hidtableid>	Lookup table identifier			
	<hidtableaddr></hidtableaddr>	Index of a point in the lookup table			
	<hidtablevalue></hidtablevalue>	Value of the point with the index <hidtableaddr> (FLOAT, -1.01.0)</hidtableaddr>			

HIT? Get HID Lookup Table Values

Used in: HID Control Configuration (57)

Description:	Queries the values of ble.	of the specified points in the specified lookup ta-	
Format:	HIT?[_ <startpoint></startpoint>	>[_ <numberofpoints>[{_<hidtableid>}]]]</hidtableid></numberofpoints>	
Arguments:	<startpoint></startpoint>	Index of the first point that is queried	
	<numberofpoints></numberofpoints>	Number of points to be queried per lookup table	
	<hidtableid></hidtableid>	Lookup table identifier	
Response:	(Data in GCS array f	(Data in GCS array format)	

HLP? Get List Of Available Commands

Used in: (20)	
Description:	Lists a help string which contains all commands available.
Format:	HLP?
Response:	(List of available commands)



HLT Halt Motion Smoothly

Used in: Triggering motion in open-loop operation (28)

Description:	Stops motion for the specified axis while considering the maximum set deceleration.			
	Sets the error code to 10.			
	Does not apply to trajectories: HLT also triggers an abrupt stop of motion when a trajectory is being followed.			
Format:	HLT[{_ <axisid>}]</axisid>			
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is con- nected		
Troubleshooting:	Illegal axis identifie			

HPA? Get List Of Available Parameters

Used in: (20), Adapting Settings (71), Parameter Commands (71)

Description:	Shows a help text that contains all available parameters with a short description.			
Format:	HPA?			
Response:	List of available parameters in the format: <pamid>=TAB<cmdlevel>TAB<maxitem>TAB<data- Type>TAB<functiongroupdescription>TAB<parameterdescrip- tion>TAB[{<possiblevalue>=<valuedescription>}]</valuedescription></possiblevalue></parameterdescrip- </functiongroupdescription></data- </maxitem></cmdlevel></pamid>			
	<pamid></pamid>	Parameter ID		
	<cmdlevel></cmdlevel>	Command level for write access to the parameter		
	<maxitem></maxitem>	Maximum number of elements of the same type that are affected by the parameter		
	<datatype></datatype>	Data type of the parameter value		
	<functiongroupde- scription></functiongroupde- 	Name of the function group which the parameter belongs to		
	<parameterde- scription></parameterde- 	Name of the parameter		
	<possiblevalue></possiblevalue>	Possible value		
	<valuedescription></valuedescription>	Value description		



HPV? Get Parameter Value Description

Description:	Displays a help text that contains possible parameter values.				
Format:	HPV?				
Response:	<pre>#Possible_parameter_values_are: LF {<pamid>_<itemid>=<listtype>[{→I<possiblevalue>=<valuedescription>}]LF} #CCL_levels_are: LF {<pamid>_<itemid>=<cmdlevel>LF}</cmdlevel></itemid></pamid></valuedescription></possiblevalue></listtype></itemid></pamid></pre>				
	end of help				
	<pamid></pamid>	Parameter ID			
	<itemid></itemid>	Element of the electronics			
		<itemid> = 0: Description applies to all elements</itemid>			
	<listtype></listtype>	Value list type			
		<listtype> = 0: Parameter does not apply to this element <listtype> = 1: List of possible values <listtype> = 2: Minimum and maximum value</listtype></listtype></listtype>			
	<possiblevalue></possiblevalue>	Possible value			
	<valuedescription></valuedescription>	Value description			
	<cmdlevel></cmdlevel>	Command level for write access to the parameter			



IFC Set Interface Parameters Temporarily

Used in: E-872.401 Interfaces (15)

	/			
Description:	Configures the interface parameters in the volatile memory.			
	The changed interface parameters are active immediately. The PC's interface configuration may also have to be changed and the connection to the electronics re-established.			
	The configuration of the interface parameters is saved only to the volatile memory (RAM) of the electronics. Use <u>IFS (p. 98)</u> to change interface parameters in the nonvolatile memory.			
Format:	IFC{_ <inte< td=""><td>erfacePam>_<pamvalu< td=""><td>e>}</td></pamvalu<></td></inte<>	erfacePam>_ <pamvalu< td=""><td>e>}</td></pamvalu<>	e>}	
Arguments:	<interfacep< td=""><td>am> Interface pa</td><td>arameters (STRING)</td></interfacep<>	am> Interface pa	arameters (STRING)	
	<pamvalue> Parameter value</pamvalue>			
Possible values	<interfa- cePam></interfa- 	<pamvalue></pamvalue>	Description	
	RSBAUD	9600, 19200, 38400, 57600 or 115200	Baud rate for the RS-232 interface	
	IPADR	<uint>.<uint>.<ui NT>.<uint>:50000</uint></ui </uint></uint>	IP address and port for the TCP/IP interface Port 50000 cannot be changed. IPADR is only used when IPSTART = 0.	
	IPSTART	0, 1	<pamvalue> = 0: The IP address de- fined by IPADR is used <pamvalue> = 1: DHCP is used (de- fault)</pamvalue></pamvalue>	
	IPMASK	<uint>.<uint>.<ui NT>.<uint></uint></ui </uint></uint>	TCP/IP interface subnet mask	

NT>.<UINT>

IPGTWAY <UINT>.<UINT>.<UI Default gateway for TCP/IP commu-

nication



IFC? Get Current Interface Parameters

Used in: E-872.401 Interfaces (15)

Description:	Queries the interface parameter values in the volatile memory.			
Format:	IFC?[{_ <interfacepam>}]</interfacepam>		'am>}]	
Arguments:	<interfacepam></interfacepam>		Interface parameters (STRING)	
Response:	{ <interfacepam>=<pa< td=""><td>amValue>LF}</td></pa<></interfacepam>		amValue>LF}	
	<interfacepa< td=""><td>am></td><td>Interface parameters (STRING)</td></interfacepa<>	am>	Interface parameters (STRING)	
	<pamvalue></pamvalue>	>	Parameter value	
	in the volatile memory			
	Possible values for <interfacepam>:</interfacepam>			
	<interfa- cePam></interfa- 	Descript	tion	
	RSBAUD	Baud rate for the RS-232 interface		
	IPADR	IP address and port for the TCP/IP interface		
	IPSTART	Startup behavior (DHCP status) of the TCP/IP interface		
	IPMASK	TCP/IP interface subnet mask		
	MACADR	Mac address (unique network hardware address)		
	IPGTWAY	Default	gateway for TCP/IP communication	



IFS Set Interface Parameters As Default Values

Used in: E-872.401 Interfaces (15)

Description:	Configures the interface parameters in the nonvolatile memory.				
	The changed interface parameters are active after the next reboot. The PC's interface configuration may also have to be changed. Notice: Note that the number of write cycles in the nonvolatile memory is limited. Therefore, save to the nonvolatile memory only when necessary.				
	Use <u>IFC (p.</u> memory (R	<mark>96)</mark> to cha AM).	ange the inte	erface parameters in the volatile	
Format:	IFS <pswd>{_<interfacepam>_<pamvalue>}</pamvalue></interfacepam></pswd>				
Arguments:	<pswd></pswd>		Password for	or writing to the nonvolatile memory	
	Default valu	ue is "100	".		
	<interfacep< td=""><td>am></td><td>Interface pa</td><td>rameters (STRING)</td></interfacep<>	am>	Interface pa	rameters (STRING)	
	<pamvalue< td=""><td colspan="2">ie> Parameter</td><td>value</td></pamvalue<>	ie> Parameter		value	
	Possible values				
	<interfa- cePam></interfa- 	<pamvalue></pamvalue>		Description	
	RSBAUD	9600, 19 57600 or	200, 38400, [.] 115200	Baud rate for the RS-232 interface	
	IPADR	<uint> NT>.<ui< td=""><td><uint>.<ui NT>:50000</ui </uint></td><td>IP address and port for the TCP/IP interface</td></ui<></uint>	<uint>.<ui NT>:50000</ui </uint>	IP address and port for the TCP/IP interface	
				Port 50000 cannot be changed. IPADR is only used when IPSTART = 0.	
	IPSTART	0, 1		<pamvalue> = 0: The IP address de- fined by IPADR is used <pamvalue> = 1: DHCP is used (de- fault)</pamvalue></pamvalue>	
	IPMASK	<uint>. NT>.<ui< td=""><td><uint>.<ui NT></ui </uint></td><td>TCP/IP interface subnet mask</td></ui<></uint>	<uint>.<ui NT></ui </uint>	TCP/IP interface subnet mask	
	IPGTWAY	<uint>. NT>.<ui< td=""><td><uint>.<ui NT></ui </uint></td><td>Default gateway for TCP/IP commu- nication</td></ui<></uint>	<uint>.<ui NT></ui </uint>	Default gateway for TCP/IP commu- nication	



IFS? Get Interface Parameters As Default Values

I lsed in: F-872 401 Interfaces	(15)	
0360 III. L-072.401 III.CITALES	110/	

Description:	Queries the values of the interface parameters in the nonvolatile memory.				
Format:	IFS?[{_ <interface< td=""><td>?am>}]</td></interface<>		?am>}]		
Arguments:	<interfacepam></interfacepam>		Interface parameters (STRING)		
Response:	{ <interfacepam>=<p< td=""><td>amValue>∟⊧}</td></p<></interfacepam>		amValue>∟⊧}		
	<interfacepa< td=""><td>am></td><td>Interface parameters (STRING)</td></interfacepa<>	am>	Interface parameters (STRING)		
	<pamvalue></pamvalue>	>	Parameter value		
	in the nonvolatile memory				
	Possible values for <interfacepam>:</interfacepam>				
	<interfa- cePam></interfa- 	Descript	tion		
	RSBAUD	Baud rate for the RS-232 interface			
	IPADR	IP address and port for the TCP/IP interface			
	IPSTART	Startup behavior (DHCP status) of the TCP/IP interface			
	IPMASK	TCP/IP interface subnet mask			
	MACADR	Mac address (unique network hardware address)			
	IPGTWAY	Default gateway for TCP/IP communication			



JRC Jump Relatively Depending On Condition

Used in: Running the Macro (65)

Description: Jumps relative to a specified number of program lines within a macro.

Jumps irrespective of a specified condition. Can only be used in macros. Possible relational operators:

	<0P>	Description	
	=	Equal	
	!=	Not equal	
	<=	Smaller than or equal	
	<	Smaller than	
	>=	Larger than or equal	
	>	Larger than	
Format:	JRC_ <jump< td=""><td>o>_<cmd?>_<0P>_<value></value></cmd?></td></jump<>	o>_ <cmd?>_<0P>_<value></value></cmd?>	
Arguments:	<jump></jump>	Size of relative jump	
	<cmd?></cmd?>	Query command that responds with a single val- ue	
	<0P>	Relational operator	
	<value></value>	Relational value with <cmd?></cmd?>	
Troubleshooting:	Wrong jur Wrong rel	mp target (<jump>) specified lational operator (<op>) specified</op></jump>	

MAC Call Macro Function

Description:	Calls a macro function.		
	Possible macro functions are described separately:		
	MAC BEG (p. 101)		
	MAC DEF (p. 101)		
	MAC DEF? (p. 101)	
	 MAC DEL (p. 101) 		
	MAC END (p. 101)		
	■ MAC ERR? (p. 102)		
	 MAC NSTART (p. 102) 		
	MAC START (p. 102)		
Format:	MAC_ <keyword>{_<parameter>}</parameter></keyword>		
Arguments:	<keyword></keyword>	Macro function called	
	<parameter></parameter>	Function-dependent parameters	
Troubleshooting:	Macro recording is active		



MAC BEG Call Macro Function: BEG

Used in: (64)				
Description:	Start recording a	Start recording a macro.		
	Recording is stop	ped by <u>MAC END (p. 101)</u> .		
Format:	MAC_BEG_ <macrona< td=""><td>ame></td></macrona<>	ame>		
Arguments:	<macroname></macroname>	Macro name		

MAC DEF Call Macro Function: DEF

Used in: (66)		
Description:	Specifies a macro as	startup macro.
Format:	MAC_DEF_ <macroname< td=""><td>></td></macroname<>	>
Arguments:	<macroname></macroname>	Name of the macro that is specified as startup macro

A startup macro is not used when no arguments are specified.

MAC DEF? Call Macro Function: DEF?

Used in: (66)		
Description:	Queries the name of	the startup macro.
Format:	MAC_DEF?	
Response:	[<macroname>] LF</macroname>	
	<macroname></macroname>	Startup macro name

MAC DEL Call Macro Function: DEL

Used in: (66)

Description:	Deletes the specified macro.	
Format:	MAC_DEL_ <macroname< td=""><td>></td></macroname<>	>
Arguments:	<macroname></macroname>	Macro name to be deleted

MAC END Call Macro Function: END

Format:	MAC_END
Description:	Ends macro recording.
Used in: (64)	



MAC ERR? Call Macro Function: ERR?

Used in: (66)		
Description:	Reports the last er	rror that occurred while the macro was running.
Format:	MAC_ERR?	
Response:	<macroname>_<u< td=""><td>int1>=<uint2>"<"<cmd>">"</cmd></uint2></td></u<></macroname>	int1>= <uint2>"<"<cmd>">"</cmd></uint2>
	<macroname></macroname>	Name of the macro
	<uint1></uint1>	Line in the micro where the error occurred
	<uint2></uint2>	Error code
	<cmd></cmd>	Bad command

MAC NSTART Call Macro Function: NSTART

Used in: (65)		
Description:	Runs the specified m	nacro several times.
	The macro is restarte ted, until <uint> has</uint>	ed when the last macro recording has comple- been reached.
Format:	MAC_NSTART_ <macro- Name>_<uint>[_<str]</str </uint></macro- 	ing1>[_ <string2>[_<string3>[_<string4>]]]</string4></string3></string2>
Arguments:	<macroname></macroname>	Macro name
	<uint></uint>	Number of runs
	<string14></string14>	Local variables 1 to 4
Troubleshooting:	No local variables sp macro	pecified although local variables are used in the

MAC START Call Macro Function: START

Used in: (65)		
Description:	Runs the specified	d macro.
Format:	MAC_START_ <macro Name>[_<string1:< td=""><td>o- >[_<string2>[_<string3>[_<string4>]]]]</string4></string3></string2></td></string1:<></macro 	o- >[_ <string2>[_<string3>[_<string4>]]]]</string4></string3></string2>
Arguments:	<macroname></macroname>	Macro name
	<string14></string14>	Local variables 1 to 4
Troubleshooting:	No local variables macro	specified although local variables are used in the



MAC? List Macros

Used in: (64)		
Description:	Lists macros or co	ontent of a specified macro.
Format:	MAC?[_ <macroname< td=""><td>2>]</td></macroname<>	2>]
Arguments:	<macroname></macroname>	Name of a macro
	lf no arguments a ted.	re specified, the names of all saved macros are lis-
Response:	<string></string>	
	<string></string>	Content of the macro or list of the names of all saved macros
Troubleshooting:	Wrong macro nan	ne (<macroname>)</macroname>

MAN? Get Help String For Command

Description:	Shows a help text for a command.	
Format:	MAN?_ <cmd></cmd>	
Arguments:	<cmd></cmd>	Command that the help text is to be shown for
Response:	<string></string>	
	<string></string>	Help text



MEX Stop Macro Execution Due To Condition

Used in: Stopping the Macros (66)

Description: Stops the macro due to a specified condition.

If the parser encounters this command, the condition is checked. If the condition is fulfilled at a later time, it is ignored by the parser. Can only be used in macros.

Possible relational operators:

	<op></op>	Description
	=	Equal
	!=	Not equal
	<=	Smaller than or equal
	<	Smaller than
	>=	Larger than or equal
	>	Larger than
Format:	MEX_ <cmd?< td=""><td>?>_<0P>_<value></value></td></cmd?<>	?>_<0P>_ <value></value>
Arguments:	<cmd?></cmd?>	Query command that responds with a single val- ue
	<0P>	Relational operator
	<value></value>	Relational value with <cmd?></cmd?>

OAD Set Open-Loop Control Value (starts motion)

Used in: Triggering motion in open-loop operation (28)

Description:	Sets the control value The control value is moved is connected to be reset to 0 and t correspondingly.	e for the specified axis to the specified value. set for the drive channel to which the axis to be . This causes the previously controlled channel the position of the axis connected to it changes	
	Immediately starts the motion. In the case of piezo inertia drives, the control value corresponds to the analog output voltage [V].		
Format:	OAD{_ <axisid>_<value>}</value></axisid>		
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis to be moved is connected	
	<controlvalue></controlvalue>	Control value that is to be set for the axis	
Troubleshooting:	Illegal axis identifier HID control is enable	ed	



OAD? Get Control Value

Used in: Triggering motion in open-loop operation (28)

Description:	Queries the control value of the specified axis.		
	In the case of piezo inertia drives, the control value corresponds to the analog output voltage [V].		
Format:	OAD?[{_ <axisid>}]</axisid>		
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	The value for all axes will be queried if no arguments are specified.		
Response:	{ <axisid>=<controlvalue>LF}</controlvalue></axisid>		
	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	<controlvalue></controlvalue>	Axis control value (FLOAT)	
Troubleshooting:	Illegal axis identifier		

OSM Open-Loop Step Moving

Used in: Commandable Items (21), Triggering motion in open-loop operation (28)

Description:	Moves the specified axis by the specified number of steps.	
	The number of steps is set for the drive channel to which the axis to be moved is connected. This causes the previously controlled chan- nel to be reset to 0 and the position of the axis connected to it changes correspondingly.	
	The velocity in open-loop step operation is controlled via the step frequency (parameter $0 \times 1F000400$).	
Format:	OSM{_ <axisid>_<value>}</value></axisid>	
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis to be moved is connected
	<value></value>	Number of steps to be made
Troubleshooting:	Illegal axis identifier HID control is enabled	



OSN? Read Number Steps

Used in: Triggering motion in open-loop operation (28)

Description:	Queries the number of steps that still have to be performed by the specified axis.		
Format:	OSN?[{_ <axisid>}]</axisid>		
Arguments:	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	The value for all axes will be queried if no arguments are specified.		
Response:	{ <axisid>=<uint>LF}</uint></axisid>		
	<axisid></axisid>	ID of the drive channel to which the axis is connected	
	<uint></uint>	Number of steps still to be made	
Troubleshooting:	Illegal axis identifier		

RBT Reboot System

Used in: Controller Macros (63)

Description:	Restarts the electronics.
	The electronics behave in the same way after restarting as they do after switching on.
	RBT cannot be used in macros.
Format:	RBT

RMC? List Running Macros

Used in: (65)	
Description:	Queries all macros currently running.
Format:	RMC?
Response:	{[<macroname>] LF }</macroname>
	<macroname> Macro name</macroname>



SAI? Get List Of Current Axis Identifiers

Used in: Commandable Items	s (21)	
Description:	Queries the axis identifiers.	
	ALL ensures that the response also includes axes that are dea ted for electronics that permit axes to be deactivated.	
Format:	SAI?[_ALL]	
Arguments:	[_ALL]	Ensures that electronics that allow axes to be de- activated (parameter $0x3C$ (p. 115) = "NOSTAGE") also allow deactivated axes to be queried.
Response:	{ <axisid>lf}</axisid>	
	<axisid></axisid>	ID of the drive channel to which the axis is con- nected

SEP Set Non-Volatile Memory Parameters

Description:	Sets a parameter	Sets a parameter in the nonvolatile memory to a specific value.	
	Up to four parame	Up to four parameters can be set per command.	
	Wrong values can ware.	Wrong values can lead to faulty operation or damage to the hard- ware.	
Format:	SEP_ <pswd>{_<ite< td=""><td colspan="2">SEP_<pswd>{_<itemid>_<pamid>_<pamvalue>}</pamvalue></pamid></itemid></pswd></td></ite<></pswd>	SEP_ <pswd>{_<itemid>_<pamid>_<pamvalue>}</pamvalue></pamid></itemid></pswd>	
Arguments:	<pswd></pswd>	Password for writing to the nonvolatile memory	
	<itemid></itemid>	Element of the electronics	
	<pamid></pamid>	Parameter ID	
	<pamvalue></pamvalue>	Parameter value	
Troubleshooting:	Impermissible element identifier		
	Wrong parameter	Wrong parameter ID	
	Wrong password		



SEP? Get Non-Volatile Memory Parameters

Used in: Parameter Commands (71), Saving Parameter Values in a Text File (72)

Description:	Queries the value of a parameter in the nonvolatile memory.		
	Up to four paramete	rs can be queried per command.	
Format:	<pre>SEP?[{_<itemid>_<pamid>}]</pamid></itemid></pre>		
Arguments:	<itemid></itemid>	Element of the electronics	
	<pamid></pamid>	Parameter ID	
Response:	{ <itemid>_<pamid>=<pamvalue>LF}</pamvalue></pamid></itemid>		
	<itemid></itemid>	Element of the electronics	
	<pamid></pamid>	Parameter ID	
	<pamvalue></pamvalue>	Parameter value	
Troubleshooting:	Impermissible element identifier		
	Wrong parameter ID		

SPA Set Volatile Memory Parameters

Used in: Parameter Commands (71)

Description:	Sets a paramete	Sets a parameter in the volatile memory to a specific value.		
	Up to four paran Wrong values ca	Up to four parameters can be set per command. Wrong values can lead to faulty operation or damage to the hard		
	ware.	ware.		
Format:	<pre>SPA{_<itemid>_<pamid>_<pamvalue>}</pamvalue></pamid></itemid></pre>			
Arguments:	<itemid></itemid>	Element of the electronics		
	<pamid></pamid>	Parameter ID		
	<pamvalue></pamvalue>	Parameter value		
Troubleshooting:	Impermissible el Wrong paramete	Impermissible element identifier Wrong parameter ID		


SPA? Get Volatile Memory Parameters

Used in: Parameter Commands (71), Saving Parameter Values in a Text File (72)

Description:	Queries the value of a parameter in the volatile memory.		
	Up to four parameters can be queried per command.		
Format:	<pre>SPA?[{_<itemid>_<pamid>}]</pamid></itemid></pre>		
Arguments:	<itemid></itemid>	Element of the electronics	
	<pamid></pamid>	Parameter ID	
Response:	{ <itemid>_<pamid>=<pamvalue>LF}</pamvalue></pamid></itemid>		
	<itemid></itemid>	Element of the electronics	
	<pamid></pamid>	Parameter ID	
	<pamvalue></pamvalue>	Parameter value	
Troubleshooting:	Impermissible element identifier Wrong parameter ID		

STP Stop All Axes

Used in: (66), Triggering motion in open-loop operation (28)

Description:	Stops all axes abruptly.
	Stops all motion started by motion commands (e.g., MOV, MVR, MVE, STE, SMO), referencing commands (FNL, FPL, FRF), and macros.
	Also stops the macro.
	Sets the error code to 10.
	After the axes are stopped, their target positions are set to their current positions.
Format:	STP

TIO? Tell Digital I/O Lines

Used in: Digital Input Signals (54), Digital Inputs and Outputs (53), Digital Output Signals (54)

Description:	Queries the number of available digital I/O lines.	
Format:	TI0?	
Response:	I= <uint1>_ւ⊧ O=<uint2>ւ⊧</uint2></uint1>	
	<uint1> Number of digital input lines (UINT)</uint1>	
	<uint2> Number of digital output lines (UINT)</uint2>	



TVI? Tell Valid Character Set For Axis Identifiers

Description:	Queries permissible characters for axis identifiers.
Format:	TVI?
Response:	<string></string>
	<string> Characters that are permitted for use in axis identifiers</string>

VAR Set Variable Value

Used in: Running the Macro (65)

Description:	Sets a variable to a specific value.	
	Local variables can only be set in macros. The variable is only in volatile memory (RAM).	
Format:	VAR_ <variable>_<string></string></variable>	
Arguments:	<variable> Name of the variable whose value is set <string> Value, that the variable is set to Can be specified directly or via the value of a variable.</string></variable>	

VAR? Get Variable Values

Used in: Running the Macro (65)

Description:	Queries the value of a variable.	
	Local variables can only be queries when a macro is running that contains local variables.	
Format:	VAR?[{_ <variable>}]</variable>	
Arguments:	<variable> Name of the variable being queried All variables are queried if no arguments are specified.</variable>	
Response:	{ <variable>=<string>LF}</string></variable>	
	<variable> Name of the variable <string> Value of the variable</string></variable>	

VER? Get Versions Of Firmware And Drivers

Used in: Important Firmware Components (19)

Description:	Queries the version numbers of the firmware.
	VER? also queries the version numbers of further components such as drivers and libraries.
Format:	VER?
Response:	{ <string1>:_<string2>LF}</string2></string1>
	<string1> Name of the component</string1>
	<string2> Version information and optional specifications</string2>



WAC Wait For Condition

Used in: Running the Macro (65)

Description: Waits until a condition is met.

WAC compares a specified value with a queried value according to a specified rule.

Can only be used in macros.

Possible relational operators:

<0P>	Description
=	Equal
!=	Not equal
<=	Smaller than or equal
<	Smaller than
>=	Larger than or equal
>	Larger than

Format:

Arguments:

WAC_ <cmd?>_<op>_<\</op></cmd?>	/alue>
<cmd?></cmd?>	Query command that responds with a single value
<0P>	Relational operator
<value></value>	Relational value with <cmd?></cmd?>



WPA Save Parameters To Non-Volatile Memory

Used in: Parameter Commands (71)

Description:	Writes the value of a parameter from the volatile memory (RAM) to
	the nonvolatile memory.

WPA can also save parameter-independent settings. The used password determines what is saved with WPA:

	<pswd></pswd>	Description	
	100	Saves current valid values of all parameters and the current valid settings for <u>HDT (p. 87)</u> , <u>HIA (p. 89)</u> , and <u>HIT (p. 93)</u> .	
	101	Saves the currently valid values of all parameters.	
	HID	Saves the current valid settings for <u>HDT (p. 87)</u> , <u>HIA (p. 89)</u> , and <u>HIT (p. 93)</u> .	
	Wrong values can lead to faulty operation or damage to the hard- ware. Notice: Note that the number of write cycles in the nonvolatile memory is limited. Therefore, save to the nonvolatile memory only when necessary.		
Format:	WPA_ <pswd>[{_<itemid>_<pamid>}]</pamid></itemid></pswd>		
Arguments:	<pswd></pswd>	Password for writing to the nonvolatile memory	
	<itemid></itemid>	Element of the electronics	
	<pamid></pamid>	Parameter ID	
	The <itemid> and <pamid> specifications are not supported by all electronics.</pamid></itemid>		
Troubleshooting:	Impermissible element identifier Wrong parameter ID Wrong password		



10 Parameter Reference

0x9	Maximum Motor Output	Maximum control value for driving an axis respectively a channel. See the response to HPA? for possible values
0x13	Is Rotary Stage?	Is this a rotation stage? Is not evaluated by the electronics but instead by the PC software. 0 Not a rotation stage 1 Rotation stage
0x3C	Stage Name	Positioner name. Default value: NOSTAGE String up to 20 characters
0x61	Invert Direction Of Motion For Joystick- Controlled Axis?	Inverts the direction of motion for HID-controlled axes.0 Direction of motion not inverted (default)1 Direction of motion inverted
0x72	Ignore Macro Error?	lgnore macro error? 0 Stop macro on error (default) 1 Ignore error
0xD000000	Controller Device S/N	Serial number of the electronics.
0xF000100	Stage Type	Mechanics type. x-xxx default positioners x-xxxKxxx customized positioners
0xF000200	Stage Serial Number	Serial number of the mechanics. 9-digit number
0xF000300	Stage Assembly Date	Manufacturing date of the mechanics. Date in DDMMYY format
0xF000400	Stage HW Version	Version number of the mechanics hardware.
0x1F000000	Q-Motion Upper Supply Voltage (V)	Maximum output voltage for piezo inertia drives. The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loaded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value! The value depends on the type of the drive.
0x1F000100	Q-Motion Lower Supply Voltage (V)	Minimum output voltage for piezo inertia drives. The value depends on the type of the drive.
0x1F000200	Q-Motion Forward Current (A)	Maximum output current for piezo inertia drives during forward motion. The value depends on the type of the drive.
0x1F000300	Q-Motion Backward Current (A)	Maximum output current for piezo inertia drives during backward motion. The value depends on the type of the drive.



0x1F000400	Q-Motion Frequency (Hz)	Frequency of the piezo voltage for open-loop operation of piezo inertia drives. Determines the velocity of a drive in open-loop operation. The value of this parameter must be chosen higher than the value of the 0x9 (Maximum Motor Output) parameter. Recommended: $0x1F000400 = 0x9 \times 1.25$
0x1F000500	Q-Motion Charge Cycle	Duty cycle of the current source during output of a step. Specified as part of a period which the current source is switched on for. 0 to 1 The value depends on the type of the drive.
0x1F000701	Q-Motion Delay (ms)	Delay time when switching between two operating modes (e.g., step mode and linear mode). 0 to 2000 [ms]

Ox9 Maximum Motor Output

Used in: How it Works (57)	
Description:	Maximum control value for driving an axis respectively a channel.
Data type	INT
Command level	0
Item type	Axis
Source of data	Positioner database
Possible values	See the response to HPA? for possible values

Ox13 Is Rotary Stage?

Description:	Is this a rotation stage? Is not evaluated by the electronics but instead by the PC software.
Data type	INT
Command level	0
Item type	Axis
Source of data	Positioner database
Possible values	0 Not a rotation stage 1 Rotation stage



Ox3C Stage Name

Used in: Commandable Item	s (21)
Description:	Positioner name.
	Default value: NOSTAGE
Data type	CHAR
Command level	0
Item type	Axis
Source of data	Positioner database
Possible values	String up to 20 characters

Ox61 Invert Direction Of Motion For Joystick-Controlled Axis?

Used in: HID Control Configu	iration (57)
Description:	Inverts the direction of motion for HID-controlled axes.
Data type	INT
Command level	0
Item type	Axis
Source of data	Positioner database
Possible values	0 Direction of motion not inverted (default) 1 Direction of motion inverted

Ox72 Ignore Macro Error?

Used in: (65)	
Description:	Ignore macro error?
Data type	INT
Command level	0
Item type	System
Source of data	PC software commands (<u>SPA (p. 108)</u> , <u>SEP (p. 107)</u>) or operating elements
Possible values	0 Stop macro on error (default)
	1 Ignore error



OxDOOOOO Controller Device S/N

Description:	Serial number of the electronics.
Data type	CHAR
Command level	2
Item type	System

OxFOOO100 Stage Type

Description:	Mechanics type.
Data type	CHAR
Command level	2
Item type	Axis
Source of data	ID chip of the mechanics
Possible values	x-xxx default positioners x-xxxKxxx customized positioners

OxF000200 Stage Serial Number

Description:	Serial number of the mechanics.
Data type	CHAR
Command level	2
Item type	Axis
Source of data	ID chip of the mechanics
Possible values	9-digit number



OxF000300 Stage Assembly Date

Description:	Manufacturing date of the mechanics.
Data type	CHAR
Command level	2
Item type	Axis
Source of data	ID chip of the mechanics
Possible values	Date in DDMMYY format

OxF000400 Stage HW Version

Description:	Version number of the mechanics hardware.
Data type	INT
Command level	2
Item type	Axis
Source of data	ID chip of the mechanics

Ox1F000000 Q-Motion Upper Supply Voltage (V)

Used in: (24)	
Description:	Maximum output voltage for piezo inertia drives.
	The level of the voltage depends on the connected positioner and is automatically set when the corresponding set of parameters is loa- ded from the positioner database. A wrong setting of this value can present a danger for the user and damage the connected positioner. Therefore, do not change the automatically set value!
Data type	FLOAT
Command level	1
Item type	Axis
Source of data	Positioner database
Possible values	The value depends on the type of the drive.



Ox1F000100 Q-Motion Lower Supply Voltage (V)

Used in: (24)	
Description:	Minimum output voltage for piezo inertia drives.
Data type	FLOAT
Command level	1
Item type	Axis
Source of data	Positioner database
Possible values	The value depends on the type of the drive.

Ox1F000200 Q-Motion Forward Current (A)

Used in: (24)	
Description:	Maximum output current for piezo inertia drives during forward mo- tion.
Data type	FLOAT
Command level	1
Item type	Axis
Source of data	Positioner database
Possible values	The value depends on the type of the drive.

Ox1F000300 Q-Motion Backward Current (A)

Used in: (24)	
Description:	Maximum output current for piezo inertia drives during backward motion.
Data type	FLOAT
Command level	1
Item type	Axis
Source of data	Positioner database
Possible values	The value depends on the type of the drive.



Ox1F000400 Q-Motion Frequency (Hz)

Used in: (24), Digital Input Signals (54), OSM Open-Loop Step Moving (105), Triggering motion in open-loop operation (28)

Description:	Frequency of the piezo voltage for open-loop operation of piezo iner- tia drives.	
	Determines the velocity of a drive in open-loop operation.	
Data type	FLOAT	
Command level	1	
Item type	Axis	
Source of data	Positioner database	
Possible values	The value of this parameter must be chosen higher than the value of the $0x9$ (p. 114) (Maximum Motor Output) parameter. Recommended: $0x1F000400 = 0x9 \times 1.25$	

Ox1F000500 Q-Motion Charge Cycle

Used in: (24)	
Description:	Duty cycle of the current source during output of a step. Specified as part of a period which the current source is switched on for.
Data type	FLOAT
Command level	1
Item type	Axis
Source of data	Positioner database
Possible values	0 to 1 The value depends on the type of the drive.



Ox1F000701 Q-Motion Delay (ms)

Used in: (24)	
Description:	Delay time when switching between two operating modes (e.g., step mode and linear mode).
Data type	FLOAT
Command level	1
Item type	Axis
Source of data	Positioner database
Possible values	0 to 2000 [ms]



11 Maintenance

11.1 Cleaning

Requirements

✓ You have disconnected the E-872.401 from the power supply.

Auxiliary Materials Required

- Soft, lint-free cloth
- Mild cleaning agent or disinfectant

If you have any questions on the auxiliary materials recommended for the E-872.401, contact our <u>customer service department (p. 9)</u>.

NOTICE

Short circuits or flashovers!

The E-872.401 contains electrostatically sensitive devices that can be damaged by short circuits or flashovers when cleaning fluids penetrate the housing.

- ▶ Before cleaning, disconnect the E-872.401 from the power supply.
- Prevent cleaning fluid from penetrating the case.

Cleaning the E-872.401

- 1. Dampen the cloth with the cleaning agent or disinfectant.
- 2. Carefully wipe the surfaces of the E-872.401.

11.2 Updating the Firmware

The following describes the procedure for updating the E-872.401's firmware.

Requirements

- ✓ You have connected the E-872.401 to the PC via the <u>communication interface (p. 41)</u>.
- ✓ "PIFirmwareManager" is installed on the PC (p. 35).
- ✓ You have copied the new firmware file, which you have received from our customer service department, to a directory on the PC.
- ✓ You have read and understood the documentation that you received from our customer service department together with the new firmware. You have learned from the documentation whether new parameters are introduced with the firmware update or the memory management of the E-872.401 changes.
- ✓ You have saved the parameter values of the E-872.401 in a text file on the PC (p. 50).
- ✓ You have saved the controller macros of the E-872.401 in files on the PC (p. 51).
- ✓ You have established communication between the E-872.401 and the PC with <u>PIMikroMove® or PITerminal (p. 43)</u>.



NOTICE

Malfunction due to faulty firmware update!

A faulty or incomplete update of the E-872.401's firmware may mean that the E-872.401 can only be made operational again by the PI customer service department.

- ► Update the E-872.401's firmware only after consulting our customer service department. If possible, ask our customer service department to do the firmware update for you.
- Before updating the firmware, make sure that you have received a suitable firmware from our customer service department and have stored it at a location that is accessible to the update program.

Information

The status LED of the E-872.401 flashes as long as the E-872.401 is in firmware update mode. The E-872.401 exits the firmware update mode only when it **reboots** after the firmware was **successfully** updated. If the firmware update was unsuccessful or aborted, the E-872.401 remains in the firmware update mode after a reboot.

If the status LED lights up continuously although the E-872.401 was restarted after updating the firmware:

- Repeat the firmware update.
- ▶ If the update of the firmware fails, contact our <u>customer service department (p. 9)</u>.

Updating the Firmware of the E-872.401

1. Start the *PIFirmwareManager* program on the PC and update the controller firmware. Proceed as described in the user manual <u>SM164E (p. 7)</u>.

Restarting the E-872.401

- 1. Switch off the E-872.401.
- 2. Switch the E-872.401 on again.
- → If the firmware update was successful, the E-872.401 exits the firmware update mode and indicates that it is in operating mode again.
- → If new parameters were added during updating of the firmware or the memory management of the E-872.401 was changed: Initialize the E-872.401.

Initializing the E-872.401 after a Firmware Update

1. Make sure that the current parameter values and controller macros of the E-872.401 have been saved on the PC.

The initialization of the E-872.401 resets all parameters to their factory settings and deletes all controller macros. Consequently, parameter values and controller macros that are not saved are lost during the initialization process.

2. On the PC, start PITerminal or PIMikroMove, connect to the E-872.401, and, if necessary, open the window to send commands.

Initialize the E-872.401 by sending the following commands successively:

ZZZ 100 parameter

ZZZ 100 macros

- → After successful initialization, the controller issues a corresponding message.
- 3. Adapt the parameter values of the E-872.401:
 - Reset the parameters that were already present prior to the firmware update to the saved values from the text file.
 - Set the parameters that were introduced with the firmware update to the appropriate values.



4. If you have saved controller macros on the PC: Load the controller macros into the E-872.401, see "Loading Controller Macros from the PC into the E-872.401 (p. 52)".



12 Troubleshooting

The positioner does not move	
Cable not connected correctly	Check the cable connections.
Unsuitable positioner cable used. Interference with the signal transmission be- tween the positioner and E-872.401 can oc- cur when an unsuitable cable is used.	 Only use genuine PI parts when connecting the positioner to the E-872.401. If you need extension cables, contact our <u>customer service department (p. 9)</u>.
Positioner or drive cable is defective	 If available, replace the defective positioner with another one and test the new combination. If available, replace the defective drive cable with another one and test the new combination.
Positioner was connected to the switched-on E-872.401 The sensor electronics in the positioner was not initialized and the sensor's ID chip was not read out.	Switch the E-872.401 off and on again, or reboot the E-872.401 with the RBT command or with the corresponding functions of the PC software.
Incorrect axis or channel commanded	Make sure that the correct axis or channel iden- tifier is used and that the positioner is connected correctly.
Incorrect configuration	Check the parameter settings of the E-872.401 with the <u>SPA? (p. 109)</u> (volatile memory) and the <u>SEP? (p. 108)</u> commands (nonvolatile mem- ory), and make the necessary corrections, refer to <u>adapting settings (p. 71)</u> .
Incorrect command or incorrect syntax	Send the ERR? command and check the error code that is returned.
HID control active Motion commands are not permitted when HID control is activated for the axis or the channel.	Deactivate <u>HID control (p. 57)</u> .
Positioner performs unintentional motion	
Control device is not connected, but HID con- trol is activated in the E-872.401	Activate <u>HID control (p. 57)</u> only when a control device is actually connected to the E-872.401.
HID axis is not calibrated	 Calibrate the axis of the <u>control device (p. 59)</u>.
Startup macro is run	Check whether a macro is specified as the <u>start-up macro (p. 66)</u> and cancel selection of the startup macro if necessary.
Communication between the E-872.401 and th	e PC not functioning
Wrong communication cable used	 Use a straight-through cable for TCP/IP connections to a network. Use a crossover network cable for TCP/IP connections direct to the PC. Use a null-modem cable for RS-232 connections. Use a standard-compliant USB cable (type A to type B or type A to type Mini-B) for USB connections
Communication cable defective	 Replace the communication cable.



TCP/IP interface not configured correctly	 Connect the controller to the network before you switch it on. Restart the E-872.401 if necessary. Check the network settings. Check the firewall settings to ensure that UDP broadcast is permitted. If necessary, contact your network administrator. Alternatively, enter the IP address of the controller manually. Make sure that the network is not blocked for unknown devices. Make sure that you have selected the correct E-872.401 when establishing communication. If you cannot solve the problems, consult your network administrator if necessary.
Another program is accessing the interface	 Close the other program.
The start procedure of the E-872.401's firm- ware has not finished yet	 Wait until the corresponding LED indicates operational readiness after switching on or rebooting the E-872.401. Try to establish communication.
Problems with special software	Check whether the system works with other software, e.g., a terminal program, or a development environment; for this purpose, enter the *IDN? or HLP? command using that software. Make sure that you end commands with an LF (line feed); a command is only executed when an LF is received.
E-872.401 does not send an error code in the o	case of incorrect system behavior
The error code was already queried by a dif- ferent instance In the case of simultaneous access to the E-872.401 by several instances, the error code is only returned to the first instance that sent the ERR? command. The error code is reset to 0 during the query.	 If possible, access the E-872.401 with one instance only. Check whether the error code is queried regularly in the background by a macro or script or PC software (e.g., PIMikroMove).
LEDs do not light up even though the E-872.40	01 is switched on
E-872.401 not connected to the power supply or the the power cord is defective.	 Switch off the E-872.401. Make sure that the E-872.401 is connected to the power supply and the power cord is not defective. Switch on the E-872.401.
If the problem is not listed in the table or cann	ot be solved as described, contact our

customer service department (p. 9).



13 Technical Data

Subject to change. You can find the latest product specifications on the product web page at <u>www.pi.ws</u>.

13.1 Specifications

	E-872.401
Function	Driver electronics for Q-Motion® positioners and PiezoMike line- ar actuators; benchtop device
Drive type	Piezo inertia drive
Channels	4 scalable to 64 channels via external module (on request)
Supported functions	Full-step mode, linear mode (analog control)
Amplifier	E-872.401
Amplifier Amplifier channels	E-872.401 1 drive of one axis at a time, the switching between the drive chan- nels is done via commands
Amplifier Amplifier channels Output voltage	E-872.401 1 drive of one axis at a time, the switching between the drive chan- nels is done via commands 0 to 100 V
AmplifierAmplifier channelsOutput voltagePeak power	E-872.4011 drive of one axis at a time, the switching between the drive chan- nels is done via commands0 to 100 V30 W



Interfaces and operation	E-872.401
Communication interfaces	USB, Ethernet
Actuator connection	4 x LEMO connector, 3-pin
Digital inputs	TTL inputs for commanding and configuration
Digital output	Error status
Command set	PI General Command Set (GCS)
User software	PIMikroMove
Application programming inter- faces	C, C++, C#, MATLAB, NI LabVIEW, Python
Display and indicators	LED indicator for status and operation
Manual control	Joystick via USB
Miscellaneous	E-872.401
Operating temperature range	0 to 50 °C
Overtemperature protection	Deactivation at 75 °C
Dimensions	147 mm × 125 mm × 40 mm
Mass	0.46 kg
Operating voltage	24 V (power adapter in the scope of delivery)

13.2 Maximum Ratings

The E-872.401 is designed for the following operating data:

Maximum operating volt-	Maximum operating fre-	Maximum power con-
age	quency	sumption
24 V	-	

13.3 Ambient Conditions and Classifications

Pay attention to the following ambient conditions and classifications for the E-872.401:



Area of application	For indoor use only
Maximum altitude	2000 m above msl
Air pressure	1100 hPa to 0.1 hPa
Relative humidity	Max. 80 % for temperatures to 31 °C, decreasing linearly to 50 % at 40 °C
Storage temperature	0 °C to 70 °C
Transport temperature	-25 °C to +85 °C
Overvoltage category	II
Protection class	1
Degree of pollution	2
Degree of protection according to IEC 60529	IP20

13.4 Dimensions



Figure 7: Dimensions of the E-872.401

Dimensions in mm. Note that the decimal places are separated by a comma in the drawings.



14 Appendix

14.1 Pin Assignment

14.1.1 Axis Connector



Figure 8: Drive connection: LEMO EPL.0S.303.HLN

Pin	Signal	Function
1	M+	Output: Motor voltage +
2	M-	Output: Motor voltage -
3	ID	Bidirectional: Data line for ID chip



14.1.2 I/O Connector



Figure 9: I/O connection: Phoenix Contact MC 1,5/14-GF-3,5-LR

Pin	Function
1 (5V)	+5 V DC, max. 50 mA (output)
2 (GND)	GND
3 (M0)	Selection of the drive channel, least significant bit (TTL, input)
4 (M1)	Selection of the drive channel, most significant bit (TTL, input)
5 (DIR)	Direction signal for step mode (TTL, input) High: Forward motion Low: Backward motion
6 (EN)	Activation of the drive in step mode (TTL, input)
7 (CMD)	Selection of command mode (TTL, input) High: Commanding via digital I/O lines Low: Commanding via PC or HID
8 (AN)	Analog input voltage for linear mode (0 - 4.8 V, input) Vch = VaN × 10 (Vch = output voltage of the channel, VaN = analog input voltage)
9 (ST)	Selection of the drive mode (TTL, input) High: Linear mode Low: Step mode
10 (ERR)	Error signal (TTL, output) High: Error (error code ≠ 0) Low: No error
11 (BMO)	Reserved
12 (BMI)	Reserved
13 (BCK)	Reserved
14 (BCS)	Reserved

The matching plug connector **MC 1,5/14-ST-3,5** is **not** included in the E-872.401's scope of delivery.



14.1.3 Power Adapter Connector



Figure 10: Voltage connection: M8 4-pin (m)

Pin	Signal	Function
1	GND	Ground
2	GND	Ground
3	V+	Input: Power supply, +24 V
4	V+	Input: Power supply, +24 V

14.2 GCS Error Codes

The error codes listed here are those of the PI General Command Set. As such, some may be not relevant to your controller and will simply never occur.



Contro	Controller errors		
0	PI_CNTR_NO_ERROR	No error	
1	PI_CNTR_PARAM_SYNTAX	Parameter syntax error	
2	PI_CNTR_UNKNOWN_COMMAND	Unknown command	
3	PI_CNTR_COMMAND_TOO_LONG	Command length out of limits or command buffer overrun	
4	PI_CNTR_SCAN_ERROR	Error while scanning	
5	PI_CNTR_MOVE_WITH- OUT_REF_OR_NO_SERVO	Unallowable move attempted on unreferenced ax- is, or move attempted with servo off	
6	PI_CNTR_INVALID_SGA_PARAM	Parameter for SGA not valid	
7	PI_CNTR_POS_OUT_OF_LIMITS	Position out of limits	
8	PI_CNTR_VEL_OUT_OF_LIMITS	Velocity out of limits	
9	PI_CNTR_SET_PIVOT_NOT_POS- SIBLE	Attempt to set pivot point while U,V and W not all 0	
10	PI_CNTR_STOP	Controller was stopped by command	
11	PI_CNTR_SST_OR_SCAN_RANGE	Parameter for SST or for one of the embedded scan algorithms out of range	
12	PI_CNTR_INVALID_SCAN_AXES	Invalid axis combination for fast scan	
13	PI_CNTR_INVALID_NAV_PARAM	Parameter for NAV out of range	
14	PI_CNTR_INVALID_ANALOG_IN- PUT	Invalid analog channel	
15	PI_CNTR_INVALID_AXIS_IDENTI- FIER	Invalid axis identifier	
16	PI_CNTR_INVALID_STAGE_NAME	Unknown stage name	
17	PI_CNTR_PAR- AM_OUT_OF_RANGE	Parameter out of range	
18	PI_CNTR_INVALID_MACRO_NAME	Invalid macro name	
19	PI_CNTR_MACRO_RECORD	Error while recording macro	



Contro	Controller errors				
20	PI_CNTR_MACRO_NOT_FOUND	Macro not found			
21	PI_CNTR_AXIS_HAS_NO_BRAKE	Axis has no brake			
22	PI_CNTR_DOUBLE_AXIS	Axis identifier specified more than once			
23	PI_CNTR_ILLEGAL_AXIS	Illegal axis			
24	PI_CNTR_PARAM_NR	Incorrect number of parameters			
25	PI_CNTR_INVALID_REAL_NR	Invalid floating point number			
26	PI_CNTR_MISSING_PARAM	Parameter missing			
27	PI_CNTR_SOFT_LIM- IT_OUT_OF_RANGE	Soft limit out of range			
28	PI_CNTR_NO_MANUAL_PAD	No manual pad found			
29	PI_CNTR_NO_JUMP	No more step-response values			
30	PI_CNTR_INVALID_JUMP	No step-response values recorded			
31	PI_CNTR_AXIS_HAS_NO_REFER- ENCE	Axis has no reference sensor			
32	PI_CNTR_STAGE_HAS_NO_LIM_S WITCH	Axis has no limit switch			
33	PI_CNTR_NO_RELAY_CARD	No relay card installed			
34	PI_CNTR_CMD_NOT_AL- LOWED_FOR_STAGE	Command not allowed for selected stage(s)			
35	PI_CNTR_NO_DIGITAL_INPUT	No digital input installed			
36	PI_CNTR_NO_DIGITAL_OUTPUT	No digital output configured			
37	PI_CNTR_NO_MCM	No more MCM responses			
38	PI_CNTR_INVALID_MCM	No MCM values recorded			
39	PI_CNTR_INVALID_CNTR_NUM- BER	Controller number invalid			



Contro	ller errors	
40	PI_CNTR_NO_JOYSTICK_CON- NECTED	No joystick configured
41	PI_CNTR_INVALID_EGE_AXIS	Invalid axis for electronic gearing, axis can not be slave
42	PI_CNTR_SLAVE_POSI- TION_OUT_OF_RANGE	Position of slave axis is out of range
43	PI_CNTR_COMMAND_EGE_SLAVE	Slave axis cannot be commanded directly when electronic gearing is enabled
44	PI_CNTR_JOYSTICK_CALIBRA- TION_FAILED	Calibration of joystick failed
45	PI_CNTR_REFERENCING_FAILED	Referencing failed
46	PI_CNTR_OPM_MISSING	OPM (Optical Power Meter) missing
47	PI_CNTR_OPM_NOT_INITIALIZED	OPM (Optical Power Meter) not initialized or can- not be initialized
48	PI_CNTR_OPM_COM_ERROR	OPM (Optical Power Meter) Communication Error
49	PI_CNTR_MOVE_TO_LIM- IT_SWITCH_FAILED	Move to limit switch failed
50	PI_CNTR_REF_WITH_REF_DISA- BLED	Attempt to reference axis with referencing disabled
51	PI_CNTR_AXIS_UNDER_JOY- STICK_CONTROL	Selected axis is controlled by joystick
52	PI_CNTR_COMMUNICATION_ER- ROR	Controller detected communication error
53	PI_CNTR_DYNAM- IC_MOVE_IN_PROCESS	MOV! motion still in progress
54	PI_CNTR_UNKNOWN_PARAME- TER	Unknown parameter
55	PI_CNTR_NO_REP_RECORDED	No commands were recorded with REP
56	PI_CNTR_INVALID_PASSWORD	Password invalid
57	PI_CNTR_INVALID_RECORD- ER_CHAN	Data Record Table does not exist



Contr	oller errors	
58	PI_CNTR_INVALID_RECORD- ER_SRC_OPT	Source does not exist; number too low or too high
59	PI_CNTR_INVALID_RECORD- ER_SRC_CHAN	Source Record Table number too low or too high
60	PI_CNTR_PARAM_PROTECTION	Protected Param: current Command Level (CCL) too low
61	PI_CNTR_AUTOZERO_RUNNING	Command execution not possible while Autozero is running
62	PI_CNTR_NO_LINEAR_AXIS	Autozero requires at least one linear axis
63	PI_CNTR_INIT_RUNNING	Initialization still in progress
64	PI_CNTR_READ_ONLY_PARAME- TER	Parameter is read-only
65	PI_CNTR_PAM_NOT_FOUND	Parameter not found in non-volatile memory
66	PI_CNTR_VOL_OUT_OF_LIMITS	Voltage out of limits
67	PI_CNTR_WAVE_TOO_LARGE	Not enough memory available for requested wave curve
68	PI_CNTR_NOT_ENOUGH_DDL_M EMORY	Not enough memory available for DDL table; DDL can not be started
69	PI_CNTR_DDL_TIME_DE- LAY_TOO_LARGE	Time delay larger than DDL table; DDL can not be started
70	PI_CNTR_DIFFERENT_AR- RAY_LENGTH	The requested arrays have different lengths; query them separately
71	PI_CNTR_GEN_SIN- GLE_MODE_RESTART	Attempt to restart the generator while it is running in single step mode
72	PI_CNTR_ANALOG_TARGET_AC- TIVE	Motion commands and wave generator activation are not allowed when analog target is active
73	PI_CNTR_WAVE_GENERA- TOR_ACTIVE	Motion commands are not allowed when wave generator is active
74	PI_CNTR_AUTOZERO_DISABLED	No sensor channel or no piezo channel connected to selected axis (sensor and piezo matrix)
75	PI_CNTR_NO_WAVE_SELECTED	Generator started (WGO) without having selected a wave table (WSL).



Contro	ller errors	
76	PI_CNTR_IF_BUFFER_OVERRUN	Interface buffer did overrun and command couldn't be received correctly
77	PI_CNTR_NOT_ENOUGH_RECOR- DED_DATA	Data Record Table does not hold enough recorded data
78	PI_CNTR_TABLE_DEACTIVATED	Data Record Table is not configured for recording
79	PI_CNTR_OPENLOOP_VAL- UE_SET_WHEN_SERVO_ON	Open-loop commands (SVA, SVR) are not allowed when servo is on
80	PI_CNTR_RAM_ERROR	Hardware error affecting RAM
81	PI_CNTR_MACRO_UN- KNOWN_COMMAND	Not macro command
82	PI_CNTR_MACRO_PC_ERROR	Macro counter out of range
83	PI_CNTR_JOYSTICK_ACTIVE	Joystick is active
84	PI_CNTR_MOTOR_IS_OFF	Motor is off
85	PI_CNTR_ONLY_IN_MACRO	Macro-only command
86	PI_CNTR_JOYSTICK_UN- KNOWN_AXIS	Invalid joystick axis
87	PI_CNTR_JOYSTICK_UN- KNOWN_ID	Joystick unknown
88	PI_CNTR_REF_MODE_IS_ON	Move without referenced stage
89	PI_CNTR_NOT_AL- LOWED_IN_CURRENT_MO- TION_MODE	Command not allowed in current motion mode
90	PI_CNTR_DIO_AND_TRAC- ING_NOT_POSSIBLE	No tracing possible while digital IOs are used on this HW revision. Reconnect to switch operation mode.
91	PI_CNTR_COLLISION	Move not possible, would cause collision
92	PI_CNTR_SLAVE_NOT_FAST_ENO UGH	Stage is not capable of following the master. Check the gear ratio.
93	PI_CNTR_CMD_NOT_AL- LOWED_WHILE_AXIS_IN_MOTION	This command is not allowed while the affected axis or its master is in motion.



Contro	ller errors	
94	PI_CNTR_OPEN_LOOP_JOY- STICK_ENABLED	Servo cannot be switched on when open-loop joy- stick control is activated.
95	PI_CNTR_INVALID_SER- VO_STATE_FOR_PARAMETER	This parameter cannot be changed in current servo mode.
96	PI_CNTR_UN- KNOWN_STAGE_NAME	Unknown stage name
97	PI_CNTR_INVALID_VAL- UE_LENGTH	Invalid length of value (too much characters)
98	PI_CNTR_AUTOZERO_FAILED	AutoZero procedure was not successful
99	PI_CNTR_SENSOR_VOLT- AGE_OFF	Sensor voltage is off
100	PI_LABVIEW_ERROR	PI driver for use with NI LabVIEW reports error. See source control for details.
200	PI_CNTR_NO_AXIS	No stage connected to axis
201	PI_CNTR_NO_AXIS_PARAM_FILE	File with axis parameters not found
202	PI_CNTR_INVALID_AXIS_PAR- AM_FILE	Invalid axis parameter file
203	PI_CNTR_NO_AXIS_PAR- AM_BACKUP	Backup file with axis parameters not found
204	PI_CNTR_RESERVED_204	PI internal error code 204
205	PI_CNTR_SMO_WITH_SERVO_ON	SMO with servo on
206	PI_CNTR_UUDECODE_INCOM- PLETE_HEADER	uudecode: incomplete header
207	PI_CNTR_UUDECODE_NOTH- ING_TO_DECODE	uudecode: nothing to decode
208	PI_CNTR_UUDECODE_ILLE- GAL_FORMAT	uudecode: illegal UUE format
209	PI_CNTR_CRC32_ERROR	CRC32 error
210	PI_CNTR_ILLEGAL_FILENAME	Illegal file name (must be 8-0 format)
211	PI_CNTR_FILE_NOT_FOUND	File not found on controller



Controller errors		
212	PI_CNTR_FILE_WRITE_ERROR	Error writing file on controller
213	PI_CNTR_DTR_HINDERS_VELOC- ITY_CHANGE	VEL command not allowed in DTR Command Mode
214	PI_CNTR_POSITION_UNKNOWN	Position calculations failed
215	PI_CNTR_CONN_POSSIBLY_BRO- KEN	The connection between controller and stage may be broken
216	PI_CNTR_ON_LIMIT_SWITCH	The connected stage has driven into a limit switch, some controllers need CLR to resume operation
217	PI_CNTR_UNEXPEC- TED_STRUT_STOP	Strut test command failed because of an unexpec- ted strut stop
218	PI_CNTR_POSI- TION_BASED_ON_ESTIMATION	While MOV! is running position can only be esti- mated!
219	PI_CNTR_POSI- TION_BASED_ON_INTERPOLA- TION	Position was calculated during MOV motion
220	PI_CNTR_INTERPOLA- TION_FIFO_UNDERRUN	FIFO buffer underrun during interpolation
221	PI_CNTR_INTERPOLA- TION_FIFO_OVERFLOW	FIFO buffer overflow during interpolation
230	PI_CNTR_INVALID_HANDLE	Invalid handle
231	PI_CNTR_NO_BIOS_FOUND	No bios found
232	PI_CNTR_SAVE_SYS_CFG_FAILE D	Save system configuration failed
233	PI_CNTR_LOAD_SYS_CFG_FAILE D	Load system configuration failed
301	PI_CNTR_SEND_BUFFER_OVER- FLOW	Send buffer overflow
302	PI_CNTR_VOLT- AGE_OUT_OF_LIMITS	Voltage out of limits
303	PI_CNTR_OPEN_LOOP_MO- TION_SET_WHEN_SERVO_ON	Open-loop motion attempted when servo ON



Contro	oller errors	
304	PI_CNTR_RECEIVING_BUF- FER_OVERFLOW	Received command is too long
305	PI_CNTR_EEPROM_ERROR	Error while reading/writing EEPROM
306	PI_CNTR_I2C_ERROR	Error on I2C bus
307	PI_CNTR_RECEIVING_TIMEOUT	Timeout while receiving command
308	PI_CNTR_TIMEOUT	A lengthy operation has not finished in the expec- ted time
309	PI_CNTR_MAC- RO_OUT_OF_SPACE	Insufficient space to store macro
310	PI_CNTR_EUI_OLDVER- SION_CFGDATA	Configuration data has old version number
311	PI_CNTR_EUI_INVALID_CFGDATA	Invalid configuration data
333	PI_CNTR_HARDWARE_ERROR	Internal hardware error
400	PI_CNTR_WAV_INDEX_ERROR	Wave generator index error
401	PI_CNTR_WAV_NOT_DEFINED	Wave table not defined
402	PI_CNTR_WAV_TYPE_NOT_SUP- PORTED	Wave type not supported
403	PI_CNTR_WAV_LENGTH_EX- CEEDS_LIMIT	Wave length exceeds limit
404	PI_CNTR_WAV_PARAMETER_NR	Wave parameter number error
405	PI_CNTR_WAV_PARAME- TER_OUT_OF_LIMIT	Wave parameter out of range
406	PI_CNTR_WGO_BIT_NOT_SUP- PORTED	WGO command bit not supported
500	PI_CNTR_EMERGEN- CY_STOP_BUTTON_ACTIVATED	The \"red knob\" is still set and disables system
501	PI_CNTR_EMERGEN- CY_STOP_BUTTON_WAS_ACTI- VATED	The \"red knob\" was activated and still disables system - reanimation required



Contro	ller errors	
502	PI_CNTR_REDUNDANCY_LIM- IT_EXCEEDED	Position consistency check failed
503	PI_CNTR_COLLI- SION_SWITCH_ACTIVATED	Hardware collision sensor(s) are activated
504	PI_CNTR_FOLLOWING_ERROR	Strut following error occurred, e.g. caused by over- load or encoder failure
505	PI_CNTR_SENSOR_SIGNAL_INVA- LID	One sensor signal is not valid
506	PI_CNTR_SERVO_LOOP_UNSTA- BLE	Servo loop was unstable due to wrong parameter setting and switched off to avoid damage.
507	PI_CNTR_LOST_SPI_SLAVE_CON- NECTION	Digital connection to external SPI slave device is lost
508	PI_CNTR_MOVE_AT- TEMPT_NOT_PERMITTED	Move attempt not permitted due to customer or limit settings
509	PI_CNTR_TRIGGER_EMERGEN- CY_STOP	Emergency stop caused by trigger input
530	PI_CNTR_NODE_DOES_NOT_EX- IST	A command refers to a node that does not exist
531	PI_CNTR_PA- RENT_NODE_DOES_NOT_EXIST	A command refers to a node that has no parent node
532	PI_CNTR_NODE_IN_USE	Attempt to delete a node that is in use
533	PI_CNTR_NODE_DEFINI- TION_IS_CYCLIC	Definition of a node is cyclic
536	PI_CNTR_HEXAPOD_IN_MOTION	Transformation cannot be defined as long as Hexapod is in motion
537	PI_CNTR_TRANSFORMA- TION_TYPE_NOT_SUPPORTED	Transformation node cannot be activated
539	PI_CNTR_NODE_PARENT_IDENTI- CAL_TO_CHILD	A node cannot be linked to itself
540	PI_CNTR_NODE_DEFINITION_IN- CONSISTENT	Node definition is erroneous or not complete (re- place or delete it)
542	PI_CNTR_NO- DES_NOT_IN_SAME_CHAIN	The nodes are not part of the same chain



Controller errors				
543	PI_CNTR_NODE_MEMORY_FULL	Unused nodes must be deleted before new nodes can be stored		
544	PI_CNTR_PIVOT_POINT_FEA- TURE_NOT_SUPPORTED	With some transformations pivot point usage is not supported		
545	PI_CNTR_SOFTLIMITS_INVALID	Soft limits invalid due to changes in coordinate system		
546	PI_CNTR_CS_WRITE_PROTEC- TED	Coordinate system is write protected		
547	PI_CNTR_CS_CON- TENT_FROM_CONFIG_FILE	Coordinate system cannot be changed because its content is loaded from a configuration file		
548	PI_CNTR_CS_CAN- NOT_BE_LINKED	Coordinate system may not be linked		
549	PI_CNTR_KSB_CS_ROTA- TION_ONLY	A KSB-type coordinate system can only be rotated by multiples of 90 degrees		
551	PI_CNTR_CS_DATA_CAN- NOT_BE_QUERIED	This query is not supported for this coordinate system type		
552	PI_CNTR_CS_COMBINA- TION_DOES_NOT_EXIST	This combination of work-and-tool coordinate systems does not exist		
553	PI_CNTR_CS_COMBINATION_IN- VALID	The combination must consist of one work and one tool coordinate system		
554	PI_CNTR_CS_TYPE_DOES_NOT_ EXIST	This coordinate system type does not exist		
555	PI_CNTR_UNKNOWN_ERROR	BasMac: unknown controller error		
556	PI_CNTR_CS_TYPE_NOT_ACTIVA- TED	No coordinate system of this type is activated		
557	PI_CNTR_CS_NAME_INVALID	Name of coordinate system is invalid		
558	PI_CNTR_CS_GENER- AL_FILE_MISSING	File with stored CS systems is missing or errone- ous		
559	PI_CNTR_CS_LEVEL- ING_FILE_MISSING	File with leveling CS is missing or erroneous		
601	PI_CNTR_NOT_ENOUGH_MEMO- RY	not enough memory		



Controller errors				
602	PI_CNTR_HW_VOLTAGE_ERROR	hardware voltage error		
603	PI_CNTR_HW_TEMPERA- TURE_ERROR	hardware temperature out of range		
604	PI_CNTR_POSITION_ER- ROR_TOO_HIGH	Position error of any axis in the system is too high		
606	PI_CNTR_IN- PUT_OUT_OF_RANGE	Maximum value of input signal has been exceeded		
607	PI_CNTR_NO_INTEGER	Value is not integer		
608	PI_CNTR_FAST_ALIGN- MENT_PROCESS_IS_NOT_RUN- NING	Fast alignment process cannot be paused be- cause it is not running		
609	PI_CNTR_FAST_ALIGN- MENT_PROC- ESS_IS_NOT_PAUSED	Fast alignment process cannot be restarted/ resumed because it is not paused		
650	PI_CNTR_UNABLE_TO_SET_PAR- AM_WITH_SPA	Parameter could not be set with SPA - SEP nee- ded?		
651	PI_CNTR_PHASE_FINDING_ER- ROR	Phase finding error		
652	PI_CNTR_SENSOR_SETUP_ER- ROR	Sensor setup error		
653	PI_CNTR_SENSOR_COMM_ER- ROR	Sensor communication error		
654	PI_CNTR_MOTOR_AMPLIFI- ER_ERROR	Motor amplifier error		
655	PI_CNTR_OVER_CURR_PRO- TEC_TRIGGERED_BY_I2T	Overcurrent protection triggered by I2T-module		
656	PI_CNTR_OVER_CURR_PRO- TEC_TRIGGERED_BY_AMP_MOD- ULE	Overcurrent protection triggered by amplifier mod- ule		
657	PI_CNTR_SAFETY_STOP_TRIG- GERED	Safety stop triggered		
658	PI_SENSOR_OFF	Sensor off?		
659	PI_CNTR_PARAM_CONFLICT	Parameter could not be set. Conflict with another parameter.		



Controller errors				
700	PI_CNTR_COMMAND_NOT_AL- LOWED_IN_EXTERNAL_MODE	Command not allowed in external mode		
710	PI_CNTR_EXTERNAL_MODE_ER- ROR	External mode communication error		
715	PI_CNTR_INVALID_MODE_OF_OP- ERATION	Invalid mode of operation		
716	PI_CNTR_FIRMWARE_STOP- PED_BY_CMD	Firmware stopped by command (#27)		
717	PI_CNTR_EXTER- NAL_MODE_DRIVER_MISSING	External mode driver missing		
718	PI_CNTR_CONFIGURATION_FAIL- URE_EXTERNAL_MODE	Missing or incorrect configuration of external mode		
719	PI_CNTR_EXTERNAL_MODE_CY- CLETIME_INVALID	External mode cycletime invalid		
720	PI_CNTR_BRAKE_ACTIVATED	Brake is activated		
725	PI_CNTR_DRIVE_STATE_TRANSI- TION_ERROR	Drive state transition error		
731	PI_CNTR_SURFACEDETEC- TION_RUNNING	Command not allowed while surface detection is running		
732	PI_CNTR_SURFACEDETEC- TION_FAILED	Last surface detection failed		
733	PI_CNTR_FIELDBUS_IS_ACTIVE	Fieldbus is active and is blocking GCS control commands		
1000	PI_CNTR_TOO_MANY_NES- TED_MACROS	Too many nested macros		
1001	PI_CNTR_MACRO_ALREADY_DE- FINED	Macro already defined		
1002	PI_CNTR_NO_MACRO_RECORD- ING	Macro recording not activated		
1003	PI_CNTR_INVALID_MAC_PARAM	Invalid parameter for MAC		
1004	PI_CNTR_RESERVED_1004	PI internal error code 1004		



Controller errors				
1005	PI_CNTR_CONTROLLER_BUSY	Controller is busy with some lengthy operation (e.g. reference move, fast scan algorithm)		
1006	PI_CNTR_INVALID_IDENTIFIER	Invalid identifier (invalid special characters,)		
1007	PI_CNTR_UNKNOWN_VARIA- BLE_OR_ARGUMENT	Variable or argument not defined		
1008	PI_CNTR_RUNNING_MACRO	Controller is (already) running a macro		
1009	PI_CNTR_MACRO_INVALID_OP- ERATOR	Invalid or missing operator for condition. Check necessary spaces around operator.		
1010	PI_CNTR_MACRO_NO_ANSWER	No response was received while executing WAC/MEX/JRC/		
1011	PI_CMD_NOT_VALID_IN_MAC- RO_MODE	Command not valid during macro execution		
1012	PI_CNTR_ERROR_IN_MACRO	Error occured during macro execution		
1024	PI_CNTR_MOTION_ERROR	Motion error: position error too large, servo is switched off automatically		
1025	PI_CNTR_MAX_MOTOR_OUT- PUT_REACHED	Maximum motor output reached		
1063	PI_CNTR_EXT_PROFILE_UNAL- LOWED_CMD	User Profile Mode: Command is not allowed, check for required preparatory commands		
1064	PI_CNTR_EXT_PROFILE_EXPECT- ING_MOTION_ERROR	User Profile Mode: First target position in User Profile is too far from current position		
1065	PI_CNTR_PROFILE_ACTIVE	Controller is (already) in User Profile Mode		
1066	PI_CNTR_PROFILE_IN- DEX_OUT_OF_RANGE	User Profile Mode: Block or Data Set index out of allowed range		
1071	PI_CNTR_PRO- FILE_OUT_OF_MEMORY	User Profile Mode: Out of memory		
1072	PI_CNTR_PRO- FILE_WRONG_CLUSTER	User Profile Mode: Cluster is not assigned to this axis		
1073	PI_CNTR_PROFILE_UN- KNOWN_CLUSTER_IDENTIFIER	Unknown cluster identifier		
1090	PI_CNTR_TOO_MANY_TCP_CON- NECTIONS_OPEN	There are too many open tcpip connections		


Contro	Controller errors		
2000	PI_CNTR_ALREADY_HAS_SERI- AL_NUMBER	Controller already has a serial number	
4000	PI_CNTR_SEC- TOR_ERASE_FAILED	Sector erase failed	
4001	PI_CNTR_FLASH_PRO- GRAM_FAILED	Flash program failed	
4002	PI_CNTR_FLASH_READ_FAILED	Flash read failed	
4003	PI_CNTR_HW_MATCHCODE_ER- ROR	HW match code missing/invalid	
4004	PI_CNTR_FW_MATCHCODE_ER- ROR	FW match code missing/invalid	
4005	PI_CNTR_HW_VERSION_ERROR	HW version missing/invalid	
4006	PI_CNTR_FW_VERSION_ERROR	FW version missing/invalid	
4007	PI_CNTR_FW_UPDATE_ERROR	FW update failed	
4008	PI_CNTR_FW_CRC_PAR_ERROR	FW Parameter CRC wrong	
4009	PI_CNTR_FW_CRC_FW_ERROR	FW CRC wrong	
5000	PI_CNTR_INVA- LID_PCC_SCAN_DATA	PicoCompensation scan data is not valid	
5001	PI_CNTR_PCC_SCAN_RUNNING	PicoCompensation is running, some actions can not be executed during scanning/recording	
5002	PI_CNTR_INVALID_PCC_AXIS	Given axis cannot be defined as PPC axis	
5003	PI_CNTR_PCC_SCAN_OUT_OF_R ANGE	Defined scan area is larger than the travel range	
5004	PI_CNTR_PCC_TYPE_NOT_EX- ISTING	Given PicoCompensation type is not defined	
5005	PI_CNTR_PCC_PAM_ERROR	PicoCompensation parameter error	
5006	PI_CNTR_PCC_TABLE_AR- RAY_TOO_LARGE	PicoCompensation table is larger than maximum table length	
5100	PI_CNTR_NEXLINE_ERROR	Common error in NEXLINE® firmware module	



Contro	oller errors	
5101	PI_CNTR_CHANNEL_AL- READY_USED	Output channel for NEXLINE® can not be rede- fined for other usage
5102	PI_CNTR_NEXLINE_TA- BLE_TOO_SMALL	Memory for NEXLINE® signals is too small
5103	PI_CNTR_RNP_WITH_SERVO_ON	RNP can not be executed if axis is in closed loop
5104	PI_CNTR_RNP_NEEDED	Relax procedure (RNP) needed
5200	PI_CNTR_AXIS_NOT_CONFIG- URED	Axis must be configured for this action
5300	PI_CNTR_FREQU_ANALY- SIS_FAILED	Frequency analysis failed
5301	PI_CNTR_FREQU_ANALY- SIS_RUNNING	Another frequency analysis is running
6000	PI_CNTR_SENSOR_ABS_INVA- LID_VALUE	Invalid preset value of absolute sensor
6001	PI_CNTR_SEN- SOR_ABS_WRITE_ERROR	Error while writing to sensor
6002	PI_CNTR_SEN- SOR_ABS_READ_ERROR	Error while reading from sensor
6003	PI_CNTR_SEN- SOR_ABS_CRC_ERROR	Checksum error of absolute sensor
6004	PI_CNTR_SENSOR_ABS_ERROR	General error of absolute sensor
6005	PI_CNTR_SENSOR_ABS_OVER- FLOW	Overflow of absolute sensor position

MOTION | POSITIONING



Interf	ace errors	
0	COM_NO_ERROR	No error occurred during function call
-1	COM_ERROR	Error during com operation (could not be specified)
-2	SEND_ERROR	Error while sending data
-3	REC_ERROR	Error while receiving data
-4	NOT_CONNECTED_ERROR	Not connected (no port with given ID open)
-5	COM_BUFFER_OVERFLOW	Buffer overflow
-6	CONNECTION_FAILED	Error while opening port
-7	COM_TIMEOUT	Timeout error
-8	COM_MULTILINE_RESPONSE	There are more lines waiting in buffer
-9	COM_INVALID_ID	There is no interface or DLL handle with the given ID
-10	COM_NOTIFY_EVENT_ERROR	Event/message for notification could not be opened
-11	COM_NOT_IMPLEMENTED	Function not supported by this interface type
-12	COM_ECHO_ERROR	Error while sending "echoed" data
-13	COM_GPIB_EDVR	IEEE488: System error
-14	COM_GPIB_ECIC	IEEE488: Function requires GPIB board to be CIC
-15	COM_GPIB_ENOL	IEEE488: Write function detected no listeners
-16	COM_GPIB_EADR	IEEE488: Interface board not addressed correctly
-17	COM_GPIB_EARG	IEEE488: Invalid argument to function call
-18	COM_GPIB_ESAC	IEEE488: Function requires GPIB board to be SAC
-19	COM_GPIB_EABO	IEEE488: I/O operation aborted
-20	COM_GPIB_ENEB	IEEE488: Interface board not found
-21	COM_GPIB_EDMA	IEEE488: Error performing DMA



Interfa	ce errors	
-22	COM_GPIB_EOIP	IEEE488: I/O operation started before previous operation completed
-23	COM_GPIB_ECAP	IEEE488: No capability for intended operation
-24	COM_GPIB_EFSO	IEEE488: File system operation error
-25	COM_GPIB_EBUS	IEEE488: Command error during device call
-26	COM_GPIB_ESTB	IEEE488: Serial poll-status byte lost
-27	COM_GPIB_ESRQ	IEEE488: SRQ remains asserted
-28	COM_GPIB_ETAB	IEEE488: Return buffer full
-29	COM_GPIB_ELCK	IEEE488: Address or board locked
-30	COM_RS_INVALID_DATA_BITS	RS-232: 5 data bits with 2 stop bits is an invalid combination, as is 6, 7, or 8 data bits with 1.5 stop bits
-31	COM_ERROR_RS_SETTINGS	RS-232: Error configuring the COM port
-32	COM_INTERNAL_RESOUR- CES_ERROR	Error dealing with internal system resources (events, threads,)
-33	COM_DLL_FUNC_ERROR	A DLL or one of the required functions could not be loaded
-34	COM_FTDIUSB_INVALID_HANDLE	FTDIUSB: invalid handle
-35	COM_FTDIUSB_DE- VICE_NOT_FOUND	FTDIUSB: device not found
-36	COM_FTDIUSB_DE- VICE_NOT_OPENED	FTDIUSB: device not opened
-37	COM_FTDIUSB_IO_ERROR	FTDIUSB: IO error
-38	COM_FTDIUSB_INSUFFI- CIENT_RESOURCES	FTDIUSB: insufficient resources
-39	COM_FTDIUSB_INVALID_PARAM- ETER	FTDIUSB: invalid parameter
-40	COM_FTDIUSB_INVA- LID_BAUD_RATE	FTDIUSB: invalid baud rate



Interfa	ce errors	
-41	COM_FTDIUSB_DE- VICE_NOT_OPENED_FOR_ERASE	FTDIUSB: device not opened for erase
-42	COM_FTDIUSB_DE- VICE_NOT_OPENED_FOR_WRITE	FTDIUSB: device not opened for write
-43	COM_FTDIUSB_FAILED_TO_WRIT E_DEVICE	FTDIUSB: failed to write device
-44	COM_FTDIUSB_EE- PROM_READ_FAILED	FTDIUSB: EEPROM read failed
-45	COM_FTDIUSB_EE- PROM_WRITE_FAILED	FTDIUSB: EEPROM write failed
-46	COM_FTDIUSB_EE- PROM_ERASE_FAILED	FTDIUSB: EEPROM erase failed
-47	COM_FTDIUSB_EE- PROM_NOT_PRESENT	FTDIUSB: EEPROM not present
-48	COM_FTDIUSB_EE- PROM_NOT_PROGRAMMED	FTDIUSB: EEPROM not programmed
-49	COM_FTDIUSB_INVALID_ARGS	FTDIUSB: invalid arguments
-50	COM_FTDIUSB_NOT_SUPPOR- TED	FTDIUSB: not supported
-51	COM_FTDIUSB_OTHER_ERROR	FTDIUSB: other error
-52	COM_PORT_ALREADY_OPEN	Error while opening the COM port: was already open
-53	COM_PORT_CHECKSUM_ERROR	Checksum error in received data from COM port
-54	COM_SOCKET_NOT_READY	Socket not ready, you should call the function again
-55	COM_SOCKET_PORT_IN_USE	Port is used by another socket
-56	COM_SOCKET_NOT_CONNEC- TED	Socket not connected (or not valid)
-57	COM_SOCKET_TERMINATED	Connection terminated (by peer)
-58	COM_SOCKET_NO_RESPONSE	Can't connect to peer



Interface errors		
-59	COM_SOCKET_INTERRUPTED	Operation was interrupted by a nonblocked signal
-60	COM_PCI_INVALID_ID	No device with this ID is present
-61	COM_PCI_ACCESS_DENIED	Driver could not be opened (on Vista: run as ad- ministrator!)
-62	COM_SOCK- ET_HOST_NOT_FOUND	Host not found
-63	COM_DEVICE_CONNECTED	Device already connected



DLL er	rors	
-1001	PI_UNKNOWN_AXIS_IDENTIFIER	Unknown axis identifier
-1002	PI_NR_NAV_OUT_OF_RANGE	Number for NAV out of rangemust be in [1,10000]
-1003	PI_INVALID_SGA	Invalid value for SGAmust be one of 1, 10, 100, 1000
-1004	PI_UNEXPECTED_RESPONSE	Controller sent unexpected response
-1005	PI_NO_MANUAL_PAD	No manual control pad installed, calls to SMA and related commands are not allowed
-1006	PI_INVALID_MANUAL_PAD_KNOB	Invalid number for manual control pad knob
-1007	PI_INVALID_MANUAL_PAD_AXIS	Axis not currently controlled by a manual control pad
-1008	PI_CONTROLLER_BUSY	Controller is busy with some lengthy operation (e.g., reference move, fast scan algorithm)
-1009	PI_THREAD_ERROR	Internal errorcould not start thread
-1010	PI_IN_MACRO_MODE	Controller is (already) in macro modecommand not valid in macro mode
-1011	PI_NOT_IN_MACRO_MODE	Controller not in macro modecommand not valid unless macro mode active
-1012	PI_MACRO_FILE_ERROR	Could not open file to write or read macro
-1013	PI_NO_MACRO_OR_EMPTY	No macro with given name on controller, or macro is empty
-1014	PI_MACRO_EDITOR_ERROR	Internal error in macro editor
-1015	PI_INVALID_ARGUMENT	One or more arguments given to function is invalid (empty string, index out of range,)
-1016	PI_AXIS_ALREADY_EXISTS	Axis identifier is already in use by a connected stage
-1017	PI_INVALID_AXIS_IDENTIFIER	Invalid axis identifier
-1018	PI_COM_ARRAY_ERROR	Could not access array data in COM server
-1019	PI_COM_ARRAY_RANGE_ERROR	Range of array does not fit the number of parame- ters



-1020	PI_INVALID_SPA_CMD_ID	Invalid parameter ID given to SPA or SPA?
-1021	PI_NR_AVG_OUT_OF_RANGE	Number for AVG out of rangemust be >0
-1022	PI_WAV_SAM- PLES_OUT_OF_RANGE	Incorrect number of samples given to WAV
-1023	PI_WAV_FAILED	Generation of wave failed
-1024	PI_MOTION_ERROR	Motion error: position error too large, servo is switched off automatically
-1025	PI_RUNNING_MACRO	Controller is (already) running a macro
-1026	PI_PZT_CONFIG_FAILED	Configuration of PZT stage or amplifier failed
-1027	PI_PZT_CONFIG_INVALID_PAR- AMS	Current settings are not valid for desired configura- tion
-1028	PI_UNKNOWN_CHANNEL_IDENTI- FIER	Unknown channel identifier
-1029	PI_WAVE_PARAM_FILE_ERROR	Error while reading/writing wave generator param- eter file
-1030	PI_UNKNOWN_WAVE_SET	Could not find description of wave form. Maybe WG.INI is missing?
-1031	PI_WAVE_EDI- TOR_FUNC_NOT_LOADED	The WGWaveEditor DLL function was not found at startup
-1032	PI_USER_CANCELLED	The user cancelled a dialog
-1033	PI_C844_ERROR	Error from C-844 Controller
-1034	PI_DLL_NOT_LOADED	DLL necessary to call function not loaded, or func- tion not found in DLL
-1035	PI_PARAMETER_FILE_PROTEC- TED	The open parameter file is protected and cannot be edited
-1036	PI_NO_PARAME- TER_FILE_OPENED	There is no parameter file open
-1037	PI_STAGE_DOES_NOT_EXIST	Selected stage does not exist
-1038	PI_PARAMETER_FILE_AL- READY_OPENED	There is already a parameter file open. Close it be- fore opening a new file



DLL er	rors	
-1039	PI_PARAMETER_FILE_OPEN_ER- ROR	Could not open parameter file
-1040	PI_INVALID_CONTROLLER_VER- SION	The version of the connected controller is invalid
-1041	PI_PARAM_SET_ERROR	Parameter could not be set with SPAparameter not defined for this controller!
-1042	PI_NUMBER_OF_POSSI- BLE_WAVES_EXCEEDED	The maximum number of wave definitions has been exceeded
-1043	PI_NUMBER_OF_POSSIBLE_GEN- ERATORS_EXCEEDED	The maximum number of wave generators has been exceeded
-1044	PI_NO_WAVE_FOR_AXIS_DE- FINED	No wave defined for specified axis
-1045	PI_CANT_STOP_OR_START_WAV	Wave output to axis already stopped/started
-1046	PI_REFERENCE_ERROR	Not all axes could be referenced
-1047	PI_RE- QUIRED_WAVE_NOT_FOUND	Could not find parameter set required by frequency relation
-1048	PI_INVALID_SPP_CMD_ID	Command ID given to SPP or SPP? is not valid
-1049	PI_STAGE_NAME_ISNT_UNIQUE	A stage name given to CST is not unique
-1050	PI_FILE_TRANSFER_BE- GIN_MISSING	A uuencoded file transferred did not start with "be- gin" followed by the proper filename
-1051	PI_FILE_TRANSFER_ER- ROR_TEMP_FILE	Could not create/read file on host PC
-1052	PI_FILE_TRANSFER_CRC_ERROR	Checksum error when transferring a file to/from the controller
-1053	PI_COULDNT_FIND_PISTAG- ES_DAT	The PiStages.dat database could not be found. This file is required to connect a stage with the CST command
-1054	PI_NO_WAVE_RUNNING	No wave being output to specified axis
-1055	PI_INVALID_PASSWORD	Invalid password
-1056	PI_OPM_COM_ERROR	Error during communication with OPM (Optical Power Meter), maybe no OPM connected



DLL er	rors	
-1057	PI_WAVE_EDITOR_WRONG_PAR- AMNUM	WaveEditor: Error during wave creation, incorrect number of parameters
-1058	PI_WAVE_EDITOR_FREQUEN- CY_OUT_OF_RANGE	WaveEditor: Frequency out of range
-1059	PI_WAVE_EDI- TOR_WRONG_IP_VALUE	WaveEditor: Error during wave creation, incorrect index for integer parameter
-1060	PI_WAVE_EDI- TOR_WRONG_DP_VALUE	WaveEditor: Error during wave creation, incorrect index for floating point parameter
-1061	PI_WAVE_EDI- TOR_WRONG_ITEM_VALUE	WaveEditor: Error during wave creation, could not calculate value
-1062	PI_WAVE_EDITOR_MISS- ING_GRAPH_COMPONENT	WaveEditor: Graph display component not instal- led
-1063	PI_EXT_PROFILE_UNAL- LOWED_CMD	User Profile Mode: Command is not allowed, check for required preparatory commands
-1064	PI_EXT_PROFILE_EXPECT- ING_MOTION_ERROR	User Profile Mode: First target position in User Profile is too far from current position
-1065	PI_EXT_PROFILE_ACTIVE	Controller is (already) in User Profile Mode
-1066	PI_EXT_PROFILE_IN- DEX_OUT_OF_RANGE	User Profile Mode: Block or Data Set index out of allowed range
-1067	PI_PROFILE_GENERA- TOR_NO_PROFILE	ProfileGenerator: No profile has been created yet
-1068	PI_PROFILE_GENERA- TOR_OUT_OF_LIMITS	ProfileGenerator: Generated profile exceeds limits of one or both axes
-1069	PI_PROFILE_GENERATOR_UN- KNOWN_PARAMETER	ProfileGenerator: Unknown parameter ID in Set/Get Parameter command
-1070	PI_PROFILE_GENERA- TOR_PAR_OUT_OF_RANGE	ProfileGenerator: Parameter out of allowed range
-1071	PI_EXT_PROFILE_OUT_OF_MEM- ORY	User Profile Mode: Out of memory
-1072	PI_EXT_PROFILE_WRONG_CLUS- TER	User Profile Mode: Cluster is not assigned to this axis
-1073	PI_UNKNOWN_CLUSTER_IDENTI- FIER	Unknown cluster identifier



DLL er	rors	
-1074	PI_INVALID_DEVICE_DRIV- ER_VERSION	The installed device driver doesn't match the re- quired version. Please see the documentation to determine the required device driver version.
-1075	PI_INVALID_LIBRARY_VERSION	The library used doesn't match the required ver- sion. Please see the documentation to determine the required library version.
-1076	PI_INTERFACE_LOCKED	The interface is currently locked by another func- tion. Please try again later.
-1077	PI_PARAM_DAT_FILE_INVA- LID_VERSION	Version of parameter DAT file does not match the required version. Current files are available at www.pi.ws.
-1078	PI_CANNOT_WRITE_TO_PAR- AM_DAT_FILE	Cannot write to parameter DAT file to store user defined stage type.
-1079	PI_CANNOT_CREATE_PAR- AM_DAT_FILE	Cannot create parameter DAT file to store user de- fined stage type.
-1080	PI_PARAM_DAT_FILE_INVA- LID_REVISION	Parameter DAT file does not have correct revision.
-1081	PI_USERSTAGES_DAT_FILE_IN- VALID_REVISION	User stages DAT file does not have correct revi- sion.
-1082	PI_SOFTWARE_TIMEOUT	Timeout Error. Some lengthy operation did not fin- ish within expected time.
-1083	PI_WRONG_DATA_TYPE	A function argument has an unexpected data type.
-1084	PI_DIFFERENT_ARRAY_SIZES	Length of data arrays is different.
-1085	PI_PARAM_NOT_FOUND_IN_PAR- AM_DAT_FILE	Parameter value not found in parameter DAT file.
-1086	PI_MACRO_RECORD- ING_NOT_AL- LOWED_IN_THIS_MODE	Macro recording is not allowed in this mode of op- eration.
-1087	PI_USER_CANCELLED_COM- MAND	Command cancelled by user input.
-1088	PI_TOO_FEW_GCS_DATA	Controller sent too few GCS data sets
-1089	PI_TOO_MANY_GCS_DATA	Controller sent too many GCS data sets
-1090	PI_GCS_DATA_READ_ERROR	Communication error while reading GCS data



DLL errors				
-1091	PI_WRONG_NUMBER_OF_IN- PUT_ARGUMENTS	Wrong number of input arguments.		
-1092	PI_FAILED_TO_CHANGE_CCL_LE VEL	Change of command level has failed.		
-1093	PI_FAILED_TO_SWITCH_OFF_SE RVO	Switching off the servo mode has failed.		
-1094	PI_FAILED_TO_SET_SINGLE_PA- RAMETER_WHILE_PERFORM- ING_CST	A parameter could not be set while performing CST: CST was not performed (parameters remain unchanged).		
-1095	PI_ERROR_CONTROLLER_RE- BOOT	Connection could not be reestablished after re- boot.		
-1096	PI_ERROR_AT_QHPA	Sending HPA? or receiving the response has failed.		
-1097	PI_QHPA_NONCOMPLI- ANT_WITH_GCS	HPA? response does not comply with GCS2 syn- tax.		
-1098	PI_FAILED_TO_READ_QSPA	Response to SPA? could not be received.		
-1099	PI_PAM_FILE_WRONG_VERSION	Version of PAM file cannot be handled (too old or too new)		
-1100	PI_PAM_FILE_INVALID_FORMAT	PAM file does not contain required data in PAM-file format		
-1101	PI_INCOMPLETE_INFORMATION	Information does not contain all required data		
-1102	PI_NO_VALUE_AVAILABLE	No value for parameter available		
-1103	PI_NO_PAM_FILE_OPEN	No PAM file is open		
-1104	PI_INVALID_VALUE	Invalid value		
-1105	PI_UNKNOWN_PARAMETER	Unknown parameter		
-1106	PI_RESPONSE_TO_QSEP_FAILED	Response to SEP? could not be received.		
-1107	PI_RESPONSE_TO_QSPA_FAILED	Response to SPA? could not be received.		
-1108	PI_ERROR_IN_CST_VALIDATION	Error while performing CST: One or more parame- ters were not set correctly.		



DLL errors				
-1109	PI_ERROR_PAM_FILE_HAS_DU- PLICATE_ENTRY_WITH_DIFFER- ENT_VALUES	PAM file has duplicate entry with different values.		
-1110	PI_ERROR_FILE_NO_SIGNATURE	File has no signature		
-1111	PI_ERROR_FILE_INVALID_SIGNA- TURE	File has invalid signature		
-1000 0	PI_PARAMETER_DB_INVA- LID_STAGE_TYPE_FORMAT	PI stage database: String containing stage type and description has invalid format.		
-1000 1	PI_PARAMETER_DB_SYS- TEM_NOT_AVAILABLE	PI stage database: Database does not contain the selected stage type for the connected controller.		
-1000 2	PI_PARAME- TER_DB_FAILED_TO_ESTAB- LISH_CONNECTION	PI stage database: Establishing the connection has failed.		
-1000 3	PI_PARAMETER_DB_COMMUNI- CATION_ERROR	PI stage database: Communication was interrup- ted (e.g. because database was deleted).		
-1000 4	PI_PARAMETER_DB_ER- ROR_WHILE_QUERYING_PARAM- ETERS	PI stage database: Querying data failed.		
-1000 5	PI_PARAMETER_DB_SYSTEM_AL- READY_EXISTS	PI stage database: System already exists. Re- name stage and try again.		
-1000 6	PI_PARAMETER_DB_QHPA_CON- TANS_UNKNOWN_PAM_IDS	PI stage database: Response to HPA? contains unknown parameter IDs.		
-1000 7	PI_PARAME- TER_DB_AND_QHPA_ARE_IN- CONSISTENT	PI stage database: Inconsistency between data- base and response to HPA?.		
-1000 8	PI_PARAMETER_DB_SYS- TEM_COULD_NOT_BE_ADDED	PI stage database: Stage has not been added.		
-1000 9	PI_PARAMETER_DB_SYS- TEM_COULD_NOT_BE_REMOVED	PI stage database: Stage has not been removed.		
-1001 0	PI_PARAMETER_DB_CONTROL- LER_DB_PARAMETERS_MIS- MATCH	Controller does not support all stage parameters stored in PI stage database. No parameters were set.		
-10011	PI_PARAMETER_DB_DATA- BASE_IS_OUTDATED	The version of PISTAGES3.DB stage database is out of date. Please update via PIUpdateFinder. No parameters were set.		



DLL errors

-1001 2	PI_PARAME- TER_DB_AND_HPA_MIS- MATCH_STRICT	Mismatch between number of parameters present in stage database and available in controller inter- face. No parameters were set.
-1001 3	PI_PARAME- TER_DB_AND_HPA_MIS- MATCH_LOOSE	Mismatch between number of parameters present in stage database and available in controller inter- face. Some parameters were ignored.
-1001 4	PI_PARAME- TER_DB_FAILED_TO_SET_PA- RAMETERS_CORRECTLY	One or more parameters could not be set correctly on the controller.
-1001 5	PI_PARAMETER_DB_MISS- ING_PARAMETER_DEFINI- TIONS_IN_DATABASE	One or more parameter definitions are not present in stage database. Please update PISTAGES3.DB via PIUpdateFinder. Missing parameters were ig- nored.



Glossary

Daisy chain

Wiring diagram by which one controller is connected to the next in sequence (series connection principle). The first controller is connected directly to the PC. The additional controllers are always connected to the ones that precede them so that a chain is formed. The signal to and from a controller goes to the PC via the previous controllers.

Dynamics profile

The dynamic profile includes the target position, speed, and acceleration of the axis calculated by the profile generator of the electronics for each point in time of motion. The calculated values are called "commanded values".

GCS

Abbreviation for "General Command Set", the command set for electronics from Pl. Piezo and servo controllers can be operated together with minimal programming effort thanks to GCS.

HID

Abbreviation for "Human Interface Device". HID refers to an input or output device that is connected to the electronics and intended for manual operation. Depending on the electronics, the connection can be made via USB, analog or digital interfaces. Joysticks and gamepads are typical HIDs.

Nonvolatile memory

Electronics read-only memory. The default values for the parameters are loaded from the nonvolatile memory into the volatile memory when the electronics are started. The parameter values in the nonvolatile memory are also referred to as "Startup Values" in the PC software from Pl.

Specifications

The performance specifications are checked before dispatch. The performance specifications apply to room temperature (22 ± 3 °C), systems in closed-loop operation are calibrated at this temperature. It may be necessary to reset the operating parameters when operating at considerably lower or higher temperatures.

Volatile memory

Electronics main memory. Parameters are stored in the volatile memory when the device is switched on. The parameter values in the volatile memory determine the current behavior of the system. The parameter values in the volatile memory are also referred to as "Active Values" in the PC software from PI.