


A-63x Series Low Profile Rotary Air Bearing Stage

Pliglide RL, Direct-drive Torque Motor Driven with Encoder Feedback



This document describes the A-63x.xxxx Series of Rotary Air Bearing Motorized Stages.

User Manual

A630D0001 Rev 3.0
29-Nov-2021



Physik Instrumente (PI) GmbH & Co. KG is the owner of the following trademarks:

PI®, PIC®, PICMA®, PILine®, PIFOC®, PiezoWalk®, NEXACT®, NEXLINE®, NanoCube®, NanoAutomation®, Picoactuator®, PInano®, PIMag®

PI owns the following patents or patent applications for the technology field Magnetic Direct Drives (PIMag®):
WO212146709A2, DE102012207082A1

© 2021 PI (Physik Instrumente) L.P. The text, photographs and drawings in this manual are protected by copyright. With regard thereto, PI (Physik Instrumente) L.P. retains all the rights. Use of said text, photographs and drawings is permitted only in part and only upon citation of the source.

Subject to change without notice. This manual is superseded by any new release. PI continually improves its product offerings, and listed options and specifications may be superseded at any time.

User Manual

A630D0001 Rev 3.0
29-Nov-2021



Table of Contents

1. About this Document	5
1.1. Objective and Target Audience of this User Manual	5
1.2. Symbols and Typographic Conventions	5
1.3. Other Applicable Documents	5
2. Safety	6
2.1. Intended Use	6
2.2. General Safety Instructions	6
2.3. Warnings and Safety Notices	7
2.4. Organizational Measures	8
3. Product Description	9
3.1. Model Overview and Part Numbering	9
3.2. Product Features	10
3.3. Product Labeling	11
3.4. Scope of Delivery	12
3.5. Accessories	12
3.6. Controllers	12
4. Technical Features	13
4.1. Air Bearing	13
4.2. Air Bearing Locking Feature	13
4.3. Torque Motor	13
4.4. Encoder	13
4.5. Index Mark (incremental encoders only)	13
5. Unpacking and Handling	14
6. Installation	15
6.1. Mounting Surface Quality and Preparation	15
6.2. Mounting Orientation	15
6.3. Mounting Procedure	16
6.4. Air Supply	16
6.5. Affixing the Payload to the Stage	17
6.6. Multi-Axis Configurations	17
6.7. Connecting the Stage to Protective Earth	18
6.8. Connecting the Cables	19

User Manual

A630D0001 Rev 3.0
29-Nov-2021



7.	Startup and Operation of the Stage	20
8.	Maintenance	21
8.1.	Cleaning the Stage	21
8.2.	Preparing the Stage for Transport	21
9.	Customer Service	22
10.	Technical Data	23
10.1.	Sizes and Load Capacities	23
10.2.	Performance Specifications	23
10.3.	Motor Electrical Specifications	24
10.4.	Encoder Specifications	24
10.5.	Ambient Conditions	25
10.6.	Dimensions	26
10.7.	Pin Assignments	29
11.	EC Declaration of Conformity	30
12.	Old Equipment Disposal	30

Table of Figures

Figure 1 - Product Features, A-63x	10
Figure 2 - Product Labeling Example	11
Figure 3 - Mounting Surface Quality	15
Figure 4 - Air Inlet Fitting Location	16
Figure 5 - Earth ground connection point location	18
Figure 6 - Mounting of the protective earth conductor (profile view)	18
Figure 7 - A-634.xxxx Stage Dimensions	26
Figure 8 - A-635.xxxx Stage Dimensions	27
Figure 9 - A-638.xxxx Stage Dimensions	28



1. About this Document

1.1. Objective and Target Audience of this User Manual

This manual contains information on the intended use of the A-63x series of linear motor-driven air bearing stages. It assumes that the reader has a fundamental understanding of basic servo systems as well as motion control concepts and applicable safety procedures.

1.2. Symbols and Typographic Conventions

The following symbols and markings are used in this User Manual:

Symbol	Meaning
 WARNING	If not avoided, the situation could result in damage to the equipment.
 DANGER DANGER DANGER	Failure to observe these precautions could result in serious injury to those performing the procedures and damage to the equipment.
1. 2.	Action consisting of several steps whose sequential order must be observed
➤	Action consisting of one or several steps whose sequential order is irrelevant

1.3. Other Applicable Documents

None at this time

2. Safety

2.1. Intended Use

The A-63x is a laboratory device as defined by DIN EN 61010. It is intended to be used in interior spaces and in an environment which is free of dirt, oil and lubricants.

In accordance with its design and realization, the A-63x is intended for rotational positioning of loads at different velocities. The A-63x is not intended for applications in areas in which a failure would present severe risks to human beings or the environment.

The A-63x is intended for horizontal mounting only in which the plane of the stage tabletop is level and parallel to the plane of the ground.

The intended use of the A-63x is only possible when completely mounted and connected.

The A-63x must be operated with a suitable controller. The controller or interconnect cables are not included in the scope of delivery of the A-63x.

2.2. General Safety Instructions




The A-63x is built according to state-of-the-art technology and recognized safety standards. Improper use can result in personal injury and/or damage to the A-63x.

- Only use the A-63x for its intended purpose, and only use it if it is in a good working order.
- Read the user manual.
- Immediately eliminate any faults and malfunctions that are likely to affect safety.
- The operator is responsible for the correct installation and operation of the A-63x.

2.3. Warnings and Safety Notices

The following statements apply throughout this manual. Failure to observe these precautions could result in serious injury to those performing the procedures and damage to the equipment. This manual and any additional instructions included with the stage should be retained for the lifetime of the stage.

 DANGER	To minimize the possibility of electrical shock and bodily injury or death, disconnect all electrical power prior to making any electrical connections.
 DANGER	To minimize the possibility of electrical shock and bodily injury or death when any electrical circuit is in use, ensure that no person comes in contact with the circuitry when the stage is connected to a power source.
 DANGER	To minimize the possibility of bodily injury or death, disconnect all electrical power prior to making any mechanical adjustments.
 DANGER	To minimize the possibility of bodily injury or death from electric shock in the case of malfunction or failure of the system, make sure a protective earth conductor is properly connected.
 DANGER	Moving parts of the stage can cause crushing or shearing injuries. All personnel must remain clear of any moving parts.
 WARNING	The stage table should never be moved without the air supply turned on. Moving the stage table with no air supply, causing sliding metal-to-metal contact, may damage the bearing surfaces.
 DANGER	Improper use of the stage can cause damage, shock, injury, or death. Read and understand this manual before operating the stage.
 DANGER	If the stage is used in a manner not specified by the manufacturer, the protection provided by the stage can be impaired.
 DANGER	Stage cables can pose a tripping hazard. Securely mount and position all stage cables to avoid potential hazards.
 DANGER	Do not expose the stage to environments or conditions outside the specified range of operating environments. Operation in conditions other than those specified can cause damage to the equipment.
 DANGER	The stage must be mounted securely. Improper mounting can result in injury and damage to the equipment.
 DANGER	Use care when moving the stage. Manually lifting or transporting stages can result in injury.
 WARNING	Use care when moving the stage. Avoid any shocks, drops or bumps that can cause scratches, dings, dents, or distortion of the stage.

 DANGER	The stage contains high power magnets that can attract ferrous objects, such as loose screws. Attracted objects can damage the stage. Make sure that there are no movable, ferrous objects within a radius of at least 10 cm around the stage.
 DANGER	The stage contains high power magnets that can damage magnetically sensitive objects such as magnetic data carriers and electronic devices. Make sure that there are no magnetically sensitive objects within a radius of at least 10 cm around the stage.
 WARNING	Dirt, oil, lubricants and condensation will damage the stage. Keep the stage clean and free of dirt, debris, oil, lubricants, and moisture.

2.4. Organizational Measures

User manual

- Always keep this user manual available near the A-63x.
- Add all information given by the manufacturer to the user manual, for example supplements or Technical Notes.
- If you pass the A-63x on to other users, also turn over this user manual as well as other relevant information provided by the manufacturer.
- Only use the device on the basis of the complete user manual. Missing information due to an incomplete user manual can result in minor injury and property damage.
- Only install and operate the A-63x after having read and understood this user manual.

Personnel qualification

The A-63x may only be installed, started up, operated, maintained and cleaned by authorized and appropriately qualified personnel.

3. Product Description

3.1. Model Overview and Part Numbering

The A-63x series offers various models, defined by the stage size, encoder type, and motor option. The dimensions of the various models vary. Encoder and motor options do not affect the dimensions.

Model	Table Diameter	Encoder Options	Motor
A-63	4 = 150mm	A = Incremental, Sine (1 Vp-p) output	100 = Standard motor option, slotless
	5 = 200mm	B = Absolute BiSS-C	
	8 = 350mm		

User Manual

A630D0001 Rev 3.0
29-Nov-2021



3.2. Product Features

The PIglide A-63x series of direct-drive rotary air bearing stages are a complete positioning solution designed for ultra-precision rotary motion in low-profile package. The RL is ideal for wafer indexing and alignment applications, as well as rotational scanning. The RL stages offer superior runout, flatness, and wobble performance. Since they are completely frictionless, they exhibit no breakaway “stiction” or drag friction during operation. They are ideal for use in cleanrooms, require no maintenance or lubrication, and have unlimited life.

The air bearing, motor, and encoder are housed in the internals of the stage and are not visible to the user.





Figure 1 - Product Features, A-63x

#	Description
1.	Stage base
2.	Moving table
3.	Motor electrical connection
4.	Encoder electrical connection
5.	Air supply inlet (radial)
6.	Air supply inlet (axial)
7.	Vacuum supply inlet
8.	Earth ground lug

3.3. Product Labeling



Figure 2 - Product Labeling Example

#	Description
1.	Product model number (example)
2.	Serial number (example), individual for each A-63x Meaning of the places (counting from left): A = PIglide Air Bearing Product 17 = year of manufacture (i.e. 2017) 160501 = unique number, 6-digit
3.	Warning sign "Observe manual"
4.	Old equipment disposal warning sign
5.	CE conformity mark
6.	Country of origin
7.	Manufacturer's address (website)
8.	Manufacturer's logo

User Manual

A630D0001 Rev 3.0
29-Nov-2021



3.4. Scope of Delivery

Item ID	Component
A-63x.xxxxxx	Stage according to the order
---	Stage Mounting Screws (4x, size depends on model)
A630D0001	User manual (this document)
---	Shipping restraint kit
----	Performance Test Report

3.5. Accessories

The following accessories are offered to complement the A-63x stage. Contact PI for all available configurations.

Part #	Description
A-80x.xxx	Air Preparation and Filtration Kit
A-851.xxx	Cable sets for integration with various controllers

3.6. Controllers

The A-63x must be connected to a suitable motion controller to be operated. The following standard controllers are available from PI to operate the A-63x. Other controllers are also available, contact PI for options.

Part #	Description
A-8xx.xxxxx	PIglide Family of Motion Controllers (1 - 8 Axes) ACS SPiiPlus

Discuss your application with a PI sales engineer to determine the proper controller and stage configuration.

4. Technical Features

4.1. Air Bearing

The A-63x series stage features a non-contact, frictionless air bearing to guide the motion of the stage and support the payload. This air bearing is a highly accurate precision instrument. The non-contact nature of the air bearings will provide years of accurate and reliable use if treated properly. Keep the bearing clean and avoid any shocks, drops or bumps that can cause scratches, dings or distortion of the bearing.

The A-63x incorporates a magnetic preload in the axial direction mechanism. The A-63x is only suitable for horizontal operation (i.e. plane of tabletop parallel to the ground). Be careful not to apply excess cantilever loads to the stage table or the bearing may be damaged.

4.2. Air Bearing Locking Feature

The stage is equipped with two air inlet fittings. One supplies air to the radial air bearing, the other supplies air to the axial/lift air bearing. The inlets are separated in this way in case the user wants to incorporate a self-lock feature. By turning the axial/lift supply on or off while keeping the radial supply on, the stage position can be locked. The stage uses magnetic preload in the axial direction, which provides the locking force. This locking can be done while the servo loop is enabled. Automation of the locking can be achieved thru use of a solenoid valve controlled by the system motion controller. Contact PI for additional information about use of this feature.

4.3. Torque Motor

The A-63x series stage features a brushless, ironless, slotless 3-phase torque motor. This type of motor technology is completely non-contact and is ideally suited to high speeds; high accelerations; fine resolution positioning; and smooth, constant-velocity scanning. The motor must be commutated by an external motor drive. Hall Effect sensors are not included, so the drive and/or controller must be capable of encoder-based (sine) commutation.

4.4. Encoder

The A-63x series stage features an optical non-contact position encoder for direct measurement of the stage position. This feedback signal is used by an external motion controller to close the servo loop for position and velocity control.

The A-63x series stage offers three types of encoders:

- Incremental with analog (sine) output: Suitable for use with controllers using on-board encoder interpolation.
- Absolute with BiSS-C 32-bit serial output: Eliminates the need for startup homing routines and limit switches.

4.5. Index Mark (incremental encoders only)







When equipped with either of the incremental encoder options, the A-63x series stage features a non-contact home index marker. The index is integral to the encoder electronics. The index mark is optical. There is one index per revolution of the stage.

5. Unpacking and Handling

Carefully unpack the air bearing stage and other components from the shipping packaging. Inspect the contents for signs of damage. If there is any sign of damage or missing parts, contact PI immediately. Compare the package contents to packing list and notify PI immediately if any parts are missing or incorrect. Keep all packaging materials in case the product needs to be returned.

Before mounting or using the stage, it is recommended to let the stage stabilize at room temperature for at least 24 hours. Clean any dust or shipping debris off the stage by blowing it off with pressurized nitrogen or clean, oil-free air.

If the stage will be mounted in such a way as to block the product label, it is recommended to record the stage serial number for future reference.

 WARNING	The A-63x stage must always be transported and shipped with the shipping restraint installed. Failure to use the shipping restraint when moving, transporting, or shipping the stage may allow movement between the stage table and stage base, causing damage.
 WARNING	The stage table should never be moved without the air supply turned on. Moving the stage table with no air supply, causing sliding metal-to-metal contact, may damage the bearing surfaces.
 DANGER	Use care when moving the stage. Manually lifting or transporting stages can result in injury.
 WARNING	Use care when moving the stage. Avoid any shocks, drops or bumps that can cause scratches, dings, dents, or distortion of the stage.
 WARNING	When lifting the A-63x, take care to lift only by the base plate of the stage. Do not lift using any other part of the mechanical system, or damage may occur.
 Caution Heavy	The A-63x stage weighs up to 24 kg in its largest size. Use care when lifting and use two people to lift.

6. Installation

6.1. Mounting Surface Quality and Preparation

The surface to which the stage will be mounted should be flat and have adequate stiffness in order to achieve the maximum performance from the A-63x. When the A-63x series stage is mounted to a non-flat surface, the stage can be distorted as the mounting screws are tightened. This distortion will decrease the overall accuracy of the stage. The effects of flatness on mounting are illustrated below.

To maintain accuracy, the mounting surface should be flat within **1 μm per 100 mm**. A laboratory grade AA granite surface plate is recommended. Do not shim under the stage base.




Figure 3 - Mounting Surface Quality

Prepare the mounting surface and bottom of the stage base with precision flat stones to remove any burrs or high spots. Clean the mounting surface and bottom of the stage with the appropriate cleaners (isopropyl alcohol).

6.2. Mounting Orientation

The A-63x is suitable for only for horizontal mounting orientation. PI recommends that you review your payload and orientation conditions with a PI sales engineer before purchasing this product.

6.3. Mounting Procedure

1. Place the stage on the mounting surface.
2. Remove the shipping restraint.
3. Connect the compressed air supply and turn on the air.
4. Affix the stage base to the mounting surface using the four mounting screws provided.
5. Torque the mounting screws. The typical maximum torque value for the mounting screws is shown in the table below. Do not over-tighten the bolts. The values shown are the maximum, using 60% of the maximum value is recommended initially, with increased tightness only as needed.

The stage should be securely mounted. Make sure to allow sufficient clearance to attach the motor and encoder cables to the stage.

Model	Mounting Screw (4x)	Max. Screw Torque (N-m)
A-634	M5 SHCS, 35mm long (minimum)	12
A-635	M6 SHCS, 35mm long (minimum)	20
A-638	M6 SHCS, 40mm long (minimum)	20

6.4. Air Supply

Air Requirements

The A-63x stage requires clean, oil-free, and dry compressed air to operate properly. See Section 10.2 for detailed air supply requirements.

It is recommended that a pressure switch is installed to monitor air supply pressure and to remove power from the stage motor if supply pressure drops below 40 psi to prevent damage to the air bearing surfaces.

The air inlet fittings to the A-63x stage accepts flexible polyurethane pneumatic tubing, 6mm OD. In the case where a single air supply line is to be connected to the stage, use a T-fitting to tie the two air lines together from a single supply line.




Figure 4 - Air Inlet Fitting Location

The A-63x includes an optional vacuum feed-thru, which allows the user to pass a vacuum supply through the rotating stage up to the stage tabletop. The A-63x can also feature an integrated vacuum chuck directly into the stage tabletop. When combined with the integral vacuum feed-thru, these two features allow direct vacuum support for a semiconductor wafer or other round, flat work piece. Connect a vacuum supply to the Vacuum inlet port using 6mm OD flexible tubing.

Turning off the air supply when not in use

When the stage is not in use, the air supply may be turned off to preserve compressed air and energy.

 WARNING	The stage table should never be moved without the air supply turned on. Moving the stage table with no air supply, causing sliding metal-to-metal contact, may damage the bearing surfaces.
--	---

6.5. Affixing the Payload to the Stage





The payload should be flat, rigid, and comparable to the stage in quality. For valid system performance, the mounting interface surface should be flat within **1 µm per 50 mm**.

The stage tabletop features tapped holes for mounting the user's payload. These are the only features that should be used to attach a payload to the stage. Mounting-hole sizes and patterns will depend on the stage model ordered; see the drawings in Section 10.6 for details.

Prepare the payload mounting surface and the stage table with precision flat stones to remove any burrs or high spots. Clean the payload mounting surface and the stage table with the appropriate cleaners (isopropyl alcohol).

For optimum performance, the payload center of mass should be centered on the stage tabletop. If the payload is not centered, the rotating mass will not be balanced about the axis of rotation. Imbalance, especially at higher rotational speeds, can cause vibration, excessive error motion, and possibly damage to the stage.

If any buzzing or vibration can be heard, the payload may be deforming the air bearing. Loosen the bolt torques until the sounds stop. If the stage still buzzes, please contact PI for additional support.

 WARNING	Do not attempt to modify the stage table in any way. Customer modifications may damage the stage.
 WARNING	The screws used to attach the payload to the stage table should not thread into the stage tabletop any more than the depth shown on the CAD drawing. Longer screws may damage the table.
 WARNING	Do not over-tighten the payload mounting screws.
 WARNING	Do not exceed the maximum payload specified for the A-63x stage.

6.6. Multi-Axis Configurations

Multi-axis configurations of the A-63x series stage are not available at this time without customization. Please contact PI for a quote if you require a multi-axis system.

6.7. Connecting the Stage to Protective Earth



To minimize the possibility of bodily injury or death from electric shock in the case of malfunction or failure of the system, make sure a protective earth conductor is properly connected.


The A-63x has an M4 threaded hole for connecting the protective earth conductor. This hole is marked with the symbol for the protective earth ground . The hole is located on the end plate of the stage near the air inlet.

Figure 5 - Earth ground connection point location




Figure 6 - Mounting of the protective earth conductor (profile view)





#	Description
1.	Base plate of the A-63x
2.	Flat washer (2x)
3.	Internal tooth washer (2x)
4.	M4 Screw
5.	Cable lug
6.	Protective earth conductor

1. If necessary, fasten a suitable cable lug to the protective earth conductor. Note that the conductor and lug are not in the scope of delivery of the stage.
2. Fasten the cable lug of the protective earth conductor to the protective earth connection of the A-63x as shown in the profile view using the M4 screw provided. You will need a 2mm Allen key.
3. Tighten the M4 screw with a torque of 1.2 Nm to 1.5 Nm.
4. Make sure that the contact resistance at all connection points relevant for mounting the protective earth conductor is $<0.1 \Omega$ at 25 A.

6.8. Connecting the Cables

Stage interconnect cables are not in the scope of delivery of the A-63x series stage. However, PI offers several standard cable sets that can be used, depending on the motion controller being used. Contact PI for a quote.

See Section 10.7 for connector pin assignments.

 WARNING	Only use the interconnect cables that have been designed for the combination of stage and controller being used. Connection using the wrong cable may result in damage to the stage and the controller.
 DANGER	To minimize the possibility of electrical shock and bodily injury or death, disconnect all electrical power prior to making any electrical connections.
 DANGER	To minimize the possibility of electrical shock and bodily injury or death when any electrical circuit is in use, ensure that no person comes in contact with the circuitry when the stage is connected to a power source.
 DANGER	To minimize the possibility of bodily injury or death, disconnect all electrical power prior to making any mechanical adjustments.









1. Connect the stage cables for the motor and encoder to the connectors on the end plate of the A-63x stage.
2. Tighten the jack screws with a flat head screwdriver to secure the cables. Do not over tighten the screws.

See Figure 1 for connector location.

7. Startup and Operation of the Stage

See the user's manual of the controller being used with the A-63x stage for instructions about startup and operation.

Note that the servo tuning values may need to be adjusted if the payload mass or size changes. If PI was not given user application information at the time of order, the servo was tuned with no payload mass.


 DANGER	Moving parts of the stage can cause crushing or shearing injuries. All personnel must remain clear of any moving parts.
 WARNING	Collisions can damage the stage and the payload. <ul style="list-style-type: none"> ➤ Take care when operating the stage to ensure that no collisions are possible between the stage, the load to be moved, and the environment in the motion range of the stage. ➤ Do not place any objects in areas where they can be caught by moving parts. ➤ Stop the motion immediately if a controller malfunction occurs.
 WARNING	Do not attempt to operate unless the stage table can move freely.
 WARNING	The A-63x can develop high forces and accelerations. If the stage has been improperly or incompletely installed, the stage, the payload, and the environment can be damaged during operation.
 WARNING	The stage table should never be moved without the air supply turned on. Moving the stage table with no air supply, causing sliding metal-to-metal contact, may damage the bearing surfaces.
 WARNING	The drive mechanism of the A-63x is not self-locking. The stage can therefore unintentionally move in the following cases: <ul style="list-style-type: none"> ▪ Switching off or restarting the controller ▪ Switching off the servo mode for the axis Unintentional displacement can damage the stage, the payload to be moved, and the environment. <ul style="list-style-type: none"> ➤ Only operate the A-63x with a horizontally aligned motion axis. ➤ Before switching off or rebooting the controller, take suitable measures to ensure that no unintentional displacement of the stage table is possible.
 DANGER	Do not exceed the operating voltage range for which the A-63x is specified.
 WARNING	The optimum values of the servo-loop parameters in the controller depend on the application and the payload mass/inertia. Unsuitable servo-control parameter settings of the controller can cause the control loop to become unstable and for the stage to vibrate. Oscillations can damage the stage and/or the load affixed to it. <ul style="list-style-type: none"> ➤ If the stage is oscillating or exhibits unusual operating noise, immediately switch off the servo mode for the axis on the controller or switch off the controller. ➤ Only switch on the servo mode for the axis on the controller after you have modified the servo-control parameter settings; see the manual of the controller. ➤ Note that the servo tuning values may need to be adjusted if the payload mass, size, or inertia changes.

8. Maintenance

Other than basic cleaning, the A-63x series stage is maintenance-free.

8.1. Cleaning the Stage

To clean the stage surfaces, use isopropanol and a clean, lint-free cloth or wipe. Apply the cleaning agent to the cloth and wipe down all of the surfaces. When cleaning the stage it is recommended to leave the air supply turned on to help blow any particles out of the bearing and prevent particles from entering the nozzles. Be especially careful of fingerprints on the surfaces as they attract dust and may tarnish the finish.






 WARNING	Do not use cleaning agents other than isopropanol. Agents such as acetone or other detergents can damage certain parts of the stage.
--	--

8.2. Preparing the Stage for Transport

If the stage requires movement, transport, or shipping, follow these steps:

1. Turn off the controller power.
2. Disconnect stage cables.
3. Remove the payload.
4. Turn off the air supply and disconnect the air supply line from the stage.
5. Install the shipping restraint and restraint label. Tighten the stage shipping restraint screws using an Allen wrench.

The stage is now secured and can be safely moved. If the stage needs to be shipped, use the original packing materials.

 WARNING	Use care when moving the stage. Avoid any shocks, drops or bumps that can cause scratches, dings, dents, or distortion of the stage.
 WARNING	The stage table should never be moved without the air supply turned on. Moving the stage table with no air supply, causing sliding metal-to-metal contact, may damage the bearing surfaces.
 WARNING	Do not attempt to move or transport the stage with the payload attached. This may damage the stage and the payload.
 WARNING	When lifting the A-63x, take care to lift only by the base plate of the stage. Do not lift using any other part of the mechanical system, or damage may occur.
 Caution Heavy	The A-63x stage weighs up to 23 kg in its largest size. Use care when lifting and use two people to lift.

9. Customer Service

For inquiries and orders, contact your PI sales engineer or use the following contacts:

Email: air@pi-usa.us

Address: 16 Albert Street, Auburn, MA 01501, USA

Tel: 508-832-3456

Fax: 508-832-0506

If you have questions concerning your system, have the following information ready:

- Product codes and serial numbers of all products in the system
- Firmware version of the controller (if present)
- Version of the driver or the software (if present)
- Operating system on the PC (if present)
- If possible: Take photographs or make videos of your system that can be sent to our customer service department if requested.

User Manual

A630D0001 Rev 3.0
29-Nov-2021



10. Technical Data

See the PI website for latest published specifications.

10.1. Sizes and Load Capacities

Model	Table Diameter (mm)	Load Capacity (N)		Tilt Load Capacity (N-m)
		Axial	Radial	
A-634	150	190	40	4.5
A-635	200	320	80	12
A-638	350	1200	200	130

Values listed assume supply pressure of 550 kPa (80 psi). Please contact PI if alternate pressures are required.

10.2. Performance Specifications

Specification	Units	A-634	A-635	A-638
Drive System	-	Frameless, brushless, slotless, direct-drive torque motor		
Feedback System	-	Non-contact optical rotary encoder		
Travel	-	Unlimited, 360° continuous		
Positioning Accuracy, Calibrated ⁽¹⁾	μrad	< +/- 8		
Repeatability, Bi-directional	μrad	< +/- 4		
Radial Error Motion, Synchronous (Eccentricity) ⁽²⁾	nm	200	150	100
Axial Error Motion, Synchronous (Flatness) ⁽²⁾	nm	75	75	50
Tilt Error Motion, Synchronous (Wobble) ⁽²⁾	μrad	2.0	2.0	1.0
Max Velocity ⁽³⁾	RPM	500		
Rotating Moment of Inertia	kg-mm ²	6,640	23,400	146,655
Rotating Mass	kg	1.9	3.6	11
Total Stage Mass	kg	4.6	7.5	24
Operating Pressure ⁽⁴⁾	550 +/-35 kPa (80 +/-5 psi)			
Air Consumption	< 56 liters/minute (2 SCFM)			
Air Quality	Clean (filtered to 1.0 μm or better) - ISO 8573-1 Class 1 Oil-free - ISO 8573-1 Class 1 Dry (-15 °C dew point) - ISO 8573-1 Class 3			
Construction	Hardcoat Aluminum, SS Fasteners			

Notes:

1. Values shown are obtained using controller-based error compensation. Stage must be purchased with a PI/ACS controller to achieve this performance. Accuracy values assume short-term time duration and do not consider the long-term effects of thermal drift on the stage.
2. Precision specifications are dependent on quality of mounting surfaces, payload, orientation, and external forces on the stage. Please consult PI for application-specific parameters. Values shown are static (zero rotational velocity during measurement) with no payload.
3. Velocity may be further limited by encoder options, payload imbalance, or controller and drive electronics.
4. To protect stage from damage, an under-pressure air sensor tied to the controller E-stop input is recommended.

User Manual

A630D0001 Rev 3.0
29-Nov-2021



10.3. Motor Electrical Specifications

Specification	Units	A-634	A-635, A-638
Motor Bus Voltage	VDC	48 VDC nominal, 80 VDC max	
Peak Current	A	6.9	13.9
Continuous Current	A	2.3	4.5
Peak Torque	N-m	4.7	8.5
Continuous Torque	N-m	1.6	2.8
Torque Constant	N-m/A	0.59	0.66
Back EMF	V/kRPM	71	80
Resistance (phase-to-phase)	Ω	6.7	4.5
Inductance (phase-to-phase)	mH	0.9	0.6
# Poles	-	48	64

10.4. Encoder Specifications

Option Code	A	B
Type	Incremental	Absolute
Output Signal	Analog Quadrature 1 Vp-p, Differential	BiSS-C 32-bit serial
Power Input	5 VDC, <200 mA	5 VDC, <250mA
Input Ripple	200 mVp-p max @ up to 500 kHz	

Model	Option Code	Units	A-634	A-635	A-638
Fundamental Lines/Rev	A	#	23,600	31,488	31,488
Resolution	A ⁽¹⁾	μ rad (arc-sec)	0.06 (0.013)	0.05 (0.010)	0.05 (0.010)
	B		0.0015 (0.0003)		
Index Mark	A	-	0.8 to 1.2 Vp-p, Differential, 1/rev		
	B	-	None		

Notes:

1. Resolution shown for encoder option "A" assumes 4096x interpolation.

10.5. Ambient Conditions

Area of use	For indoor use only
Vacuum Operation	This product is not compatible with operation in a vacuum environment.
Maximum Altitude	2000m
Relative humidity	40% to 60% non-condensing
Operating temperature ⁽¹⁾	+15°C to +25°C
Storage temperature	0°C to +40°C in original packaging
Dust Exposure	The A-63x series stage is not suited for dusty, dirty, oily, or wet environments.
Overvoltage Category	II
Protection Class	I
Degree of Pollution	1
Degree of protection according to IEC 60529	IP20
Area of use	For indoor use only

Notes:

1. For optimum performance, the stage should be operated at 20°C. Any deviation from this temperature could degrade the precision and performance of the stage. Any deviation outside the range shown above may damage the stage.

User Manual

A630D0001 Rev 3.0
29-Nov-2021



10.6. Dimensions




Figure 7 - A-634.xxxx Stage Dimensions

User Manual

A630D0001 Rev 3.0
29-Nov-2021




Figure 8 - A-635.xxxx Stage Dimensions

User Manual

A630D0001 Rev 3.0
29-Nov-2021





Figure 9 - A-638.xxxx Stage Dimensions

10.7. Pin Assignments

If a pin is not listed, assume it is N/C.


Motor Connector

Type: DB9W4M

		
Pin	Function	Description
A1	PHA	Motor phase A
A2	PHB	Motor phase B
A3	PHC	Motor phase C


Encoder Connector, Encoder Option "A"

Type: DB15M

		
Pin	Function	Description
1	Cos-	Encoder Analog Cosine -
2	Sin-	Encoder Analog Sine -
3	Index+	Encoder Analog Reference +
4	+5v	Encoder power
5	+5v Sense	Encoder power sense line
6	Vx	Encoder Setup
7	Lim+	Open collector Limit+
8	Lim-	Open collector Limit-
9	Cos+	Encoder Analog Cosine +
10	Sin+	Encoder Analog Sine +
11	Index -	Encoder Analog Reference -
12	GND	Encoder ground
13	GND Sense	Encoder ground sense line
14	CAL	Encoder Calibration

Encoder Connector, Encoder Option "B"

Type: DB15M

		
Pin	Function	Description
2	MA+	Encoder CLK+ (MA+)
3	MA-	Encoder CLK- (MA-)
4	+5v	Encoder power
5	+5v	Encoder power
6	SLO+	Encoder Data+ (SLO+)
7	SLO-	Encoder Data- (SLO-)
8	GND	Encoder ground
9	GND	Encoder ground

11. EC Declaration of Conformity

For the model A-63x (all options and configurations), an EC Declaration of Conformity has been issued in accordance with the following European directives:

- 2004/108/EC, EMC Directive
- 2014/35/EU, Safety/Low Voltage Directive
- 2011/65/EU, RoHS Directive

The applied standards certifying the conformity are listed below.

- EMC: EN 61326-1:2013
- Safety/LVD: EN 61010-1:2010
- RoHS: EN 50581:2012

If an electrical operating device is designed to be integrated in another electrical operating device: The operator is responsible for a standards compliant integration of the electrical device into the overall system.

12. Old Equipment Disposal

In accordance with EU law, electrical and electronic equipment may not be disposed of in EU member states via the municipal residual waste.

Dispose of your old equipment according to international, national, and local rules and regulations.

In order to fulfill its responsibility as the product manufacturer, Physik Instrumente (PI) GmbH & Co. KG undertakes environmentally correct disposal of all old PI equipment made available on the market after 13 August 2005 without charge.

Any old PI equipment can be sent free of charge to the following addresses:

Physik Instrumente (PI) GmbH & Co. KG
Auf der Roemerstr. 1
D-76228 Karlsruhe
Germany

PI (Physik Instrumente) L.P.
16 Albert Street
Auburn, MA 01501
USA

