

# E-515 Display Module for Piezo Controllers

## Voltage and Displacement Display for E-500 Piezo Controller System



The E-515.03 displays piezo voltage or displacement for up to three channels

### Ordering Information

**E-515.01**  
Display Module for Piezo Voltage and Displacement, 1 Channel

**E-515.03**  
Display Module for Piezo Voltage and Displacement, 3 Channels

- 3½-digit Display for Voltage and Position
- 1- & 3-Channel Versions
- Plug-In Module for E-500 System

The E-515.01 and E-515.03 are one and three channel display modules for piezo voltage and displacement data. Toggle switches for each channel select voltage or displacement mode. The voltage / displacement range for each channel is internally set by jumpers and trimmers.

The display module is designed to work in the E-500 piezo controller system (see p. 2-142).

### Technical Data

Model	E-515.01	E-515.03
Function	Display Module for Piezo Voltage and Position	Display Module for Piezo Voltage and Position
Channels	1	3
Display linearity	0.1 %	0.1 %
Display	1 x 3½ digits	3 x 3½ digits
Dimensions	21HP/3U	21HP/3U
Mass	0.3 kg	0.3 kg
Operating voltage	E-500 System	E-500 System